

FINAL REPORT • SEPTEMBER 2016

Lower Columbia Region Habitat Status and Trends Monitoring Implementation Plan Report and Quality Assurance Project Plans



PREPARED FOR

Lower Columbia Fish Recovery Board
2127 8th Ave.
Longview, WA 98632

PREPARED BY

Stillwater Sciences
108 NW Ninth Ave., Suite 200
Portland, OR 97209

Part 1: Implementation Plan Report

Part 2: Quality Assurance Project Plan for Water
Quality and Quantity Monitoring in Urban
Areas (Urban HSTM QAPP)

Part 3: Quality Assurance Project Plan for Regional
Landscape and Habitat Monitoring
(Regional HSTM QAPP)

Suggested citation:

Stillwater Sciences. 2016. Lower Columbia Region Monitoring Implementation Plan Report and Quality Assurance Project Plans. Prepared by Stillwater Sciences, Portland, Oregon for Lower Columbia Fish Recovery Board, Longview, Washington.

Cover photo: Clockwise from top left: East Fork Lewis River (photo courtesy of Stephanie Brock, Ecology); agriculture along the Columbia River Gorge (photo courtesy gorgelodging.com); view from Oregon Port of Longview (photo courtesy of Castle Rock Business Park); map of Lower Columbia region (photo courtesy of LCFRB).

ABBREVIATIONS AND ACRONYMS

This list contains abbreviations and acronyms used frequently in this document. Other abbreviations and acronyms are used infrequently and defined only in the text.

Term	Definition
AREMP	Aquatic and Riparian Effectiveness Monitoring Program, Northwest Forest Plan
BFW	Bankfull Width
B-IBI	Benthic Index of Biotic Integrity
CHaMP	Columbia Habitat Monitoring Program
COC	Chain of Custody
CPR	Cardiopulmonary Resuscitation
DEM	Digital Elevation Model
Ecology	Washington State Department of Ecology
ECY	Washington State Department of Ecology
EIM	Environmental Information Management
EMAP	Environmental Monitoring and Assessment Program
EPA	U.S. Environmental Protection Agency
EPT	The EPT Index is named for three orders of aquatic insects that are common in the benthic macroinvertebrate community: Ephemeroptera (mayflies), Plecoptera (stoneflies), and Trichoptera (caddisflies).
ESA	Endangered Species Act
ESU	Evolutionarily Significant Units
FPW	Floodprone Width
GC-MS	Gas Chromatography-Mass Spectrometry
GIS	Geographic Information System
GPS	Global Positioning System
HDPE	High Density Polyethylene
HSTM	Habitat and Water Quality Status and Trends Monitoring
ICP-MS	Inductively Coupled Plasma Mass Spectrometry
ISTM	Integrated Status and Trends Monitoring
LCFRB	Lower Columbia Fish Recovery Board
LCMS	Lower Columbia Master Sample
LTER	Long-Term Ecological Research
LWD	Large Woody Debris
MQO	Measurement Quality Objectives
NAWQA	National Water-Quality Assessment Program
NLCD	National Land Cover Database
NO ₃	Nitrate
NOAA	National Oceanic and Atmospheric Administration
NPDES	National Pollutant Discharge Elimination System
NRC	National Research Council
ODFW	Oregon Department of Fish and Wildlife
O/E	Observed-to-Expected
OHW	Ordinary High Water
OSWER	Office of Solid Waste and Emergency Response
PAH	Polycyclic Aromatic Hydrocarbons
PFC	Properly Functioning Conditions
PFD	Personal Flotation Device
PNAMP	Pacific Northwest and Aquatic Monitoring Partnership
PPE	Personal Protective Equipment
QA	Quality Assurance

Term	Definition
QA/QC	Quality Assurance/Quality Control
Qa/Qx	Water Quality and Water Flow (Quantity)
QAMP	Quality Assurance Monitoring Plan
QAPP	Quality Assurance Project Plan
QC	Quality Check
RPD	Relevant Percent Difference
RSD	Relative Standard Deviation
RSMP	Regional Stormwater Monitoring Program (Puget Sound Region)
SOP	Standard Operating Protocol
SRFB	Salmon Recovery Funding Board
SRM	Standard Reference Material
SRMD	Standard Reference Material and Data
TN	Total Nitrogen
TOC	Total Organic Carbon
UGA	Urban Growth Area
USEPA	United States Environmental Protection Agency
USDA Forest Service	United States Department of Agriculture Forest Service
USGS	United States Geological Survey
VWI	Valley Width Index
WA	Washington
WAC	Washington Administrative Code
WRIA	Water Resource Inventory Area
WDFW	Washington State Department of Fish and Wildlife
WSDOT	Washington State Department of Transportation

Table of Contents - Part I: Implementation Plan Report

ABBREVIATIONS AND ACRONYMS	ii
EXECUTIVE SUMMARY	ES-1
INTRODUCTION	1
1 SECTION 1: PROJECT PLANNING AND MANAGEMENT.....	1
1.1 Background.....	1
1.1.1 Study area and surroundings	1
1.1.2 Logistical considerations for monitoring.....	4
1.1.3 Parameters of concern (“Indicators”).....	4
1.1.4 Previous studies and key ongoing efforts.....	5
1.1.5 Related criteria or standards	6
1.2 Project Description	6
1.2.1 Questions and objectives.....	6
1.2.2 Information and data to meet objectives	12
1.2.3 Target populations.....	12
1.2.4 Study boundaries and sample stratification.....	12
1.2.5 Practical constraints on the study design.....	13
1.2.6 Summary of tasks needed to collect data	14
1.2.7 Decisions that could be made using data.....	14
1.3 Organization and Schedule	15
1.3.1 Participating organizations and HSTM program leadership	15
1.3.2 Project schedule and limitations.....	16
1.3.3 Budget information for the project.....	17
1.4 Quality Objectives	18
1.4.1 Decision quality objectives	18
1.4.2 Measurement quality objectives.....	19
1.5 Sampling Design.....	19
1.5.1 Experimental design and sampling locations	19
1.5.2 Representativeness	20
1.5.3 Comparability.....	21
1.5.4 Completeness	21
1.6 Signal-to-Noise Analysis	21
1.7 Sample Collection, Analysis, and Reporting Guidelines.....	24
1.7.1 General field safety considerations	24
1.8 Sampling Procedures and Laboratory Measurements.....	24
1.9 Quality Control	24
2 SECTION 2: SAMPLE SITE SELECTION	24
2.1 Sampling Site Selection and Evaluation.....	24
2.1.1 Evaluation under the sampling design.....	24
2.1.2 Sample populations	25
2.1.3 Mid-study changes affecting site suitability.....	33
2.1.4 Field criteria for selecting a suitable sampling site	33
2.2 Candidate Site List for Monitoring Sites	34
3 SECTION 3: INDICATORS.....	34
3.1 Water Quality Indicators for Urban+NPDES Sites	34
3.1.1 Base program and extended program indicators	34
3.1.2 Laboratory quality control measures.....	37
3.1.3 Data management, review and validation	37
3.2 Habitat Indicators – Physical and Biological.....	38

3.2.1	List and rationale	38
3.2.2	Field sampling procedures.....	40
3.2.3	Laboratory measurement procedures	40
3.2.4	Measurement quality objectives.....	40
3.2.5	Quality control.....	40
3.2.6	Data management, review and validation	41
3.3	Landscape Indicators	41
3.3.1	List and rationale	41
3.3.2	Data sources	43
3.3.3	Known magnitude of classification/location errors.....	43
3.3.4	Analytical procedures.....	43
3.3.5	Validation and quality control.....	44
3.3.6	Data management	44
4	SECTION 4: DATA ANALYSIS AND INTERPRETATION.....	44
4.1	Interpreting Qa/Qx Indicators within the Urban+NPDES Areas.....	45
4.1.1	Benthic macroinvertebrates.....	46
4.1.2	Sediment metals and PAHs	46
4.1.3	Continuous indicators.....	47
4.2	Interpreting Indicators at Regional Sites throughout the Lower Columbia Region...	50
5	REFERENCES.....	54

Tables

Table 1.	Average annual costs to implement urban monitoring.	18
Table 2.	Annual monitoring costs to implement regional sampling.	18
Table 3.	Habitat indicators and Signal/Noise ratings from various sources.	23
Table 4.	Master Sample sites within urban+NPDES areas that also drain watersheds with predominately urban landcover.....	30
Table 5.	Master Sample sites outside of urban+NPDES areas that also drain watersheds with predominately agricultural landcover.	30
Table 6.	Master Sample sites outside urban+NPDES areas classified as forested. Strata that meet the minimum site criteria are shaded.....	31
Table 7.	Water quality indicators for the base and extended programs.	36
Table 8.	Water quality indicators and associated rationale.....	37
Table 9.	Habitat indicators and their associated metrics.....	39

Figures

Figure 1.	Lower Columbia Region boundary.....	3
Figure 2.	Stream segments that contain Master Sample points meeting the drainage-area criteria of 2.5–10 km ² or 10-50 km ²	26
Figure 3.	GIS view of the Master Sample points in Clark County.....	27
Figure 4.	Master sample points draining watersheds with predominately urban land cover	28
Figure 5.	Master sample points draining watersheds with predominately agricultural land cover.....	29
Figure 6.	Discharge and stage for the past four years at Mercer Creek, Washington.	48
Figure 7.	Left panel: Temperature variation in a small lowland stream in the Tualatin Basin, western Oregon. Right panel: Distribution of rainfall at Vancouver, WA, with bar graph indicating that about 4 to 5 inches of potentially run-off-generating rainfall falls during the period of the year when instream temperatures have the potential to reach ecologically problematic levels.....	49

Appendices

Appendix A-1.	Stormwater Roles and Responsibilities
Appendix B-1.	Habitat Roles and Responsibilities
Appendix C-1.	Hydrology
Appendix D-1.	Temperature
Appendix E-1.	Conductivity

EXECUTIVE SUMMARY

In 2012, the Lower Columbia Fish Recovery Board (LCFRB) and the City of Longview initiated a collaborative project to design and implement an integrated Habitat and Water Quality Status and Trends Monitoring project (HSTM) in the Lower Columbia Region. Pursuit of such integration is motivated by two monitoring needs that face the region: supporting the recovery of watershed health and salmonid species listed as threatened or endangered under the Endangered Species Act (Chinook, coho, chum, and steelhead), and addressing anticipated future monitoring requirements under municipal stormwater National Pollutant Discharge Elimination System (NPDES) permits for eight cities and counties and the Washington State Department of Transportation (WSDOT) in southwest Washington. By developing a coordinated strategy across these two monitoring programs, fiscal efficiencies and more robust and meaningful regional assessments should be achieved.

The primary goal of the HSTM project is to complete a monitoring design to meet the status and trends monitoring needs of the Washington State Department of Ecology (Ecology), southwest Washington municipal stormwater permittees, LCFRB, and other partners of the Pacific Northwest Aquatic Monitoring Partnership's program for Integrated Status and Trends Monitoring. This Implementation Report represents the culmination of past and present efforts conducted over the past year, representing "Phase 3" of this three-phase effort. Phase 1, completed in June 2013, developed the overarching framework for the coordinated strategy. Subsequently, Phase 2 produced the Design Report (Stillwater Sciences 2015a) that articulated the goals and objectives for the integrated monitoring project, and it specified the target populations, sampling stratification, and indicators to be used. This Implementation Report, the product of Phase 3, has refined the pragmatic details necessary for the actual initiation of monitoring—site selection, measurement protocols, data analyses, data management, and reporting—all of which are essential for successful on-the-ground execution.

The project study area includes all of the Lower Columbia Region Recovery domain, also referenced as the Lower Columbia Evolutionarily Significant Unit (ESU), which comprises the Columbia River mainstem from its mouth up to Bonneville Dam, and all Columbia River tributary subbasins from the mouth of the Columbia River up to and including the White Salmon River in Washington and the Hood River in Oregon, and the Willamette River up to Willamette Falls. The project currently addresses only the monitoring design for tributaries in the Washington portion of the ESU. Anticipated future phases may also include the Oregon portion of the Region upon participation and funding by Oregon agencies, and incorporate monitoring of the Columbia River mainstem and tidally influenced habitats, in order to generate a more complete picture of the landscape and its habitats. At present, the project also addresses the need for status and trends monitoring under anticipated requirements of future municipal stormwater NPDES permits.

Project Planning and Management

Project planning was largely accomplished through Phases 1 and 2 of the HSTM project; the focus of the Implementation Plan is on the refinement of prior guidance to ensure a robust, implementable program. The guiding questions and objectives developed during Phase 2 have been affirmed, although some of the objectives are unlikely to be fully satisfied within the first several years of implementation given the inherent variability of the parameters being measured and the complexity and expense of fully addressing all of the objectives.

At the regional scale, the key monitoring questions from the Monitoring Design Report are:

- Question 1:** What are the status and trends of water quality and stream flow in surface waters?
- Question 2:** What are the status and trends of water quality in surface waters draining watersheds with a substantial fraction of land that has been cleared for agriculture or recent (<20 years) forest harvests?
- Question 3:** What are the status and trends of instream biological health and instream/riparian habitat conditions (in terms of both quality and quantity)?
- Question 4:** Do instream biological health and instream/riparian habitat conditions correlate to changes in abundance, productivity, spatial structure, and diversity of the natural-origin fish in this population at the reach/subwatershed scale?
- Question 5:** Where on the landscape are key potential land-use activities occurring, and in what watersheds are one or another of these activities dominant?
- Question 6:** Are land-cover changes occurring at detectable rates across the Lower Columbia Region, and if so where are they occurring?

The monitoring recommended to characterize regional-scale water quality conditions (termed “Qa/Qx monitoring” in the reports and covered by Questions 1 and 2) has been significantly reduced from that originally envisioned, in light of cost and feasibility concerns. Stream temperature and benthic macroinvertebrates will be the only non-habitat indicators collected at these regional sites, but they should nonetheless provide useful characterization of these conditions and any significant trends over one or more ten-year periods of annual monitoring. The physical habitat indicators also to be collected at these sites, in total, are sufficiently comprehensive to address Question 3 over a similar period. They will also provide a basis to address Question 4 if fish population data are also available. Questions relating to landscape-level changes (Questions 5 and 6) have been addressed to the extent that their characterization was needed to implement other elements of the program; documentation of other current conditions and determination of future change has been deferred for future reporting and implementation.

At the scale of urban areas, particularly those subject to stormwater NPDES permitting, the key monitoring questions from the Monitoring Design Report are:

- Question 7:** What are the status and trends of water quality and stream flow in surface waters draining subwatersheds that are primarily within the jurisdiction of municipal stormwater NPDES permittees?
- Question 8:** What are the status and trends of water quality and stream flow in surface waters that are being affected by stormwater discharges from urban areas first developed under requirements of the 2013 Phase I and Phase II Western Washington Municipal Stormwater Permits?
- Question 9:** What are the status and trends of instream biological health and instream/riparian habitat conditions that are primarily within the jurisdiction of municipal stormwater permittees (in terms of both quality and quantity)?
- Question 10:** Do instream biological health and habitat conditions correlate to changes in observed abundance, productivity, spatial structure, and diversity of the natural-origin fish in this population (reach/subwatershed scale)?

The flow and water quality indicators recommended in the Design Report (Stillwater Sciences 2015a) have been affirmed as adequately balancing the need to assess the status and trends of these conditions (Question 7) with the cost of implementing a systematic, statistically rigorous sampling program. In addition to this “base program,” the nine stormwater permittees of the Lower Columbia Region have also advanced an “enhanced monitoring program” that can provide

them with additional information (by collecting additional indicators, at additional cost) judged important for the management of their respective stormwater management programs. Although not a part of the Design Report (Stillwater Sciences 2015a), the details of this augmented water quality monitoring will be included as an appendix to the Urban Quality Assurance Project Plan for the HSTM program (Urban HSTM QAPP). Habitat monitoring within the urban areas of the Region (Questions 9 and 10) is included as a stratum within the regional-scale monitoring (see above), and as such it provides answers of equivalent resolution and timeliness as for Questions 3 and 4.

The HSTM project, once initiated, is expected to be implemented through one or two steering committees whose proposed roles and responsibilities are outlined in appendices A and B to this Implementation Plan. Their activities include overall program management, fund acquisition and management, collection and analysis of data (either directly or via contractors), reporting, and maintaining stakeholder engagement and communication. Preliminary budgets for both Qa/Qx and habitat monitoring have been developed and total approximately \$68,000 per year for base Qa/Qx monitoring at the urban sites addressing NPDES permit requirements and potentially about ten times that amount for habitat monitoring, region-wide.

Sample Site Selection

A preliminary set of sample sites for both the urban areas (termed “urban+NPDES sites”) and the Region as a whole (termed “regional sites”) have been selected via a two-step process. The first step involved the stratification of the target population of previously identified points along stream channels in the Lower Columbia Region (known as the “Master Sample”) into physically meaningful strata, appropriate to the monitoring activities and intended uses of the data, using GIS characterization of the stream and watershed characteristics associated with each point in the Master Sample. These strata were defined in the Design Report (Stillwater Sciences 2015a) and refined as part of this Implementation Plan:

- For urban+NPDES sites: one strata combination, consisting of stream segments with watersheds draining 2.5-50 km² and predominately urban land cover as determined from the 2011 National Land Cover Database. There are 18 such independent stream segments that meet these criteria; an additional four sites were added based on considerations of geographic coverage, near-alignment with Design Report criteria, and Stormwater Caucus recommendations.
- For regional sites: 270 potential unique strata combinations, based on watershed area (5 categories), stream gradient (3 categories), number of primary salmonid populations in the subwatershed (3 categories, to ensure that the most biologically diverse streams are well-represented in the final random site selection), jurisdictional setting (i.e., inside or outside of urban+NPDES areas) (2 categories), and predominant watershed land cover (3 categories). Many of these strata combinations, however, lack a sufficient number of Master Sample points (or, in some instances, *any* such points) to be viable strata combinations; indeed, only 45 strata combinations have a minimum number of points (15) as recommended in the Design Report (Stillwater Sciences 2015a), on the basis of statistical considerations, to be further considered for this sampling effort. This results in the potential for 675 (i.e., 45 × 15) regional monitoring sites.

Given the great disparity in the number of candidate sites for the two monitoring elements, the approach to the sampling design differs between the urban+NPDES sites and the regional sites. For the 22 urban+NPDES, six sites (all but one of which having preexisting data collection) will be monitored continuously and visited annually throughout the duration of the program. The other sites will be visited under a 5-year rotating panel design, where approximately 20% of the

remaining 16 sites will be monitoring for a single year and then left while the next panel is sampled. This is a true census design, insofar as every stream meeting the stratification criteria will be sampled. In contrast, there are far too many habitat sites to do more than take a random and presumably representative subsample of the entire population. These habitat sites so selected will be monitored on a strict 5-year rotating panel design in which 20% of the selected sites will be visited in any given year with repeat visits starting in year 6 and beyond. No habitat sites will be visited every year.

Indicators

The indicators recommended for this HSTM program have been identified on the basis of historic utilization and regional experience, prior recommendations from Phase 1 of this project, known issues with data quality and variability, cost of implementation, and direct relevance to the monitoring questions that are guiding this program. Because the habitat and water quality status and trend monitoring (HSTM) focus is to characterize the physical and water-quality status and trends of the streams and rivers of the Lower Columbia Region, the parameters of concern could be any and all that might contribute to that characterization. However, limitations on the technical feasibility of collecting certain parameters and on the overall scope of an affordable monitoring program have required great selectivity in the choice of monitoring parameters to actually measure.

The final suite of recommended parameters listed below comprises a range of water-quality, physical-habitat, and biological conditions that are closely linked to a variety of known or potential threats to aquatic resources: limiting habitat conditions for the Region's ESA-listed salmonid species and other biota, and impairment of watershed-specific beneficial uses.

Water Quality and Flow (Qa/Qx)

Water temperature^{1, C}

Conductivity^C

Stage^C

Sediment metals^{5-yr}

Sediment polycyclic aromatic
hydrocarbons^{5-yr}

Biological

Benthic macroinvertebrates^{2, A}

Habitat^A

Sample reach length

Channel type

Reach slope

Sinuosity

Bank modification

Density of habitat types

Bankfull width/depth³

Pools per unit length

Floodplain width

Side channel habitat

Flow category

Residual pool depth

Bank stability

Relative bed stability

Density/distribution instream wood

Substrate particle size³

Shade

Riparian canopy

Riparian understory

¹ Also collected during habitat monitoring

² Collected under both habitat and Qa/Qx monitoring

³ Also collected during Qa/Qx monitoring

^C Parameters collected continuously

^A Parameters collected annually

^{5-yr} Parameters collected once per 5-year period

The parameters were selected based on (1) the specific monitoring needs for addressing the program-specific questions and objectives, (2) the relative value of some parameters over others in their ability to detect meaningful changes, (3) the instream changes that land-use and infrastructure change (both positive and negative) may potentially create, (4) regulatory requirements, and (5) financial constraints.

With respect to the recommended water-quality monitoring elements of this program, its most noteworthy aspects relative to prior efforts are its emphasis on continuously monitored (or otherwise integrative) indicators, and the overall brevity of the indicator list. These outcomes are driven by considerations long-articulated by project partners and stakeholders: statistical and scientific rigor of the chosen indicators, and feasible cost of implementation. It is anticipated that these indicators will meet the requirements of the upcoming 2018 NPDES Municipal Stormwater Permit's Special Condition S8 Monitoring and Assessment, subsection B Status and Trends Monitoring (S8.B), and their implementation will satisfy Ecology's need for a statistically valid stormwater status and trends regional monitoring program. In this Implementation Report the collection and analysis of the above-listed Qa/Qx indicators is referenced as the "base program" for water quality at urban+NPDES sites.

Stakeholders have also expressed the desire to gain further value from the HSTM program by collecting an expanded list of indicators. They have defined what is herein referenced as an "extended monitoring component" that will be implemented at the same sites, and following the same panel design, as for the base indicators to the extent that sufficient funds are available. Monitoring of these indicators will be conducted under the exclusive guidance of the steering committee that is expected to be established to manage the stormwater monitoring program once implemented, and it will be supported on a funding-available basis from the permittees' pooled monitoring funds once the costs associated with collection, interpretation, and reporting of the base monitoring program indicators have been fully covered:

EXTENDED MONITORING COMPONENT INDICATORS	
Water temperature	X ^m
Conductivity	X ^m
Dissolved oxygen	X ^m
pH	X ^m
Turbidity	X ^m
Total suspended solids	X ^m
Total solids	X ^m
Total nitrogen	X ^m
Nitrate + nitrite-nitrogen	X ^m
Total phosphorus	X ^m
Dissolved copper	X ^m
Dissolved zinc	X ^m
Fecal coliform bacteria	X ^m

X^m = monthly sampling

The detailed approach and methods for collecting these "extended monitoring component" indicators will be fully detailed in a future update of Part 2 of this document, the Urban HSTM QAPP.

INTRODUCTION

In 2012, the Lower Columbia Fish Recovery Board (LCFRB) initiated a collaborative project to design and implement an integrated Habitat and Water Quality Status and Trends Monitoring project (HSTM) in the Lower Columbia Region. Pursuit of such integration was motivated by two monitoring needs that face the region: supporting the recovery of salmonid species listed as threatened or endangered under the Endangered Species Act (Chinook, coho, chum, and steelhead) and addressing anticipated future monitoring requirements under municipal stormwater National Pollutant Discharge Elimination System (NPDES) permits for eight cities and counties in southwest Washington and the Washington State Department of Transportation (WSDOT). The project has built on the progress of the Pacific Northwest Aquatic Monitoring Partnership's (PNAMP) Integrated Status and Trends Monitoring (ISTM) Project, which sought ways to design and implement more coordinated, efficient, and effective aquatic ecosystem monitoring than under the independence by which the various monitoring program had historically been conducted. By integrating status and trends monitoring related to municipal stormwater permits with other existing monitoring efforts in the WA Lower Columbia ESU, the intent is to gain fiscal efficiencies and more robust and meaningful regional assessments than could be achieved by either program in isolation.

The primary goal of the HSTM project is to complete a monitoring design and implementation plan to meet the status and trends monitoring needs of Ecology, southwest Washington municipal stormwater permittees, LCFRB, and other partners of the Pacific Northwest Aquatic Monitoring Partnership's program for ISTM. The HSTM project has been executed in three phases, of which the first established the framework of the program (Tetra Tech 2013) and the second refined the monitoring design (Stillwater Sciences 2015a). This Implementation Plan, based on Ecology guidance (Ecology 2006), represents the final step of this HSTM program and contains the pragmatic details necessary for the actual initiation of monitoring—site selection, measurement protocols, data analyses, data management, and reporting—all of which are essential for successful on-the-ground execution. Detailed monitoring plans have been developed in tandem with this report and are documented in the Quality Assurance Project Plans – Urban and Regional HSTM QAPPs (Parts 2 and 3 of this report).

1 SECTION 1: PROJECT PLANNING AND MANAGEMENT

1.1 Background

1.1.1 Study area and surroundings

The project study area includes the Lower Columbia Region, comprising all Columbia River tributary subbasins from the mouth of the Columbia River up to the White Salmon River in Washington (WRIAs 25, 26, 27, 28 and 29) and the Hood River in Oregon, and the Willamette River up to Willamette Falls (Figure 1). This phase of the project was focused on the Washington portion of the Region with intent to include the Oregon portion of the Region at a later time, subject to participation and funding by Oregon agencies. This project also addresses the anticipated future needs for status and trends monitoring by the southwest Washington municipal stormwater NPDES permittees within the Lower Columbia Region.

The study area has had European settlements for well over a century, first concentrated along the valley of the Columbia River, with first agricultural and then urban development progressively

expanding north and south along the Willamette/Puget Lowland trough. Today, major transportation links are primarily north/south through the west-central part of the region, and east/west along the Columbia River. Access is relatively good in the western two-thirds of the Region but almost entirely blocked by the Cascade Range to the east, whose crest forms the eastern edge of the study area.




Figure 1. Lower Columbia Region boundary. Source: Stillwater Sciences.

1.1.2 Logistical considerations for monitoring

Conditions across the study area are generally representative of those throughout all of western Washington, presenting typical opportunities and constraints for monitoring coverage and field access. Urban areas are well covered by road networks, permitting ready access to streams and other watercourses but posing some potential limitations as a result of private property restrictions. Farther east, in the Cascade Range foothills and mountains, direct access to potential sites are much more constrained by limited roads and rugged topography, which are likely to impose some restrictions on site access. Elsewhere, agricultural and rural residential land uses are also likely to impose local challenges to access, as a consequence of both limited roads and private property, which are likely to necessitate adjustment to the sites selected for sampling once implementation actually begins.

1.1.3 Parameters of concern (“Indicators”)

Because the HSTM focus is to characterize the physical and water-quality status and trends of the streams and rivers of the Lower Columbia Region, the parameters of concern could be any and all that might contribute to that characterization. However, limitations on the technical feasibility of collecting certain parameters and on the overall scope of an affordable monitoring program have required great selectivity in the choice of monitoring parameters to actually measure. The final suite of recommended parameters listed below comprises a range of water-quality, physical-habitat, and biological conditions that are closely linked to a variety of known or potential threats to aquatic resources: limiting habitat conditions for the Region’s ESA-listed salmonid species and other biota, and impairment of watershed-specific beneficial uses.

Water Quality and Flow (Qa/Qx)

Water temperature^{1, C}

Conductivity^C

Stage^C

Sediment metals^{5-yr}

Sediment polycyclic aromatic
hydrocarbons^{5-yr}

Biological

Benthic macroinvertebrates^{2, A}

Habitat^A

Sample reach length

Channel type

Reach slope

Sinuosity

Bank modification

Density of habitat types

Bankfull width/depth³

Pools per unit length

Floodplain width

Side channel habitat

Flow category

Residual pool depth

Bank stability

Relative bed stability

Density/distribution instream wood

Substrate particle size³

Shade

Riparian canopy

Riparian understory

¹ Also collected during habitat monitoring

² Collected under both habitat and Qa/Qx monitoring

³ Also collected during Qa/Qx monitoring

^C Parameters collected continuously

^A Parameters collected annually

^{5-yr} Parameters collected once per 5-year period

The parameters were selected based on (1) the specific monitoring needs for addressing the program-specific questions and objectives, (2) the relative value of some parameters over others in their ability to detect meaningful changes, (3) the instream changes that land-use and infrastructure changes (both positive and negative) may potentially create, (4) regulatory requirements, and (5) financial constraints. No known toxic sources or areas of toxic contamination within the Region are explicitly being targeted by this monitoring program.

Stakeholders have also expressed the desire to gain further value from the HSTM program by collecting an expanded list of indicators. They have defined what is herein referenced as an “extended monitoring component” (see Section 3.1.1) that will be implemented at the same sites, and following the same panel design, as for the base indicators to the extent that sufficient funds are available.

Parameters of interest have been referred to as “metrics” throughout the development of this HSTM program. That term warrants clarification as the parameters are not explicitly metrics (i.e., a system or standard of measurement). Furthermore, most monitoring programs commonly collect a broad array of metrics and then subsequently identify the metrics of greatest value for a given set of questions. The resulting subset of metrics are then each termed “indicators.” However, the development of the Lower Columbia HSTM program sought to identify only the most meaningful and feasible parameters to collect during the development of this Implementation Plan, rather than a broad array of indicators. As such, and for the sake of clarity and consistency, this document will use the term “indicators” from this point forward to reflect the parameters of interest.

1.1.4 Previous studies and key ongoing efforts

This report represents the third phase of the three-phase project to design and implement a coordinated HSTM program for the Lower Columbia Region. Phase 1 of the project, summarized in Tetra Tech (2013), developed preliminary recommendations for the coordinated monitoring strategy that included recommendations regarding the choice of habitat indicators, water quality indicators, and stratification of prospective sampling sites. It also supported completion of the Lower Columbia Master Sample, a GIS-based database of over 100,000 potential sampling points that constitutes the target population for the study as a whole. Phase 2 of the project, the HSTM design (Stillwater Sciences 2015a), articulated the final goals and objectives for the integrated monitoring project for water quality and habitat; and it specified the target populations, sampling stratification, and proposed indicators.

A multitude of other studies that relate to water-quality and fish-habitat monitoring in the Pacific Northwest and beyond have been completed and published, and these were consulted extensively in the course of preparing the reports for both Phase 1 (Tetra Tech 2013) and Phase 2 (Stillwater Sciences 2015a), although only a few refer directly to status and trends monitoring in the Lower Columbia Region. A notable exception was the ISTM Habitat Objectives 1&2 report (Puls et al. 2014), a summary to compare the goals, objectives, protocols, and inference domains of habitat status and trends monitoring programs in the Lower Columbia Region. This work was spearheaded by the Pacific Northwest Aquatic Monitoring Partnership (PNAMP), with help from regional partners. In addition to identifying the measurements and metrics that seven Lower Columbia monitoring programs had in common, an effort was made to determine the “shareability” of the most commonly calculated site-level metrics. For the full results, see the final report at <http://www.pnamp.org/document/4769>.

A second effort, the Puget Sound area's Regional Stormwater Monitoring Program for small streams (RSMP), has also been particularly valuable in the preparation of this document. The RSMP's Puget Lowland streams status and trends monitoring is a collaborative monitoring program between Puget Sound municipal stormwater permittees and state and federal agencies, recommended to Ecology and overseen by the "Stormwater Work Group" of stakeholders in 2010 (<http://www.ecy.wa.gov/programs/wq/psmonitoring/recommendations.html>), and fully operational as of its first season of field sampling in 2015 (<http://www.ecy.wa.gov/programs/wq/stormwater/municipal/rsmp/status.html>). The choice of indicators, sampling protocols, and QA/QC procedures for the RSMP small streams were consulted extensively during the design and implementation phases of the Lower Columbia HSTM, and both the insights and many of the specific implementation elements provided by this example has been invaluable in specifying and refining the recommended program here.

1.1.5 Related criteria or standards

A number of the monitoring questions and objectives for the HSTM program seek to evaluate the status and trends of physical, chemical, and biological parameters in relationship to published standards for beneficial uses (WAC 173-201A-602) and for Properly Functioning Conditions (PFCs) (NOAA 1996). This is not compliance monitoring, however—a different and more extensive program would be needed to diagnose the causes of any failure to meet standards in receiving waters in a regulatory sense. More severe thresholds, such as for acute or chronic toxicity in water-column constituents, do exist but are not anticipated to be approached by any sample at any of the sites that are eventually selected for monitoring. Those water-column indicators will not be sampled as part of the base program.

Concerns have been raised regarding the suitability of applying PFCs in evaluating physical habitat under this program. For example, they do not distinguish variable target conditions across gradients that are known to have natural variation. However, it is a widely applied set of standards for physical, chemical and biological parameters that works well in many of the environments found in the Lower Columbia Region. In order to address the stakeholder concerns and potential limitations of PFC criteria, documentation of appropriate use and constraints are in development by NOAA staff.

Additional criteria or standards are also needed to link instream biological health and habitat conditions to changes in observed abundance, productivity, spatial structure, and diversity of the natural-origin fish. Although studies have proposed such linkages (e.g., Beechie et al. 2015), no criteria currently exists (Jeff Anderson, NOAA, pers. comm., 2016). This is noteworthy because such linkages are one of the specific program questions to be answered by this study (Question 10 in the following section). In the absence of explicit criteria or standards, we recommend that positive progress towards achieving PFCs for a given monitoring indicator will serve as a surrogate for explicit criteria by which to evaluate trends. Section 4 of this report proposes key physical, chemical and biological indicators and their association with fish population parameters.

1.2 Project Description

1.2.1 Questions and objectives

The project presents an integrated, coordinated design to monitor the status and trends of natural rivers and streams in the Lower Columbia Region of southwest Washington, with a robust design that will allow region-wide, statistically supported inferences about instream habitat and water-quality conditions throughout the region. It is also intended to inform future Municipal

Stormwater NPDES Permit requirements for permittees in the Lower Columbia River Region through a monitoring design that addresses multi-scale questions about status and trends of physical, chemical and biological attributes, including those influenced by stormwater. The project built on the progress of the PNAMP ISTM Project, which explored design and implementation alternatives in pursuit of more coordinated, efficient, and effective aquatic ecosystem monitoring. The intent of integrating status and trends monitoring mandated by municipal stormwater permits with other existing monitoring efforts in the WA Lower Columbia Region is to gain fiscal efficiencies and more robust and meaningful regional assessments.

The monitoring objectives, which underlie the purpose for the monitoring, have been developed in the context of 10 monitoring “questions.” They are reproduced below from the Monitoring Design (Stillwater Sciences 2015a) in order to provide a full context for the reader, together with some discussion of their feasibility given constraints imposed by the final monitoring design and its anticipated implementation (as described in this report). They are organized at their highest level by the spatial scale of the monitoring, either Region-wide or focused more specifically on the urban areas associated with the municipal stormwater permittees’ jurisdictions.

1.2.1.1 Regional-scale questions and objectives

Water quality and water quantity (Qa/Qx)

Question 1 (Tetra Tech 2013, p. 14): What are the status and trends of water quality and stream flow in surface waters?

Objective 1.1 (status): In wadeable and non-wadeable streams, as stratified by predominant land-use categories in their contributing watersheds³, evaluate whether water-quality conditions generally support the waterbody-specific beneficial uses identified in WAC 173-201A-602 (<http://apps.leg.wa.gov/WAC/default.aspx?cite=173-201A-602>) and meet the “Properly Functioning” conditions of NOAA (1996), using the indicators recommended in Section 3.5 of this report.

Objective 1.2 (trends): For the population of sites measured under Objective 1.1, evaluate whether measured water-quality indicators show a statistically significant trend over a 10-year period towards the best conditions represented by the population of sites in the random draw from the Master Sample, and as described as “Properly Functioning” in NOAA (1996).

Discussion of feasibility:

Based on recommendations of the HSTM stakeholders that considered cost and feasibility during development of this plan, regional-scale Qa/Qx monitoring has been significantly reduced from the originally anticipated design. Stream flow will not be monitored and the sole water-quality indicator planned for measurement is water temperature. In addition, benthic macroinvertebrates will be collected at each site to provide an integrative biological indicator (e.g., B-IBI) of overall aquatic-system health. Although both temperature and indices of macroinvertebrates are widely used to evaluate general aquatic-system conditions, these indicators alone will be insufficient to evaluate more broad progress towards (or attainment of) beneficial uses or PFCs (Objective 1.1). Ten years should be sufficient to detect significant trends, if any, in these two parameters; and

³ From Tetra Tech (2013), p. 28: “A subwatershed would be assigned to either the forested land use/class category, or a combined urban/suburban/rural land use/class category, based on the category with at least 51% cover in that subwatershed.”

because the direction of “best conditions” (i.e., cooler water, higher B-IBI scores) is well known, it should be possible to meet Objective 1.2.

Question 2: What are the status and trends of water quality in surface waters draining watersheds with a substantial fraction of land that has been cleared for agriculture or recent (<20 years) forest harvests? (In other words, are our forest practices or agricultural BMPs making a difference in the status and trends of these working landscapes?)

Objective 2.1 (status): In wadeable and non-wadeable streams primarily draining agricultural areas outside of Urban Growth Areas, evaluate whether measured water-quality indicators generally support the waterbody-specific beneficial uses identified in WAC 173-201A-602 (<http://apps.leg.wa.gov/WAC/default.aspx?cite=173-201A-602>).

Objective 2.2 (trends): In wadeable and non-wadeable streams primarily draining subwatershed(s) with recent (<20 years) forest harvest area(s), evaluate whether measured water-quality indicators show a statistically significant trend over a 10-year period towards reference conditions.

Discussion of feasibility:

As with the objectives under Question 1, the limited number of Qa/Qx indicators collected at this spatial scale similarly narrows the degree to which these objectives can be addressed. Because there are a sufficient number of Master Sample points that drain predominately agricultural watersheds, addressing Objective 2.1 to the same degree as for Objective 1.1 (see above discussion) should be possible, although only for wadeable streams. There is an insufficient number of sites along larger, non-wadeable rivers to meet the predominant agricultural land-cover criterion. It is presently unknown whether sufficient Master Sample points will be selected to provide adequate statistical power to address Objective 2.2.

Habitat

Question 3: What are the status and trends of in-stream biological health and in-stream/riparian habitat conditions (in terms of both quality and quantity)?

Objective 3.1 (status): In wadeable and non-wadeable streams, as stratified by predominant land-use categories in their contributing watersheds, evaluate the status of biological and habitat conditions relative to PFCs (Appendix A-1).

Objective 3.2 (trends): Analyze for statistically significant spatial and temporal trends of biological and habitat indicators (annually).

Discussion of feasibility:

The suite of habitat indicators adopted for regional monitoring sites address many of the “Habitat Elements” contained in NOAA’s (1996) table of PFCs. Additional key indicators were also identified that provide value to understanding the status and trends of in-stream biological health and in-stream/riparian habitat conditions. Together, they should be sufficient to characterize most conditions relative to regional standards (Objective 3.1) and demonstrate statistically significant changes in these PFC’s (Objective 3.2). An exception exists for low-gradient floodplain habitats that are not well represented by PFC criteria. This uncertainty will require additional reference conditions to be considered during evaluation of low-gradient sites. Furthermore, some of the

indicators are slow to change and may require one or more decades to detect a significant change in the absence of major disturbances to the watershed.

Question 4: Do in-stream biological health and in-stream/riparian habitat conditions correlate to changes in abundance, productivity, spatial structure, and diversity of the natural-origin fish in this population at the reach/subwatershed scale?

Objective 4.1 (trends): Identify statistically significant correlations between trends in select habitat indicators and trends in fish population metrics being conducted by other monitoring programs.

Discussion of feasibility:

Attaining Objective 4.1 is dependent in part on the availability of fish population metrics, whose collection and dissemination lie outside of the domain of this project. It also requires linkages between habitat indicators and fish population metrics, which are in development by NOAA. Despite these significant constraints, this objective remains of primary concern to addressing watershed health and salmon recovery. Correlations between fish metrics and habitat indicators collected under the HSTM program are most likely to emerge from the most integrative of indicators being collected here (i.e., B-IBI) and will undoubtedly require one or more decades to emerge in the absence of major watershed disturbances.

Landscape

Question 5: Where on the landscape are key potential land-use activities occurring, and in what watersheds are one or another of these activities dominant?

Objective 5.1 (status): Identify subwatersheds of the Lower Columbia Region at a suitable size to support other monitoring efforts under this program having "dominant" land uses of urban, agriculture, or recent (<20 year) forest harvest; identify subwatersheds with dominant intact (>20 year old) forest cover.

Discussion of feasibility:

Elements of this objective have already been implemented (specifically, the identification of Master Sample points with watersheds draining predominately urban or agricultural land cover) in order to support other element of the HSTM program implementation. The methodology for implementing the other elements of this objective is included in this Implementation Report (see Section 3.3.1) but their execution has been suspended until such time that their findings are needed to interpret the other HSTM data being collected.

Question 6: Are land-cover changes occurring at detectable rates across the Lower Columbia Region, and if so where are they occurring?

Objective 6.1 (trends): Identify and quantify areas of land-cover change in subwatersheds of the Lower Columbia Region that drain to habitat and/or Qa/Qx monitoring sites at 5-year intervals.

Objective 6.2 (trends): Identify and quantify how land cover is changing within a selected buffer zone (e.g., 60 m) around channels included in the Qa/Qx and habitat monitoring elements at 5-year intervals.

Discussion of feasibility:

The methodology for implementing the elements of these objectives is also included in this Implementation Report (Section 3.3.1) but their execution has been suspended until such time that their findings are needed to interpret the other HSTM data being collected.

1.2.1.2 Municipal stormwater NPDES permit-related questions and objectives**Water quality and water quantity (Qa/Qx)**

Question 7: What are the status and trends of water quality and stream flow in surface waters draining subwatersheds that are primarily within the jurisdiction of municipal stormwater NPDES permittees?

Objective 7.1 (status): In streams in urban NPDES areas, evaluate whether water-quality conditions generally support the watershed-specific beneficial uses identified in WAC 173-201A-602 (<http://apps.leg.wa.gov/WAC/default.aspx?cite=173-201A-602>).

Objective 7.2 (trends): For the population of sites measured under Objective 7.1, evaluate whether measured water-quality indicators show statistically significant trends over a 10-year period towards the best conditions.

Discussion of feasibility:

The design for Qa/Qx monitoring in urban+NPDES areas has sought to balance the competing interests of comprehensiveness, economy, and utility to regulators, permittees, and other stakeholders. The base program's suite of indicators emphasizes time-integrative parameters that should minimize random variability introduced by episodic sampling; the rotating panel design will allow the entire population of streams within the identified stratum (2.5–50 km² drainage area, predominately urban watershed land cover) to be sampled at least twice in a 10-year period, with a sufficient range of indicators to provide some general indication of the attainment of beneficial uses but not to systematically evaluate every criterion. The extended monitoring component's suite of indicators will provide a richer array of indicators at a subset of these locations and allow a more complete determination of whether those uses are being achieved, at least for some locations and some parameters. In aggregate they should provide a robust characterization of overall conditions (Objective 7.1) of water quality and stream flow throughout the urban portions of the Lower Columbia Region. Based on prior studies, these data should also be sufficient to demonstrate any significant trends in those conditions over the course of one to two decades, and for which the "direction" of change representing improved conditions is well known for each indicator (Objective 7.2).

Question 8: What are the status and trends of water quality and stream flow in surface waters that are being affected by stormwater discharges from urban areas first developed under requirements of the 2013 municipal stormwater permits?

Objective 8.1 (status): In streams whose catchment areas now drain primarily non-urbanized areas within Urban Growth Areas, evaluate whether water quality generally supports the watershed-specific beneficial uses identified in WAC 173-201A-602 (<http://apps.leg.wa.gov/WAC/default.aspx?cite=173-201A-602>) and

meet the “Properly Functioning” conditions of NOAA (1996).

Objective 8.2 (trends): In the sample population of Objective 8.1, evaluate whether measured water-quality and flow (i.e., stage) metrics show statistically significant trends over a 10-year period in those subwatersheds that have experienced measureable land-use changes while under provisions of the 2013 (or later) municipal stormwater permit.

Discussion of feasibility:

This question, and its associated objectives, begin to explore the boundary between “status and trends” monitoring and “effectiveness” monitoring, because they are targeting those locations where a particular activity (i.e., land development) is anticipated to have a potentially causal relationship with measured indicators. Given the rates and distribution of newly developed (and developing) land, however, it is unlikely that a statistically robust number of sites (i.e., 15 or more) that meet these criteria is likely to be identified over the course of even a decade. Although worthy in principle, these objectives are likely to be answered only with indications of conditions or of trends that might have a meaningful association with upstream development, but which will require more targeted evaluation beyond the scope of the HSTM program to conduct.

Habitat

Question 9: What are the status and trends of in-stream biological health and in-stream/riparian habitat conditions that are primarily within the jurisdiction of NPDES stormwater permittees (in terms of both quality and quantity)?

Objective 9.1 (status): In streams in urban NPDES areas, evaluate the status of biological and habitat conditions according to the habitat indicators relative to PFCs (NOAA 1996).

Objective 9.2 (trends): Analyze for statistically significant spatial and temporal trends of biological and habitat metrics (annually) in urban NPDES areas.

Discussion of feasibility:

Given the narrow scope of biological and habitat monitoring at urban+NPDES sites (i.e., width/depth and substrate), the coverage of these streams will provide insufficient insight into physical conditions to comprehensively address either objective. However, the stream benthos data will provide a sound integrative assessment of overall condition. In addition, the habitat monitoring at a regional scale includes a strata combination that will incorporate many of the streams within the urban+NPDES area, and which should address these two objectives to a similar degree, and over a similar time frame, as Objectives 3.1 and 3.2. Should that monitoring occur, a broader understanding and context will become available.

Question 10: Do in-stream biological health and habitat conditions correlate to changes in observed abundance, productivity, spatial structure, and diversity of the natural-origin fish in this population (reach/subwatershed scale)?

Objective 10.1 (trends): Identify statistically significant correlation between trends in select habitat indicators and trends in fish population metrics (e.g., abundance, productivity, spatial structure, and diversity) being conducted by other monitoring programs.

Discussion of feasibility:

Because the spatial scale of the urban+NPDES monitoring sites is significantly less than that of the fish populations of interest in the Lower Columbia Region, this objective is likely to be less easily or successfully addressed than its regional counterpart (Objective 4.1). At best, correlations may emerge between these locally collected indicators and more localized fish presence/absence data. However, it is not known whether those fish data are being systematically collected by others in a spatial domain that would prove relevant to this objective, and so its potential for attainment through even a decade (or more) of HSTM implementation is unknown at this time.

1.2.2 Information and data to meet objectives

In order to address the project objectives, which broadly seek to characterize the status and trends of stream conditions across the Lower Columbia Region, a set of indicators will need to be measured with sufficient precision and statistical rigor to adequately characterize “status,” and over a sufficient period of time to discern any “trends.” Developing the specific approaches to meet these requirements was the primary task of the Design Report; specifying the procedures, timing, and locations for executing those approaches is the primary task of this Implementation Report and its associated QAPP, as described in the subsections that follow.

1.2.3 Target populations

The target populations differ for the two major types of monitoring activities described in this plan: namely, water-quality and quantity sampling (hereafter, “Qa/Qx sampling”) and physical habitat sampling. A third monitoring type, biological monitoring of benthic macroinvertebrates, occurs at both Qa/Qx and habitat sampling locations.

The Qa/Qx target population will take advantage of the “continuity” of flowing water, under the assumption that most water-quality parameters vary only gradually, if at all, along a given stream reach in the absence of tributary or manmade inputs. Thus, the population of Qa/Qx sites from which sampling locations will be drawn will be *segments* having a specified range of drainage areas (see below). Within each selected segment, the location chosen for sampling should have only modest influence on the collected data, and thus ancillary considerations (such as site access or the reoccupation of legacy sampling sites that are located within the selected segments) can be incorporated without undermining the random spatial design. Thus, all Lower Columbia Master Sample sites within a specified range of drainage areas will be used to define stream segments as potential Qa/Qx sampling sites. To maintain data independence, however, no selected site should drain into any other selected site.

For habitat monitoring, more localized stream *reaches* are the appropriate target population for assessing habitat. Sampling sites will be located in reaches of continuous, freshwater streams with non-constructed channels and lotic, perennial flow. To adequately represent variability across stream reaches throughout the Region for wadeable and non wadeable streams, habitat monitoring will sample randomly chosen sites selected from all stream reaches that meet a specific set of strata-based selection criteria (see below).

1.2.4 Study boundaries and sample stratification

Although the sampling domain is the entire Lower Columbia Region within Washington state, adequate coverage of the diverse habitats and conditions with a relatively limited number of samples requires some degree of stratification. Stratifying a sample population is necessary to ensure that “like” is being compared to “like,” and that a subset of that population can provide a

credible representation of the group as a whole. For example, published reference conditions for large woody debris loading distinguish between values for wide rivers and narrow streams; pool frequency is not equivalent in low-gradient meandering streams and steep cascade channels. Thus, subdividing the population of sample sites on the basis of physical attributes is commonly necessary. In addition, stakeholders wanted to ensure that the random selection of sites would sufficiently represent key areas (such as the Lewis River subbasin, which supports a large number of ESA-listed salmonid species) on the basis of jurisdictional or regulatory considerations (e.g., recovery planning). Thus, this stratification was also included.

Based on considerations of geographic distribution, variability of channel types, and future management needs, the following strata have been defined:

For Qa/Qx sampling *within* the urbanized or designated Urban Growth Areas (UGAs) of an NPDES municipal stormwater permittee, stream segments should have a predominant urban land cover in their contributing watershed with drainage areas between 2.5 and 50 km², a watershed area that broadly corresponds to the scale of urban development and of effective stormwater management treatments e.g., Schueler 1994). Thus, this “urban+NPDES” Qa/Qx sampling is not further stratified and includes only a single category of sites.

Qa/Qx sampling *outside* of urban areas was included as a separate category of sampling in the Design Report. Based on a consensus decision by the stakeholders, however, a single Qa/Qx parameter (temperature) and biological indicator (B-IBI) are now simply integrated into habitat sampling sites.

For habitat sampling, the following strata and categories are defined:

- Within the urban+NPDES areas, and “regional sites” that lie outside of all urban areas = **2 categories**
- Drainage area (0.6-2.5, 2.5-50, 50-200, 200-1000, >1000 km²) = **5 categories**
- Stream gradient groups (<1.5%, 1.5-3%, 3-7.5%) = **3 categories**
- Predominant watershed land cover (forested, agricultural, urban) = **3 categories**
- Number of salmonid Primary Populations in the subbasin (0-2 and 3+) = **2 categories** (only applied outside of urban areas)

This stratification represents a reduction in two categories from the Design Report (. Stakeholders determined that three categories of gradient and two categories of Primary Populations would adequately represent the range of conditions and in support of management needs in the Lower Columbia Region. As such, the two strata were removed to avoid unnecessary excessive stratification and associated monitoring costs.

In addition to Qa/Qx and habitat sampling, a third type—biological sampling of benthic macroinvertebrates—will occur at all selected sites where either Qa/Qx or habitat sampling is implemented (i.e., at both urban+NPDES and regional monitoring sites).

1.2.5 Practical constraints on the study design

As noted in the Background section, the Region is a patchwork of public and private land ownership, and of transportation networks of widely varying density and coverage. Not every site that is randomly selected will be accessible. Such circumstances were recognized in the Design Report as needing to be addressed during implementation. They will constrain the final design

only if a particular combination of strata have so few members that the necessary exclusion of a subset of points would result in too few remaining members for statistically robust representation of the population as a whole. The Design Report (Stillwater Sciences 2015a) detailed the rationale supporting 15 sites per stratum as a minimum number for implementation.

Affordability, and the commitment from stakeholders to fund the HSTM, are other practical constraints yet to be resolved. With limited resources and existing monitoring programs already in place, agencies and permittees are still in the process of determining their level of engagement as part of the development of this Implementation Plan. Such modifications are likely to continue throughout the implementation of this program.

Lastly, one of the primary goals of the HSTM for the Lower Columbia Region was to engage the Oregon portion of the Region and the associated stakeholders. That remains an incomplete goal and practical constraint on the study design, which is currently restricted to the Washington state portion of the Region.

1.2.6 Summary of tasks needed to collect data

To collect data under the HSTM program, the roles and responsibilities for financing and implementing both the water quality and habitat components have been recommended by their respective caucuses (see Appendices A and B). With these agreements and understandings in hand, the sequence of tasks required to collect data can be broadly summarized as follows:

- Identify the specific candidate sites at which monitoring will occur (specific sampling locations are provided with this report in the form of separate digital files).
- Identify the 5-year sampling schedule.
 - For the habitat monitoring: field-evaluate candidate sites for a given year based on access logistics. Fifteen viable sites per strata combination should be identified.
 - For the Qa/Qx monitoring: field-evaluate all candidate sites based on access logistics and site security for equipment deployment.
- Acquire field sampling equipment and permanently installed sensors.
- Deploy sensors at sites where continuous monitoring will occur, and initiate regular maintenance schedule.
- Plan and implement summer-season site visits to Qa/Qx and habitat sites.

1.2.7 Decisions that could be made using data

Because sampling under the HSTM project has not yet begun and data have not yet been analyzed, how the monitoring data will be used by project partners has not been fully determined and will likely evolve throughout the lifetime of this program. The primary purpose of the data is to answer the program questions set forth in the Design Report (Stillwater Sciences 2015a) and reiterated in Section 1.2.1 above. In general they are summarized as follows:

- Satisfy future municipal stormwater permit requirements for status and trends monitoring;
- Track the status and trends of regional watershed health known to support ESA-listed salmonid species; and
- Infer the potential value and success of various salmon-recovery and stormwater-management efforts at a broad, landscape scale.

Based on the experience of other such status and trends monitoring program that are already implemented, potential approaches to analyzing and interpreting data to be collected by this program are discussed in Section 4 of this report.

1.3 Organization and Schedule

1.3.1 Participating organizations and HSTM program leadership

For habitat monitoring, the regional program will be guided by a Steering Committee composed of representatives from the regional habitat and water quality monitoring agencies and organizations (see Appendix B-1). Membership should include, at a minimum, representatives from:

- NOAA
- USDA Forest Service
- U.S. Fish and Wildlife Service
- USGS Pacific Northwest Aquatic Monitoring Partnership
- Washington Department of Fish and Wildlife
- Washington Department of Ecology's Environmental Assessment Program
- Washington Department of Ecology's Water Quality Program
- Representative from SW Washington Stormwater Permittees
- Washington Salmon Recovery Funding Board
- Oregon Department of Fish and Wildlife
- Oregon Department of Environmental Quality
- Oregon Watershed Enhancement Board

A Technical Review committee will also be formed to provide feedback on annual reports and performance of the protocols. The feedback from the Technical Review committee will inform program management decisions by the Steering committee. Based on feedback from the Habitat Caucus members, the following agencies are interested in serving on the Technical Review committee:

- NOAA
- U.S. Geologic Survey
- USDA Forest Service
- U.S. Fish and Wildlife Service
- Ecology's Environmental Assessment Program
- Oregon Department of Fish and Wildlife

For the Qa/Qx monitoring of urban areas under the municipal stormwater NPDES permit, a steering committee and technical review committee are also anticipated to be formed (see the Stormwater Roles and Responsibilities, detailed in Appendix A-1 of this report). Clark County is proposed to serve as the project manager conducting the data collection, analysis, and reporting. The committee membership will include the permittees, Ecology, and other interested parties with specific roles to be defined in advance of the planned re-issuance of the next municipal stormwater NPDES permit in summer 2018.

The permittees are: Cities of Battle Ground, Camas, Kelso, Longview, Vancouver, and Washougal; Clark and Cowlitz Counties; and WSDOT.

1.3.2 Project schedule and limitations

Detailed program schedules will be developed by HSTM Program Managers responsible for water quality, habitat and biological monitoring. Table 4 from Ecology’s Quality Assurance Monitoring Program guidance document (Ecology 2006) is a useful example of what should result from this forthcoming effort:

Table 4: Logistics schedule for the status and trends program.

[illegible]

Qa/Qx monitoring prescribed in the Stormwater Roles and Responsibilities document (Appendix A-1) includes the following recommendations:

- Site reconnaissance and site confirmation—begin in 2017 to acquire landowner approval and confirm site access, security of sampling equipment, and monitoring feasibility; and to be ready to begin the monitoring in 2018.
- Prioritize extended monitoring component parameters and finalize budget (see Section 1.3.3.1 below).
- Equipment purchase – begin in summer 2018 depending on 2018 NPDES permit requirements.
- Data collection – begin October 1, 2018 (or October 1, 2019 depending on 2018 NPDES permit requirements).

Regional monitoring prescribed in the Habitat Roles and Responsibilities document (Appendix B-1) includes the following recommendations:

- Site reconnaissance—begin in March to acquire landowner approval, site access, and monitoring feasibility.
- Field training workshop—prepare field crews by the end of May. All field personnel should participate in trainings every year.
- Data collection—July 1 to September 30th annually to capture low-flow conditions, ensure field crew safety and avoid spawning fish and emerging fry in Lower Columbia tributaries. Sites at higher elevation should be sampled later in the season to allow flows to decrease following snowmelt.

1.3.3 Budget information for the project

1.3.3.1 Urban+NPDES monitoring

Based on cost data and experience from the Puget Sound RSMP for small streams, recent small-stream monitoring for Clean Water Services (Stillwater Sciences 2015b), and prior experience from Clark County, the estimated cost of the recommended base urban+NPDES Qa/Qx monitoring as described in this Implementation Plan is approximately \$68,000 per year (Table 1; see Section 3.1.1 for the list of base indicators), based on constant 2016 costs. This cost compares favorably with prior estimates of population-adjusted costs relative to status and trends monitoring in the Puget Sound area under the RSMP.

This cost estimate was prepared by the permittees and includes monthly maintenance of continuous data-recording installations and amortizes the equipment and installation costs over a presumed 5-year period of the NPDES permit cycle. It assumes that labor will be provided by Clark County staff at a fully burdened rate, and it draws on that program's monitoring experience to apply realistic unit costs. Based on one year of implementation of the Puget Sound RSMP for small streams, an additional contingency fund should be added to these totals, but that has not yet been included. Other modifications to this budget may include the establishment of an initial start-up year, in which equipment is purchased and program management is finalized but no data collection occurs. QA/QC costs, typically adding approximately 10% for additional field data collection and laboratory analysis, are not presently included in this budget estimate. This estimate is also being reevaluated for potentially optimistic estimates for data checking and uploading to a regional database.

Although the permittees' extended monitoring component to the Qa/Qx monitoring at urban+NPDES is not part of the primary monitoring of the HSTM program, the cost of their collection and analysis has been identified (about \$59,000 per year, which would result in an annual combined monitoring cost [base+extended] of \$127,000, based on constant 2016 dollars), using the same approach and assumptions as for the suite of monitoring indicators described above. The detailed cost spreadsheet for this extended program is included with its associated Urban HSTM QAPP. It will be the responsibility of the permittees to prioritize the extended monitoring component indicators and adjust its implementation as needed to ensure sufficient remaining funding to successfully implement the base program in the event of presently unanticipated cost increases or underestimates.

Table 1. Average annual costs to implement urban monitoring.

w	Base Program	Extended Program
	(Watershed Health)	(Water Quality)
Data Collection:		
Continuous Data	\$18,800	n/a
Macroinvertebrates	\$7,900	n/a
Sediment Chemistry	\$2,900	n/a
Water Quality Grab Samples	n/a	\$43,280
Data Management	\$32,040	
Data Analysis and Reporting	\$21,860	
Project Management (10%)	\$12,678	
TOTAL	\$139,458	

1.3.3.2 Regional monitoring

Based on cost data and experience from ongoing monitoring programs (Ecology, WDFW, and USGS), the estimated staff cost of the recommended regional monitoring as described in this implementation plan is approximately \$709,000 per year (Table 2). This assumption presumes two 2-person crews will sample up to 70 sites/year/crew with a 5-year rotation of sites. This estimate does not yet include travel expenses (e.g., equipment, gas, lodging, meals), which is likely to increase the total cost by about 10%, depending on the final location of sites and where crews are based.

Table 2. Annual monitoring costs to implement regional sampling.

	Staff	Annual hours	Rate	Total
Project management	1		10% total budget	\$ 64,432
Data collection	4	1520	\$76	\$ 62,080
Data management	1	320	\$76	\$ 24,320
Data analysis	1	520	\$112	\$ 58,240
	1	520	\$76	\$ 39,520
Reporting	1	320	\$112	\$ 35,840
	1	320	\$76	\$ 24,320
				\$ 708,752

1.4 Quality Objectives

1.4.1 Decision quality objectives

“At the level of the decision, there is a need to specify tolerable limits of making decision errors. These tolerable limits are required, along with other information, to determine the numbers and

locations of samples from the site that must be collected and analyzed.” (from Ecology 2004, p. B-2) [<http://www.ecy.wa.gov/biblio/0403030.html>]

Principles established during Phase 1 of the HSTM project have specified that basing future management on the results of monitoring will require a robust statistical design. This is being accomplished through: (1) use of the Master Sample for the Lower Columbia Region, which applied a probabilistic site selection algorithm to generate a spatially-balanced set of sites, to implement status and trends monitoring; and (2) ensuring a sufficient number of sites in each unique monitoring strata combination that a specified level of statistical confidence can be achieved (95% confidence and 80% power for water quality and 90% confidence and 80% power for habitat and biological indicators). In addition to these two criteria, a third has been added, namely that individual indicators should have a signal-to-noise ratio that is at least of “moderate” precision (Kaufmann et al. 1999), in order to improve the statistical likelihood that identified trends in the data are reflecting true changes in environmental variables and not just random fluctuations or errors in measurement.

1.4.2 Measurement quality objectives

“At the level of measurements used to support the decision or study question, quality objectives are expressed as measurement quality objectives or MQOs. The MQOs are performance or acceptance criteria for the data quality indicators precision, bias, and sensitivity.” (Ecology 2004, p. B-2)

Because the HSTM program includes a wide variety of indicators, measurement quality objectives vary significantly between the various categories. An overarching focus for indicator selection has been to use only those metrics with relatively high levels of measurement precision and signal-to-noise. For parameters measured with on-site sensors or laboratory analyses (water temperature, sediment metals, conductivity, stage), typical values are within a few percent and are specified more precisely in Section 3.1.4. For field methods (i.e., habitat indicators), commonly reported values for the precision of replicate values for those indicators recommended for inclusion in this program are on the order of 10% (e.g., Kaufmann et al. 1999).

1.5 Sampling Design

1.5.1 Experimental design and sampling locations

The experimental design for this project will follow two distinct approaches: one for the urban+NPDES sample sites, at which primarily Qa/Qx indicators will be collected; and the other for the regional sites, at which primarily habitat indicators will be collected. Both, however, share the same basic elements and underlying principles to guide site selection and data acquisition:

- Sites are drawn from the Master Sample for the Lower Columbia Region within Washington state
- The entire population of prospective sites will be stratified into categories that are scientifically relevant for the parameters being measured
- Within each unique combination of strata and categories, at least 15 sites will be sampled to ensure an sufficient level of statistical significance to support the decisions being made on the basis of the results
- Care will be taken to avoid sites that are affected by Columbia River backwater or tidal fluctuation

For the prospective sites that lie within the urbanized area or designated UGA of a municipal stormwater permittee (i.e., urban+NPDES areas), sampling for the Qa/Qx indicators will be limited to those that drain watersheds of 2.5-50 km² with predominantly (i.e., >50%) “urban” land cover. Although the Design Report included a provision for identifying sites outside of urban+NPDES areas (i.e., “regional” sites) that would be sampled exclusively for Qa/Qx indicators (Stillwater Sciences 2015a), decisions by the HSTM stakeholders during preparation of this implementation plan changed that element of the design. Instead, a single Qa/Qx indicator (temperature) will be collected at the regional sites as part of the habitat sampling effort (see below).

For habitat monitoring, the sample population will be stratified first on the basis of whether or not a site lies within the urbanized or designated UGA of a municipal stormwater permittee (i.e., the same “urban+NPDES” areas noted above). Within these areas, monitoring sites will be selected from strata defined by categories of drainage area size (0.6–2.5 km², 2.5–50 km², 50–200 km², 200–1,000 km², >1,000 km²), stream gradient (<1.5%, 1.5–3%, 3–7.5%), and predominant land cover in the contributing watershed (forested, agricultural, urban). For those habitat sites outside the urban areas (i.e., not in a designated UGA or other urban area), an additional stratification will be added for the number of Primary Populations within the contributing subbasin (two categories, namely 0–2 or 3+ Primary Populations).

This sampling design has been motivated entirely by the measurements required to answer the ten monitoring questions developed in the Design Report and discussed above, and by scientific understanding of how various chemical and physical attributes of streams vary with location and with watershed characteristics.

1.5.2 Representativeness

“Representativeness” is a property of both the region being assessed and the parameter being measured (Ecology 2006). The probabilistic sampling design is intended to achieve statistically valid spatial representations of stream status and trends at the scale of the entire Lower Columbia Region. Field measurements (except for those made by continuous data-collecting sensors) will be conducted in the summer, a period when hydrologic, physical, and biological conditions are most stable and the likelihood of confounding high flows is low. Ensuring that the laboratory measurements of field-collected samples are representative of those field conditions, established procedures for sample holding time, equipment calibration, and analytical duplicates as described for each parameter below.

Representativeness of water-quality parameters is particularly enhanced by the Design Report’s emphasis on collecting continuous parameters in real time, eliminating the otherwise inescapable uncertainties associated with the time-varying nature of most water-column constituents.

1.5.2.1 Field measurements

Field measurement and data collection for Qa/Qx monitoring will be conducted at the downstream-most location of an identified stream segment that meet criteria for feasible logistics for access and site security. The indicators in the water column are not anticipated to vary greatly throughout the stream segment. For those with particular site requirements (i.e., sediment metals and PAHs and macroinvertebrates), the conditions necessary for representative field measurements are specified in the Urban HSTM QAPP as part of the measurement protocols.

Most of the field measurements conducted at habitat sampling locations are conducted throughout the entire 20×-bankfull-width-long reach, ensuring that results are truly “representative” of the reach. This distance is designed to include multiple pool-riffle or step-pool sequences in an alluvial channel coupled with measurements at 11 transects to avoid overrepresenting unique characteristics of any one segment. Variability will be reduced through refinement of site selection and rotating panel designs. Field personnel will record where samples are measured and note general descriptions of physical conditions of the channel, gradient, habitat types, water velocity, weather, and other parameters or unique local features that could influence data quality. These narrative field notes can be used to qualitatively assess how well the data represent the conditions characterized by this study, should any questions later arise about the representativeness and accuracy of the measured indicators.

1.5.2.2 Laboratory measurements

Typical protocols to ensure the representativeness of lab data is to provide triplicates of every 20th sample, with a goal of <5% variability as the standard. This provides a high confidence that each sample accurately reflects a representative value of the measured parameter.

However, sampling under the Qa/Qx program will never include as many as 20 samples in a given year. Thus, this generic guidance should be modified to randomly select one of the ten samples for triplicate measurement in the first year. Findings of this quality assurance investigation will inform future QA/QC needs.

1.5.3 Comparability

All sites with once-per-year measurements will be visited during summer low-flow conditions, and the field methods will be documented in sufficient detail to ensure comparable results. The selection of indicators has been guided by the need to avoid those with recognized high levels of observer variability, and so many of the problems of (in)comparability that plague other such monitoring efforts have been addressed through the initial design. For sites with continuous data collection, field sensors will be similar or identical at all sites, and episodic calibration with hand-held sensors will ensure that the data are equivalent across all sites.

1.5.4 Completeness

Completeness will be calculated as a percentage of the number of valid samples that should have been collected relative to the number that actually are obtained. The standard for completeness is 90% in order that the data can be determined as valid in proportion to the goals for the project as a whole.

1.6 Signal-to-Noise Analysis

The first phase of signal-to-noise analysis was conducted for all metrics to support the final selection of protocols based in part on the predictive strength of a given metric and the shareability of data. However additional work and stakeholder input was needed to determine the best course of action regarding the shareability of data. As a result, a second phase of the signal-to-noise analysis was conducted as part of this Implementation Plan.

Signal-to-noise (S/N) analyses compare the magnitude of “true” change in a metric with the magnitude of its random (or otherwise irreducible) variability. The knowledge and management

of such information is critical to ensuring a successful HSTM program because “High noise in habitat descriptions relative to the signal (i.e., low *S/N*) diminishes statistical power to detect differences among subpopulations” (Kaufmann et al. 2014).

Given the desire to manage the program development with *S/N* consideration, research was conducted to explore *S/N* data gaps and to work closely with the HSTM stakeholders to evaluate methods, *S/N* ratings, protocol selection and data shareability. The resulting ratings are listed below (Table 3). As explained in the Monitoring Design, the rating system can be interpreted as follows:

- *S/N* >10: negligible adverse effects of noise variance in environmental monitoring;
- *S/N* 6-10: minor adverse effects of noise variance in environmental monitoring,
- *S/N* 2-6: moderate adverse effects of noise variance in environmental monitoring, and
- *S/N* <2: severe adverse effects of noise variance in environmental monitoring.

Such information is highly valuable when considering the suitability of a given metric to detect meaningful signals (trends). It is also useful to evaluate the potential for monitoring programs to share data. Although some monitoring programs may find their data to be shareable based on standard protocols, if one program produces high *S/N* ratios and the other low *S/N* ratios, it would be ill-advised to pool such data. Because the HSTM program includes a wide variety of indicators, measurement quality objectives vary significantly between the various categories. Nevertheless, a program goal was set forth to identify only those indicators with relatively high levels of measurement precision and signal-to-noise.

Protocol discussion and selection by the stakeholders was supported by *S/N* ratings. For example, the Habitat Caucus used a decision matrix developed by Stillwater Sciences to evaluate the range of methodologies known for each indicator, the associated *S/N* ratings and recommendations for caucus consideration. The caucus reviewed and discussed the decision matrix during multiple meetings before arriving at consensus for field data collection methods that are presented in details within this report.

S/N studies reviewed for this effort included the following monitoring programs and organizations:

AREMP—Northwest Forest Plan Aquatic and Riparian Effectiveness Monitoring Program;
CDFG—California Department of Fish and Game Protocols;
ECOLOGY—Washington State Department of Ecology
EMAP—EPA Environmental Monitoring and Assessment Program;
NIFC—Northwest Indian Fisheries Commission;
ODFW—Oregon Department of Fish and Wildlife;
PIBO—USDA Forest Service-BLM (effectiveness monitoring program for PACFISH/INFISH biological opinion);
UC—Upper Columbia Monitoring Strategy.

Table 3. Habitat indicators and Signal/Noise ratings (“grades”) from various sources.

Indicators*	Signal to Noise Rating							
	AREMP ¹	CDFG ¹	EMAP ¹	NIFC ¹	ODFW ¹	PIBO ¹	UC ¹	Ecology ²
Temperature ^{W,NW}								B
Conductivity ^W								A
Stage ^W								
Sediment metals ^W								
Sediment PAHs ^W								
Sample reach length ^{W,NW}	C ³		B ³			B ³		
Channel type ^{W,NW}								
Reach slope ^{W,NW}	B ³ A ⁴	C ⁴	B ⁴ A ⁴ A ⁵		A ⁴	A ³ A ⁴	A ⁴	
Sinuosity ^{W,NW}	D ³ A ⁴		B ⁴ D ⁵			C ³ D ⁴	C ⁴	
Bank modification ^{W,NW}								
Density of habitat types (% pools) ^W	F ³		D ³ C ⁵			B ³		C
Bankfull width/depth ^{W,NW}	F ³ C ⁴	D ⁴	D ⁴ B ⁵	B ⁴	C ⁴	C ³ D ⁴	D ⁴	A
Pools per unit length ^W	D ⁴	F ⁴	D ⁴	D ⁴	C ⁴	F ⁴	D ⁴	
Floodplain width ^{W,NW}								
Side channel habitat ^{W,NW}								
Flow category ^{W,NW}								
Benthic macroinvertebrates ^W								C
Residual Pool depth ^W	B ⁴	F ⁴	B ⁴ B ⁵	C ⁴	C ⁴	A ³ B ⁴	A ⁴	A
Bank stability ^W								F,F
Relative bed stability ^W								
Density / distribution instream wood ^{W,NW}	B ³ A ⁴	C ⁴	F ³ A ⁴	A ⁴	A ⁴	D ³ A ⁴	A ⁴	B,D
Particle size (D50)	B ³ C ⁴		C ³ B ⁴			B ³ B ⁴	C ⁴	
Particle size (percent fines)	A ³ C ⁴	F ⁴	A ³ C ⁴		C ⁴	A ³ B ⁴	D ⁴	
Shade ^W								D,A
Riparian canopy ^{W,NW}								
Riparian understory ^W								

* Indicators were previously labeled “metrics” in the Monitoring Design Report

Blank cells indicate no applicable signal-to-noise ratios or ratings identified

^W Wadeable

^{NW} Non-wadeable

¹ S:N ratios converted to letter grades from Merritt and Hartman 2012. If a log transformation improved S:N ratios, the letter grades for the transformed data are reported

² Merritt and Hartmann 2012. When two grades are present from the same source document, the first is for wadeable streams and the second is nonwadeable rivers

³ Whitacre et al. 2007

⁴ Roper et al. 2010

⁵ Kauffman et al. 1999

1.7 Sample Collection, Analysis, and Reporting Guidelines

1.7.1 General field safety considerations

In any field data collection effort, there can be significant risks. It is the responsibility of each crew member, not just the crew lead, to insure the health and safety of crew members. A written health and safety plan must be prepared prior to the commencement of field activities. Details for this plan are articulated in the Urban and Regional HSTM QAPPs (Parts 2 and 3 of this document).

1.8 Sampling Procedures and Laboratory Measurements

Much care was taken to select appropriate indicators, field sample collection and laboratory analysis methods that will allow the greatest comparison of data among existing programs. All field sampling and laboratory analyses will follow the established protocols articulated in the Urban and Regional HSTM QAPPs (Parts 2 and 3 of this document).

1.9 Quality Control

An overarching focus for indicator selection has been to use only those indicators with relatively high levels of measurement precision and signal-to-noise. For water quality indicators measured with on-site sensors (water temperature, conductivity, stage), typical values for data quality and bias are within a few percent. The accuracy and instrument bias of each sensor will be verified through post-deployment calibration checks following the procedures as detailed in the Urban and Regional HSTM QAPPs (Parts 2 and 3 of this document).

For those samples that are field-collected and transported to a laboratory (benthic macroinvertebrates and sediment), established procedures for preservation, holding times, and chain-of-custody will be followed. Field replicates will be used to evaluate the representativeness of the data. Habitat indicators will be measured using established, field-tested protocols (see the Urban and Regional HSTM QAPPs, Parts 2 and 3 of this document) by trained crews, with multiple checks during the recording, transferring, and data entry of field-collected information.

Sediment and benthic macroinvertebrate samples are the only samples that will need to be analyzed by a laboratory. To ensure the quality and consistency of sample collections, equipment maintenance and sample collection protocols described in the appendices of this report will be followed. For the laboratory measurement of sediment PAHs and metals, bias and precision values should be less than 20–40% depending on the indicator (see the Urban and Regional HSTM QAPPs, Parts 2 and 3 of this document) and will be checked through replicate samples. All laboratories used for the analyses will have their own approved internal quality-control procedures, which will be confirmed and documented prior to sample submission.

2 SECTION 2: SAMPLE SITE SELECTION

2.1 Sampling Site Selection and Evaluation

2.1.1 Evaluation under the sampling design

Sample site selection and evaluation occurs at two levels in this program. The first level involved the stratification of the target population into physically meaningful strata, appropriate to the

monitoring activities and intended uses of the data, by use of GIS characterization of the stream and watershed characteristics associated with each point in the Master Sample. The second level, the actual determination of whether monitoring can occur at the designated location, is covered in the following sections.

Site evaluations, including a field visit to each candidate site, will be used to determine the suitability of each site for monitoring to meet the HSTM goals. Site suitability will be determined by selection criteria related to accessibility, hydrologic and geomorphic characteristics (flow, physical features, and salinity), and location relative to a candidate sites' original coordinates (see below).

2.1.2 Sample populations

The locations of potential sampling sites is difficult to display because the full population of >100,000 Master Sample points cannot be shown on a single page. Thus, only partial representations are possible in a written report. Several such examples are shown below (Figure 2 through Figure 5); specific sampling locations are provided as separate digital files as part of the Implementation Plan.




Figure 2. Stream segments that contain Master Sample points meeting the drainage-area criteria of 2.5-10 km² (red) or 10-50 km² (yellow).

The example below shows the distribution of sampling sites in the urban area of Clark County relative to only those Master Sample points that meet the criteria of having drainage areas between 2.5 and 50 km² and that drain watersheds with predominately urban land cover.




Figure 3. GIS view of the Master Sample points in Clark County (dark pink area). Individual points meeting the recommended drainage-area criteria and that drain watersheds with predominately urban land cover are indicated by red squares (0.6–2.5 km² drainage area) or yellow squares (2.5–50 km²). All such locations that correspond to a qualifying master sample point (i.e., red or yellow square) constitute the set of “trend” urban+NPDES sampling sites referenced in this report, with their downstream-most locations indicated by black circles.

Two additional examples show the distribution of Master Sample sites draining watersheds with predominately urban (Figure 4) and agricultural (Figure 5) land uses over the Lower Columbia Region as a whole, providing the basis for selecting sites within these land-cover categories for the regional sampling.




Figure 4. Master sample points draining watersheds with predominately urban land cover. Points are stratified with respect to drainage area and number of primary populations associated with the larger watershed within which they are located. Note the near-absence of such points outside of urban+NPDES areas.




Figure 5. Master sample points draining watersheds with predominately agricultural land cover. Points are stratified with respect to drainage area and number of primary populations associated with the larger watershed within which they are located.

Due to the large number of sites in the master sample (>100,000), it was infeasible to calculate the dominant watershed drainage for all potential sample sites. However because there are only a limited number of sites that meet the criterion of having a predominate watershed land cover of “urban” or “agriculture,” a GIS analysis was run to determine how many of the strata combinations will have a sufficient number of Master Sample points to have sufficient master sample points to merit inclusion in the final implementation Tables 4 and 5). Such data were also used to generate the costs estimates in Section 1.3.4.

Table 4. Master Sample sites within urban+NPDES areas that also drain watersheds with predominately urban landcover. Strata combinations that meet the minimum site number criteria (≥ 15 sites) for inclusion in the regional monitoring effort are shaded.

0-2 Primary Populations			
Drainage area	<1.5%	Gradient class	
		1.5–3%	3–7.5%
0.6–2.5 km ²	25	14	15
2.5–50 km ²	83	14	7

3+ Primary Populations			
Drainage area	<1.5%	Gradient class	
		1.5–3%	3–7.5%
0.6–2.5 km ²	46	8	3
2.5–50 km ²	33	0	2

Table 5. Master Sample sites outside of urban+NPDES areas that also drain watersheds with predominately agricultural landcover. Strata that meet the minimum site number criteria (≥ 15 sites) for inclusion in the regional monitoring effort are shaded.

0-2 Primary Populations			
Drainage area	<1.5%	Gradient class	
		1.5–3%	3–7.5%
0.6–2.5 km ²	88	8	3
2.5–50 km ²	59	6	0

3+ Primary Populations			
Drainage area	<1.5%	Gradient class	
		1.5–3%	3–7.5%
0.6–2.5 km ²	136	27	44
2.5–50 km ²	46	13	0

Given the large number of forested sites, a GIS analysis was focused on the 45 sites/strata randomly selected from the Master Sample to confirm that they are in fact sites that drain watersheds with predominantly forested land cover. The results demonstrate 26 strata combinations (bins) meet the minimum site criteria (Table 6).

Table 6. Master Sample sites outside urban+NPDES areas classified as forested. Strata that meet the minimum site criteria (≥ 15 sites) are shaded.

Drainage area	Slope	Urban+NPDES	Regional	
		Primary population categories		
		0–2	0–2	3+
0.6–2.5 km ²	<1.5%	9	68	320
	1.5–3%	7	115	362
	3–7.5%	9	434	1257
2.5–50 km ²	<1.5%	15	199	794
	1.5–3%	13	285	753
	3–7.5%	2	687	1627
50–200 km ²	<1.5%	6	97	337
	1.5–3%	1	98	195
	3–7.5%	1	44	169
200–1,000 km ²	<1.5%	1	135	197
	1.5–3%	0	33	43
	3–7.5%	0	33	15
>1,000 km ²	<1.5%	0	2	44
	1.5–3%	0	0	5
	3–7.5%	0	0	3

Note that there are no strata with 15 or more Master Sample points with predominate watershed land cover of “urban” outside the urban+NPDES area. Likewise, there are no strata with 15 or more Master Sample points with predominant watershed land cover of “agricultural” inside the urban+NPDES area. These results (Tables 6, 7, and 8) thus indicate that no more than 37 strata combinations (i.e., 5 urban, 6 agricultural, 26 forested) will meet the minimum-number criterion in the Lower Columbia Region, which has significant cost implications for the final design of the regional sampling program—37 strata with 15 sites/strata results in 555 regional monitoring sites.

2.1.2.1 Site selection and evaluation for Urban+NPDES monitoring

Within the urban+NPDES areas of the region, the selection of a single stratum (stream segments with watersheds draining 2.5–50 km² and predominately urban land cover) and the presence of preexisting sampling locations (the legacy sites of Clark County and the City of Vancouver) results in a modified approach to site selection. First, the total number of independent segments meeting these criteria is 18. An additional 4 sites with watersheds somewhat shy of 50% urban landcover have been identified by the Stormwater Caucus as being of particular value for sampling (three that increase the representation of samples in Cowlitz County in the Kelso-Longview area, and one long-term legacy site). Thus, a suitable rotating panel design can sample all 22 sites within a five-year period: this leads to true *census* sampling rather than *representative* sampling. Second, 6 of these sites already have known access (i.e., the legacy sites), and virtually all of the others lie in close proximity to roads, bridge crossings, or other likely access points. Thus, well more than half of these sites are anticipated to be accessible at some point along the

stream segment that contains them. For purposes of this Implementation Report, it is assumed that all of these stream segments will prove to have feasible sampling locations. The precise monitoring locations will be confirmed in the process of completing the final QAPP for field sampling.

For identifying locations for sampling Qa/Qx parameters within the urban+NPDES areas of the Region, “sites” are considered the entire stream segment along which the criteria of drainage area and land cover are met (see Figure 2 for their graphical display). Where a legacy site exists along a designated segment, it will presumably function as the actual monitoring location for this program. For those designated segments without a legacy site, desktop identification of prospective sampling location(s) should proceed from downstream to upstream, targeting the most promising locations for subsequent field checking. Preference should be given to the downstream-most location that meets all criteria for access, safety, security, and flow suitability (see below).

2.1.2.2 Site selection and evaluation for regional monitoring

Within each unique strata combination (bin), 15 “viable” monitoring sites are needed to meet the statistical objectives. Because of recognized challenges with site access, a working assumption based on experience in the RSMP program for small streams is that about twice as many “provisional” sites need to be identified and evaluated in order to meet the final target number. In other words, individual strata combinations should have at least 30 points initially identified. To be conservative, we increased that recommendation and identified 45 candidate sites from the Master Sample for each bin (i.e., each unique strata combination). The 45 provisional sites should be sufficient to identify 15 viable monitoring sites within a bin. A bin must have at least 15 possible candidate sites in order to be included in the random draw. Sites must be physically independent of one another. This is unlikely to be an issue for the forested parts of the Region, given the vast number of channel segments. Due to a small number of sites that drain watersheds with predominately urban or agricultural land cover, however, it is likely that more than one regional monitoring site could be selected within the same stream segment. To avoid such clustering of sample locations and ensure the best possible distribution of sites, only one regional monitoring site will be sampled per stream segment. A detailed list will be kept of the sites not sampled and the reason(s) for not sampling. This list will be used when adjusting the sample weights prior to statistical data analysis.

Desktop evaluation of candidate regional sites will be performed in advance of the initial site evaluation visit, and will include comparing candidate site coordinates to existing information on such items as surficial geology, parcel/property ownership, NHD waterbody type, historical stream flow and/or water quality data, and aerial photographs. For all of the initial candidate sites deemed unsuitable for monitoring, additional candidate sites for the relevant assessment region will be evaluated in sequence order in the Master Sample Site list.

Across the population of regional monitoring sites, roads and bridge crossings will be sparse, and so access to many sites will undoubtedly be a limiting (or at least logistically challenging) factor for many of those that are selected by random draw from their respective strata. This may require a revisit and augmented selection from the Lower Columbia Master Sample to acquire a sufficient number of actual monitoring sites. The process of initial random selection, the outcome of site evaluations, and any subsequent re-drawing of additional points from the Master Sample will be documented in the initial report write-ups for the first year’s implementation of the program. In particular, the basis for rejection of any site will be highlighted.

In order to maximize the statistical rigor of the monitoring program and to be consistent with other regional monitoring designs, e.g., Aquatic and Riparian Effectiveness Monitoring Plan (AREMP), regional monitoring sites will be visited in a rotating panel design as illustrated in the graphic below such that 1/5th of the sites would be visited each year and the full region will be sampled within a 5-year time period. To enable “repeat visits”, the sites monitored in years 1–5 will be resampled according to the same annual schedule in years 6–10, 11–15 and so on. Given this implementation approach, regional status can be assessed annually for sites sampled in any given year, whereas trends will be evaluated at “repeat sites” on a 5-year rotation beginning in year 6.

	Year									
	1	2	3	4	5	6	7	8	9	10
Group A	X					X				
Group B		X					X			
Group C			X					X		
Group D				X					X	
Group E					X					X

2.1.3 Mid-study changes affecting site suitability

If a site becomes unsuitable for sampling during the course of the study, the Project Manager(s) will be notified. Reasons a site may become unsuitable include, but are not limited to: a stream goes dry; the adjacent parcel(s) change ownership, and the new owner does not grant permission; or natural causes such as mudslides or animals make the site no longer safe to access. A decision about whether to simply discontinue the site or to identify a replacement site within the same strata combination will be made by project partners on the basis of its position in the rotating panel design, the amount of data already collected, and whether the strata combination would become underrepresented if the site (and, potentially others) were simply discontinued without replacement.

2.1.4 Field criteria for selecting a suitable sampling site

The process of field evaluation of sampling sites may need to continue through the sampling season as necessitated by potential changes in site conditions that affect suitability for sampling. Selection criteria for determining the suitability of a candidate site for monitoring to meet the HSTM goals are described in the Urban and Regional HSTM QAPPs (Parts 2 and 3 of this report).

The field measurement and data collection for Qa/Qx monitoring will be conducted at the downstream-most location of an identified stream segment that meet criteria for feasible logistics for access and site security. Most of the indicators are in the water column and are not anticipated to vary greatly throughout the stream segment. For those with collection at specific locations and with particular site requirements (i.e., sediment metals and PAHs, and macroinvertebrates), the conditions necessary for representative field measurements are specified in this document as part of the measurement protocols (see the Urban HSTM QAPP, Part 2 of this report).

Most of the field measurements conducted at habitat sampling locations are conducted throughout the entire 20×-bankfull-width-long reach, ensuring that results are truly “representative” of the

reach. This distance is designed to include multiple pool-riffle or step-pool sequences in an alluvial channel coupled with measurements at 11 transects to avoid overrepresenting unique characteristics of any one segment. The protocols to ensure accuracy and representativeness are detailed in the Regional HSTM QAPP (Part 3 of this report).

2.2 Candidate Site List for Monitoring Sites

The candidate lists are provided in the Urban and Regional HSTM QAPPs (Parts 2 and 3 of this report). Sites will be evaluated according to selection criteria for suitability. For regional monitoring, the first 15 of the listed 45 sites that meet sampling criteria will be identified as the monitoring sites for a given strata combination.

3 SECTION 3: INDICATORS

3.1 Water Quality Indicators for Urban+NPDES Sites

3.1.1 Base program and extended program indicators

The Qa/Qx indicators recommended for this HSTM program have been identified on the basis of historic utilization and regional experience, prior recommendations from Phase 1 of this project (and archived in Tetra Tech 2013), known issues with data quality and variability, cost of implementation, and direct relevance to the monitoring questions that are guiding this program. Relative to many other water-quality monitoring programs, the most noteworthy aspects of the recommended base program are its emphasis on continuously monitored (or otherwise integrative) indicators, and the overall brevity of the list. These outcomes are driven by considerations long-articulated by project partners and stakeholders: statistical and scientific rigor of the chosen indicators, and feasible cost of implementation.

A rigorous, defensible indicator that is useful for regional status and trends monitoring needs to meet several goals: it should not be subject to significant variability that is dependent only on the vagaries of the day or hour when it is measured, its variability due to watershed and in-stream conditions should be high relative to the random or non-systematic variability that cannot be eliminated by the sampling protocol (i.e., a high signal-to-noise ratio), it should be responsive to the environmental stressors of greatest concern to resource managers, and its collection and analysis should be affordable.

Many traditional water-quality indicators, including many considered in earlier stages of this project, are challenged by one or more of these criteria. Most problematic are those that have been long-accepted as part of a “normal” or “conventional” stormwater monitoring program (e.g., NRC 2009), but which are known either to have high random variability (e.g., total phosphorus, total suspended solids, pH; Merritt and Hartman 2012) or to express instantaneous conditions that would require continuous water-column sampling that is likely cost-prohibitive because of the required degree of site maintenance (e.g., dissolved oxygen, dissolved metals, dissolved nutrients, turbidity) to generate useful data on regional status and trends.

Based on these considerations of both suitability and cost efficiency, a list of indicators recommended for measurement at each of these sites was presented in the Design Report and are described in Table 7. It is anticipated that these indicators will meet the requirements of the upcoming 2018 Municipal Stormwater NPDES Permit’s Special Condition S8 Monitoring and Assessment, subsection B Status and Trends Monitoring, and their implementation will satisfy

Ecology's need for a statistically valid regional status and trends monitoring program in receiving waters throughout areas covered by the permits. In this Implementation Report their collection and analysis is referenced as the "base program" for water quality at urban+NPDES sites.

However, permittees have also expressed the desire to gain further value from the HSTM monitoring program by collecting an expanded list of indicators. They have defined an extended monitoring component that will be implemented at the same sites, and following the same panel design as for the base indicators, to the extent that sufficient funds are available. This list of extended program indicators is also presented in Table 7.

Monitoring of these indicators will be conducted under the exclusive guidance of the permittees, and it will be supported on a funding-available basis from the pooled monitoring funds once the costs associated with collection and interpretation of the base program indicators have been fully covered. The details of field and laboratory methods, protocols, and data quality objectives as detailed in the QAPPs for the Puget Sound Regional Stormwater Monitoring Program (Ecology 2014) and/or Clark County's wadeable streams program (Clark County 2013) will be used for the extended monitoring program. In combination, these references articulate these details for all of the parameters/indicators currently under consideration for the extended monitoring program. In preparation for Qa/Qx monitoring to begin, the necessary sections from these sources will be included as an appendix to the final version of the Urban HSTM QAPP for Qa/Qx monitoring.

All field sampling and laboratory measurement procedures are described in the Urban HSTM QAPP (Part 2 of this report).

Table 7. Water quality indicators for the base and extended programs.

BASE PROGRAM INDICATORS	
Water quality indicators*	Recommendation
Water temperature	X ^c
Conductivity	X ^c
Sediment metals	X ⁵
Sediment PAHs	X ⁵
Other indicators	
Stage (surrogate for discharge)	X ^c
Macroinvertebrate index (B-IBI)	X ^a
Habitat indicators at Qa/Qx sites	
Bankfull width, depth	X ⁵
Wetted width, depth	each visit
Substrate composition	X ⁵
EXTENDED PROGRAM INDICATORS	
Water temperature	X ^m
Conductivity	X ^m
Dissolved oxygen	X ^m
pH	X ^m
Turbidity	X ^m
Total suspended solids	X ^m
Total solids	X ^m
Total nitrogen	X ^m
Nitrate + nitrite-nitrogen	X ^m
Total phosphorus	X ^m
Dissolved copper	X ^m
Dissolved zinc	X ^m
Fecal coliform bacteria	X ^m

* Indicators were previously labeled “metrics” in the Monitoring Design Report

X⁵ = data collection once per 5-yr permit cycle

X^a = annual data collection

X^c = continuous collection

X^m = monthly collection (as funding allows, by field meter or grab sample)

The Design Report also recommended chloride and periphyton as additional parameters worth considering for future years of the program. Their added benefits for characterizing the status and trends of streams of the Region are uncertain at present, but they may be informed by the findings of other programs’ efforts in future years and should be (re)considered as additional data and conclusions from other relevant studies across the region become available.

The overarching justification for nearly all of the indicators recommended for the Qa/Qx program was summarized by the Puget Sound RSMP, which provides a useful synopsis that is equally

relevant to the Lower Columbia Region (Table 8, modified from Ecology 2011). Further discussion of this topic is provided in Section 4.

Table 8. Water quality indicators and associated rationale.

Indicators*	Rationale
Stage/discharge	Discriminating low-flow from high-flow periods is fundamental to interpreting other continuous parameters; alterations to the frequency and rate of change of stage/discharge is widely recognized as a (or <i>the</i>) major impact of land-use change on aquatic systems (e.g., NRC 2009).
Specific Conductance	Easily measured and correlates to the total dissolved solids.
Temperature	Key parameter affecting the health and survival of biological communities. Subject to state water quality criteria.
Sediment metals	A group of ecologically consequential heavy metals with defined sediment management standards in WA. Heavy metals contribute to toxic effects on aquatic life and impact the beneficial use of a water body.
Sediment polycyclic aromatic hydrocarbons	Associated with urban runoff; characteristic of highway and industrial sources. Can accumulate in aquatic organisms and are known to be toxic at low concentrations. Can be persistent in sediments for long periods, resulting in adverse impacts on benthic community diversity and abundance.
Aquatic macroinvertebrates (B-IBI)	Integrates water quality and habitat impacts from stormwater over time (Karr 1998; Karr and Rossano 2001; Fore et al. 2001).
Physical Habitat (Slope and bearing, wetted width, bankfull width, bar width, substrate size, substrate depth, shade, human influence, riparian vegetation, large woody debris).	Urban development can alter basin hydrology and adversely affect stream channels (e.g., accelerated bank erosion, loss of LWD, reduced baseflow). Will aid in trend detection, interpretation of biological parameters, and stressor identification.

* Indicators were previously labeled “metrics” in the Monitoring Design Report

3.1.2 Laboratory quality control measures

The Urban HSTM QAPP, or Part 2 of this report, discusses the laboratory QC procedures that will be implemented to provide high quality data. QC will be monitored throughout the duration of the study. The quality of raw, unprocessed, and processed data is subject to review according to established protocols in the Measurement Procedures section of the QAPPs.

3.1.3 Data management, review and validation

Effective data management is an essential component of a successful monitoring program. The HSTM program manager will identify a data manager in charge of data QA, data entry, and data export to support the routine data analysis or in response to data requests. Data verification should occur at multiple steps in the process of collecting and analyzing monitoring data. In the field, all data recording sheets should be reviewed by all crew members before leaving the site. Analyses performed by an environmental laboratory will follow their own established procedures to ensure that results being reported are accurate. Details of procedures for field data collection, laboratory analysis, database design, data entry, data verification, and data compilation are in the Urban and Regional HSTM QAPPs (Parts 2 and 3 of this report).

Incomplete or missing data are not anticipated to be a significant problem if procedures are followed. Lost laboratory samples are also very uncommon for accredited labs, and in the context of the overall HSTM program any such event would be unlikely to compromise the validity of the overall results unless criteria for completeness are not achieved.

3.2 Habitat Indicators - Physical and Biological

3.2.1 List and rationale

Habitat indicators proposed in the Monitoring Design were carefully vetted by the Habitat Caucus to determine the most appropriate protocols based on a desire to balance efficiency, accuracy and shareability. In the process of making such decisions, two of the recommended indicators were deemed non-essential (embeddedness and thalweg depth) given the cost of measurement and their value relative to other indicators. The remaining indicators (Table 9) were determined to be the minimum set necessary to document and track the status and trends of habitat conditions in the Lower Columbia Region. The indicators also include a subset of contextual data to characterize the monitoring site, but not expected to change over time. In an effort to be consistent with other regional monitoring programs, we have advised following existing protocols to the extent possible.

Table 9. Habitat indicators and their associated metrics.

Indicators*	Contextual data	Metric
1. Sample reach length ^{W,NW}	X	NA
2. Channel type ^{W,NW}	X	NA
3. Reach slope ^{W,NW}	X	Length-weighted average of individual slope measurements
4. Sinuosity ^{W,NW}	X	Ratio of centerline/straight-line lengths
5. Bank modification ^{W,NW}		Percent total
6. Density of habitat types ^W		Percent habitat for each type
7. Bankfull width/depth ^{W,NW}		Average of the unambiguous measurements for both bankfull width and bankfull depth
8. Pools per unit length ^W		Pools per unit length
9. Floodplain width ^{W,NW}		Categorize the floodplain width into categories scaled by bankfull width (e.g., 0-1 W_{bkn} ; >1 W_{bkn}) (bins TBD)
10. Side channel habitat ^{W,NW}		Qualifying channels – side channel length in meters; width and temperature measurements (upstream, midpoint and downstream); degree of connectivity to the mainstem (%). Nonqualifying—document presence only
11. Flow category ^{W,NW}		Dry, puddled, low, moderate, high, bankfull, flood as defined by ODFW protocols. Modify “Low Flow” to include surface water flowing across <75% of active channel surface
12. Benthic Macroinvertebrates ^W		Samples processed to provide summary statistics/models (e.g. O/E and BIBI) to the lowest practical taxonomic level (Larson 2015).
13. Residual Pool depth ^W		Maximum pool depth minus pool crest depth
14. Bank stability ^W		Median of the 22 transect-specific measurements. The result is a categoric (not a decimal) value for the entire reach
15. Relative bed stability ^W		Ratio of reach D_{50} to [(average bankfull depth)×(reach slope)]; apply roughness correction if/as indicated by selected protocol
16. Density / distribution instream wood ^{W,NW}		Number of pieces and total wood volume (m^3) per unit length
17. Substrate particle size ^W		Median grain size (D_{50}); also D_{84} , D_{16} for the entire reach
18. Shade ^W		Shade score; could be reported as percent shade
19. Riparian canopy ^{W,NW}		% cover of vegetation > 5 m height
20. Riparian understory ^W		% cover of vegetation 0.5 – 5 m height
21. Temperature ^{W,NW}		7-day moving average maximum temp, daily maximum temp, average daily temp

W Wadeable
NW Non-wadeable

During the first or initial 5-year monitoring cycle, data on all 21 habitat indicators would be collected at each site. Four of these indicators (sample reach length, channel type, reach slope, sinuosity) are contextual and would be collected only during the initial 5-year monitoring cycle. During the second and subsequent 5-year monitoring cycles, the same sites would be revisited in the same sequence utilized during the first 5-year cycle. Only data on the 17 non-contextual indicators would be collected during these subsequent monitoring cycles.

3.2.2 Field sampling procedures

All field sampling procedures are described in Part 3, Quality Assurance Project Plan for Regional Landscape and Habitat Monitoring (Regional HSTM QAPP). Field sampling procedures are based on existing protocols. In some cases, the existing protocols are used without modification; in some cases existing protocols were modified to meet specific project goals; and in some cases entirely new protocols were developed when applicable pre-existing protocols were not available.

3.2.3 Laboratory measurement procedures

Laboratory measurements (and field procedures) for benthic macroinvertebrates are the same for habitat monitoring as for Qa/Qx monitoring and are detailed in the Urban and Regional HSTM QAPPs.

3.2.4 Measurement quality objectives

Because the HSTM program includes a wide variety of indicators, measurement quality objectives vary significantly between the various categories. An overarching focus for indicator selection has been to use only those parameters with relatively high levels of measurement precision and signal-to-noise. For field methods (i.e., habitat indicators), commonly reported values for the precision of replicate values for those indicators recommended for inclusion in this program are on the order of 10% (e.g., Kaufmann et al. 1999).

3.2.5 Quality control

Variability will be reduced through refinement of site selection and local phenomenon based on physical criteria. Field personnel will record where samples are measured and note general descriptions of physical conditions of the channel, gradient, habitat types, water velocity, weather, and other parameters or unique local features that could influence data quality. These narrative field notes can be used to qualitatively assess how well the data represent the conditions characterized by this study, should any questions later arise about the representativeness and accuracy of the measured indicators.

Specific quality control procedures will include having a crew member other than the initial recorder review the data sheets prior to crews leaving the field. It is important to QC the data sheets in the field prior to leaving, in order to insure that all required data has been collected. When data collection requires crews to make visual estimates (for instance on riparian and understory cover percentages), individual crew members will independently make estimates, compare their results, and come to consensus.

3.2.6 Data management, review and validation

The HSTM program manager will identify a data manager in charge of data QA, data entry, and data export to support the routine data analysis or in response to data requests. Data management review and validation procedures specific to habitat indicators are detailed in the Regional HSTM QAPP.

3.3 Landscape Indicators

Several of the monitoring questions and objectives of the Design Report invoked a “landscape” analysis:

- Question 5: Where on the landscape are key potential land-use activities occurring?
- Question 6: Are land-cover changes occurring at detectable rates across the Lower Columbia Region, and if so where are they occurring?

They were included in the Design Report because the results of such analyses provide necessary support to other monitoring objectives, and the stratification of sampling points by the dominant land cover in their contributing watersheds provides necessary context for much of the in-stream monitoring data being collected under both the Qa/Qx and habitat elements. In addition, characterizing the status and trends of key attributes in the surrounding landscape can help separate the regional influence of natural variability from the more localized impacts (both positive and negative) of human actions.

The most feasible of these landscape attributes to monitor systematically over time are those relating to land cover, which has been systematically characterized across the entire Lower Columbia Region by the National Land Cover Database and has compiled categorized land-cover coverage for 1992, 2001, 2006, and (most recently) 2011 (Homer et al. 2015). This data set, fully downloadable from the Multi-Resolution Land Characterization Consortium (www.mrlc.gov), provides the basis for all landscape-level analyses conducted for the HSTM project.

3.3.1 List and rationale

To maximize the accuracy of land-cover categorization and because determining the influence of particular landscape-level attributes on in-stream conditions is not a goal of status and trends monitoring, the following coarse land-cover categories were used to process and analyze the NLCD data, hereafter termed the “aggregated 2011 NLCD” (for the full list of categories see http://www.mrlc.gov/nlcd11_leg.php):

- “Urban” includes NLCD categories 21 (“Developed, Open Space”), 22 (“Developed, Low Intensity”), 23 (“Developed, Medium Intensity”), and 24 (“Developed High Intensity”);
- “Agriculture” includes NLCD categories 81 (“Pasture/Hay”) and 82 (“Cultivated Crops”);
- “Forest” includes NLCD categories 41 (“Deciduous Forest”), 42 (“Evergreen Forest”); and 43 (“Mixed Forest”);
- “Other” includes all other categories, particularly water, wetlands, ice and snow, and barren land.

These indicators were used to address those objectives of the landscape questions that are critical to the implementation of the HSTM program as described in this report. Other questions and their associated objectives that were raised in the Design Report could enhance the ultimate interpretation of the monitoring data but are not essential for the program’s implementation. The

effort necessary to address those objectives is also substantial, and beyond both the scope of the current effort to develop the Implementation Plan and the resources presently available from project partners. Should such resources become available, however, the following list of monitoring questions and objectives articulated in the Design Report, and their associated technical approaches, should be useful:

- Watershed landcover change: What areas of the 2011 NLCD are changed from the 2006 NLCD? What is the minimum magnitude of change so identified that is likely to constitute a “true” change, given unavoidable errors in classification? (Supports Objective 6.1. of the Design Report)

The process to make this analysis would be to (a) register both grids to one another so that pixels from both datasets overlay exactly; (b) compare the pixel change between both years (both total change and change between classes); and (c) include some error or uncertainty report either based on published information or selecting a set of points from detailed imagery from either year. There is a confidence value of 70% for changes between 2001 and 2011 NLCD (Fry et al. 2008).

- Stream buffer landcover change: What areas of the 2011 NLCD are changed from the 2006 NLCD within 60-m-wide buffer zones for 1 and/or 5 km upstream of identified sampling site? (Supports Objective 6.2)

The process to make this analysis would be to (a) select a set of sampling sites, (b) identify its location on the NHD High dataset, (c) “travel” upstream 1 or 5 km and define the upstream point, (d) split and buffer the lines, and (e) overlay the buffers with the land cover change dataset obtained in (a).

- Discriminate “recent” (less than ~20 years) forest harvest areas using the NLCD. What watersheds have this as a dominant land cover? (Supports Objective 2.2); identify “mature” (greater than ~20 years) forested areas using the NLCD (i.e., distinct from other “forested” areas? (Supports Objective 5.1)

For these two evaluations, use of the 2002 NLCD dataset would be most appropriate to use. Using the Land Cover change developed in the first analysis, comparison of the two classified images would provide answers to these questions.

- Identify subwatersheds in the range of 2.5-50 km² with a single “dominant” land cover type (i.e., >50% urban, forested, or agriculture) over the entire Lower Columbia Region. (Supports Objective 5.1)

This analysis has already been run on spatially restricted areas within the Lower Columbia Region to identify those Master Sample points draining watersheds with predominately “urban” or “agricultural” land cover. It has also been run on those points randomly selected for sampling. To comprehensively apply the same analysis to all 28,000 Master Sample points with drainage areas >0.6 km², prior experience suggests that it would require about one week of GIS processing time.

- Are there other potentially useful land-cover class aggregations that yield more information than our 4 basic categories? (Supports Objectives 6.1 and 6.2)

There appears to be no identified applications for which more detailed land classification schemes would be warranted on a region-wide basis. The 20 categories of the NLCD coverage, from which our four aggregated land-cover categories were derived, could provide a readily generated greater level of detail; other approaches could provide even greater discrimination but would require airphoto interpretation and a substantial investment of time (e.g., Lucchetti et al. 2014).

3.3.2 Data sources

The NLCD coverages (all years) are available for free download at <http://www.mrlc.gov/finddata.php>. This was the source of all land-cover data used in the analyses for the HSTM project.

3.3.3 Known magnitude of classification/location errors

Extensive evaluation of land-cover classification accuracy typically returns values of up to 80% or better accuracy, with the best classifications found for the coarsest (i.e., most aggregated) classes, such as used in this report. For example, see Homer et al. (2007) and associated references for specific evaluations of the 2006 classification; Jin et al. (2013) offers some preliminary evaluations of the 2011 classification.

3.3.4 Analytical procedures

For the Design Report, a preliminary determination of the land cover associated with individual Master Sample points was made by evaluating the local land cover, as represented by the aggregated 2011 NLCD, at the location of the point itself. On this basis, some preliminary determinations were made regarding which strata combinations were likely to lack sufficient members (e.g., very large watersheds with a predominantly “urban” land cover) to require sampling. For actual implementation, however, the key attribute is the land cover of the *contributing watershed*, which requires a more extensive analysis. For this purpose, a script was written in ArcMap that delineated the entire watershed to a specified point, aggregated the underlying NLCD pixels, and tabulated the percentage land cover in each of four categories (urban, agriculture, forest, other).

Since the original 2011 NLCD dataset was for the conterminous 48 United States, a subset for the Lower Columbia Region was extracted and pixel-matched to the original dataset. Watershed size comparisons included comparing the watershed-generated areas to those of each Master Sample point to which they included contributed the area. Small discrepancies occurred due to the need to snap to the DEM-generated stream networks to prevent false (and typically very small) watersheds from being generated.

For the stratifications required by the Qa/Qx and habitat sampling design, Master Sample points with predominant (i.e., >50%) watershed land coverage of “urban” or “agriculture” were identified by first visually outlining areas where these land cover types are present in sufficient area to provide the possibility of such an outcome (for each, this was <10% of the total area of the Lower Columbia Region) and then running the script on all Master Sample points so contained. Many such points do not have a dominant land cover of urban or agriculture; only those that do (275 for “urban” and 430 for “agriculture”) were retained for subsequent inclusion in their appropriate strata).

Identifying “forest”-dominated points, however, requires a different procedure because the total number of points in the Lower Columbia Region is so large (>28,000 for just those draining watersheds larger than 0.6 km²), and simply running the watershed land-cover script for all such points is not feasible at present. Fortunately, the vast majority of such points have a dominant “forest” land cover, and so it is also not necessary. Thus, alternative methods were employed: for the strata combinations requiring “urban” or “agriculture” land covers, Master Sample points were drawn from their respective subsamples; but those requiring “forest” land cover were drawn from the entire Master Sample (as appropriately stratified for drainage area, channel slope, etc.) without pre-determination of land cover. Only those so selected were then evaluated as to their watershed land cover. Those that are not “forest” were discarded and replaced with additional randomly drawn points (which themselves were tested for watershed land cover, repeating as necessary until full complements of points meeting each strata combination were identified).

3.3.5 Validation and quality control

Quality control of the underlying land-cover data relies on the processing that occurred prior to its posting on the Internet, and no additional evaluation was made for this project. A variety of quality-control procedures were made for the identification of watershed land-cover tallies, including visual comparisons of watershed outlines with land-cover layers in GIS and tabulation of watershed sizes with those having dominant urban or agriculture land covers (given the limited extent of these land uses throughout the Lower Columbia Region).

3.3.6 Data management

The NLCD data and ArcGIS file geodatabases are stored on servers that are backed up daily. Metadata is written when a dataset is finalized and includes source datasets, methods and changes made to the original dataset. LCFRB and project partners have received copies of the finalized datasets with metadata, including the source data and descriptions of processes done on them to allow full understanding of how the final versions were derived.

4 SECTION 4: DATA ANALYSIS AND INTERPRETATION

Because no part of the HSTM program has been implemented to date (June 2016) according to the study design, the full range of analyses and interpretations that the monitoring data may ultimately support cannot be known with certainty. However, the program is built on a rich legacy of monitoring aquatic resources across the Pacific Northwest and beyond, and so a variety of potential uses of the indicator data can be anticipated.

Fundamental to the design of the HSTM program, including the target populations, stratification, and choice of indicators is the *purpose* of status and trends monitoring. Its various definitions over the last several decades largely echo one another:

“Status, the current state of the resource, can be characterized in terms of its extent, its productivity, or its condition. Each of these attributes can be investigated with regard to its trend, or its change with time.” (Olsen et al. 1999)

“Status monitoring assesses the current condition of a population or environmental condition across an area. Monitoring for trends aims at monitoring changes in populations or environmental condition through time.” (Maas-Hebner et al. 2015)

And, as summarized by Ecology for the Puget Sound RSMP, the goal of measuring status and trends in receiving waters is “to measure whether things are getting better or worse and identify patterns in healthy and impaired Puget Lowland streams and Puget Sound urban shoreline areas”

(<http://www.ecy.wa.gov/programs/wq/stormwater/municipal/rsmp/status.html>).

Of critical importance to the design and implementation of a status and trends monitoring program is the recognition of what is, and is not, included. Common to all of these definitions is the clear articulation that the primary goal of such programs is to provide a broad characterization of conditions across the target population. Conversely, there is no attempt through status and trends monitoring to diagnose direct cause-and-effect relationships between stressors and their effects on the environment. Recognizing this distinction can avoid the pitfall of trying to meet both goals with a single design, and ultimately accomplishing neither. Although elements of a status and trends monitoring design can serve to support a more diagnostic effort, diverting resources to the identification of specific impacts (or its inverse, directly evaluating the effectiveness of remedial measures on environmental conditions) would inherently reduce the scope (or increase the cost) of the regional characterization.

Through the history of development of the Lower Columbia HSTM program, this distinction has been largely, but not entirely, acknowledged. So, for example, the Phase 1 Report for this project articulated suitable monitoring questions for a status and trends program (e.g., “What are the status and trends of in-stream biological health and both in-stream and riparian habitat conditions?” “What is the status and trends of water quality and stream flow in surface waters?”), but it also raised important management questions that nonetheless lie outside of what such a monitoring program can answer (“Are there significant effects of habitat degradation or improvement on the observed abundance, productivity, spatial structure, and diversity of the natural-origin fish in this population?”).

Thus, any planned analysis or interpretation of the monitoring data collected under this program needs to maintain a focus on what these data were originally designed to accomplish: provide a statistically rigorous characterization of the physical, chemical, and biological conditions in the rivers and streams of the Region, respecting limitations on both the intensity of sampling and the number of indicators that are imposed by financial practicalities while still accomplishing this fundamental goal. Stratification of the target population, particularly with respect to the specific upcoming requirements for municipal stormwater NPDES permittees, can provide useful and cost-efficient guidance on where to invest additional monitoring resources into diagnosing observed or inferred impairments to receiving waters, or in evaluating the effectiveness of existing or future stormwater-management techniques. A status and trends monitoring program can do no more than highlight problematic areas and suggest fruitful next steps—it must fall to other programs to take those next steps.

4.1 Interpreting Qa/Qx Indicators within the Urban+NPDES Areas

Within the urban+NPDES areas, all lotic, minimally engineered streams draining 2.5–50 km² with predominately urban watershed land cover will be sampled during the course of the five-year rotating panel design (which presumably will correspond to the next NPDES permit cycle). Five of these sites also correspond to “legacy” sites that have been monitored for various parameters by the City of Vancouver or Clark County for between 1 and 10 years, of which those that include long-term macroinvertebrate sampling will be most directly applicable to the data

subsequently collected under this program. In addition, there are likely four strata combinations with enough master sample points within the urban+NPDES area to support the collection of habitat indicators according to the regional monitoring design.

4.1.1 Benthic macroinvertebrates

Most integrative of the indicators being measured at all of these sites will be the benthic macroinvertebrates, which can provide a coarsely integrative but biologically relevant characterization of conditions. Impacts can influence any of the primary “water features” of the urban environment (i.e., hydrology, water quality, physical habitat, biotic interactions, and energy fluxes; Booth et al. 2004, Karr and Yoder 2004), and this indicator has shown little success in clearly discriminating amongst those potential sources of stress. However, its value as a high-level indicator of overall conditions, of relevance to both stormwater and fisheries managers, has become well-established in the Pacific Northwest.

This indicator has been used in western Washington for well over a decade. As a result, the methods for data analysis and the framework for their interpretation are well-established. A broadly implemented, regionally appropriate framework for scoring the raw data is located at <http://pugetsoundstreambenthos.org/BIBI-Scoring-Types.aspx>; such results are commonly provided by the laboratory or contractor conducting the invertebrate counts. For the purpose of this monitoring program, the benthic Index of Biotic Integrity [B-IBI] and multivariate (Observed/Expected [O/E]) models should be calculated. Further investigation of the data can follow any or all of the alternative analyses compiled under the “Analysis” tab of the homepage <http://pugetsoundstreambenthos.org/Default.aspx>.

Annual reporting should include site locations, individual metric values, composite BIBI and O/E scores, and the overall conditions and any irregularities in the sites and the collected data. Summary graphs of all sites’ scores over multiple years, including those that are visited only once in a five-year period, should also be included. Although the anticipated five-year synthesis report will evaluate whether any trends are present, even annual inspection of the data may reveal trends or patterns of interest that need not wait for a formal “summary report” to become apparent.

4.1.2 Sediment metals and PAHs

Less local experience is available on the value and interpretation of sediment metals and PAHs, although they have been utilized in monitoring programs throughout the nation for many years. They are time-integrative by virtue of the residence time of fine sediment, although the history of prior sediment-transporting storms undoubtedly imposes year-to-year variability. The contaminants are largely (although, for some PAH’s, not exclusively) specific to urban activity—particularly automobiles, roadways, and the incomplete combustion of fuels (e.g., Huang and Foster 2006), and so these indicators not only provide an indication of the status of biologically significant compounds in these receiving waters but also offer the ancillary benefit of narrowing the list of possible stressors on these systems.

Reporting of these data will be sparse, because each site will be sampled only once in a 5-year period. The laboratory-reported values may be of only minimal utility by themselves unless some cross chronic or acute thresholds for human or biotic toxicity, but their spatial pattern across the region, particularly in comparison to urban land-cover percentages in their contributing watersheds, may offer some clues as to the driver(s) of impairment in these indicators. There will also surely be benefit to compare the values obtained in the Lower Columbia Region with those

of the more extensive Puget Sound RSMP small stream dataset, when the data are compiled in a format that will allow for easy comparison between the two. This might present an ideal opportunity for collaboration between the two programs to enhance the value of both.

Simple sorting of the LC HSTM data will likely identify outliers (if any are present) in comparison to the aggregation of all sites' data or with the RSMP small stream monitoring results, as the latter become available. For PAH's, cross-plots of different compounds or ratios of compounds have been explored by others (e.g., Yunker et al. 2002); these are likely to prove of interest in source identification, particularly the discrimination of urban vs. non-urban sources, but are not of direct relevant to a strict status-and-trends monitoring program.

4.1.3 Continuous indicators

The final set of indicators, the monitoring of stage, temperature, and conductivity, addresses the related problems of sampling rapidly varying parameters by collecting the raw data at a greater frequency than that underlying variability. Useful processing of these data, and their interpretation, differs somewhat for each.

4.1.3.1 Stage

Stage has been long measured as a surrogate for streamflow, or discharge, which in turn is broadly recognized as one of the key drivers of both physical and biological instream conditions. It is also particularly sensitive to watershed urbanization and is probably the single best indicator of stormwater impacts to smaller, lotic receiving waters (NRC 2009). Conversion of stage (i.e., water depth) to discharge is accomplished by a rating curve, whose construction requires episodic field visits to the measurement station to manually measure discharge (flow width, depth, and velocity) in order to correlate the observed depth with the measured discharge. Multiple such measurements, spanning a wide range of discharges, are necessary to construct a reliable rating curve, and the rating curve must be updated whenever flow events or other changes to the channel geometry are likely to have altered the stage–discharge relationship. These activities typically result in significant cost.

Although absolute discharge is a critical parameter for such applications as flood studies, stage alone should be nearly as useful for exploring the patterns of discharge over time, both short-term and long-term. An example from an urban watershed with a long-term gage record (Mercer Creek, in the Puget Sound region just east of Lake Washington, illustrates this well (Figure 6).




Figure 6. Discharge (left) and stage (right) for the past four years at Mercer Creek, Washington. Although the relationship between the two parameters is not identical over the full range of flows, the differences are clearly minimal and suggest that either could provide a useful basis for analysis of hydrologic patterns and trends.

Although constructing and maintaining a rating curve is not precluded by this monitoring design for the sites where stage data will be collected, it is not specifically recommended in recognition of the additional staff cost in collecting and analyzing the stage–discharge data. Primary indicators of hydrologic condition and alteration can be evaluated on stage data as easily as on discharge data, and both their range of values relative to regional conditions (see King County 2015) and their change over time can be used to characterize both the status and the trend of hydrologic conditions.

The recommended indicators to calculate from continuous stage data are those anticipated to have the greatest relevance to both land-use changes and biological response (Konrad and Booth 2005). Appendix C-1 evaluates the performance of three such indicators in particular, namely T_{Qmean} or the Richards-Baker Flashiness Index, and high-flow reversals (Konrad and Booth 2002, Baker et al. 2004, DeGasperi et al. 2009). Their annual calculation should be accomplished no later than 30 days following the end of every water year (September 30th) and the results displayed as both same-year plots across all sites and same-site plots for all years for which they have an individual record. As noted in Appendix C-1, existing data from the region suggest that none of these indicators can be expected to show significant trends in less than a decade (or more), but their magnitude relative to one another should provide insights into the runoff behavior of individual watersheds, and of the urbanized parts of the Lower Columbia Region as a whole.

4.1.3.2 Temperature

Temperature is another water quality parameter that has a long history of collection using continuous data sensors, in recognition of the critical biological importance of water temperature, the wide range of stream channels that are impaired by overly high temperatures, and the rapid (diurnal) fluctuations of this indicator. Obviously, high water temperatures occur almost exclusively during the summer, suggesting that this indicator need only be collected during a portion of the year, and final implementation of the monitoring plan can elect to terminate the downloading of temperature data for the coolest 7 or 8 months of each year without significant loss of information (Figure 7). The *causes* of high temperature are varied, including (but not necessarily limited to) poor riparian cover, low groundwater input, and infrequent summertime

stormwater discharges, which complicates any direct diagnostic value of this indicator for guiding immediate response by stormwater management programs. The value of this indicator in *evaluating* the status and trends of instream conditions, however, is widely recognized.




Figure 7. Left panel: Temperature variation in a small lowland stream in the Tualatin Basin, western Oregon (about 20 miles west of urban areas of the Lower Columbia Region). In 2015, biologically critical temperatures were reached at multiple locations in mid-June and persisted into September (data courtesy of Clean Water Services). Right panel: Distribution of rainfall at Vancouver, WA, with bar graph indicating that about 4 to 5 inches of potentially run-off-generating rainfall (about 10-15% of the annual total) falls during the period of the year when instream temperatures have the potential to reach ecologically problematic levels (data courtesy of HSTM Stormwater Caucus).

Common indicators derived from continuous temperature data include the annual maximum temperature, the mean of daily high temperatures over a specified month, and the maximum of mean 7-day maximum temperatures (i.e., the week-long period with the warmest daily maxima, abbreviated MWMT). The first two indicators provide simple, straightforward comparisons between sites and from year-to-year; the last is a commonly applied biological criterion that considers heat stress over a more biologically relevant time frame. All can be readily calculated from a temperature record (see Appendix D-1), and as with the stage indicators should be plotted as for all sites per year, and all years at all site. Substantial interannual variability in maximum water temperatures, however, confound the ability to detect any systematic underlying trends rapidly, but the aggregate patterns of data across all sites should help determine and adjust for any such variability.

Although these data are primarily to inform a better understanding of the status and trends of stream conditions across the Lower Columbia Region, the data (particularly the MWMT) can also be compared to biological criteria to help identify streams with particularly significant impairment for temperature-sensitive species.

4.1.3.3 Conductivity

The final continuously collected indicator recommended by the LC HSTM, conductivity, is only slightly less common as a broad-based indicator of instream conditions. “Conductivity” (or its temperature-corrected correlative, specific conductance) is widely recognized as a useful, easy-to-measure surrogate for total dissolved solids (TDS) (e.g., Minton 2003; Ecology 2011). As with temperature, causes of high TDS are varied and range from natural sources, particularly groundwater with a high mineral content, to stormwater inputs containing a range of inorganic

salts such as calcium, magnesium, potassium and sodium, and anions such as carbonates, nitrates, bicarbonates, chlorides and sulfates (GeoSyntec Consultants and Wright Water Engineers 2011). Natural waters in most settings have low TDS and thus low conductivity; elevated levels from human activity include wash-off from streets, fertilizers, industrial discharges, and soil erosion (see, for example, <http://bcn.boulder.co.us/basin/data/NEW/info/TDS.html> or <http://www.epa.gov/your-drinking-water/table-regulated-drinking-water-contaminants>).

The potentially greatest value of this indicator, however, is its ease of collection and its high correlation to other sediment-related measures (Miguntanna et al. 2010), particularly total suspended solids, which in turn has widely recognized ecological impacts at elevated levels and can be driven both directly by land-use activities i.e., (land-surface erosion) and indirectly via hydrologic alteration (resulting in stream-channel erosion from high flows). As with temperature, determining the precise *cause* of elevated sediment loading in a particular stream, whether measured directly or by a surrogate indicator, lies beyond the scope of a status and trends monitoring program. Characterizing the conditions, however, is a fundamental first step in effectively guiding subsequent management actions.

Existing data from elsewhere in the region offer limited guidance for how best to analyze and interpret these data. Absent an ancillary project to explore functional relationships between conductivity and TDS in streams of the Lower Columbia Region, data analysis and reporting is likely to be limited to annual plots of this indicator for all sites where it is being collected, with a highlighting of any sites that fall outside of normative regional values (see Appendix E-1).

4.2 Interpreting Indicators at Regional Sites throughout the Lower Columbia Region

Monitoring of streams across the region comprises annual measures of a range of physical habitat indicators together with collection and analysis of continuous temperature and benthic macroinvertebrates. The status of watershed health will be reported annually with trends available starting in year 6. As discussed in Section 1.1.5 of this report, PFCs will be used to rate and assess the status and trends of specific indicators. This summary information will aid resource managers in succinctly communicating program results. Although PFCs are not explicitly linked to changes in fish abundance, productivity, spatial structure, and diversity, they do serve as reasonable surrogates until additional guidance becomes available. The following seven indicators are those most closely aligned to PFC criteria:

1. Temperature
2. Substrate particle size
3. Density/distribution instream wood
4. Pools per unit length
5. Residual Pool depth
6. Bankfull width/depth
7. Bank stability

Remaining indicators not currently included in PFC criteria will be used for additional interpretation in regional status and trend evaluation.

- Bank modification
- Density of habitat types

- Floodplain width
- Side channel habitat
- Relative bed stability
- Shade
- Riparian canopy
- Riparian understory
- Benthic macroinvertebrates

In some cases, data analysis and presentation methods are self-evident from the methodologies for collecting habitat indicators in Section 3.2 above. The following are suggested data analyses, potential benchmarks and presentation guidelines that will provide for easier applicability across programs in the region.

Given the ongoing advancement in benchmark development, we have provided recommendations rather than prescriptions. For technical as well as management purposes, these benchmarks may require refinement through the course of program implementation. For instance, many programs such as the U.S. Forest Service are either investigating or adopting reference conditions, rather than strict numerical benchmarks. The use of reference sites from within the study area can provide a more suitable, fine-scale basis for comparison of indicator results than regionally based benchmarks. Reference sites are defined as those that have been least disturbed by anthropogenic stress; data from these reference sites are then used to develop management targets for protection and restoration of aquatic resources. However, reference sites would need to be independently developed for specific strata, and thus, only more broadly applicable benchmarks to use for gross site characterization are presented below.

1. Temperature. The seven-day running average of maximum daily temperature is typically calculated. This number can then be compared to applicable benchmark criteria. NMFS defines a PFC to be water temperatures between 50° and 57°F (10° and 14°C). “At Risk” temperature conditions are defined by NMFS as 14°C to 15.5°C for spawning and 14°C to 17.8°C for rearing and migration. In Washington State, streams are designated in the following beneficial use categories (benchmark temperatures in parentheses) (Water Quality Standards for Surface Waters of the State of Washington, Chapter 173-201A WAC):
 - a. Char spawning and rearing (12°C)
 - b. Core summer salmonid habitat (16°C)
 - c. Salmonid spawning, rearing, and migration (17.5°C)
 - d. Salmonid rearing, & migration only (17.5°C)
 - e. Non-anadromous Interior Redband Trout (18°C)
 - f. Indigenous Warm Water Species (20°C)
2. Substrate particle size. Substrate metrics frequently reported include percentage of gravels and cobbles (suitable for spawning) and percent of sand and fines. Sand and fines can fill the interstices of gravels, reducing their suitability as spawning and rearing habitat. The percent of sand and fines can be compared to published criteria. NOAA (1996) states that a properly functioning condition is <12% fines; an at risk conditions is 12–17% (west side of the Cascades) or 12–20% (east side of the Cascades); and not properly functioning conditions are above these benchmarks. During data analysis and processing, the data can also be plotted by size class and frequency to determine the D_{16} , D_{50} and D_{84} for the entire

- reach (i.e., the sediment diameter that is coarser than 16, 50, and 84% of the total population). Shifts in the size of D_{16} , D_{50} and D_{84} signal a corresponding coarsening or fining of the substrate.
3. Density and distribution of instream wood. The total volume of LWD should be calculated and reported, and the number of “key pieces” should be tallied. The number of key pieces present could then be compared to applicable benchmarks. Key pieces are defined in different ways, depending on protocol. NMFS PFCs, as well as the USDA Forest Service interim Riparian Management Objectives (RMO) (Quigley et al. 1997) define key pieces in coastal areas as >24 inch diameter; >50 foot length, and for areas east of the Cascades as >35 feet length and >12 inches diameter. The key piece benchmark RMOs and PFCs are >12 key pieces per km (>20 key pieces per mile) east of the Cascades, and >50 pieces per km (80 pieces per mile) elsewhere.
 4. Pools per unit length. Pools per unit length should be calculated from the number of pools identified and the total reach length. NMFS PFCs for pool frequency are based on channel width:

Channel width (feet)	Minimum # pools/mile for PFCs
5	184
10	96
15	70
20	56
25	47
50	26
75	23
100	18

Other pool metrics that could be reported are the percentage of habitat units and/or habitat area as pools, and number of channel widths per pool. These values could then be compared to applicable benchmark values. NMFS does not provide a PFC for percentage of pool habitat or pool frequency; in Oregon, however, benchmark values for “desirable” salmonid habitat conditions are >35% of the stream area comprised of pool habitat, and pool frequency of at least one pool every five to eight channel widths (ODFW 2014). “Undesirable” salmonid habitat conditions includes streams with <10% of total area in pools, and pool frequency >20 channel widths per pool (ibid).

5. Residual pool depth. As stated in Section 3.2 above, the minimum, maximum, and average residual pool depth for the sampling reach should be calculated and reported. The primary metric of interest related to residual pool depth is the number of pools greater than 1 meter (3 feet) deep. These deep pools tend to be more uncommon and serve as important holding habitat for adult salmonids. However, there is no established numerical criteria for the number of deep pools required per unit length of stream.
6. Bankfull width/depth. The average bankfull width and depth can be calculated from the data obtained at transects. The width:depth ratio could then also be determined. The width-to-depth ratio is a metric that can indicate the loss of pools, accelerated streambank erosion rates, high sediment supply and channel aggradation, channel over-widening due to direct mechanical impacts, and other causes. The NMFS PFC for width:depth ratio is the same as the USDA Forest Service interim RMOs (Quigley et al. 1997): <10.
7. Bank Stability. The percentage of each bank that is stable should be calculated from the data collected at the transects. According to NMFS, a properly functioning condition with

regard bank stability is >90% stable; i.e., on average, less than 10% of banks are actively eroding. “At risk” conditions are 80–90% stable, and “not properly functioning” conditions are <80% stable banks.

While the preceding seven indicators can be compared across locations to pre-existing benchmarks or other established criteria, the remaining nine indicators are (in general) more appropriate for monitoring longer-term trends within a particular site, rather than making comparisons between sites. Exceptions to this statement are discussed below.

- **Bank modification.** The visual estimate of the percentage of each bank occupied by human-modified morphologies (i.e., pavement, rip-rap, etc.) can be compared within sites over time (if restoration activities return banks to a more natural state) or across sites. More remote site (those in locations with less human impact), will obviously have a lesser degree of bank modification, but there are no guidelines for a comparison of what constitutes a desirable condition (other than the fact that less human modification is generally considered more desirable).
- **Density of habitat types.** The prevalence of different habitat types (geomorphic habitat units) should be calculated by unit length (i.e. the percentage of each habitat type per 1,000 meters of surveyed stream length). The prevalence of different habitat types should also be reported by area (using the average length and width of each habitat unit to calculate cumulative and individual habitat area). The importance of different habitat types varies by species and life stage of fish utilizing the surveyed streams. The only frequently cited benchmarks for the prevalence of different habitat types are related to the prevalence of pools, as discussed above. However, when reported on a percent of available habitat basis, this data can be used to draw broad comparisons between sites, and can be used to track changes within a site over time.
- **Floodplain width.** Floodplain width is normally an intrinsic property of a reach, determined by topographic confinement. Thus it has no value as an intrinsic indicator of stream “quality” except insofar as human infrastructure may have restricted access to part or all of that area. For purposes of evaluating actual or potential opportunities for off-channel habitat, surveyed reaches could be categorized into bins for comparison with each other, as streams with wide floodplains have different inherent qualities and evolve differently over time than streams with restricted floodplains. We recommend that investigators identify natural breaks in floodplain width within their monitored watersheds as a first step in identifying relative quality and potential for habitat development.
- **Side-channel habitat.** Side channels can provide important off-channel habitat for rearing salmonids. The length, average width, degree of connectivity to the mainstem and spot temperatures in the side channel vs. those in the main channel at the time of the survey should be reported. The length of side channels as a percentage of length of the main channel (or as a percent of total channel length, main channels and side channels combined) could also be reported, and gives an indication of habitat complexity in the surveyed reach.
- **Relative bed stability (RBS).** As described in the Monitoring Design (Stillwater Sciences 2015a), RBS is the ratio of the discharge predicted to move the median grain-size sediment on the bed of a channel to the bankfull discharge. For the RBS to be meaningful, the channel in question needs to have a reasonably well-defined bankfull level, and it needs to have a mixed-grain-size, gravel-bed substrate (these conditions are common, although not ubiquitous, across the Lower Columbia Region). An RBS score less than one predicts a relatively unstable streambed, because a progressively lower value indicates that the

median bed sediment can be mobilized by flows progressively less (and so progressively more frequent) than the bankfull discharge. In relatively undisturbed coastal watersheds in the Pacific Northwest, Kaufmann et al. (2009) reported RBS values that ranged from 0.15 to 1.65. These results suggest that RBS values from suitable channels that are lower than this range should be considered indicative of ecological stress.

- **Shade.** The amount of shade recorded at each of the readings within a transect could be averaged for each individual transect, and an average calculated for the stream as a whole (average of all transects in the reach). Both of these numbers could then be reported and compared among sites and over time. The amount of channel shading is dependent on the width of the channel, channel morphology (if shade is provided by landforms rather than riparian vegetation), and the size and amount of riparian vegetation. In the absence of tree harvest, fire or other disturbance, channel shade should increase over time, but it is not an indicator that responds rapidly.
- **Riparian canopy and riparian understory.** Results for the riparian canopy, understory and groundcover should each be reported separately with the range and average of values for each transect. Results for the right and left banks could be lumped, but additional detail would be provided if they were reported separately. An example data summary could read: “Of the 22 assessed locations (right and left banks at each of 11 transects) two were dominated by deciduous trees, three were mixed and the remaining 16 were evergreen dominated. For large trees, the canopy cover categories ranged from two to four, with an average of 3.5 (40–75% coverage). Canopy cover of small trees was much less, ranging from one to two, with an average of 1.1 (approximately 10% coverage).”
- **Benthic macroinvertebrates.** Methods for data analysis and the framework for their interpretation are well-established. A broadly implemented, regionally appropriate framework for scoring the raw data is located at <http://pugetsoundstreambenthos.org/BIBI-Scoring-Types.aspx>; such results are commonly provided by the laboratory or contractor conducting the invertebrate counts. For the purpose of this monitoring program, the Benthic Index of Biotic Integrity [B-IBI] and multivariate (Observed/Expected [O/E]) models should be calculated. Further investigation of the data can follow any or all of the alternative analyses compiled under the “Analysis” tab of the homepage <http://pugetsoundstreambenthos.org/Default.aspx>.

Annual reporting should include site locations, individual metric values, composite BIBI and O/E scores, and the overall conditions and any irregularities in the sites and the collected data. Summary graphs of all sites’ scores over multiple years, including those that are visited only once in a five-year period, should also be included. Although the anticipated five-year synthesis report will evaluate whether any trends are present, even annual inspection of the data may reveal trends or patterns of interest that need not wait for a formal “summary report” to become apparent.

5 REFERENCES

- Baker, D. B., R. P. Richards, T. T. Loftus, and J. W. Kramer. 2004. A new flashiness index: characteristics and applications to midwestern rivers and streams. *Journal of the American Water Resources Association*, 40(2).
- Beechie, T. J., O. Stefankiv, B. Timpane-Padgham, J. Hall, G. P. Pess, M. Rowse, M. Liermann, K. Fresh, and M. Ford. 2015. Monitoring habitat status and trends in Puget Sound: development

of sample designs, monitoring metrics, and sampling protocols for nearshore, delta, large river, and floodplain environments. NOAA Technical Memorandum. Draft.

Booth, D. B., J. R. Karr, S. Schauman, C. P. Konrad, S. A. Morley, M. G. Larson, and S. J. Burges. 2004. Reviving urban streams: land use, hydrology, biology, and human behavior: *Journal of the American Water Resources Association* 40: 1,351–1,364.

Clark County. 2013. Wadeable Streams Status Monitoring Project, Quality Assurance Project Plan. Prepared by Clark County Environmental Services, Clean Water Program, Version 2012-2016, August 2013, 23 pp.

DeGasperi, C. L., H. B. Berge, K. R. Whiting, J. J. Burkey, J. L. Cassin, and R.R. Fuerstenberg. 2009. Linking hydrologic alteration to biological impairment in urbanizing streams of the Puget Lowland, Washington, USA. *Journal of the American Water Resources Association* 45: 512–533.

Ecology (Washington Department of Ecology). 2004. Guidelines for preparing quality assurance project plans. Ecology Publication No. 04-03-003.

Ecology. 2006. Status and trends monitoring for watershed health and salmon recovery—Quality Assurance Monitoring Plan. Ecology Publication No. 06-03-203.

Ecology. 2011. 2012 Status and trends stormwater monitoring and assessment strategy for small streams—an addendum to quality assurance monitoring plan status and trends monitoring for watershed health and salmon recovery. Draft.

Ecology. 2014. Quality assurance project plan for status and trends monitoring of small streams in the Puget Lowlands ecoregion for monitoring conducted using pooled RSMP funds contributed by western Washington municipal stormwater permittees. Ecology Publication no. 14-10-054.

Fore, L. S., K. Paulsen and K. O’Laughlin. 2001. Assessing the performance of volunteers in monitoring streams. *Freshwater Biology* 46: 109–123.

Fry, J. A., M. J. Coan, C. G. Homer, D. K. Meyer, and J. D. Wickham. 2008. Completion of the National Land Cover Database (NLCD) 1992–2001 land cover change retrofit product. USGS OFR 2008-1379.

GeoSyntec Consultants and Wright Water Engineers. 2011. International stormwater Best Management Practices (BMP) database pollutant category summary: solids (TSS, TDS and turbidity). Available from <http://www.bmpdatabase.org>

Homer, C. G., J. Dewitz, J. Fry, M. Coan, N. Hossain, C. Larson, N. Herold, A. McKerrow, J. N. VanDriel, and J. Wickham. 2007. Completion of the 2001 National Land Cover Database for the conterminous United States. *Photogrammetric Engineering and Remote Sensing* 73: 337–341.

Homer, C. G., J. A. Dewitz, L. Yang, S. Jin, P. Danielson, G. Xian, J. Coulston, N. D. Herold, J. D. Wickham, and K. Megown. 2015. Completion of the 2011 National Land Cover Database for the conterminous United States- representing a decade of land cover change information. *Photogrammetric Engineering and Remote Sensing*, v. 81, no. 5, p. 345-354.

- Huang, H.-M. and G. D. Foster. 2006. Characterization of polycyclic aromatic hydrocarbons in urban stormwater runoff flowing into the tidal Anacostia River, Washington, DC, USA. *Environmental Pollution* 140: 416–426.
- Jin, S., L. Yang, P. Danielson, C. Homer, J. Fry, J., and G. Xian. 2013. A comprehensive change detection method for updating the National Land Cover Database to circa 2011. *Remote Sensing of Environment* 132: 159–175.
- Karr, J. R. 1998. Rivers as sentinels: using the biology of rivers to guide landscape management. Pages 502–528 in R. J. Naiman and R. E. Bilby, editors. *River ecology and management: lessons from the Pacific Coastal ecoregion*. Springer, New York.
- Karr, J. R., and E. M. Rossano. 2001. Applying public health lessons to protect river health. *Ecology and Civil Engineering* 4: 3–18.
- Karr, J. R. and C. O. Yoder. 2004. Biological assessment and criteria improve total maximum daily load decision making. *Journal of Environmental Engineering* 130: 594–604.
- Kaufmann, P. R., R. M. Hughes, J. Van Sickle, T. R. Whittier, C. W. Seeliger, and S. G. Paulsen. 2014. Lakeshore and littoral physical habitat structure: A field survey method and its precision. *Lake and Reservoir Management* 30: 157–176.
- Kaufmann, P.R., D.P. Larsen, and J.M. Faustini, 2009. Bed stability and sedimentation associated with human disturbances in Pacific Northwest streams. *J. Am. Water Resources Assoc.* 45(2):434-459.
- Kaufmann, P. R., P. Levine, E. G. Robison, C. Seeliger, and D. V. Peck. 1999. Quantifying physical habitat in wadeable streams. EPA/620/R-99/003. U.S. Environmental Protection Agency, Washington, D.C.
- King County. 2015. Monitoring for adaptive management: status and trends of aquatic and riparian habitats in the Lake Washington/Cedar/Sammamish watershed (WRIA 8). King County Water and Land Resources Division. Seattle, Washington.
- Konrad, C. P., and Booth, D. B. 2002. Hydrologic trends resulting from urban development in western Washington streams. U.S. Geological Survey Water-Resources Investigation Report, 02-4040.
- Konrad, C. P., and Booth, D. B. 2005. Hydrologic changes in urban streams and their ecological significance. *American Fisheries Society Symposium* 47: 157–177.
- Larson, C. 2015. Standard Operating Procedures and Minimum Requirements for the Collection of Freshwater Benthic Macroinvertebrates in Streams and Rivers, Version 2.0, 13 pp. Available at http://www.ecy.wa.gov/programs/eap/qa/docs/ECY_EAP_SOP_BenthicMacroinvertebrateDataCollection_v2_0EAP073.pdf.
- Lucchetti, G., J. Burkey, C. Gregersen, L. Fore, C. Knutson, J. Latterell, P. McCombs, R. Timm, J. Vanderhoof, and J. Wilhelm. 2014. Assessing land use effects and regulatory effectiveness on streams in rural watersheds of King County, Washington. Prepared by Water and Land Resources Division. Seattle, Washington. <http://your.kingcounty.gov/dnrp/library/water-and-land/critical-areas/CAO-Report-Final-for-Web.pdf>

- Maas-Hebner, K. G., M. J. Harte, N. Molina, R. M. Hughes, C. Schreck, J. A. Yeakley. 2015. Combining and aggregating environmental data for status and trend assessments: Challenges and approaches. *Environmental Monitoring and Assessment* 187: 1–16.
- Merritt, G., and C. Hartman. 2012. Status of Puget Sound tributaries 2009 – biology, chemistry, and physical habitat. Publication No. 12-03-029. Washington State Department of Ecology, Olympia, Washington.
- Miguntanna, N. S., P. Egodawatta, S. Kokot, and A. Goonetilleke. 2010. Determination of a set of surrogate parameters to assess urban stormwater quality. *Science of the Total Environment* 408: 6,251–6,259.
- Minton, G. R. 2003. Stormwater treatment—biological, chemical, and engineering principles: Seattle, WA. Resource Planning Associates.
- NOAA (National Oceanic and Atmospheric Administration). 1996. Coastal salmon conservation: working guidance for comprehensive salmon restoration initiatives on the Pacific coast.
- NRC (National Research Council). 2009. Urban stormwater management in the United States: committee on reducing stormwater discharge contributions to water pollution. National Academies Press, Washington, DC.
- ODFW (Oregon Department of Fish and Wildlife). 2014. Aquatic inventories project methods for stream habitat surveys. Conservation and Recovery Program.
- Olsen, A. R., J. Sedransk, D. Edwards, C. A. Gotway, W. Liggett, S. Rathbun, K. H. Reckhow L. J. Young. 1999. Statistical issues for monitoring ecological and natural resources in the United States. *Environmental Monitoring and Assessment* 54: pp. 1–45.
- Puls, A., K. A. Dunn, and B. G. Hudson. 2014. Evaluation and prioritization of stream habitat monitoring in the Lower Columbia salmon and steelhead recovery domain as related to the habitat monitoring needs of ESA recovery plans. Pacific Northwest Aquatic Monitoring Partnership.
- Quigley, T. M., K. M. Lee, S. J. Arbelbide, technical editors. 1997. Evaluation of the environmental impact statement alternatives by the Science Integration Team. 2 Vols. Gen. Tech. Rep. PNW-GTR-406. USDA Forest Service, Pacific Northwest Research Station, Portland, Oregon.
- Roper, B. B., J. M. Buffington, S. Bennett, S. H. Lanigan, E. Archer, S. T. Downie, J. Faustini, T. W. Hillman, S. Hubler, K. Jones, C. Jordan, P. R. Kaufmann, G. Merritt, C. Moyer, and A. Pleus. 2010. A comparison of the performance and compatibility of protocols used by seven monitoring groups to measure stream habitat in the Pacific Northwest. *North American Journal of Fisheries Management* 30: 565–558.
- Schueler, T. R. 1994. The importance of imperviousness. *Watershed Protection Techniques* 1: 100–111.

Stillwater Sciences. 2015a. Integrated design for habitat and water quality status and trends monitoring in the Lower Columbia. Prepared by Stillwater Sciences, Portland, Oregon for Lower Columbia Fish Recovery Board, Longview, Washington.

Stillwater Sciences. 2015b. Flow restoration monitoring program in the upper Tualatin basin – year 3 monitoring plan. Final report. Prepared by Stillwater Sciences, Portland, Oregon for Clean Water Services.

Tetra Tech. 2013. Lower Columbia habitat status and trends Project. Technical Report 3. Prepared by Tetra Tech, Sitka Technology Group, and Stevens Environmental Statistics for Lower Columbia Fish Recovery Board.

Whitacre, H. W., B. B. Roper, and J. L. Kershner. 2007. A comparison of protocols and observer precision for measuring physical stream attributes. *Journal of the American Water Resources Association* 43: 923–937.

Yunker, M. B., Macdonald, R. W., Vingarzan, R. Mitchell, R.H. Goyette, D., Sylvestre, S. 2002. PAHs in the Fraser River basin: a critical appraisal of PAH ratios as indicators of PAH source and composition. *Organic Geochemistry* 33: 489–515.

Appendices

Appendix A-1

Stormwater Roles and Responsibilities

APPENDIX A-1 – Recommendations for Implementing Stormwater Status and Trends Monitoring in the Lower Columbia Region under the 2018 NPDES Permits

Lower Columbia Stormwater Caucus Recommendations to Ecology June 22, 2016

Contents

Introduction

Recommendations

 Roles and Responsibilities

 Data Collection

 Data Management

 Data Analysis and Reporting

 Scaling the Monitoring Effort

Stormwater Caucus Members

Introduction

The Lower Columbia Habitat Status and Trends Integrated Monitoring (HSTM) Phase 2 design was presented in February 2015 and submitted to the Washington Department of Ecology (Ecology) in fulfillment of requirements of a Grant of Regional and Statewide Significance.

The Lower Columbia HSTM monitoring design was collaboratively developed by local, state and federal stakeholders with diverse interests in impacts to habitat, designated uses, overall watershed health, and promoting salmon recovery.

As the first step in the implementation phase, the stakeholders formed caucuses to produce recommendations for executing a monitoring program based on the Phase 2 design. The Stormwater Caucus (Caucus) represents the eight local governments in the Lower Columbia Basin and the Washington State Department of Transportation (WSDOT) that have responsibilities for stormwater management and will have a NPDES MS4 permit requirement for status and trends monitoring effective in the next permit cycle.

Since June of 2015, the Caucus has worked to address the following questions and issues:

- Roles and Responsibilities:
 - Who are the primary program participants
 - How will the program be funded by the stormwater permittees
 - Who will manage the program
 - Who will conduct the monitoring and perform the data analysis and reporting
 - How other stakeholders will be able to participate in project implementation
- Data Collection:
 - Stream segment identification and selection
 - The use of legacy sites
 - Expected timing and frequency of the data collection
 - Parameters and metrics

DRAFT

APPENDIX A-1 – Recommendations for Implementing Stormwater Status and Trends Monitoring in the Lower Columbia Region under the 2018 NPDES Permits

- o Protocols to be used
- Data Management:
 - o Data sharing objectives and mechanics (Why share? How to use the data? Who will use the data? What do they actually want to use?)
 - o Database design
- Data Analysis and Reporting:
 - o Who should analyze the data
 - o How should the findings be reported including indicators to be used to answer the overall project questions and objectives for the urban stormwater management areas
- Scaling:
 - o How the monitoring effort can be scaled (sites and frequency) to adequately answer management questions within available funding resources.

The group developed this set of recommendations and made decisions based on a consensus approach (Table 1).

This document contains the recommendations for the logistical roles and responsibilities for implementation of the stormwater (urban+NPDES) portion of the Lower Columbia HSTM plan. A full overview of the plan and additional technical aspects of implementation planning can be found in the implementation plan report and QAPP document.

Table 1. Definition of Consensus

Consensus is defined in terms of agreement along a continuum. Caucus members may register the degree of their agreement with the language in any of the first six columns:						
Endorse	Endorse with a minor point of contention	Agree with reservation	Abstain	Stand aside	Formal disagreement but will go with the majority	Block
"I like it"	"Basically I like it"	"I can live with it"	"I have no opinion"	"I don't like it but I don't want to hold up the group"	"I want my disagreement to be noted in writing but I'll support the decision"	"I veto this proposal"
The last (shaded) column on the right side of the continuum is <i>not</i> considered acceptable for consensus in this process.						
However, anything to the left has been considered "agreement by consensus."						

DRAFT

APPENDIX A-1 – Recommendations for Implementing Stormwater Status and Trends Monitoring in the Lower Columbia Region under the 2018 NPDES Permits

Recommendations

The Lower Columbia Stormwater Caucus (Caucus) has endorsed, with full consensus, the following recommendations for supporting and funding monitoring in the NPDES MS4-permitted jurisdictions and respective Urban Growth Areas (UGA's) in the Lower Columbia Region.

Roles and Responsibilities

Program Partners

The primary program partners for the stormwater component of the Lower Columbia HSTM program will consist of the nine NPDES municipal stormwater permittees in the Lower Columbia Basin:

- City of Battle Ground
- City of Camas
- City of Kelso
- City of Longview
- City of Vancouver
- City of Washougal
- Clark County
- Cowlitz County
- Washington State Department of Transportation (WSDOT)

These nine entities will fund and guide the work of the program, and will be represented on the Lower Columbia Stormwater Work Group.

Funding for Status and Trends Monitoring

The Caucus recommends that the program be funded by a cost-sharing formula based on population of the nine NPDES municipal stormwater permittees. WSDOT would be considered a medium-sized jurisdiction and pay a commensurate contribution. Funding for the program would be determined using the population-based allocation method and per capita rate used in the current permit for Puget Sound status and trends monitoring. Funding would be capped at the equivalent funding provided by the Puget Sound permittees.

Permittee contributions would be paid directly to Ecology to fulfill the Permit S8 requirement for status and trends monitoring. Ecology will serve as a pass-through of these funds to the Program Manager under a deliverables-based agreement.

Who Will Manage the Program and Who Should Conduct the Monitoring

The Program Manager will be responsible for field work and sample collection, lab analyses, data management, QA/QC, and data analysis and reporting. The Caucus recommends that Clark County serve as the Program Manager.

D R A F T

APPENDIX A-1 – Recommendations for Implementing Stormwater Status and Trends Monitoring in the Lower Columbia Region under the 2018 NPDES Permits

Program Administration and Oversight

A Lower Columbia Stormwater Work Group comprised of the nine funding entities, Ecology and other interested agencies, organizations and stakeholders will meet at least once annually to review and guide the work of the monitoring program in conjunction with the Program Manager. The Stormwater Work Group will also interact with the Lower Columbia HSTM Habitat Steering Committee. The funding entities will make key decisions on the administration of the program scope and budget in conjunction with the Program Manager.

APPENDIX A-1 – Recommendations for Implementing Stormwater Status and Trends Monitoring in the Lower Columbia Region under the 2018 NPDES Permits

Data Collection

Monitoring Program Overview

The Caucus recommends an implementation of the HSTM Phase 2 monitoring design utilizing a census-based approach to monitoring candidate stream sites within the Urban+NPDES strata in Clark and Cowlitz counties. Four stream segments (“status” sites) would be selected for the program each year, rotating through a set of 20 candidate segments within a 5-year period. In addition, the program would perform monitoring at a separate set of six non-rotating stream segments (“trend” sites) during the 5-year period. The total program of 26 stream segments meets the HSTM project’s criteria of 10-20 sites per strata for statistical analyses. *NOTE: The final site list is yet to be confirmed. If more or fewer qualifying sites are identified, the sampling rotation will be adjusted accordingly to include all sites in the census over 5 years.*

Monitoring Indicators

The HSTM stormwater program focuses on two different sets of indicators and metrics: a **base** program which focuses on watershed health monitoring (i.e. physical habitat, soil chemistry measurements, and biological community characterization) and an **extended** program of traditional water quality monitoring parameters and indicators.

The Caucus recommends the following base program and extended program indicators/parameters be collected at each of the status and trend sites in the monitoring program:

- | | |
|---|--|
| • Temperature (<i>continuous</i>) [base] | • Nitrate+Nitrite (NO ₃ +NO ₂) [extended] |
| • Conductivity (<i>continuous</i>) [base] | • Total Phosphorus (TP) [extended] |
| • Stage (<i>continuous</i>) [base] | • Dissolved Copper (Cu) [extended] |
| • Dissolved Oxygen (DO) [extended] | • Dissolved Zinc (Zn) [extended] |
| • pH [extended] | • Fecal Coliform Bacteria [extended] |
| • Turbidity [extended] | • Sediment Metals [base] |
| • Total Suspended Solids (TSS) [extended] | • Sediment PAHs [base] |
| • Total Solids (TS) [extended] | • Benthic Macro-invertebrates [base] |
| • Total Nitrogen (TN) [extended] | |

Site Identification and Selection

The potential program stream segment candidates for the NPDES MS4-permitted jurisdictions and respective Urban Growth Areas (UGA’s) were developed from the Lower Columbia Master Sample, following the framework developed for this project.

The prospective pool of stream segments includes 22 stream segments in Clark County and 4 segments in Cowlitz County which have their contributing watershed either partially or wholly within NPDES jurisdictions or UGA’s. It is anticipated that one of the six trend sites be selected from the candidate stream segments in Cowlitz County.

DRAFT

APPENDIX A-1 – Recommendations for Implementing Stormwater Status and Trends Monitoring in the Lower Columbia Region under the 2018 NPDES Permits

The Use of Legacy Sites

Legacy sites are those that have been sampled in the past and have a longer data record that might be useful in establishing long-term trends. Historical water quality monitoring and streamflow measurements have been performed in NPDES MS4-permitted jurisdictions and respective Urban Growth Areas (UGA's) by Clark County, the City of Vancouver, and the Washington Department of Ecology.

The Caucus recommends that the program's five trend sites in Clark County be located at legacy sites, as practicable, in order to leverage the existing trend data at these locations and build upon existing analyses.

Recommendations for Expected Timing and Frequency of Data Collection

The Caucus recommends that each of the status and trend sites be visited monthly to allow for site maintenance and downloading continuous parameter logger data, as well as the collection of field measurements and grab samples for other parameters.

Benthic macroinvertebrates will be assayed annually at each site (once at status sites and five times at trend sites, within the 5-year period). Sediment chemistry samples (PAHs and metals) will be collected once at each site within the 5-year period.

Indicator/Parameter	Indicator Type	Sampling Frequency
• Temperature • Conductivity • Stage	Watershed Health (base program)	Continuous
• pH • Turbidity • Total Suspended Solids (TSS) • Total Solids (TS) • Total Nitrogen (TN) • Nitrate+Nitrite (NO₃+NO₂) • Total Phosphorus (TP) • Dissolved Copper (Cu) • Dissolved Zinc (Zn) • Fecal Coliform Bacteria	Water Quality (extended program)	Monthly (field measurement or grab sample)
• Benthic macroinvertebrates	Watershed Health (base program)	Annually
• Sediment Metals • Sediment PAHs	Watershed Health (base program)	Once per site in a 5-year period

APPENDIX A-1 – Recommendations for Implementing Stormwater Status and Trends Monitoring in the Lower Columbia Region under the 2018 NPDES Permits

Recommendations for Expected Timing and Frequency of Reporting

The Caucus recommends that reporting include annual status and data QC reports (within six months of all the data being collected), and comprehensive stream health and long-term trends reports once every five years (once per permit cycle).

Methods Used to Collect Data

All parameters will be collected from data loggers, field measurements or grab samples, and analyzed by an accredited lab according to established protocols in the program Quality Assurance Project Plan (QAPP). See the QAPP for a full discussion on methods for collecting the data for each indicator.

Data Management

Data Sharing Objectives and Mechanics

The Caucus recommends that the data be managed by the Program Manager, which will be responsible for performing QA/QC on all data and uploading the data to the Ecology's EIM database.

The Caucus expects this data will be shared among permittees, as well as other monitoring partners and stakeholders. The PNAMP website and monitoring database will be utilized to help facilitate this data exchange. Data compatible with EIM will be uploaded for general access to the public. Final time series data as time series files can be posted to the internet for download. The possibility of web access via Aquarius software may be included as part of the contract for services.

Database Design

The Caucus recommends that all data collected under the program be stored in Ecology's EIM database. Clark County currently manages data in its water quality database built under an Ecology grant in the early 2000's, which is capable of managing water quality and macroinvertebrate data collected under the program, and could serve as an alternative database. Clark County uses the Aquarius software to manage stage and flow data.

Data Analysis and Reporting

Who Should Analyze the Data

The Caucus recommends that Clark County as the Program Manager be responsible for analyzing and interpreting the data collected under the program. Results collected under the program could potentially be pooled with data and analyses from the Puget Sound RSMP and PNAMP partners.

How Should the Findings be Reported

In addition to annual reporting of the data collected in the previous year, data analysis and interpretation would be provided by Clark County as the Program Manager in a comprehensive report at

D R A F T

APPENDIX A-1 – Recommendations for Implementing Stormwater Status and Trends Monitoring in the Lower Columbia Region under the 2018 NPDES Permits

the end of each 5-year permit term and provided for access and review to permittees, Ecology and other interested stakeholders.

Scaling the Monitoring Effort

Scaling the Monitoring Effort to Answer Management Questions within Available Resources

The Caucus recommends the full funding of the “base” portion of the program (which includes continuous temperature, conductivity and stage data, sediment PAHs and metals and benthic macroinvertebrates), including an appropriate contingency buffer, before funding the collection and analysis of “extended” program parameters which include DO, pH, turbidity, TSS, TS, TN, NO₃+NO₂, TP, Cu, Zn and fecal coliform bacteria.

If funding is insufficient to fully implement the extended monitoring, the scope of extended monitoring would be reduced to stay within the funding cap and/or additional funding would be sought.

If enough funding is available, the collection of additional continuous parameters such as DO and TN may be considered.

DRAFT

APPENDIX A-1 – Recommendations for Implementing Stormwater Status and Trends Monitoring in the Lower Columbia Region under the 2018 NPDES Permits

Stormwater Caucus Members

Entities

- City of Battle Ground
- City of Camas
- City of Kelso
- City of Longview
- City of Vancouver
- City of Washougal
- Clark County
- Cowlitz County
- Washington State Department of Transportation (WSDOT)

Participants

- Sam Adams – City of Camas
- Anita Ashton – City of Camas
- Fred Bergdolt – WSDOT
- Jeff Cameron – City of Longview
- Rob Charles – City of Washougal
- Dick Gersib – WSDOT
- Annette Griffy – City of Vancouver
- Patrick Harbison – Cowlitz County
- Steve Haubner – City of Longview
- Van McKay – City of Kelso
- Jeff Schnabel – Clark County
- Dorie Sutton – City of Vancouver
- Rod Swanson – Clark County
- Kelly Uhacz – City of Battle Ground
- Steve Warner – City of Longview

Appendix B-1

Habitat Roles and Responsibilities

D R A F T

Recommendations for Implementing Habitat Status and Trends Monitoring in the
Lower Columbia Region

**Lower Columbia Habitat Caucus Recommendations
June 9, 2016**

Contents

Introduction	2
Recommendations	3
Partners	3
Structure of the Integrated Habitat Status and Trends Monitoring Program.....	3
Periodic Program Review	4
How will agencies participate in monitoring implementation	4
Who Will Manage the Program	5
Who Should Conduct the Monitoring.....	5
Data Collection	5
Site Identification and Selection	5
The Use of Legacy Sites	6
Recommendations for Expected Timing and Frequency of Data Collection	6
Methods Used to Collect Data	7
Data Management	14
Data Sharing Objectives and Mechanics	14
Database Design	15
Data Analysis and Reporting.....	15
Who Should Analyze the Data	15
How Should the Findings be Reported including Indicators to be Used	16
Response to Findings.....	16
Scaling	16
Scaling the Monitoring Effort to Answer Management Questions within Available Resources.....	16
Available Resources	17
Appendix 1: Resolution of Disagreements.....	17
Appendix 2: Habitat Caucus Members	18

Recommendations for Implementing Habitat Status and Trends Monitoring in the Lower Columbia Region

Introduction

The Lower Columbia Habitat Status and Trends Integrated Monitoring Design was finalized in February of 2015 and submitted to the Washington Department of Ecology in fulfillment of requirements of a Grant of Regional and Statewide Significance. This monitoring design was collaboratively developed by local entities with interests in stormwater impacts to habitat, watershed health, and salmon recovery. As a step toward implementation planning, those entities have broken out into caucuses to develop recommendations for how the design will be implemented.

Since August of 2015, the Habitat Caucus has worked to address the following issues:

- Partners;
 - Who will collect the data
 - How the collective resources of the habitat monitoring partners in the Lower Columbia should be pooled to support the effort
 - How agencies will participate in project implementation
- Data Collection;
 - Site identification and selection
 - The use of legacy sites
 - Expected timing and frequency of the data collection
 - The protocols to be used
- Data Management;
 - Data sharing objectives and mechanics (Why share? How to use the data? Who will use the data? What do they actually want to use?)
 - Database design
- Data Analysis;
 - Who should analyze the data
 - How should the findings be reported including indicators to be used
- Scaling;
 - How the monitoring effort can be scaled to adequately answer management questions within available resources

Stillwater Sciences assisted the caucus by providing various resources to consider as a starting point for caucus members to engage and contribute their ideas before arriving at a recommendation. The group developed these recommendations based on consensus (Table 1). Disagreements with any decision and the resolution to those disagreements will be documented in Appendix 1 of this report. At the time of this draft, there have been no disagreements among the Caucus.

This report represents only the portion of the full implementation plan that required logistical input. The technical aspects of implementation planning are found in the main body of the implementation plan report.

DRAFT

Recommendations for Implementing Habitat Status and Trends Monitoring in the Lower Columbia Region

Table 1. Definition of Consensus

Consensus is defined in terms of agreement along a continuum. Caucus members may register the degree of their agreement with the language in any of the first six columns:						
Endorse	Endorse with a minor point of contention	Agree with reservation	Abstain	Stand aside	Formal disagreement but will go with the majority	Block
"I like it"	"Basically I like it"	"I can live with it"	"I have no opinion"	"I don't like it but I don't want to hold up the group"	"I want my disagreement to be noted in writing but I'll support the decision"	"I veto this proposal"
The last (shaded) column on the right side of the continuum is <i>not</i> considered acceptable for consensus in this process. However, anything to the left has been considered "agreement by consensus."						

Recommendations

The Lower Columbia Habitat Caucus has endorsed the following recommendations for supporting and funding habitat monitoring in the Lower Columbia Region.

Partners

Structure of the Integrated Habitat Status and Trends Monitoring Program

In order to maintain momentum and keep the partners engaged, this program will be guided by a Steering committee composed of representatives from the regional habitat and water quality monitoring agencies and organizations. This steering committee would meet quarterly to provide an authoritative body to this multi-partner organization. In cooperation with the program manager, they would continue to foster partnerships in regional monitoring, continue to seek funding necessary to support the project, resolve obstacles and review methods to improve the program, and communicate results with stakeholders. Membership should include, at a minimum, representatives from:

- NOAA
- US Forest Service
- US Fish and Wildlife Service
- USGS Pacific Northwest Aquatic Monitoring Partnership
- Washington Department of Fish and Wildlife
- Washington Department of Ecology's Environmental Assessment Program

DRAFT

Recommendations for Implementing Habitat Status and Trends Monitoring in the Lower Columbia Region

- Washington Department of Ecology's Water Quality Programs
- Representative from SW Washington Stormwater Permittees
- Washington Salmon Recovery Funding Board
- Oregon Department of Fish and Wildlife
- Oregon Department of Environmental Quality
- Oregon Watershed Enhancement Board

In addition, a Technical Review committee will meet quarterly to provide feedback on annual reports and performance of the protocols. The feedback from the Technical Review committee will inform program management decisions by the Steering committee. Based on feedback from the Habitat Caucus members, the following agencies are interested in serving on the Technical Review committee:

- NOAA
- US Geologic Survey
- US Forest Service
- US Fish and Wildlife Service
- Washington Ecology's Environmental Assessment Program
- Oregon Department of Fish and Wildlife

Periodic Program Review

Considerable advances will take place in monitoring techniques and equipment, data management and analysis, and the associated science over time. The Steering Committee should seek periodic review by a national or international panel of academic and professional experts in the field to provide comment on how we might keep our efforts current and relevant. Such feedback and other proposed changes that inevitably result from implementation can then be considered, and the program modified as an integrated whole for future implementation. The Technical Advisory Committee and Steering Committee will make recommendations regarding whether there are targeted reviewers that could provide desired input, and how to solicit peer review from a broader audience. This review should take place on a 5 or 10-year interval.

How will agencies participate in monitoring implementation

The habitat caucus has identified a number of organizations in the Lower Columbia region that have an interest in habitat conditions, many of which are members of the Caucus. Some of these organizations have existing habitat monitoring programs that were designed to answer questions other than status and trends. Ideally, these agencies could also contribute to this monitoring program in a number of ways including:

- Staff – for field work, data management, analysis and reporting
- Funds to support implementation of the program
- Technical advice – participation in the habitat caucus and future program support
- Field equipment donation or loan
- Serving on the Technical Review Committee
- Serving on the Steering Committee

DRAFT

Recommendations for Implementing Habitat Status and Trends Monitoring in the Lower Columbia Region

Who Will Manage the Program

It is the recommendation of the Caucus that the Lower Columbia Fish Recovery Board manage the status and trends monitoring effort for both habitat and regional water quality monitoring tasks. This position could rotate or shift over time among the partners as negotiated by the Steering Committee. The Steering Committee would ultimately be in charge of appointing a program manager. To accommodate contracting needs, interagency agreements for program management should be secured on a 5-year basis consistent with the reporting cycle of the program. This agreement should recognize the biennial funding cycle of most government agencies by inserting a clause related to funding contingencies.

The Program Manager will work under the guidance of the Steering Committee to facilitate and coordinate the execution of data collection, management, analysis, and reporting through the combined efforts of the regional monitoring partners and contracted work. They will develop an annual work plan, convene the Steering Committee, organize and convene the Technical Review Committee, secure funding from regional monitoring partners, and provide a webpage to convey results and project information.

Who Should Conduct the Monitoring

Monitoring will be conducted by regional monitoring partners to the extent possible under their existing monitoring programs, and supplemented where necessary by contract labor. To date, we have heard verbal communications with NOAA, USFS AREMP, and Washington DNR, that they would be able to provide staff and equipment to visit a small number of sites each year. NOAA has the capacity to start with 2 sites a year. Washington DNR has stated that they could provide site visits, though the number and locations will be determined upon implementation. USFS/AREMP has the capacity to visit sites within the Gifford Pinchot National Forest. The program manager and steering committee will maintain an open policy for partners to conduct monitoring or contribute funding toward program operations as resources become available. To accommodate contracting needs, interagency agreements for data collection should be secured on a 5-year basis consistent with the reporting cycle of the program. This agreement should recognize the biennial funding cycle of most government agencies by inserting a clause related to funding contingencies.

Data Collection

Site Identification and Selection

As part of the Implementation Plan, 15 “viable” monitoring sites for each unique strata combination (bin) are needed. Given the challenges of site access and landowner approval, up to 45 provisional sites for each unique strata combination (bin) will be identified by random draw from the Lower Columbia Master Sample, following the framework developed in Phase 2 of this project (LCFRB, 2015). A bin must have at least 15 possible candidate sites in order to be included in the random draw. The 45 “provisional” sites should be sufficient to identify 15 “viable” monitoring sites within a bin.

Sites must be physically independent of one another. Given the vast number of channel segments, this is unlikely to be an issue for the forested parts of the Region. However, due to the small number of sites that drain watersheds with predominately urban or agricultural land cover, it is likely that more than one regional monitoring site could be selected within the same stream segment. To avoid such

DRAFT

Recommendations for Implementing Habitat Status and Trends Monitoring in the Lower Columbia Region

clustering of sample locations and ensure the best possible distribution of sites, only one regional monitoring site will be sampled per stream segment.

The Use of Legacy Sites

Legacy sites are those that have been sampled in the past and have a longer data record that might be useful in establishing historical trends. Legacy sites have been incorporated into the Lower Columbia HSTM Master Sample to allow the possibility of incorporating data from those sites. Legacy sites are not guaranteed to be included in the sample draw, but have equal probability of being “selected” as any other site in the Master Sample. If a legacy site is drawn and a partner has plans to visit that site in a subsequent year, another site will be drawn so that the legacy site is visited in the year that corresponds with the partner’s field schedule.

Recommendations for Expected Timing and Frequency of Data Collection

Selected sites will be visited using a rotating panel design such that 1/5th of the sites would be visited each year, covering the region over a 5-year period. This 5-year cycle is consistent with the reporting cycle used by NOAA in their 5-year status reviews for Salmon Recovery in the Lower Columbia. Site reconnaissance should begin in March to verify access permission from landowners and make a brief site visit to ensure the location is still accessible and safe to enter. A field training workshop should be held by the end of May to prepare field crews. All field personnel should participate in trainings every year. Data should be collected during the low flow months between July 1 and September 30th. Considerations behind this recommendation include the accuracy at which measurements can be taken at low flows, the safety of the field crew, and the relative absence of spawning fish and emerging fry in Lower Columbia tributaries. Sampling within the region should be timed in consideration of conditions within strata. For example, sampling at sites at higher elevation should occur later in the season to allow flows to decrease after snow melt.

During the first or initial 5-year monitoring cycle, data on 21 habitat indicators would be collected at each site. These habitat indicators are equivalent to the habitat metrics identified in the HSTM monitoring design. Four of these indicators (sample reach length, channel type, reach slope, sinuosity) are contextual and would be collected only during the initial 5-year monitoring cycle. During the second and subsequent 5-year monitoring cycles, the same sites would be revisited in the same sequence utilized during the first 5-year cycle. Only data on the 17 non-contextual indicators would be collected during these subsequent monitoring cycles. These indicators include:

- Bankfull width/depth
- Pools per unit channel length
- Floodplain area
- Side channel habitat
- Density of habitat type
- Flow category
- Residual Pool Depth
- Bank Stability
- Relative bed stability

DRAFT

Recommendations for Implementing Habitat Status and Trends Monitoring in the Lower Columbia Region

- Density/distribution of instream wood
- Substrate particle size
- Shade
- Riparian Canopy
- Riparian understory
- Temperature (continuous measurements during summer season)
- Metrics associated with macroinvertebrate communities.

Regional status will be evaluated annually based on the sites sampled in a given year. Regional trends within and across stratum will be reported starting in year 6 based on a 5-year schedule for resampling. This monitoring approach maximizes the utility of the sites sampled for multiple purposes over a broad spatial extent.

Recommendations for Expected Timing and Frequency of Reporting

The caucus considered what would be useful for timing of reporting for the users of the data. NOAA reports on habitat condition with their 5-year status review. The LCFRB updates the Recovery Plan on a 6-year cycle that is tied in with fish cohort and life cycles. No other reporting needs were brought forward. The group recommends that the Lower Columbia HSTM program conduct reporting to allow managers to be as responsive as possible to the results. An annual status report should be generated during the year following each field season. Recognizing that some data sets may take longer to analyze than others (i.e. macroinvertebrates), there are two potential options for the structure and timing of the release of annual reports to the public. The first is a series of independent reports based on parameter (Habitat, Chemistry, Biological) be released as the data is analyzed and reports written. This would allow management responses to occur in as timely a fashion as possible. The risk associated with this method of reporting is that responses to a shift in a specific parameter could be better informed and more efficient with the context that comes with a complete dataset. The second option for structuring the annual report would be to release the data and report as a whole. This may occur too late to make changes in methods or procedures for the next year's data collection effort, but could be incorporated the following year. The Steering Committee will make the decision regarding the structure and timing of release of annual reports. A more detailed report on the analysis of both status and trends will be generated on a 5-year schedule. If necessary, individual organizations could create interim reports derived from a summary of the most recent 5-year HSTM report, and the additional annual status reports needed to support their own reporting needs.

Methods Used to Collect Data

Stillwater Sciences compiled the methodologies of 7 active monitoring programs in the region to develop a decision matrix displayed, in part, in Table 1. This matrix documented the following for each measurement:

- the method from each program
- its associated signal to noise (where available)
- recommendations for caucus consideration regarding which method might be used

DRAFT

Recommendations for Implementing Habitat Status and Trends Monitoring in the Lower Columbia Region

The Caucus reviewed the decision matrix and discussed additional suggestions to arrive at the recommendations for field data collection methods. By consensus, the habitat caucus recommends using the methods cited in Table 2 to collect data for each indicator. The actual methodologies are provided in an appendix of the Implementation Plan report. Monitoring partners are asked to use the HSTM protocols and methods to collect data to inform this program. The implementation report identifies methods that result in potentially sharable data. If the partner's methods are listed as sharable, then they may choose to use their methods to collect data to contribute to the HSTM program. If it is not possible to use the established methods, and the partner's methods are not among those identified in the implementation report as potentially sharable, then participation in this capacity may not be appropriate.

DRAFT

Recommendations for Implementing Habitat Status and Trends Monitoring in the Lower Columbia Region

Table 1. Excerpt from the decision matrix used by the Habitat Caucus in 2015 to discuss recommendations for data collection methodology of the Lower Columbia HSTM program.

Indicator ¹ signal to noise grade*	Methods currently used in Lower Columbia (Puls et al. 2014)*	Notes on methods	Cost-effective method to implement? (high, med, low)	Protocol recommendation and justification
Substrate particle size 1=A,C; 3,4=A,B		all measure or estimate particle size in some way. Different categories.	low	
	1	do pebble counts and visually estimate percent fines in pool tails.	low	
	2	pebble counts	low	**
	3,4,6	modified pebble counts on transects	low	**
	5	% distribution in 6 size classes visually estimated	low	
	7	modified pebble count, 12 substrate classes	low	
Embeddedness an intrinsically noisy metric	1, 5	not measured or estimated	low	
	2	For all cobbles selected in pebble count estimate % buried, and % fine sediments in immediate surroundings	low	
	3,4	Estimate for gravel, cobble and boulder from pebble counts. Four categories	low	**
	6, 7	estimate 10cm around pebble count	medium	

* Indicators were previously labeled “metrics” in the Monitoring Design Report

- *1. AREMP
- 2. CHaMP
- 3. Clark Co.
- 4. ODEQ
- 5. ODFW
- 6. SRFB
- 7. WADOE

** Preliminary recommendation

D R A F T

Recommendations for Implementing Habitat Status and Trends Monitoring in the Lower Columbia Region

Table 2. Summary of methods for data collection selected by consensus of the Habitat Caucus in 2015.

Monitoring Design Indicator*	Method/Measurement	Metric	Programs with potentially shareable protocols
1. Sample reach length ^{W,NW}	Reach length (m). 20x BFW, 150m minimum, 500m ^W /2000m ^{NW} maximum Use air photo for initial designation, followed by field confirmation	NA	AREMP, CHaMP, EMAP, ODFW, SRFB, Ecology
2. Channel type ^{W,NW}	Bedrock, colluvial, cascade, step pool, forced step pool, plane bed, pool-riffle, forced pool-riffle, regime (Montgomery and Buffington 1997)	NA	Ecology
3. Reach slope ^{W,NW}	Direct reading(s) of water-surface slopes using hand-held clinometer from top of reach to bottom (minimum number of segments as need to visually span reach)	Length-weighted average of individual slope measurements	AREMP, CHaMP, EMAP, ODFW, SRFB, Ecology
4. Sinuosity ^{W,NW}	1) Centerline channel length of the entire reach (measured by airphoto if possible; using field-measured thalweg profile [see below] if not) (2) straight-line distance between the starting and ending points of the thalweg/centerline measurement	Ratio of centerline/straight-line lengths	AREMP, EMAP, ODFW
5. Bank modification ^{W,NW}	% of human modified bank – both sides	Percent total	
6. Density of habitat types ^W	Length and width for distinct habitat types meeting minimum size criteria—pool, step pool, riffle, cascade habitat, falls, run/glide, dry channel	Percent habitat for each type	CHaMP, EMAP, ODFW, Ecology
7. Bankfull width/depth ^{W,NW}	Lengths of the bankfull width and depth, as identified using standard field indicators, at each of the 11 transects in a reach (measurements should be omitted at transects with ambiguous indicators).	Average of the unambiguous measurements for both bankfull width and bankfull depth.	AREMP, CHaMP, EMAP, ODFW, SRFB, Ecology
8. Pools per unit length ^W	Number of minimum-sized pools identified during habitat mapping, and total reach length	Pools per unit length	AREMP, CHaMP, EMAP, ODFW, Ecology

D R A F T

Recommendations for Implementing Habitat Status and Trends Monitoring in the Lower Columbia Region

Monitoring Design Indicator*	Method/Measurement	Metric	Programs with potentially shareable protocols
9. Floodplain width ^{W,NW}	Employ field-based estimates; supplement with air photos for non-wadeable streams. Estimate width of the alluvial surface beyond the bankfull channel ^{W,NW} ; document presence of additional off-channel features such as scroll bars, oxbow lakes, etc.	Categorize the floodplain width into categories scaled by bankfull width (e.g., 0-1 W_{bkt} ; >1 W_{bkt}) (bins TBD)	EMAP
10. Side channel habitat ^{W,NW}	Determine “qualifying” vs. “nonqualifying” side channels (defined by CHaMP) Length, width, temperature, connectivity to mainstem	Qualifying channels – side channel length in meters; width and temperature measurements (upstream, midpoint and downstream); degree of connectivity to the mainstem (%) Nonqualifying – document presence only	
11. Flow category ^{W,NW}	Visual estimate of flow conditions at time of survey	dry, puddled, low, moderate, high, bankfull, flood as defined by ODFW protocols. Modify “Low Flow” to include surface water flowing across <75% of active channel surface	ODFW
12. Benthic Macroinvertebrates ^W	Employ Ecology’s transect-based methods – one kick sample at 8 of the 11 transects for either flowing or slack water. Details found in http://www.ecy.wa.gov/programs/eap/qa/docs/ECY_EAP_SOP_BenthicMacroinvertebrateDataCollection_v2_0EAP073.pdf	Samples processed to provide summary statistics/models (e.g. O/E and BIBI). Use Level 2 standard nomenclature http://www.pnamp.org/project/4210 as developed by the Macroinvertebrate Planning Group.	Ecology, AREMP, CHaMP, EMAP, ODFW, SRFB
13. Residual Pool depth ^W	Maximum pool depth, pool crest depth	Maximum pool depth minus pool crest depth	AREMP, CHaMP, EMAP, ODFW, SRFB, Ecology

D R A F T

Recommendations for Implementing Habitat Status and Trends Monitoring in the Lower Columbia Region

Monitoring Design Indicator*	Method/Measurement	Metric	Programs with potentially shareable protocols
14. Bank stability ^w	Categorize bank condition at each end of each transect, integrating the conditions observed along the bank from the transect point up- and downstream half-way to the next adjacent transect (22 measurements).	Median of the 22 transect-specific measurements. The result is a categoric (not a decimal) value for the entire reach.	EMAP
15. Relative bed stability ^w	None	Ratio of reach D50 to [(average bankfull depth) × (reach slope)]; apply roughness correction if/as indicated by selected protocol.	EMAP and Ecology
16. Density / distribution instream wood ^{w,NW}	Number and size of individual qualifying logs (AREMP protocol-minimum 15 cm dia., 3 m length). 1st ten pieces measured, then every fifth up to 35th pieces, then every 10th piece, size and location of accumulations and jams. Other pieces visually estimated; location of wood recorded (mid, bar, side, etc...)	Number of pieces and total wood volume (m ³) per unit length	AREMP, possibly others...
17. Substrate particle size ^w	Randomly selected, "first-touch" grains across the entire bankfull channel along fast-water (i.e., riffle) transects only. Count number of grains per transect to achieve at least 200 grains counted per entire reach. Record b-axis length in 1/2-phi intervals; subdivide <4 mm grains into "sand" and "fines".	Median grain size (D50); also D84, D16 for the entire reach.	CHaMP
18. Shade ^w	Canopy cover measured with densiometer (Mulvey et al. 1992 as cited by Ecology) on left bank and right bank for 11 transects and in 4 directions at each location	Shade score; could be reported as percent shade	EMAP, SRFB, Ecology
19. Riparian canopy (% cover) ^{w,NW}	Visually estimated for different vegetation types (see Ecology protocol) in a 10x10m plot at 11 transects	% cover of vegetation > 5m height	CHaMP, EMAP, ODFW, SRFB, Ecology
20. Riparian understory (% cover) ^w	Visually estimated for different vegetation types (see Ecology protocol) in a 10x10m plot on both banks at 11 transects	% cover of vegetation 0.5 - 5m height	CHaMP, EMAP, ODFW, SRFB, Ecology

DRAFT

Recommendations for Implementing Habitat Status and Trends Monitoring in the Lower Columbia Region

Monitoring Design Indicator*	Method/Measurement	Metric	Programs with potentially shareable protocols
21.Temperature ^{W,NW}	Temperature logged with hobo or similar data loggers at one representative location at each selected site at half hour intervals. Hobos will be deployed, retrieved and downloaded by the Field Reconnaissance crew, and the data sent to the Data Manager.	7-day moving average maximum temp, daily maximum temp, average daily temp	AREMP, CHaMP, EMAP, ODFW, SRFB, Ecology

* Indicators were previously labeled “metrics” in the Monitoring Design Report

W Wadeable

NW Non-wadeable

Recommendations for Implementing Habitat Status and Trends Monitoring in the Lower Columbia Region

Data Management

Data Sharing Objectives and Mechanics

The program manager in consultation with the Steering Committee and Technical Review Committee will identify the responsibilities of a data management team composed of a quality assurance (QA) manager in charge of data QA, and a separate data manager in charge of entry to a database, and data export to support the analysis manager or in response to data requests. Data QA is a task that is time consuming and requires attention to detail and focus. Best practices dictate that QA be conducted by someone other than the person entering the data. The data manager and QA manager will work closely, and the work flow and division of labor are outlined below.

To accommodate contracting needs, interagency agreements for data management should be secured on a 5-year basis consistent with the reporting cycle of the program. This agreement should recognize the biennial funding cycle of most government agencies by inserting a clause related to funding contingencies.

Data flow will occur as follows:

Raw Data

- Data entry and QA will occur between July and December of each year.
- Each organization collecting data will QA their data sheets in the field or lab, reviewing them for completeness and ensuring that the values entered make sense. This task should be done BEFORE leaving the field site.
- Data collectors will submit data on a weekly basis to the data manager in digital format (either scanned images of datasheets or digital files from a field tablet) and copy the Program Manager. If paper datasheets are used, original datasheets should be mailed to the program manager for archiving on a weekly basis.
- The data manager will enter the data into the database upon arrival. A long term goal would be to develop an online database with clear guidance on data entry to allow monitoring partners to enter data themselves. The data manager would focus on trouble shooting and export tasks. The QA manager will review the data upon entry, checking for consistency between submitted and entered data, completeness of data sets, and accurate use of terminology and codes. The QA manager will communicate with the data manager regarding any issues with incomplete or inconsistent data sets, or errors in the use of terminology or codes. It is not recommended that the QA manager attempt to fix the issues, since this could compound errors. The data manager will fix any issues pertaining to consistency between submitted and entered data. Issues with incomplete data or errors in terminology or codes should be rectified between the data manager and the data collectors.

Indicators and Indices

- Entry of indicators and indices will occur between December and April of each year.

DRAFT

Recommendations for Implementing Habitat Status and Trends Monitoring in the Lower Columbia Region

- The analysis manager (discussed below) will provide any calculated indicators and indices to the data manager for entry into the database. A long-term goal is to have database functionality to generate those values in real time.
- For specific datasets there may be existing tools available to share data and indicator values, such as the Puget Sound Stream Benthos Database, which stores and presents data and calculated indices to the public in an online format (<http://www.pugetsoundstreambenthos.org/>)
- The QA manager will review the indicators upon entry, checking for consistency between submitted and entered indicators. The QA manager will communicate with the analysis manager regarding any issues with incomplete or inconsistent data sets, or errors in the use of terminology or codes. It is not recommended that the QA manager attempt to fix the issues, since this could compound errors. The data manager will fix any issues pertaining to consistency between submitted and entered data. Issues with incomplete data or errors in terminology or codes should be rectified between the data manager and the analysis manager.

Database Design

The caucus recommends that near-term storage occurs through an access database, however the long term vision is to secure funding to develop and maintain an online database website. The database will store raw data, as well as calculated indicators and indices. At this time, protocols for data sharing and upload to the database are simple. The data manager will input and extract data. Upon development of a more sophisticated database, more elaborate rules should be developed to facilitate multiple partners uploading and extracting data at will.

Data Analysis and Reporting

Who Should Analyze the Data

The program manager in consultation with the Steering Committee and Technical Review Committee will identify a data analysis manager who may consult with a team of technical experts as needed to analyze data and produce reports. The data analysis manager should have a strong background in biometrics/bio-statistics with experience using probabilistic sample designs, be a biometrician/statistician themselves, or consult closely with one to result in an accurate interpretation of the data, speak to any nuances (for example) in the data sets and ensure a scientifically sound data analysis and accurate reporting. The duties of the data analysis manager will require close communication as a “team” with the data manager and QA manager as well. To maintain consistency and continuity, interagency agreements for data analysis should be secured on a 5-year basis consistent with the reporting cycle of the program. This agreement should recognize the biennial funding cycle of most government agencies by inserting a clause related to funding contingencies.

Analysis and reporting should be a combined activity. This will increase the chances that the data is properly interpreted. The parties writing the report would then know the caveats and limitations of the data and analyses.

The data analysis manager should analyze the data on an annual basis between December and April, and provide a brief status update of those findings. A more detailed report of both year 5 status and overall

DRAFT

Recommendations for Implementing Habitat Status and Trends Monitoring in the Lower Columbia Region

trends (from inception of monitoring to current year) on a regional basis will be generated between December and July every 5-years, consistent with the guidance in the implementation plan. Draft updates and reports will be submitted to the program manager for review by the Technical Review committee. Prior to release of the data and report, the data analysis manager will incorporate the Technical Review Committee's comments, and the program manager will finalize the document, post it online (program webpage and PNAMP), and send email notification to the Steering Committee and interested parties.

How Should the Findings be Reported including Indicators to be Used

Annual status updates will be generated by the data analysis and reporting manager to allow for adaptive responses to the monitoring protocol before the coming field season. 5-year Status and Trends reports will be generated by the data analysis and reporting manager between December and July following every 5th year of data collection. In addition to the annual and 5-year reports, a short public communication should be written that can be posted to the web page or printed in a brochure format to provide information about how the monitoring effort is progressing. These reports will be sent to the Program Manager for dissemination among the Technical Review committee for their review and comment prior to posting online and dissemination to the Steering Committee and interested parties.

The program manager will post the annual status report, short public communications, and 5-year status and trends reports to the program webpage. Findings will be disseminated by the program manager to NOAA, the Salmon Recovery Funding Board, Washington Department of Ecology, monitoring partners, and other interested parties identified during the implementation phase of program development through distribution of an email with links. Links or copies of the reports should be posted on the PNAMP website to reach a broader regional audience.

Because the metrics selected for measurement are those that are most meaningful for describing habitat conditions, the metrics themselves are the primary indicators to be reported. For the macroinvertebrates, a multi-metric index and a multivariate index (O/E model) will be used. Details about these metrics are provided in the Implementation Report authored by Stillwater Sciences.

Response to Findings

Members of the Steering Committee, the Technical Review Committee, and interested parties, may need to take an agency specific response to findings presented in the annual and 5-year reports. Findings may highlight the need for more targeted studies to identify sources and solutions to problems, or to better explain the mechanics behind successes. The Steering Committee may choose to offer opportunities to academic, government, and private research organizations, to explore questions in need of further controlled or experimental research.

Scaling

Scaling the Monitoring Effort to Answer Management Questions within Available Resources

The following options were explored to provide a mechanism for reducing the overall magnitude and financial requirements of the monitoring effort:

- Determine the variability in habitat data to see if fewer sites would still support a robust assessment.

DRAFT

Recommendations for Implementing Habitat Status and Trends Monitoring in the Lower Columbia Region

- Reduce statistical power/confidence
- Reduce the number of strata
- Condense and truncate strata categories
- Use remotely sensed data to collect some metrics
- Reduce the annual effort by adopting a rotating panel sampling design.

After consideration it was found that only three of these options were realistic:

- Reduce the level of statistical confidence required
 - Investigations into acceptable levels of confidence for biological and ecological measurements indicate that there is precedent for lowering our level of confidence from 95% to 90%. There are at least 3 regional programs that conduct monitoring in the Lower Columbia that use a 90% confidence level to detect changes in environmental data. This shift does not result in a recommendation for a reduction in magnitude or financial requirements to support this program, however, it does allow us to detect changes with high confidence in a shorter time frame.
- Condense and truncate strata categories
 - It was recommended that the least problematic reduction of strata categories could be accomplished by removing those sites that are in areas of >7.5% gradient, and by condensing the subbasin/primary population strata from 3 to 2 categories, combining the bins for those subbasins that support 3 primary populations and those that support 4 or more. This will reduce our effort by nearly 100 site visits per year.
- Reduce the annual effort by adopting a rotating panel sampling design.
 - Reducing the annual effort by adopting a rotating panel would provide savings on an annual basis, and make it a more manageable funding amount. It would allow us to visit fewer sites per year. However, there are implications for reporting, namely that a complete, statistically robust picture of regional habitat status would not be generated as quickly.

Available Resources

Currently, there is no designated funding for the habitat component of the Lower Columbia HSTM monitoring program. The LCFRB and others will present the completed monitoring package (Design and Implementation Plan) to potential funding sources to find funding for this effort. The discussion of the estimated resources necessary to support this program can be found in the implementation plan report.

Appendix 1: Resolution of Disagreements

At this time, the Caucus has not experienced any disagreement during our discussion.

DRAFT

Recommendations for Implementing Habitat Status and Trends Monitoring in the Lower Columbia Region

Appendix 2: Habitat Caucus Members

Affiliation	First Name	Last Name	Active	Inactive
Bureau of Land Management/AREMP	Stephanie	Miller	X	
City of Vancouver	Dorie	Sutton	X	
Cowlitz Indian Tribe	Rudy	Salakory		X
Cowlitz Indian Tribe	Shannon	Wills		X
Lower Columbia Fish Recovery Board	Karen	Adams	X	
Lower Columbia Fish Recovery Board	Jeff	Breckel	X	
Lower Columbia Fish Recovery Board	Steve	Manlow		X
Lower Columbia Fish Recovery Board	Melody	Tereski		X
Lower Columbia Estuary Partnership	Amanda	Hanson		X
Lower Columbia Estuary Partnership	Matthew	Schwartz		X
Natural Systems Design	Jennifer	O'Neal		X
NOAA	Scott	Anderson	X	
NOAA	Jeffrey	Fisher	X	
NOAA	Scott	Rumsey		X
Oregon Department of Environmental Quality	Shannon	Hubler	X	
Oregon Department of Environmental Quality/ Northwest Region	Wade	Peerman		X
Oregon Department of Fish and Wildlife	Kara	Anlauf-Dunn		X
Oregon Department of Fish and Wildlife	Jamie	Anthony		X
Oregon Department of Fish and Wildlife	Charlie	Stein		X
Stillwater Sciences	Jody	Lando	X	
TetraTech/SRFB	Tricia	Gross		X
US Forest Service	Jim	Capurso		X
US Forest Service Gifford Pinchot National Forest	Baker	Holden		X
US Forest Service Gifford Pinchot National Forest	Ruth	Tracy		X
US Forest Service/AREMP	Mark	Raggon	X	

DRAFT

Recommendations for Implementing Habitat Status and Trends Monitoring in the Lower Columbia Region

US Fish and Wildlife Service	Sam	Lohr		X
USFWS	Ron	Rhew	X	
US Geologic Survey	Ian	Waite	X	
US Geologic Survey Pacific Northwest Aquatic Monitoring Partnership	Jennifer	Bayer	X	
US Geologic Survey Pacific Northwest Aquatic Monitoring Partnership	Meg	Dethloff	X	
US Geologic Survey Pacific Northwest Aquatic Monitoring Partnership	Amy	Puls	X	
Washington Department of Natural Resources	Abby	Barnes	X	
Washington Department of Natural Resources	Allen	Lebovitz		X
Washington Department of Ecology	Chad	Larson	X	
Washington Department of Ecology	Glenn	Merritt		X
Washington Department of Fish and Wildlife	Emelie	McKain		X
Washington Department of Fish and Wildlife	Steve	West	X	
Washington Department of Fish and Wildlife	Dave	Howe		X
Washington Department of Natural Resources	James	Huinker	X	
Yakama Nation	Jeanette	Burkhardt		X
Yakama Nation	Lee	Carlson	X	
Yakama Nation	Michelle	Steg-Geltner		X
Yakama Nation	Paul	Ward		X

Appendix C-1

Hydrology

STAGE AS AN INDICATOR FOR HSTM QA/QX MONITORING

The HSTM design recommends the continuous collection of stage data at the Qa/Qx Urban+NPDES monitoring sites in order to characterize the status and trends of in-stream hydrology. This approach raises two issues: (1) to what degree is “stage” an adequate surrogate for “discharge,” the more typical parameter used to characterize hydrology; and (2) which specific indicators of hydrology are likely to be most useful to characterize conditions and track trends in these urban and urbanizing watersheds? These issues are best addressed in reverse order, because the utility of a stage–discharge substitution depends in part on the how the data will be used in any subsequent evaluation.

Hydrologic Indicators with Utility for Stormwater Management

Land-cover changes have been long recognized to alter the hydrology of watersheds and the flow regime of streams, particularly small streams (e.g., Leopold 1968). However, there has been little consensus over the years about the “best” indicators of such alterations, or even what the “best” would constitute. The earliest studies tended to focus on the increased magnitude of floods of a particular recurrence interval, of which the compilation by Hollis (1975) remains one of the more robust characterizations of this widely-recognized phenomenon (Figure C-1).




Figure C-1. The compilation of Hollis (1975), displaying the results from multiple studies (individual labeled dots) that characterized the multiplicative increase in peak discharge (curved dark lines) for a given flood recurrence (x axis) in a watershed that has undergone a specified increase in impervious area (y axis). For those floods that tend to exceed infrastructure design standards and are large enough to cause damage (i.e., commonly greater than about a 10-year event), typical suburban impervious-area percentages tend to increase peak discharges by 2- to 3-fold.

Subsequent work, most prominently developed in the Pacific Northwest by King County’s Basin Planning Program in the late 1980’s and later embraced more broadly (e.g., MacRae 1997), focused on the fractional increases in cumulative flow durations, producing graphs such as from the Soos Creek Basin Plan (Figure C-2) that allowed for the calculation of long-term increases in sediment transport.




Figure C-2. Flow-duration curve for Soosette Creek, developed for the Soos Creek Basin Plan (King County 2001). The hydrologic simulation program HSPF was used to predict runoff from the 14-km² watershed if all urban-zoned parcels were fully built out (“FUTURE LAND USE”). This graph indicates that flows exceeding the magnitude of the existing 2-year discharge (about 22 m³/sec) will persist for more than 20 times longer under future land use (as compiled over a period of many decades). During the same interval, the 100-year discharge will be exceeded for more than 100 times longer.

Other indicators of flow change were also explored during the 1980’s and 1990’s, including the frequency at which discharge exceed a chosen threshold of presumed streambed disturbance or significant erosion. This indicator was identified under the assumption that it could highlight changes of particular importance to biota, particularly bottom-dwelling macroinvertebrates that depend on a relatively stable substrate for their livelihood (e.g., Figure C-3).




Figure C-3. Interval between significant “disturbance events,” here defined as a flow that exceeds the 5-year (predevelopment) discharge. Within a 40-year simulation period under forested land-cover conditions (left), three such floods occur in the year following one such event; but there is also an interval of 14 years with no such peak flow at all. Under the urban land-cover condition (right), however, only one year *lacks* such a flood; indeed, most years have multiple such events every winter (modified from Booth 1991).

Although national efforts were also developing a widely recognized set of indicators (e.g., the Indicators of Hydrologic Alteration, or IHA) (Richter et al. 1996), these were exhaustive in their treatment of flow and developed primarily with the changes in hydrology imposed on large rivers by dam regulation. A suite of indicators focused more explicitly on hydrologic changes caused by watershed urbanization were explored by Konrad and Booth (2002), who suggested that changes in flashiness, peak flow, and baseflow could all serve as credible indicators. Focusing more explicitly on those attributes of the flow regime that would likely have biological effects, Konrad and Booth (2005) explored metrics that characterized the variability in four aspects of a stream hydrograph: high flows, low flows, daily flows, and the distribution of runoff between peak flows and baseflows. They tested these indicators on 13 small watersheds, nationwide—5 that had undergone little land-cover change over an 80-year gage record, and 8 that had seen substantial urbanization over the same period. Importantly, they found that no single metric reliably discriminated “urbanized” from “non-urbanized” watersheds; and no urbanized watershed showed a systematic change in every hydrologic metric. Thus, there is no “silver bullet” for detecting and characterizing the effects of watershed urbanization on flow regime, but many such indicators show promise, and a diverse suite is most likely to provide the most robust indications of hydrologic conditions and change.

DeGasperi et al. (2009) explored the relationship between B-IBI scores, watershed imperviousness, and hydrology through the investigation of eight hydrologic metrics (Low Pulse Count and Duration; High Pulse Count, Duration, and Range; Flow Reversals, T_{Qmean} , and R-B Index). This work was continued in King County (2012), which made use of the developed relationships between hydrologic metrics and B-IBI scores to evaluate the potential *biological* effectiveness of alternative stormwater management approaches to flow control. They considered eight metrics:

Metric name	Description
Low Pulse Count	Number of times each calendar year that discrete low flow pulses occurred
Low Pulse Duration	Annual average duration of low flow pulses during a calendar year
High Pulse Count	Number of days each water year that discrete high flow pulses occur
High Pulse Duration	Annual average duration of high flow pulses during a water year
High Pulse Range	Range in days between the start of the first high flow pulse and the end of the last high flow pulse during a water year
Flow Reversals	The number of times that the flow rate changed from an increase to a decrease or vice versa during a water year. Flow changes of less than 2% are not considered
T_{Qmean}	The fraction of time during a water year that the daily average flow rate is greater than the annual average flow rate of that year
R-B Index	Richards-Baker Index – A dimensionless index of flow oscillations relative to total flow, based on daily average discharge measured during a water year
Peak 2-yr:Winter Baseflow	Ratio of the estimated 2-year peak flow to winter baseflow (i.e., mean flow for October through April)

As with the results of Konrad and Booth (2005), all correlations between any given flow metric and B-IBI scores are imperfect, although the overall trends are as hydrologic theory and

biological inference would anticipate. In the interest of reducing the list to a more tractable number of indicators for application in the HSTM program, two criteria were applied to reduce the number of metrics from this list for more careful evaluation: strength of their biology–hydrology correlation, and their potential to be influenced by common stormwater-management approaches over time. So, for example, the “High Pulse Range” shows a good correlation with B-IBI, but stormwater management is not likely to substantially influence this metric.

With this rationale, three indicators from the above list of eight have been selected for investigation by this HSTM monitoring design:

- T_{Qmean}
- R-B Index (henceforth, “RBI”)
- Flow Reversals

T_{Qmean} is the aggregate fraction of time during a water year that a hydrograph lies above the mean discharge for that water year (Konrad and Booth 2002). Thus, a stream whose hydrograph is primarily a slowly varying baseflow and only limited peak flows may spend nearly half of the time above the mean discharge, resulting in indicator values at or above 0.40. In contrast, a very flashy hydrograph will have peaks that may greatly exceed the *magnitude* of the mean discharge, but the *duration* of those excursions may be rather brief. Thus, T_{Qmean} values for such systems may fall to values around 0.20.

The Richards-Baker Index (RBI) (Baker et al. 2004) is calculated for each water year as the sum of all day-to-day discharge differences (i.e., the absolute value of the difference between today’s flow and yesterday’s flow) divided by the sum of daily discharges. The numerator can be visualized as the length of the line making up a continuous average hydrograph, while the denominator would simply be the sum of all daily discharges stacked on top of one another.

Flow reversals are the simple tally of the number of days during the fall and winter seasons (specifically, October 1 through April 30) when the flow has changed from a rising or a falling trend to its opposite over the course of one day. A minimum threshold of change is commonly applied to avoid counting minor fluctuations; following King County (2012), that threshold was set at 2%. Thus, for example, a daily sequence of 90→100→95 cfs would count as a reversal, but 99→100→99 cfs would not.

For each of these indicators, their correlation with biological health (as measured by B-IBI) is relatively strong and monotonic (King County 2012). In these aquatic systems, more uniform and less flashy flow regimes are associated with more diverse species assemblages with a greater proportion of intolerant species. Thus, biologically “better” conditions are associated with higher values of T_{Qmean} , lower values of the R-B Index, and fewer fall/winter flow reversals. These relationships provide a clear basis to recognize the relative “status” of any given site on the basis of their flow indicators.

Evaluation of Flow Indicators in Western Washington Streams

Data source and the selection of test watersheds

Nearly all hydrologic data used in this evaluation were downloaded from the King County Hydrologic Information Center (<http://green2.kingcounty.gov/hydrology/>), selecting stations draining 2.5–50 km² to maximize their applicability to the HSTM Qa/QX Urban+NPDES monitoring sites, and with a relatively long period of record (at least 10 years of flow data for

most) (Table C-1). The sites in total span a wide range of urbanization, from nearly undeveloped watersheds to more than 70% urban land cover (Figure C-4). The one non-King County-operated gage site, that at Mercer Creek, was selected because it has the longest record (60 years) and the data are of equivalent quality and presentation.

Table C-1. Site list. All data from King County, except Mercer Creek (USGS gage 12120000). The watersheds fall into three natural groups based on their 2011 urban land-cover percentage, and are so indicated by the shading. The three least urban watersheds (Webster, Griffen, and Fisher) serve as useful “control” sites insofar as they each have urban land cover less than 3%, forest cover greater than 60%, and essentially no discernable change in urbanization over the 10-year period covered by the 2001 and 2011 National Land Cover Databases.

GAGE	GAGE #	LATITUDE	LONGITUDE	Drainage Area (km ²)	Start date Q	Stop date Q	% Forest 2011	% Urban 2011	% Urban change 2001-->2011
Webster	31q	47.4164	-121.9195	4.64	WY 2010	WY 2015	93.3%	0	0.0%
Griffen	21a	47.6163	-121.9070	44.54	WY 2002	WY 2015	62.9%	0.3%	0.0%
Fisher	65B	47.3841	-122.4815	5.03	WY 2005	WY 2015	60.9%	2.7%	0.0%
Tahlequah	65A	47.3345	-122.5089	3.98	WY 2005	WY 2015	81.4%	4.5%	0.0%
Cherry trib.	05b	47.7410	-121.9409	3.75	WY 2009	WY 2015	63.9%	4.7%	0.0%
Judd	28a	47.4034	-122.4688	12.12	WY 2000	WY 2015	62.2%	4.7%	0.1%
Weiss	53e	47.6926	-121.9454	8.40	WY 2009	WY 2013	64.8%	8.9%	0.1%
Crisp	40d	47.2883	-122.0672	8.02	WY 1995	WY 2015	46.4%	15.8%	4.2%
Seidel	02o	47.7117	-122.0519	3.75	WY 2009	WY 2015	53.7%	16.9%	15.5%
Taylor U/S	31i	47.4090	-122.0254	9.43	WY 1992	WY 2015	38.6%	21.5%	0.9%
Taylor D/S	31h	47.4207	-122.0412	13.17	WY 1992	WY 2015	40.0%	22.4%	0.9%
L Jacobs	15c	47.5654	-122.0521	11.89	WY 1992	WY 2015	25.8%	46.0%	3.9%
L Jacobs	15c	47.5654	-122.0521	11.89	WY 2000	WY 2015	25.8%	46.0%	3.9%
Lakota	33b	47.3288	-122.3726	8.96	WY 1990	WY 2009	9.9%	71.6%	3.1%
Mercer	12120000	47.6031	-122.1797	32.30	WY 1956	WY 2015	12.0%	71.7%	1.2%
Juanita	27a	47.7077	-122.2149	16.99	WY 1993	WY 2015	10.0%	78.0%	2.0%
Miller	42a	47.4455	-122.3520	23.13	WY 1989	WY 2015	4.8%	80.7%	3.5%




Figure C-4. All sites used in the hydrologic indicator analysis for this section.

Results of Analysis for hydrologic indicators

Of the 16 sites identified as candidate gage records, three were excluded from hydrologic analysis either because they had short (4-year) records and their level of urban land cover was close to other site(s) with lengthier records (Cherry tributary, Weiss), or because they were tributary to a farther downstream gage and so not independent (Taylor U/S). The remaining 13 sites in aggregate display the anticipated relationships between urban land cover and hydrology: with increasing levels of urbanization, the average-over-full-record values of T_{Qmean} decreased, the RBI increased, and the tally of annual fall/winter flow reversals increased (Figure C-5). However, the significant scatter in the graphs of all indicators reinforces the long-standing recognition that “urban land cover” is a good but not perfect surrogate for hydrologic alteration of a watershed, and that each indicator responds differently within a given watershed setting.




Figure C-5. All sites with analyzed hydrologic data, with the specified indicator plotted against the 2011 watershed urban land cover. Plotted indicator values are those of each individual water year averaged over the full period of record. Two sites with somewhat anomalous relationships are labeled.

Examples of local disparities within an overall urban-driven trend are readily identified. For example, the flow of Crisp Creek, with a moderate 15.8% watershed urban land cover, is supported by abundant deep groundwater flow (which is why a tribal fish hatchery has made use of its cold, reliable flow since 1987). This site is an outlier on the plots for all three metrics, because the relatively high, steady groundwater flow damps the expression of urban flashiness. In contrast, Lakota Creek (71.6% urban land cover) is a steep tributary to Puget Sound that drains a largely suburban watershed in the city of Federal Way. It is fully “on-trend” with respect to T_{Qmean} relative to other watersheds of comparable urban land-cover percentages (for example, that of Mercer Creek is an identical 0.26 with an urban land cover of 71.7%), but its RBI is below the regional trend (i.e., less flashy) whereas its flow reversals are well above the corresponding trend (i.e., more flashy).

Comparisons between metrics

Differences between indicators at the same site can be assessed more systematically by comparing their pairwise behavior to one another. Figure C-6 shows these comparisons, which demonstrate their overall good correspondence but with some informative differences.




Figure C-6. All sites with analyzed hydrologic data, with the specified indicators plotted against one another using the values for each individual water year averaged over the full period of record. The only systematically outlier is Griffin Creek, which has many fewer flow reversals then either of its other two indicators might otherwise suggest. Possible explanations for this behavior are that the watershed is the largest of this group, and with one of the largest fractions of wetlands (>5% watershed area) of any site.

Unlike the relationships between urban land cover and hydrologic indicators, each indicator is likely to be affected equivalently by the unique attributes of each watershed—not only urban land cover, but also baseflow contribution, hillslope and channel gradients, and watershed size. Thus, their relatively good correlation between indicators (particularly between T_{Qmean} and RBI, two related measures of the magnitude of high-flow peaks relative to more common, persistent flows) is not surprising. It also suggests that seeking yet additional indicators may not result in a commensurate increase in understanding.

Ability to detect trends

These datasets are also suitable to evaluate the ability of these indicators to detect changes over time, given the decade to multi-decade length for many of them and the parallel availability of land-cover data from both 2001 and 2011, a period covered by many of these records. The aggregated results, however, are not particularly encouraging (Figure C-7). The range of “natural” variability, as expressed by the points plotting along the y-axis (i.e., with no detectable change in urban land cover over the 10-year period) fully encompasses the observed range of change for any degree of urban land cover increases at many of the other sites. For those that exceed the range of values expressed by the three sites with little/no change, most show very small or mixed responses over their period of record (e.g., Taylor D/S, with less flashy T_{Qmean} and RBI trends but more flashy reversals).




Figure C-7. Rate of change in hydrologic indicators as a function of urban land-cover change. No site with active urbanization during the decade 2001-2011 shows a consistent pattern with respect to all three indicators; the three sites with no significant change that plot close or on the y-axis (and for which all have <5% urban land cover as of 2011) can be used to infer a range of natural variability, which suggests somewhat more flashy flows on the basis of T_{Qmean} and RBI (but not if considering flow reversals).

These results do not offer much promise for systematic detection of decadal-scale hydrologic trends, even for those watersheds with relatively rapid rates of change. Although several watersheds showed changes in specific indicators beyond the range defined by the near-“control” sites (those lying on or close to the y-axis of Figure C-6, and which themselves suggest a somewhat inconsistent picture of greater natural flashiness in runoff over the period), no site shows a consistent response in all three indicators. Reversals at the control sites define the widest interval of natural variability, for which only Taylor and Crisp Creek exceed: and for those two, the apparent trend of Crisp Creek suggests a *less* flashy regime, despite its relatively high rate of urban land-cover change, whereas the trend for reversals at Taylor Creek contradicts those for T_{Qmean} and RBI.

More revealing is the behavior of two specific sites: Seidel Creek, with a relatively short hydrologic record (spanning 7 years in total but with data for only WYs 2009, 2010, 2011, 2012, and 2015) but the greatest change in urban land cover between 2001-2011 (15.5%, with an accompanying decrease in forest cover of 23.5%), and Mercer Creek, with more than a half-century of gage data. On Seidel Creek, rapid suburban development in the decade of the 2000’s (Figure C-8) resulted in significant hydrologic changes, although the relatively sparse data paint a somewhat ambiguous picture of hydrologic response (Figure C-9).



Figure C-8. Aerial views of Seidel Creek watershed from 2002 (left) and 2014 (right). Imagery from Google Earth. Over one-half square kilometer (133 acres) of this 3.5 km² watershed converted to urban land cover during the decade 2001–2011.




Figure C-9. Decadal rate of change in hydrologic indicator values for Seidel, extrapolated from the period 2009–2015. Trends imply lower hydrologic changes than those expressed for the control sites using T_{Qmean} or RBI; however, the trend for reversals is dramatically more rapid (i.e., more urban) than for those same control sites.

Mercer Creek has the unique advantage of having a near-continuous 60-year hydrologic record, spanning a period when urban development was only just beginning in this 32-km² watershed up to its current condition with more than 70% urban land cover. The trends for all three hydrologic metrics are strong and consistent over the full period of record (Figure C-10 and Figure C-11), which likely span a period when urban land cover would have been increasing as rapidly as any other site in this study over the last 10 years (i.e., >5%/decade). However, they also all suggest a possible reversal of these trends over the last ~10 years or so, particularly well-expressed by a reduction in the RBI but also displayed in T_{Qmean} (an increase) and in flow reversals (a less distinct reduction). These long-term records also suggest that the RBI has the lowest interannual variability and flow reversals the greatest—but even for the former, at least two to three decades of record would have been necessary to identify any consistent trends. Absent widespread and highly effective stormwater management, this is likely to be the minimum duration of monitoring that would be required to detect statistically meaningful trends in hydrologic indicators.




Figure C-10. Water-year values of the three hydrologic indicators for Mercer Creek at USGS gage 12120000, the longest record in the data set.




Figure C-11. Average rate of change in hydrologic indicators for Mercer Creek over the full period of record (WY 1956–2016, with control-site averages from the last decade provided for reference). All Mercer Creek changes are of consistent direction, supporting an inference of long-term increase in flashiness corresponding to the multi-decadal period of urbanization in the watershed.

Suitability of Stage as a Surrogate for Discharge

Rationale for substitution

Accurate stream gaging can require significant levels of both expertise and time/cost, because it requires not only the continuous recording of water level (stage) but also relatively frequent site visits to directly measure discharge. The resulting relationship between recorded stage and measured discharge (the rating curve) is generally considered accurate only within the range that discharges have been measured (i.e., it is reliable for interpolation but progressively less so for extrapolation), which requires site visits during times of high or peak flow. Of course, this will typically correspond to times when every such site is experiencing such flows, making measurement logistics difficult for a limited number of trained crews. In addition, the underlying relationship between stage and discharge can change, most commonly as a result of erosion or sediment deposition at the gaging site, and so rating curves must be developed a new following significant (or potentially significant) channel-altering events. These requirements all increase the cost of reliable discharge measurements.

However, for many applications the conversion of stage to discharge is unnecessary. Since discharge is normally a *calculated* value derived from stage, those parameters that depend on patterns or variations in discharge should actually be more accurately represented by direct evaluation of the raw (i.e., stage) data. Only for those applications that require a direct knowledge of the flow magnitude (e.g., culvert capacity, floodplain inundation) is the conversion to discharge mandatory. In addition, many of the issues associated with fluctuations in the flow, such as sediment transport or substrate disturbance, are only dependent on stage (because stage is the direct measure of flow depth, a key determinant of the tractive stress that mobilizes sediment); the absolute discharge is in fact irrelevant.

For these reasons, the use of stage data was explored as a surrogate for discharge in implementing the hydrologic monitoring components of this HSTM program. In general, hydrologic indicators have been developed and implemented solely on the basis of discharge, and so the purpose of this exploration was to determine the degree to which stage can be used effectively as a surrogate for discharge, and to identify any potential pitfalls to the naïve substitution of one measurement (i.e., stage) for another (discharge).

Approach

The same set of gage records from King County's Hydrologic Information Center (plus USGS 12120000) was mined for suitable data sets. Although stage must have been recorded for all dates with reported discharge, the data are not readily available for all such entries. From the population of gage records used to evaluate the hydrologic indicators, 10 have at least ten years of jointly reported daily stage–discharge data from which comparisons can be made. Evaluations of both individual years and record-averaged values and trends were made to determine the suitability, and the limitations, of using stage records without needing to invest the additional effort in developing and maintaining a rating curve.

Results

Comparison of the three indicators using both the discharge record and the stage record yield very mixed results (Figure C-12). T_{Qmean} shows by far the most consistent relationship, suggesting that this indicator could be calculated and interpreted using either data set with only minimal uncertainty associated with its use or integration with prior studies. The other two indicators, however, have rather poor correlations between calculations using the two alternative data sets, and so which require further discussion.




Figure C-12. The three hydrologic indicators recommended for use in the HSTM program, comparing the decadal-averaged values for each site calculated using the discharge record (x axis) and the stage record (y axis). Only T_{Qmean} shows as a useful relationship with the data as it presently exists.

The Richards-Baker Index (RBI), the quotient of summed day-to-day discharge differences divided by the sum of daily discharges, depends not only on the magnitude of interday fluctuations (an intuitive measure of “flashiness,” which is why the RBI is widely used) but also on the overall magnitude of the denominator. Using discharge data, this relationship is understandable: an interday fluctuation can be considered “large” only in the context of the overall magnitude of discharge. However, the “magnitude” of stage is entirely arbitrary, since the datum from which it is measured can be any value (and may well change from year to year, or even within a single water year) (Figure C-13).

This result does not require that RBI be calculated only from discharge, but it does require that the actual flow *depth* (i.e., a physical measurement of the flow) be preserved from the original field measurements and pressure transducer record. This is not commonly done, and it would need to be incorporated into any procedure that sought to avoid the added time and expense of creating stage–discharge rating curves. Unlike stage, depth is not an “arbitrary” value, and fluctuations around an average depth are quite likely to have physical and biological importance. Without these data, however, extraction of a meaningful value of the RBI is not possible.




Figure C-13. Comparison of discharge (left) and stage (right) records from Miller Creek (gage 42a) for the first three months of WY 2002. The stage record as reported is the upper curve on the right panel; the lower curve reflects an arbitrary 3' lowering of the datum, as might occur after a scouring event in the channel or if the gage location were moved. Although no physical change exists between the two records, the calculated RBI from the "shifted" record is more than 5 times larger. This indicator shift would not occur if the data were of actual flow *depth*, rather than stage.

Flow reversals, the tally of daily flow reversals during the fall and winter seasons that exceed a specified threshold (here, 2%), should in principle be entirely unaffected by whether stage or discharge is the variable being used, since any discharge record is based on a monotonic function of stage (i.e., if stage increases then calculated discharge increases, and vice versa). The poor correlation between these two approaches (Figure C-12, right) is therefore not an intrinsic shortcoming of the data but rather of its typical implementation. To avoid "counting" even miniscule reversals in the annual total, a minimum threshold of change is normally applied to include a day's reversal in the tally (King County 2012 recommends 2%). However, calculated discharge is commonly a power function of measured stage, such that a given change in discharge may reflect a somewhat smaller change in stage. In our data set, discharge reversals invariably exceeded stage reversals for every site, using the same 2% threshold for identifying a true reversal for both. This limitation can be significantly reduced with a lower (or no) threshold for identifying reversals in the stage record (Figure C-14), but they can be eliminated altogether only if the full precision of the recorded stage data is preserved throughout the calculating and archiving of these data. Typically, values are reported only to 2 or 3 significant digits, which may result in identical day-to-day records of the stage but nonetheless produce calculated changes in discharge.




Figure C-14. Comparison of alternative flow reversal records (from Tahlequah Creek [gage 65A], the site with the worst naïve correlation of reversal calculations). Using the 2% minimum day-to-day threshold for identifying flow reversals on both the (recorded) stage record and the (calculated) discharge record, there is essentially no correlation between the two indicators, with a five-fold (or greater) difference between them in any given year. Eliminating the threshold for identifying stage reversals results in a dramatically improved correlation. The remaining mismatch is almost certainly a consequence of rounding the reported stage values (which span only a 2-ft range over the period of record and are reported to the nearest 0.01', whereas discharge spans an order of magnitude greater range of values but is also reported with a precision of 0.01).

Conclusions

This appendix explores the application, interpretation, and limitations of hydrologic indicators, using an unprecedented data set in terms of its quality, length, and applicability to urban and urbanizing watersheds of the Pacific Northwest. Three indicators previously identified for their utility in identifying hydrologic conditions that respond to watershed urbanization and with biological importance— T_{Qmean} , the Richards-Baker Index, and the annual tally of wet-season inter-day flow reversals—are all successful in stratifying watersheds across a range of urban development. The indicators are well correlated, and so in principle any one or two could provide nearly the same degree of understanding as the entire set. However, their calculation is straightforward and makes use of the same data, suggesting that the minimal savings in time is not worth the potential loss of insight. None of the indicators appear to reliably detect trends in watershed urbanization over the course of a single decade, at least given the rates of such development across the region over the past 10 to 20 years, but they all appear to respond with a reasonable degree of statistical significance to longer, multi-decadal trends. Use of stage as a surrogate for discharge in the calculation of these indicators appears plausible but cannot be implemented under current reporting practices. Instead, the original data for water depth would need to be preserved, along with the full precision of the original recorded data. With these caveats, there is every reason to expect that hydrologic indicators based on stage will prove as or more useful, at least in the context of status-and-trends monitoring, as those based on subsequent calculations of discharge.

References

- Baker, D. B., R. P. Richards, T. T. Loftus, and J. W. Kramer. 2004. A new flashiness index: characteristics and applications to midwestern rivers and streams. *Journal of the American Water Resources Association*, 40: 503–522.
- Booth, D. B. 1991. Urbanization and the Natural Drainage System—Impacts, Solutions, and Prognoses. *Northwest Environmental Journal* 7:93–118.
- DeGasperi, C. L., Berge, H. B., Whiting, K. R., Burkey, J. J., Cassin, J. L., Fuerstenberg, R. R. 2009. Linking hydrologic alteration to biological impairment in urbanizing streams of the Puget Lowland, Washington, USA. *Journal of the American Water Resources Association* 45: 512–533.
- Hollis, G. E. 1975. The effect of urbanization on floods of different recurrence interval. *Water Resources Research* 11: 431–435.
- King County. 2012. Stormwater retrofit analysis for Juanita Creek Basin in the Lake Washington watershed. Ecology Grant: G0800618. Prepared by Jeff Burkey, Mark Wilgus P.E., and Hans Berge. King County Department of Natural Resources and Parks. Water and Land Resources Division. Seattle, Washington. King County, 1990, Soos Creek Basin Plan and Final Environmental Impact Statement: Seattle, Department of Public Works, Surface Water Management Division.
- Konrad, C. P., and D. B. Booth. 2002. Hydrologic trends resulting from urban development in western Washington streams. U.S. Geological Survey Water-Resources Investigation Report, 02-4040p.
- Konrad, C. P., and D. B. Booth. 2005. Hydrologic changes in urban streams and their ecological significance. *American Fisheries Society Symposium* 47: 157–177.
- Leopold, L. B. 1968. Hydrology for urban planning: a guidebook on the hydrologic effects of urban land use: U.S. Geological Survey Circular 554.
- MacRae, C. R. 1997. Experience from morphological research on Canadian streams: is control of the two-year frequency runoff event the best basis for stream channel protection? Pages 144–162. *in* L. A. Roesner, editor. Effects of watershed development and management on aquatic ecosystems, Proceedings of an ASCE Engineering Foundation Conference, Snowbird, Utah, August 4–9, 1996. ASCE, Reston, Virginia.
- Richter, B. D., J. V. Baumgartner, J. Powell, and D. P. Braun. 1996. A method for assessing hydrologic alteration within ecosystems. *Conservation Biology* 10: 1,163–1,174.

Appendix D-1

Temperature

TEMPERATURE AS AN INDICATOR FOR HSTM QA/QX MONITORING

Temperature

The influence of urbanization on the temperature of rivers and streams is widely recognized. Decades of study have investigated the causes, and the consequences, of warmed water in rivers and streams (e.g., Hannah et al. 2008), but their quantification in any given watershed is confounded by channel-network geometry, groundwater inflow and hyporheic exchange, and the interplay of stream orientation and sun angle, canopy cover, and air temperature (Smith 1972, Poole and Berman 2001). Heat is added to and lost from a stream by radiation, sensible heat from inflows and outflows, latent heat by evaporation or condensation, bed conduction, and friction (e.g., Brown 1969).

Decades of measurements and models demonstrate that the most important term for streams is the net radiation, which in turn is determined by the sun angle, stream aspect, and canopy cover (Pluhowski 1970, Poole and Berman 2001). The least important are generally those of conduction and evaporation, while bed conduction and friction are sometimes ignored altogether. Of the remaining terms, the types and magnitude of sensible heat inputs are quite variable. The presence and influence of cool groundwater inflows depend on both local and regional variations in subsurface geology, soil thickness and permeability, and upland land cover (e.g., Smith and Lavis 1975, Tague et al. 2007). In contrast, prior studies of urban stream temperatures typically have focused on the sensible heat contribution of urban runoff, but they have almost exclusively been conducted in regions where thunderstorms fall on recently sun-warmed pavement surfaces that result in runoff up to 5–10°C warmer than the receiving stream, and with the highest runoff temperatures occurring in the mid-afternoon on sunny days during storm events with low total rainfall amounts (Herb et al. 2008). However, these climatological conditions are not ubiquitous, and they are particularly rare in the Pacific Northwest. Thus, prior work offers surprisingly little insight into a matter of significant regional environmental concern and regulatory attention.

Existing studies, both empirical and model-based, provide some guidance on the likely magnitude of stream-temperature changes resulting from human activity, particularly as a result of increased solar radiation on the water surface. Hewlett and Fortson (1982) reported typical water-temperature increases in the southeastern Piedmont of about 3°C ($\pm$ 3°C) from riparian clearing (and up to about 7°C during the hottest days of a Georgia summer). A pre- and post-clearcutting investigation of a small headwater stream in Pennsylvania (Rishel et al. 1982) showed the average monthly maximum stream-temperature increase to be 4.4°C. Burton and Likens (1973) found increases of 4–5°C in riparian-cleared areas of Hubbard Brook experimental forest, New Hampshire, a similar magnitude to the measured and modeled influence of shading in western Oregon (Risley et al. 2002). LeBlanc and others (1997) investigated various human-induced changes via a calibrated temperature model for a temperate mid-latitude site; they found typical simulated temperature increases from vegetation removal to be 2°C from direct solar radiation augmented by increased channel width (resulting from urban-increased discharges) and baseflow reduction.

To address the paucity of urban-watershed temperature studies in the Pacific Northwest, a four-year data set of summertime stream temperatures collected across the Puget Lowland in 1998, 1999, 2000, and 2001 was recently analyzed (Booth et al. 2014). Four watershed variables presumed to be influential (total watershed area and the watershed percentages of urban development, upstream lakes, and permeable glacial outwash soils as an indicator of groundwater exchange) were significant predictors of stream temperature only when considered together, with

the strongest influence identified for percent outwash followed by percent urban development and percent upstream lake area. Upstream lakes resulted in downstream warming of up to 3°C; variability in riparian shading imposed a similar temperature range.

Thus, watershed urbanization itself is not the most important determining factor for summertime stream temperatures in this region, and even the long-recognized effects of riparian shading can be no more influential than those imposed by other local-scale and watershed-scale factors. These issues must be appreciated to make sense of instream temperature data, either as previously collected by other programs or as recommended here for the HSTM program. This discussion focuses on maximum instream temperature as the key indicator of concern, insofar as these typically raise the greatest concerns for their influence on cold-water fish species in the Pacific Northwest.

To explore the potential value and interpretation of the temperature data that is recommended for collection under the HSTM program, a similar suite of data from King County Water and Land Resources Division was identified and analyzed. King County maintains a network of continuously recording stream temperature stations, distributed across streams that drain a range of watersheds from the urban lowlands to the forested Cascade foothills. Daily average temperature data were downloaded from the King County Hydrologic Information Center (<http://green2.kingcounty.gov/hydrology/>), choosing 11 sites that span a broad range of urbanization but with all draining watersheds within the range of 2.5–50 km² (Table D-1). Record lengths varied from 5 to 20 years, with most spanning the period 2005–2015.

Table D-1. List of King County gages used in evaluating the application of continuous stream temperature data. All of these sites also have gages with hydrologic data reported in Appendix C-1 of this report (however, not all hydrologic sites have recorded temperature data).

Gage name	Webster	Griffen	Fisher	Tahlequah	Cherry trib.	Judd	Crisp	Taylor	Laughing Jacobs	Juanita	Miller
GAGE #	31q	21a	65B	65A	05b	28a	40d	31i	15c	27a	42a
W'shed Area (km ²)	4.64	44.54	5.03	3.98	3.75	12.12	8.02	9.43	11.89	16.99	23.13
% Forest 2011	93.3%	62.9%	60.9%	81.4%	63.9%	62.2%	46.4%	38.6%	25.8%	10.0%	4.8%
% Urban 2011	0.0%	0.3%	2.7%	4.5%	4.7%	4.7%	15.8%	21.5%	46.0%	78.0%	80.7%
% Urban change 2001-->2011	0.0%	0.0%	0.0%	0.0%	0.0%	0.1%	4.2%	0.9%	3.9%	2.0%	3.5%
Start date T	2009	2005	2004	2004	2009	2000	1998	2009	1996	2000	2001
Stop data T	2013	2015	2015	2015	2012	2015	2015	2012	2015	2015	2015
	RURAL WATERSHEDS						SUBURBAN		SUBURBAN—URBAN		

For each gage, the full available record was downloaded at a daily time step and inspected for thermal maxima. An example of the data, using those from the gage with the longest record (Laughing Jacobs, gage 15c) displays many of the key features of these records (Figure D-1):




Figure D-1. Daily thermograph for Laughing Jacobs Creek, expressing the full period of record. The average temperature trend line is plotted as a faint dotted line (about 11°C), and it shows no trend over the 20 years of record.

Most apparent in these data is the annual cycle of stream temperature, which peaks in late July in most years (rarely, early August) and reaches its minimum around the turn of the year. There is some suggestion of a wider annual range of temperatures in the latter half of the record, but the linear best-fit trend (dashed blue line) is unchanged over the twenty-year period.

Although the annual averages are essentially unchanged, annual maximum temperatures show a fairly distinct pattern at this site. With the exception of 1999, all of the ten warmest maximum temperatures have occurred post-2006 (Figure D-2).




Figure D-2. Annual maximum daily temperatures at Laughing Jacobs Creek. In contrast to the mean temperature, this record shows a relatively distinct (but irregular) increasing trend.

A variety of factor may explain the broad increase in maximum temperatures (about 1°C per decade) over this 20-year period, including random variability (the standard deviation of the data is only slightly less than that of the apparent trend), more widespread regional summertime warming, or the effects of increased urbanization over this period (a 3.9% increase in watershed

urban land cover from 2001 to 2011, based on changes between the 2001 and 2011 National Land Cover Database).

Separating the influence of regional climate from that of more local human activity can be explored using six of the temperature stations from the King County dataset that have urban land cover values of less than 5% (as of 2011) and show an increase of no more than 0.1% in this parameter over the preceding decade (Figure D-3). These “reference” sites suggest no systematic temperature change during their respective period(s) of record, suggesting that the Laughing Jacobs results are reflecting changes specific to that watershed and/or monitoring site (and that may or may not be related to watershed urbanization specifically)




Figure D-3. Annual maximum temperatures for six sites with low watershed urbanization and no significant increase in urban land cover during the period 2001–2011. Nearly 4°C separate the warmest from the coolest of these “low-urban” sites, and none show any apparent trend during this period.

To further explore the potential influence of regional climate warming, daily maximum air temperatures for two long-term weather stations (SeaTac airport, in the center of the Puget Lowland; and Landsburg, in the Cascade foothills) were downloaded from <http://weather-warehouse.com/>. Annual maximum temperatures, maximum July temperatures (to maintain an analogous record to that of the stream temperatures), and the average of all July daily maxima were plotted and inspected for trends over both the full period of record (68 years in the case of SeaTac, 100 years in the case of Landsburg) and for the last two decades (Figure D-4).




Figure D-4. Regional air temperatures over the last 60+ years (top) and the last 20 years (bottom). Linear trends are given by the equations, which show the greatest increase in maximum summer temperatures over the last two decades (1°C or more per decade in the case of SeaTac). Recent SeaTac changes are greatest, regardless of the specific metric being considered, and are lowest over the last century's record at Landsburg.

For Landsburg, well-separated from most urban development and other human activity, there is little discernable change in air temperature regardless of the metric or the period of investigation. The most prominent trend is the recent one-degree increase over the last two decades in maximum summertime temperature, although neither the average of all daily maxima shows nor the maxima of July temperatures show any such change. For SeaTac, comparable averages are about 1 degree *cooler* than at Landsburg, regardless of which period is compared, but the trends in temperature *change* are both stronger and more consistent than at Landsburg, with SeaTac temperature increases of 2 to 4 degrees over the last two decades regardless of which metric is evaluated (coincidentally, a rate quite similar to that of Laughing Jacobs Creek). These results suggest that there is both a regional climatic component and a more local, urban-related component to changes in ambient air-temperature maxima, which in turn are likely to exert a real (but ill-defined) influence on measured stream temperatures.

The effects of urbanization cannot be fully separated from the potential regional influences of geography in our existing data set, because urbanization is not randomly distributed across the landscape--in general, the more urban localities are lie east of Puget Sound towards the center of the Lowland, whereas the less urban sites are either farther east in the forested Cascade foothills or along the coastline of Vashon Island, immediately adjacent to Puget Sound. This confounding relationship notwithstanding, the existing King County stream stations with temperature data

show a strong correlation between urbanization and maximum temperatures, whether for selected years or as averaged over the available records for all gages (Figure D-5).




Figure D-5. Relationships between watershed urban land cover and maximum stream temperatures. Top, average of maximum July temperatures over each site's entire period of record; bottom, maximum July temperature for two successive years at each site. Note that the full-record average plots close to that for 2010; 2011 was cooler by an average of about 2°C across all sites.

Although the geographic location of the two long-term air temperature stations suggests that the eastern, low-urban sites might be up to one degree warmer, it is the most urban sites that are up to three degrees warmer than their more forested, less-developed counterparts. Of course, these data offer no insight into whether urbanization is the cause, or if so then what might cause these differences—reduced infiltration and so lower summertime flow, reduced riparian shading, and/or urban runoff across warmed surfaces from human activities (landscape watering, pavement washing, etc.) have all been suggested as possible agents. However, they do suggest that whatever the cause there are likely to be discernible effects of urbanization on stream temperatures; they can impose an effect that is as much as several degrees in magnitude; and they occur across a temperature range that is significant for the health of cold-water fisheries and so have potential biological consequences.

Are these data suitable for detecting trends in changing stream temperature more generally? The suburban station with the longest temperature record (Crisp Creek) also shows the greatest land-cover change between 2001 and 2011 (an increase of 4.2% in urban land cover, to a total of 15.8% in 2011). Unlike the reference sites it does show a distinct trend of increasing maximum temperatures (Figure D-6), although the summertime streamflow at this site is dominated by groundwater and the rate of warming (about 0.5°C per decade) is only half that of the air temperature rise at SeaTac. Based on the scatter of the data and the magnitude of the trend at this site, even though it has the greatest land-cover change it is unlikely to demonstrate statistically significant changes with only a single decade of measurement here.




Figure D-6. Temperature changes at Crisp Creek over its full period of record. Given the magnitude of change and the scatter of the data, a single decade of measurement probably cannot demonstrate statistically significant change.

Conclusions

Long-term stream temperature data show intriguing patterns of decadal-scale warming, loosely correlated with the magnitude of urban development in the watershed. These results are broadly consistent with, and of the same magnitude as, prior studies in both western Washington and elsewhere about the potential range of effects of human activity on stream temperatures. However, those influences vary in both location and scale (e.g., local riparian clearing vs. watershed-scale land-cover change), and they can be dwarfed by intrinsic watershed conditions of geology and groundwater and the annual variability of climate that render any deterministic interpretation of such data challenging. Nonetheless, the widespread impairment of lowland streams from high summertime temperature, the importance that this parameter has for aquatic biota, and the potential for significant temperature changes to result from human activities and watershed management clearly justify its inclusion in any status-and-trends monitoring program.

Thermal “conditions” are likely to be identifiable, at least with respect to key biological thresholds, within a few years of continuous monitoring during July and August; detecting “trends” in a statistically defensible manner, however, is likely to require over a decade of such monitoring. Unravelling the co-varying influences of human activity, interannual weather variability, and climate change will require not only more targeted investigations of the watershed

and riparian zone of interest but also the presence of a regional temperature monitoring framework that can reveal regional trends independent of local influences.

References

- Booth, D. B., K. A. Kraseski, and C. R. Jackson. 2014. Local and watershed-scale determinants of summertime urban stream temperatures: *Hydrological Processes* 28: 2,427–2,438.
- Brown, G. W. 1969. Predicting temperature of small streams. *Water Resources Research* 5: 68–75.
- Burton, T. M., and G. E. Likens. 1973. The effect of strip-cutting on stream temperatures in Hubbard Brook Experimental Forest New Hampshire. *Bioscience* 23: 433–435.
- Hannah, D. M, B. W. Webb, and F. Nobilis. 2008. River and stream temperature: Dynamics processes models and implications. *Hydrological Processes* 22: 899–901.
- Herb, W. R., B. Janke, O. Mohseni, and H. G. Stefan. 2008. Thermal pollution of streams by runoff from paved surfaces. *Hydrological Processes* 22: 987–999.
- Hewlett, J. D., and J. C. Fortson. 1982. Stream temperature under an inadequate buffer strip in the southeast Piedmont. *Water Resources Bulletin* 18: 983–988.
- LeBlanc, R. T., R. D. Brown, and J. E. FitzGibbon. 1997. Modeling the effects of land use change on the water temperature in unregulated urban streams. *Journal of Environmental Management* 49: 445–469.
- Pluhowski, E. J. 1970. Urbanization and its effect on the temperature of streams on Long Island, New York. U.S. Geological Survey Professional Paper 627-D.
- Poole, G. C., and C. H. Berman. 2001. An ecological perspective on in-stream temperatures—natural heat dynamics and mechanisms of human-caused degradation. *Environmental Management* 27: 787–802.
- Rishel, G. B, J. A. Lynch, and E. S. Corbett. 1982. Seasonal stream temperature changes following forest harvesting. *Journal of Environmental Quality* 11: 112–116.
- Risley, J. C., E. A. Roehl Jr., and P. A. Conrads. 2003. Estimating water temperatures in small streams in Western Oregon using neural network models. U.S. Geological Survey Water Resources Investigations Report 2002-4218.
- Smith, K. 1972. River water temperatures: An environmental review. *Scottish Geographers Magazine* 88: 211–220.
- Smith, K, and M. E. Lavis. 1975. Environmental influences on the temperature of a small upland stream. *Oikos* 26: 228–236.
- Tague, C., M. Farrell, G. Grant, S. Lewis, and S. Rey. 2007. Hydrogeologic controls on summer stream temperatures in the McKenzie River basin Oregon. *Hydrological Processes* 21: 3,288–3,300.

Appendix E-1

Conductivity

CONDUCTIVITY AS AN INDICATOR FOR HSTM QA/QX MONITORING

“Conductivity” (or its temperature-corrected correlative, specific conductance) is widely recognized as a useful, easy-to-measure surrogate for total dissolved solids (TDS) (e.g., Minton 2003; Ecology 2011). As with temperature, causes of high TDS are varied and include both natural sources and stormwater inputs. Natural waters in most settings have low TDS and thus low conductivity; elevated levels from human activity include wash-off from streets, fertilizers, industrial discharges, and soil erosion.

As summarized by the USEPA (<https://www.epa.gov/national-aquatic-resource-surveys/indicators-conductivity>):

“Conductivity is a measure of the ability of water to pass an electrical current. Because dissolved salts and other inorganic chemicals conduct electrical current, conductivity increases as salinity increases. Organic compounds like oil do not conduct electrical current very well and therefore have a low conductivity when in water. Conductivity is also affected by temperature: the warmer the water, the higher the conductivity.

“Conductivity is useful as a general measure of water quality. Each water body tends to have a relatively constant range of conductivity that, once established, can be used as a baseline for comparison with regular conductivity measurements. Significant changes in conductivity could then be an indicator that a discharge or some other source of pollution has entered the aquatic resource.

“Significant changes (usually increases) in conductivity may indicate that a discharge or some other source of disturbance has decreased the relative condition or health of the water body and its associated biota. Generally, human disturbance tends to increase the amount of dissolved solids entering waters which results in increased conductivity. Water bodies with elevated conductivity may have other impaired or altered indicators as well.”

The potentially greatest value of this indicator is its ease of collection and its high correlation to other sediment-related measures (Miguntanna et al. 2010), particularly total suspended solids, which in turn has widely recognized ecological impacts at elevated levels and can be driven both directly by land-use activities (particularly land-surface erosion) and indirectly via hydrologic alteration (resulting in stream-channel erosion from high flows).

Roy et al. (2003) conducted a comprehensive assessment of physical, chemical, and biological conditions in 30 streams along a rural-to-urban gradient in the Piedmont region of the southeastern US. They emphasized the high degree to which specific conductance (i.e., conductivity normalized to 25°C) correlated with both land use and to biological impairment. They parameterized SC as the annual average value of multiple baseflow measurements, and summarized their findings as follows:

“The consistently strong relationships we observed between biotic indices and SC [specific conductance] indicate that increased SC may lead to biotic impairment of surface waters. Other studies have also found a strong relationship between SC and land cover (Omato et al., 2000) and have determined predictive relationships between SC and changes in macroinvertebrate assemblages (Tate & Heiny, 1995;

Imert & Stanford, 1996). Specific conductance might be a good indicator of sediment disturbance as a source of increased ions (in addition to ion input via catchment run off), as it was positively correlated with decreased riffle and emergent bar particle size. Thus, its inclusion in the regression models may partially be due to its relationship with these variables, or as a surrogate ‘chemical signal’ from increased non-point sources in the catchments (e.g. fertilisers, pesticides, sediment), as suggested by its relationships with forest land cover and ammonium concentration.” (p. 340)

King County Water and Land Resources Division has maintained a modest set of continuously recording conductivity meters in small streams throughout the central Puget Lowland. Eight such sites have about four years of data; one additional site (Miller) has less than a single year, but its unique location (draining a significant portion of SeaTac Airport, and with the highest fraction of watershed urban land cover) make it an instructive additional example.

The raw data (available from the King County Hydrologic Information Center at <http://green2.kingcounty.gov/hydrology/>) expresses a well-understood phenomenon—when discharge increases, SC decreases as a result of dilution. When plotted on appropriate scales, the hydrograph and the plot of SC over time are near-perfect inverses of each other (Figure E-1).




Figure E-1. Example graphs of continuous conductivity measurements at two King County gage sites. Note the near-perfect opposite oscillations of conductivity and discharge, albeit on very different scales of measurement. The average value of conductivity over the period of record is shown by the dashed red line for each; they are markedly different for the suburban site (Seidel Creek) and the more intensively urban site (Miller Creek).

Most noteworthy is the substantial difference in average SC values for these two examples, presumably reflecting influences of both groundwater composition and contributions of urban runoff (Seidel Creek has 16.9% urban land cover, Miller Creek has 80.7%). Considering all nine gages, a broad pattern between watershed urbanization and conductivity emerges (Figure E-2), although the outlying position of Miller Creek is what drives any apparent relationship. The low-urban sites have values that range from about 30 to over 130 $\mu\text{ohms/cm}$, suggesting that this range is indicative of regional conditions without significant human influence. Note, however, that even the moderate-urban sites (e.g., Talyor U/S, Seidel) also fall within this range.




Figure E-2. All sites with conductivity data, plotting their record-averaged conductivity value against their 2011 watershed urban land cover. There is no evident relationship except that the one high-urban site has a significantly greater conductivity value than the others.

Overall, there are no apparent trends across the period of record on any gage. Seidel Creek experienced the most rapid increase in urban land cover of all watersheds during the 2001–2011 period, but inspection of its conductivity graph (Figure E-1, top) suggests no significant trend.

Conclusions

The relative paucity of existing data, and its apparent insensitivity to all but the largest of land-use differences or changes, suggest that monitoring for this parameter may only identify heavily impacted systems that could be readily identifiable by other means. It also suggests that trends as a result of incremental management or land-use changes are unlikely to be detected until an indeterminate (but undoubtedly large) number of years have passed. Nevertheless, its inclusion is supported by the ease of data collection, the previously recognized correlation of this parameter with both watershed impacts and biological health, and the potential for expanding what is currently a very limited data set to support a better regional understanding of such conditions.

References

Ecology. 2011. 2012 Status and trends stormwater monitoring and assessment strategy for small streams—an addendum to quality assurance monitoring plan status and trends monitoring for watershed health and salmon recovery. Draft.

GeoSyntec Consultants and Wright Water Engineers. 2011. International stormwater Best Management Practices (BMP) database pollutant category summary: solids (TSS, TDS and turbidity). Available from <http://www.bmpdatabase.org>

Miguntanna, N. S., P. Egodawatta, S. Kokot, and A. Goonetilleke. 2010. Determination of a set of surrogate parameters to assess urban stormwater quality. *Science of the Total Environment* 408: 6,251–6,259.

Minton, G. R. 2003, Stormwater treatment—biological, chemical, and engineering principles: Seattle, WA. Resource Planning Associates.

Roy, A. H., A. D. Rosemond, M. J. Paul, D. S. Leigh, and J. B. Wallace. 2003. Stream macroinvertebrate response to catchment urbanisation (Georgia, U.S.A.). *Freshwater Biology* 48: 329–346.

FINAL TECHNICAL REPORT • SEPTEMBER 2016

Habitat Status and Trends Monitoring for the Lower Columbia Region: Quality Assurance Project Plan for the Urban Monitoring Program



PREPARED FOR

Lower Columbia Fish Recovery Board
2127 8th Ave.
Longview, WA 98632

PREPARED BY

Stillwater Sciences
108 NW Ninth Ave., Suite 200
Portland, OR 97209

- Part 1: Implementation Plan Report
- Part 2: Quality Assurance Project Plan for
the Urban Monitoring Program
(Urban HSTM QAPP)
- Part 3: Quality Assurance Project Plan for
Regional Monitoring Program
(Regional HSTM QAPP)

Cover photos clockwise from top left: Monitoring on Burnt Bridge Creek (photo provided by City of Vancouver); Stillwater staff monitoring dissolved oxygen; LCFRB staff assessing habitat in the Hamma Hamma River (photo provided by LCFRB); turbidity sampling in Longview (photo provided by City of Longview).

Habitat Status and Trends Monitoring in the Lower Columbia Region

Part 2: Quality Assurance Project Plan for the Urban Monitoring Program

Prepared by:
Stillwater Sciences
for the Lower Columbia Fish Recovery Board and the City of Longview
Funded by Washington Department of Ecology Grant G1400531
July 2016

APPROVED BY:

Signature: _____

Steve Manlow, Project Manager Lower Columbia Fish Recovery Board

Date: _____

Signature: _____

Karen Dinicola, Washington Department of Ecology

Date: _____

Signature: _____

Chad Larson, Washington Department of Ecology

Date: _____

Signature: _____

Jeff Breckel, Director Lower Columbia Fish Recovery Board

Date: _____

Signature: _____

Jody Lando, Stillwater Sciences

Date: _____

Signature: _____

Derek Booth, Stillwater Sciences

Date: _____

Signature: _____

To Be Determined, Lab Director

Date: _____

Signature: _____

To Be Determined, Organization Quality Assurance Officer/Manager

Date: _____

Table of Contents – Part 2: Quality Assurance Project Plan for the Urban Monitoring Program

1	PROJECT DESCRIPTION	1
1.1	Summary of Tasks Needed to Begin Collecting Data	1
2	ORGANIZATION AND SCHEDULE.....	2
2.1	Project Schedule and Limitations	2
2.2	Budget Information for the Project.....	2
3	QUALITY OBJECTIVES.....	2
3.1	Decision Quality Objectives	2
3.2	Measurement Quality Objectives.....	3
4	SAMPLING PROCESS DESIGN	5
4.1	Experimental Design and Sampling Locations.....	5
4.1.1	Mid-study changes affecting site suitability.....	6
4.1.2	Field criteria for selecting a suitable sampling site	6
4.2	Representativeness.....	8
4.2.1	Field measurements.....	8
4.2.2	Laboratory measurements	8
4.3	Comparability	8
4.4	Completeness.....	8
4.5	Candidate Site List for Monitoring Sites	9
5	INDICATORS AND SAMPLING PROCEDURES FOR QA/QX MONITORING	9
5.1	Lists of Base Program and Extended Program Indicators	9
5.2	Field Sampling Procedures for Water Quality and Benthic Macroinvertebrates.....	10
5.2.1	Continuous indicators.....	10
5.2.2	Sediment metals and PAHs	11
5.2.3	Benthic macroinvertebrates.....	12
5.3	Field Safety Considerations	12
5.3.1	Wadeable streams.....	13
5.3.2	Protecting from invasive species.....	13
6	MEASUREMENT PROCEDURES	14
6.1	Laboratory Measurement Procedures	14
6.1.1	Instrument calibration.....	15
6.1.2	Duplicate/splits.....	16
6.1.3	Matrix spikes and matrix spike duplicates	16
6.1.4	Blanks and standards.....	16
6.1.5	Inter-laboratory comparison	17
6.2	Procedures for Benthic Macroinvertebrates.....	17
6.3	Procedures for Analysis of Landscape Indicators.....	18
6.3.1	List and rationale.....	19
6.3.2	Data sources	20
6.3.3	Known magnitude of classification/locational errors.....	20
6.3.4	Analytical procedures.....	20
7	QUALITY CONTROL.....	21
7.1	Field Quality Control Procedures for Water Quality Sampling.....	21
7.2	Field Quality Control Procedures for Sediment and Benthic Macroinvertebrate Sampling	22
7.2.1	Sample holding times	22
7.2.2	Composite/grab field replicate samples.....	22
7.3	Quality Control for Landscape Indicators.....	23

8	DATA MANAGEMENT	23
8.1	Data Compilation	23
8.2	Database Design for Long-Term Data Storage	24
8.3	Data Management for GIS-based Landscape Indicators	25
8.4	Data Verification and Quality Assessment	25
8.4.1	Field	25
8.4.2	Laboratory	25
8.5	Quality Assessment	26
9	AUDITS	27
10	REPORTING	27
11	REFERENCES	28

Tables

Table 1.	Acceptance thresholds for metals and PAH data	4
Table 2.	Accuracy and precision limits.	5
Table 3.	Water quality indicators for the urban+NPDES base monitoring program	10
Table 4.	Schedule for laboratory QC samples	14
Table 5.	Sample containers, amounts, holding times, and preservation for sediment and macroinvertebrate samples	22
Table 6.	Field quality control schedule for benthic macroinvertebrate and sediment samples collected	23

Appendices

Appendix A-2. Candidate Qa/Qx Monitoring Sites

Appendix B-2. Detailed Field-collection Protocols

1 PROJECT DESCRIPTION

This QAPP is for the Urban-Area Water Quality and Quantity (Qa/Qx) component of the Lower Columbia Habitat Status and Trends Monitoring (HSTM) Program. A detailed project description and background information are provided in Part 1: Implementation Plan Report. The information below is provided to ensure quality data collection and analysis to meet the HSTM objectives, which broadly seek to characterize the status and trends of stream conditions across the Lower Columbia Region. A set of indicators will need to be measured with sufficient precision and statistical rigor to adequately characterize “status,” and over a sufficient period of time to discern any “trends.” Developing the specific approaches to meet these requirements was the primary task of the Design Report; specifying the procedures, timing, and locations for executing those approaches is the primary task of this QAPP.

This QAPP will be finalized and approved by the key signatories indicated at the beginning of this document in preparation for conducting the monitoring.

1.1 Summary of Tasks Needed to Begin Collecting Data

Candidate monitoring sites were identified in a previous HSTM program effort. The sites need to be confirmed, project staff must be identified, and equipment must be procured, accredited laboratories must be identified and selected, and the field sampling effort must be planned. The sequence of tasks required in advance of collecting data can be broadly summarized as follows:

- Identify a project manager and project staff.
 - Conduct staff training.
- Confirm the specific list of sites at which monitoring will occur.
 - Field evaluate the sites and assign site identification numbers.
 - Identify the 5-year sampling schedule.
 - Field-evaluate candidate sites for a given year based on access logistics and site security (for equipment deployment).
- Plan field sampling and maintenance visits
 - Acquire all required field sampling equipment and permanently installed sensors.
 - Develop needed field forms for monthly and summer site visits.
 - Deploy sensors at sites where continuous monitoring will occur, and initiate regular monthly maintenance schedule.
 - Plan and implement summer-season visits to collect stream benthos at all sites.
- Select qualified laboratories.
 - Acquire necessary sample collection containers and chain of custody sheets.
- Complete final QAPP and submit for approval.

2 ORGANIZATION AND SCHEDULE

2.1 Project Schedule and Limitations

A detailed program schedule will be developed by Program Managers responsible for water quality, habitat and biological monitoring. Section 1.3 of the Implementation Plan (Part 1 of this report) provides a useful example of what should result from this forthcoming effort:

The recommended schedule for this effort is:

- Site reconnaissance—begin in March 2019 to ensure landowner approval, site access, and monitoring feasibility.
- Field training workshop—prepare field crews by the end of May 2019. All field personnel should participate in trainings every year.
- Continuous data collection—begins October 1, 2019 (the beginning of the water year).
- Summer season data collection—July 1–September 30 annually to capture low flow conditions, ensure field crew safety and avoid spawning fish and emerging fry in Lower Columbia tributaries. Sites at higher elevation should be sampled later in the season to allow flows to decrease following snowmelt.

2.2 Budget Information for the Project

As detailed in the Implementation Report, the anticipated total cost of the Qa/Qx monitoring base and extended components is \$127,000, which consists of annual costs for the recommended base monitoring as described in this QAPP (\$68,000) and the extended monitoring (\$59,000). The amount of funding collected for the program in the five-year permit cycle is not expected to increase; however, all costs are expected to increase by the time this program is implemented. The final QAPP will make reasonable adjustments to the scope of the extended monitoring program indicator sampling to stay within the total program budget while preserving resources needed to conduct the base program.

3 QUALITY OBJECTIVES

3.1 Decision Quality Objectives

“At the level of the decision, there is a need to specify tolerable limits of making decision errors. These tolerable limits are required, along with other information, to determine the numbers and locations of samples from the site that must be collected and analyzed.” (from Ecology 2004, page B-2) [<http://www.ecy.wa.gov/biblio/0403030.html>]

Principles established during Phase 1 of the HSTM project have specified that basing future management on the results of monitoring will require a robust statistical design. In the special case of the urban+NPDES monitoring, this is being accomplished by conducting a true census design, wherein every stream that meets the specified criteria will be sampled at least once in every five-year period. In addition, the individual indicators are either being continuously collected or have a signal to noise ratio that is at least of “moderate” precision (Kaufmann et al. 1999), in order to improve the statistical likelihood that identified trends in the data are reflecting true changes in environmental variables and not just random fluctuations or errors in measurement.

3.2 Measurement Quality Objectives (MQOs)

MQOs specifically are used to address instrument and analytical performance. “At the level of measurements used to support the decision or study question, quality objectives are expressed as measurement quality objectives or MQOs. The MQOs are performance or acceptance criteria for the data quality indicators precision, bias, and sensitivity” (from Ecology, 2004 page B-2).

Because the HSTM program includes a wide variety of indicators, measurement quality objectives vary significantly between the various categories. An overarching focus for indicator selection has been to use only those metrics with relatively high levels of measurement precision and signal-to-noise. For parameters measured with on-site sensors or laboratory analysis (i.e., water temperature, sediment metals, conductivity, stage), typical values are within a few percent and will be specified more precisely when specific laboratories are selected and specific instrumentation is identified. Table 1 shows the draft acceptance thresholds for metals and PAH data to be collected through sediment sampling.

Table 1. Acceptance thresholds for metals and PAH data.

Sediment parameters for bioassessment	Analysis methods in sediment MQO	Reporting limit target	Lab replicate (RPD) ¹	Matrix spike ² (% recovery)	Matrix spike duplicate (RPD) ¹	Control standard/surrogate (% recovery)
		Sensitivity	Bias and precision	Bias and accuracy	Bias and precision	Bias and accuracy
Grain Size on <2 mm sieved sediment	PSEP, 1986 sieve and pipette or ASTM D422	Sensitivity = 1.0%	≤20%	n/a	n/a	n/a
Metals: (Ag, As, Cd, Cr, Cu, Pb, Zn)	EPA Method 6020A or 200.8 (ICP-MS)	(0.1, 0.2, 0.1, 2.0, 0.5, 0.5, 5.0) mg/kg dw	≤20%	75–125	≤20%	85–115 (spiked blank) ERA Soil ⁴ 80–120 (As, Cd, Cu, Pb, Zn) 74–126 (Ag) 79–120 (Cr)
Polycyclic aromatic hydrocarbon (PAH) compounds ⁴	EPA 8270D (GC-MS)	70 µg/kg dw	Compound specific ≤40%	Compound Specific 50–150	≤40%	Spiked blank compound-specific 50–150 ³ SRM 1944 compound-specific 40–200 ⁵

EPA: Environmental Protection Agency Method (http://water.epa.gov/scitech/methods/cwa/methods_index.cfm).

SM: *Standard Methods for the Examination of Water and Wastewater* (www.standardmethods.org).

PAH compounds include: 1-methylnaphthalene, 2-methylnaphthalene, acenaphthylene, acenaphthene anthracene, benzo(a)anthracene, benzo(a)pyrene, benzo(b, j and k) fluoranthene, benzo(ghi)perylene, dibenzo(a,h)anthracene, carbazole, chrysene, fluoranthene, fluorene, indeno (1,2,3-cd)pyrene, naphthalene, phenanthrene, pyrene, and retene.

RPD: Relative percent difference.

¹ The RPD is calculated when at least one of the result values is above the practical quantitation limit; if both values are below then the RPD is not calculated.

² For inorganics, the *Laboratory Program Functional Guidelines* state that the spike recovery limits do not apply when the sample concentration exceeds the spike concentration by a factor of 4 or more (USEPA 2010).

³ Semivolatile surrogate recoveries are compound-specific. MQOs are based on Johnson (2005) and Dutch et al. (2010).

⁴ ERA solid LCS, “Metals in Soil”. The catalogue number is 540; the lot number for the current KCEL aliquot in-house is e D081-540.

⁵ SRM 1944, “New York/New Jersey Waterway Sediment”. This Standard Reference Material (SRM) is a mixture of marine sediment collected near urban areas in New York and New Jersey. SRM 1944 is intended for use in evaluating analytical methods for the determination of selected polycyclic aromatic hydrocarbons (PAHs), polychlorinated biphenyl (PCB) congeners, chlorinated pesticides, and trace elements in marine sediment and similar matrices.

For continuous parameters (stage, temperature, and conductivity), the accuracy and instrument bias measurement quality objectives (MQOs) of each sonde and/or sensor is verified through post-deployment calibration checks following the manufacturer's procedures (Swanson 2007).

In addition, deployment, mid-deployment, and retrieval measurements using hand-held probes at the deployment location will be used to evaluate the accuracy criteria in Table 2. Note that the accuracy criteria also include errors associated with the instantaneous measurement results. Grab sample data may be used to first correct continuous data for linear drift or a constant offset. This will be done prior to evaluating accuracy and precision if the mean difference between grab sample and LDO results is greater than 2%.

Table 2. Accuracy and precision limits.

Parameter	Accuracy	Precision (% relative standard deviation)
Stage	±0.1 ft	10
Temperature	±0.4°C	10
Conductivity	±µS/cm or 10%, whichever is greater	10

Continuous data will be compared to post-calibration checks and grab sample results. Differences not meeting criteria in Table 2 may result in the affected data set being qualified or rejected, depending on the amount of difference and the number of checks that failed to meet the criterion. Precision MQOs are to be compared against the average relative standard deviation of data pairs collected during a deployment (Mathieu 2007).

Measurements of wetted width and depth will be taken by field staff during each site visit; measurements of substrate composition and bankfull width and depth will be taken during the sample collection event for sediment metals and PAHs. All field staff will follow the collection methods, reporting requirements, and quality control (QC) procedures summarized in this QAPP. This approach will provide field measurement data that meet measurement quality objectives (MQOs) for status and trends monitoring for small streams as described in this section.

Field staff will make a good faith effort to collect monitoring data described per QAPP requirements. If a water quality sample or measurement is missed on occasion, a second effort will be made to collect the sample within the same month. If a second attempt is also unsuccessful, then the Program Manager will be notified, and a third attempt is not required.

Reasons a sample or measurement may not be made include, but are not limited to: a stream goes dry; the stream site cannot be accessed due to high flow conditions, vandalism, extreme climatic conditions, or monitoring equipment has a sudden failure. Water quality samples and measurements made during very high flows may be made from anywhere within the site reach.

4 SAMPLING PROCESS DESIGN

4.1 Experimental Design and Sampling Locations

Sample site selection and evaluation occurs at two levels in this program. The first level involved the stratification of the target population into physically meaningful strata, appropriate to the

monitoring activities and intended uses of the data, by use of GIS characterization of the stream and watershed characteristics associated with each point in the Master Sample. The second level, the actual determination of whether monitoring can occur at the designated location, is covered below.

Within the urban+NPDES areas of the region, given the selection of a single stratum (stream segments with watersheds draining 2.5–50 km² and predominately urban land cover) and the presence of preexisting sampling locations (the legacy sites of Clark County and the City of Vancouver), all identified segments are presumed to have suitable access and security somewhere along their length. The design also anticipates sampling every qualifying segment within the 5-year rotating panel, resulting in true *census* sampling rather than *representative* sampling. The list of stream segments and precise monitoring locations will be confirmed in the process of completing the final QAPP for field sampling, which will include a field visit to each candidate site. Final site suitability will be determined by selection criteria related to accessibility, hydrologic and geomorphic characteristics (flow, physical features, and salinity), and location relative to a candidate sites' original coordinates

“Sites” are considered the entire stream segment along which the criteria of drainage area and land cover are met (see Figure 2 for their graphical display). Where a legacy site exists along a designated segment, it will presumably function as the actual monitoring location for this program. For those designated segments without a legacy site, desktop identification of prospective sampling location(s) should proceed from downstream to upstream, targeting the most promising locations for subsequent field checking. Preference should be given to the downstream-most location that meets all criteria for access, safety, security, and flow suitability.

4.1.1 Mid-study changes affecting site suitability

If a site becomes unsuitable for sampling during the course of the study, the Monitoring Coordinator will be notified. Reasons a site may become unsuitable include, but are not limited to: a stream goes dry; the adjacent parcel(s) change ownership, and the new owner does not grant permission; or natural causes such as mudslides or animals make the site no longer safe to access. A decision about whether to simply discontinue the site or to identify a replacement site within the same strata combination will be made by project partners on the basis of its position in the rotating panel design, the amount of data already collected, and whether the strata combination would become underrepresented if the site (and, potentially others) were simply discontinued without replacement.

4.1.2 Field criteria for selecting a suitable sampling site

The process may need to continue through the sampling season as necessitated by potential changes in site conditions that affect suitability for sampling. Selection criteria for determining the suitability of a candidate site for monitoring to meet the HSTM goals are described below.

4.1.2.1 Accessibility criteria

These criteria concern whether land owners permit access to a site, and if the site can be safely accessed and sampled throughout the year. A site may also be deemed unsuitable or impractical for sampling certain if more than one hour is required to access the site from the nearest parking location.

If a candidate site is not obviously accessible through public property, property owners and/or tenants whose property will need to be accessed will, if feasible, be contacted prior to site evaluation. Parcel information gained from the desktop evaluation will be researched and a good faith effort to contact owners or tenants will be made. A site will be deemed unsuitable for sampling if permission has been denied by all land owners, tenants, or resource managers along the entire hydrologic reach. The Washington State Department of Natural Resources (WDNR 2010) describes how to discern public and state-owned waters.

Overall safety conditions for access and sampling will be assessed prior to sampling, based on state and federal law and organizational policy. But it is ultimately the responsibility of the field crew at each time of arrival to decide if it is safe to enter the stream to conduct the sampling. Appropriate reasons for disqualifying a site from sampling may include:

- flow is too swift or too deep;
- route of entry is unstable;
- hostile people or animals are present.

Site security for installation of long-term continuous sampling equipment is also a consideration. The field crew will make a judgment call as to whether equipment is likely to be subject to tampering or vandalism.

4.1.2.2 Flow, physical, and salinity criteria

These criteria concern the conditions of the stream and streambed with regard to the specific types of data desired. To be considered a suitable sampling site, the waterbody at the candidate site coordinates must be on a stream or small wadeable river, and not on a lake, pond, wetland, or estuary. Specifically, the waterbody must have:

- a net flow of water that is unidirectional;
- defined left and right banks readily discernible from mid-stream;
- uninterrupted surface-water flow for more than half the length of approximately 20 bankfull widths or a minimum of 150 meters surrounding the candidate site coordinates;
- perennial flow (as best as can be determined at the time of the site visit);
- flow in a natural channel that might have been highly modified, but was not constructed (such as canals, ditches, or pipelines);
- natural substrate on the channel bottom; and
- Freshwater, as defined by a water column with more than 95 percent of its depth with less than 1 part per thousand salinity at any time during the year.
 - Multiple lines of evidence may be used to make this estimation (*e.g.*, vegetation, proximity to a known estuary, or salinity measurement).
 - As noted in the Design Report, streams subject to backwater from the Columbia River are not considered suitable sampling sites for this program.

4.1.2.3 Location criteria

The most-downstream feasible location on the stream segment will serve as the suitable sampling location.

4.2 Representativeness

“Representativeness” is a property of both the region being assessed and the parameter being measured (Ecology 2006). The probabilistic sampling design is intended to achieve statistically valid spatial representations of stream status and trends at the scale of the entire Lower Columbia Region. Field measurements (except for those made by continuous data-collecting sensors) will be conducted in the summer, a period when hydrologic, physical, and biological conditions are most stable and the likelihood of confounding high flows is low. Ensuring that the laboratory measurements of field-collected samples are representative of those field conditions, established procedures for sample holding time, equipment calibration, and analytical duplicates as described for each parameter below.

Representativeness of water-quality parameters is particularly enhanced by the Design Report’s emphasis on collecting continuous water-column parameters in real time, eliminating the uncertainties associated with the time-varying nature of most water-column constituents.

4.2.1 Field measurements

Most of the field measurement and data collection for the urban+NPDES monitoring will be conducted at the downstream-most location of an identified stream segment that meet criteria for feasible logistics for access and site security. Most of the indicators are in the water column and are not anticipated to vary greatly throughout the stream segment. For those with collection at specific locations and with particular site requirements (i.e., sediment metals and PAHs, and macroinvertebrates), the conditions necessary for representative field measurements are specified in this document as part of the measurement protocols (Section 5.2).

4.2.2 Laboratory measurements

Typical protocols to ensure the representativeness of lab data is to provide triplicates of every 20th sample, with a goal of <5% variability as the standard. This provides a high confidence that each sample accurately reflects a representative value of the measured parameter. Because each year’s sampling under this program will only include ten water-quality samples for laboratory analysis, however, this guidance should be modified to randomly select one of those ten samples each year for triplicate measurement.

4.3 Comparability

Field methods will be documented in sufficient detail to ensure comparable results. The selection of indicators has been guided by the need to avoid those with recognized high levels of observer variability, and so many of the problems of (in) comparability that plague other such monitoring efforts have been addressed through the initial design. For the continuous indicators, field sensors will be similar or identical at all sites, and episodic calibration with hand-held sensors will ensure that the data are equivalent across all sites.

4.4 Completeness

Completeness will be calculated as a percentage of the number of valid samples that should have been collected relative to the number that actually are obtained. The standard for completeness is 90% in order that the data can be determined as valid in proportion to the goals for the project as a whole.

4.5 Candidate Site List for Monitoring Sites

The candidate list for Qa/Qx monitoring is also provided in Appendix A-2 with a total of 22 sites available.

5 INDICATORS AND SAMPLING PROCEDURES FOR QA/QX MONITORING

5.1 Lists of Base Program and Extended Program Indicators

The Qa/Qx indicators recommended for this HSTM program have been identified on the basis of historic utilization and regional experience, prior recommendations from Phase 1 of this project (and archived in Tetra Tech 2013), known issues with data quality and variability, cost of implementation, and direct relevance to the monitoring questions that are guiding this program. Relative to many other water-quality monitoring programs, the most noteworthy aspects of this recommended program are its emphasis on continuously monitored (or otherwise integrative) indicators, and the overall brevity of the list. These outcomes are driven by considerations long-articulated by project partners and stakeholders: statistical and scientific rigor of the chosen indicators, and feasible cost of implementation.

Two sets of Qa/Qx indicators have been defined for this program. The “base program” indicators are expected to meet the requirements of the upcoming 2018 Municipal Stormwater NPDES Permit’s Special Condition S8 Monitoring and Assessment, subsection B Status and Trends Monitoring, and they are listed in Table 3.

In addition, permittees have also expressed the desire to collect an “extended” set of indicators that will be collected at the same sites, and following the same panel design as for the base indicators, to the extent that sufficient funds are available. The field and laboratory methods, protocols, and data quality objectives for the extended monitoring program are in development and will be provided at a later time. It is anticipated that they will be closely aligned with the Quality Assurance Program Plan (QAPP) for the Puget Sound Regional Stormwater Monitoring Program.

Table 3. Water quality indicators* for the urban+NPDES base monitoring program.

Water quality indicators	Recommendation
Water temperature	X ^c
Sediment metals	X ⁵
Sediment PAHs	X ⁵
Conductivity	X ^c
Other indicators	
Stage (surrogate for flow)	X ^c
Macroinvertebrate index (B-IBI)	X ^a
Habitat indicators at Qa/Qx sites	
Bankfull width, depth	X ⁵
Wetted width, depth	each visit
Substrate composition	X ⁵

* Indicators previously labeled “metrics” in the Monitoring Design Report

X⁵ = data collection once per 5-yr permit cycle

X^a = annual data collection

X^c = continuous collection

5.2 Field Sampling Procedures for Water Quality and Benthic Macroinvertebrates

Even before field measurements are taken, established procedures are required to ensure the highest degree of data quality. Field equipment will undergo routine cleaning, calibrations, and maintenance at the recommended frequency specified by each manufacturer and described in SOPs. For samples that require laboratory analysis (sediment metals, sediment PAHs, and benthic macroinvertebrates), chain-of-custody (COC) procedures are necessary to ensure thorough documentation of handling for each sample, from field collection to laboratory analysis. The purpose of this procedure is to minimize errors, maintain sample integrity, and protect the quality of data collected. A COC form will accompany each cooler of samples sent to a laboratory. Individuals who manipulate or handle these samples are required to log their activities on the form. When the laboratory receives a cooler of samples, it will assume responsibility for samples and maintenance of the COC forms. The laboratory will then conduct its procedures for sample receipt, storage, holding times, tracking, and submittal of final data to the responsible parties.

5.2.1 Continuous indicators

The sampling procedures will follow the detailed descriptions in Appendix B-2. Loggers will be deployed in locations where representative data may be obtained throughout the entire monitoring period. Combination probes for all three continuous parameters listed below may prove to be the most economical and feasible approach. All loggers will be deployed inside a ~2-foot-long piece of 1.5-inch camouflage-painted PVC pipe to shade them from sunlight and to prevent them from being found and vandalized. In addition, each deployment location will be photographed and have site-specific survey information documented on a standardized form. For all of the continuous indicators, the accuracy and instrument bias of each sensor will be verified through

post-deployment calibration checks following the procedures described in Swanson (2007) and with deployment, retrieval, and monthly grab check samples collected as described in Ward (2007).

- **Water Temperature:** Temperature loggers (e.g., VEMCO Minilog-II-T-351133) will be installed following manufacturer's instructions and downloaded on a regular basis, as determined by battery life and memory capacity. Spot checks during each visit will be made of temperature using a hand-held thermometer, with the time and temperature recorded in a field notebook for subsequent checking with the downloaded data to ensure that data-quality objectives are being met. The sampling protocols will follow the procedures described in the *Continuous Temperature Sampling Protocols for the Environmental Monitoring and Trends Section* (Ward 2003) and in the *TFW Stream Temperature Survey Manual* (Schuett-Hames et al. 1999).
- **Stage:** Stage will be collected by permanent installation of a pressure transducer, following the manufacturer's instructions (e.g., those for the Solinst Leveloggers are available at <http://www.solinst.com/Prod/3001/Levelogger-User-Guide/10-Levelogger-Installation-Maintenance/10-Installation.html>). Manual stage measurements are also needed so data are available to confirm/correct the pressure transducer data (Appendix E-5 of the RSMP QAPP; Ecology 2014). Barologgers could be deployed to monitor atmospheric pressure conditions at each site, although the added expense is likely unnecessary given the intended uses of the stage data and the relative magnitude and rate of change of the atmospheric correction.
- **Conductivity:** A conductivity probe (e.g., YSI 600LS) will be installed and maintained following manufacturer's instructions.

5.2.2 Sediment metals and PAHs

This section draws on sediment sampling protocols for sampling and sieving composite sediment samples in streams from USGS National Field Manual (USGS 2005) and NAWQA protocols (USGS 1994) (Appendix C-4 in Ecology 2014), which in turn are derived from methods described in Manchester Environmental Laboratory (2008). Additional references cited as sampling protocols in Ecology (2014) (namely, Blakley 2008, Johnson 1997, Radke 2005, and Shelton and Capel 1994) are not included in that document's reference list and are unavailable.

A composite sample will be collected at each stream segment, composed of 5 individual shallow-water sub-stations. Specific locations within a Qa/Qx sampling segment will be identified by field inspection to identify locations of water-deposited fine sand and silt-sized material, typically in alcoves and backwater areas, that have not been directly affected by local bank erosion. The composite sample will be delivered to the lab, where it will be processed (sieved) to make two unique samples. The first sample will be sieved to less than 2.0 mm and analyzed for multiple organic compounds (PAHs). The second sample will be sieved to less than 63 μm and analyzed for metals (testing for the same analytes as for the RSMP small streams program: arsenic, cadmium, chromium, copper, lead, silver and zinc). Prior to use, all equipment will be cleaned for organics and all sediment samples will be collected and handled with Teflon scoops, scrapers, and spatulas. Samples will be stored in glass only, held in coolers with ice after collection to maintain a temperature $\leq 6^{\circ}\text{C}$, and delivered to the lab within 7 days following the chain-of-custody procedures outlined above (USEPA 1982).

Specifications for minimum volumes of collected sediment will be made in conjunction with the determination of analytical laboratories to process the material. This will be about 10 g (dry weight) of sieved sediment.

5.2.3 Benthic macroinvertebrates

Sampling will follow established State of Washington protocols (Larson 2015). This method describes how to collect benthic macroinvertebrate samples for conducting community-level assessments in Washington's Status and Trends Program.

Invertebrate sampling is one of the first methods to be performed on-site, after site verification and layout. It starts concurrently with water sampling, with initial components of the benthos sample collected downstream of the water sample. Working upstream, one kick sample is collected at each of 8 randomly selected transects, half of which are located mid-channel and half located within the margins of the stream. Each kick sample will be added to a composite sample for the site.

A different procedure is needed for the collection of each kick sample depending upon whether the station sits within flowing water or slack water. Flowing water is where the stream current can sweep organisms into the net; slack water is where water is so slow that active net movement is required to collect organisms.

- For sampling at flowing water stations, position a D-frame kick net and quickly and securely on the stream bottom to eliminate gaps under the frame. Collect benthic macroinvertebrates from a 1 ft² (0.9 m²) quadrat located directly in front of the frame mouth. Work from the upstream edge of the quadrat backward and carefully pick up and rub stones directly in front of the net to remove attached animals. Quickly inspect each stone to make sure you have dislodged everything and then set it aside.
- For sampling at slack water stations, visually define a rectangular quadrat with an area of 1 ft² (0.09 m²). Inspect the stream bottom within the quadrat for any heavy organisms, such as mussels and snails. Remove these organisms by hand and place them into the sample jar. Pick up any loose rocks or other larger substrate particles within the quadrat and rub any clinging organisms off of rocks or other pieces of larger substrate (especially those covered with algae or other debris) into the net. Vigorously kick the remaining finer substrate within the quadrat with your feet while dragging the net repeatedly through the disturbed area just above the bottom.

For preservation, ethanol will be added to each sample jar so that the resulting solution consists of 1/3 sample and 2/3 ethanol. The sample jars will be stored by field crews and delivered *en masse* to the analytical laboratory at the end of the field season.

5.3 Field Safety Considerations

In any field data collection effort, there can be significant risks. It is the responsibility of each crew member, not just the crew lead, to insure the health and safety of crew members. A written health and safety plan must be prepared prior to the commencement of field activities. The health and safety plan must include at a minimum: phone numbers and a communication tree for notification should an emergency occur; maps to the nearest hospital, fire station, and/or emergency response facility; and the enumeration of the anticipated potential hazards.

All crew members must review and sign the health and safety plan during a field work "tailgate" kick-off meeting. During the tailgate meeting, the crew lead will summarize the potential hazards

and ensure that all crew members are aware of safety procedures and appropriate lines of communication.

At least two crew members must be present during all field sampling activities. In areas where water or sediment contamination is known or suspected, exposure to water and sediments should be minimized. Crews may encounter hazardous materials, or sample preservatives may be hazardous if handled inappropriately. Crews should not disturb or retrieve improperly disposed hazardous materials. Field personnel should be familiar with the signs of heat stroke and hypothermia, and there should always be at least one person trained in first aid and CPR on every field crew.

5.3.1 Wadeable streams

Common hazards in wadeable streams include slip, trip and fall hazards; submerged objects; poisonous snakes, insects, and plants; and adverse weather conditions.

- Field crews must wear appropriate personal protective equipment (PPE), including waders (or at a minimum neoprene booties), hats, sunglasses (or safety goggles as needed), and should use sunscreen on exposed skin.
- When waders are worn, they must be equipped with a belt
- Extreme care should be used when walking on rip rap as rocks can easily shift
- Large woody debris (LWD) must be navigated carefully to avoid falls or getting pinned between pieces of debris
- First aid kits must be available at all times
- Appropriate gloves must be worn when agitating substrate for the collection of benthic macroinvertebrates
- Personnel with allergies to bees, other insects, poison oak, etc., must take proper precautions and have needed medications at the ready
- Motor vehicles must be operated with care and in observance of all applicable laws and regulations.
- Crews in remote locations must be equipped with radios or satellite phones.
- Crew leads must ensure that all equipment is in safe working order
- Sampling should be discontinued during thunderstorms

5.3.2 Protecting from invasive species

After conducting field work, field staff will:

Inspect and clean all equipment by removing any visible soil, vegetation, vertebrates, invertebrates, plants, algae or sediment. If necessary, a scrub brush will be used then rinsed with clean water either from the site or brought for that purpose. The process will be continued until all equipment is clean.

Drain all water in samplers or other equipment that may harbor water from the site. This step will take place before leaving the sampling site or at an interim site. If cleaning after leaving the sampling site, no debris will leave the equipment and potentially spread invasive species during transit or cleaning.

6 MEASUREMENT PROCEDURES

This section discusses the laboratory (for water quality samples) procedures and analytical procedures (for GIS-based land cover data) that will be implemented to provide high quality data. Field QC procedures were previously described as part of the Quality Control Procedures – Field section of this report. QC will be monitored throughout the duration of the study. The quality of raw, unprocessed, and processed data is subject to review according to established protocols (below).

6.1 Laboratory Measurement Procedures

This section discusses QC procedures that will be implemented by the contracted analytical laboratory to provide high quality chemical and physical analyses that meet these QAPP requirements. Sediment metal and PAH analyses will be conducted at a laboratory or laboratories to be determined in consultation with the Steering Committee and Technical Review Community (see Appendix A-2). Ecology's Laboratory Accreditation Program maintains a searchable database that may be accessed from this website: <http://www.ecy.wa.gov/programs/eap/labs/lab-accreditation.html>. Contract laboratories will make every effort to meet sample holding times and target reporting limits for all parameters. Laboratory QC procedures and results will be closely monitored throughout the duration of the sampling.

The schedule for laboratory QC samples is shown in Table 4 and, at a minimum, includes:

- Laboratory duplicates
- Matrix spikes
- Matrix spike duplicates
- Method/instrument blanks
- References (lab standards/surrogate standards/internal standards)

Table 4. Schedule for laboratory QC samples.

Quality control sample ¹	Analysis type	Frequency ²	Corrective action
Laboratory Duplicates	Metals	5% of total samples, minimum 1 per batch (method-specific)	Evaluate procedure; reanalyze or qualify affected data
	Organics		
Matrix Spikes (full constituent list)	Metals	5% of total samples, minimum 1 per batch	Evaluate procedure and assess potential matrix effects; reanalyze or qualify data
	Organics	5% of total samples, minimum 1 per batch	Evaluate duplicates and surrogate recoveries and assess matrix effects; evaluate or qualify affected data
Matrix Spike Duplicates ³	Metals and Organics	At least 1 sample per year; Metals can be run either by MSD or lab duplicates at otherwise; 5% of total samples, minimum 1 per batch	Evaluate procedure and assess potential matrix effects; reanalyze or qualify data

Quality control sample ¹	Analysis type	Frequency ²	Corrective action
Method Blanks	Metals	5% of total samples, minimum 1 per batch (method-specific)	Blank concentration may be used to define a new reporting limit. Evaluate procedure; ID contaminant source; reanalyze samples if blanks are within 10x concentration. No action necessary if samples are >10x blank concentrations
	Organics		
Spiked (or Fortified) Blanks	Metals and Organics	5% of total samples, minimum 1 per batch (primarily water)	Evaluate matrix spike recoveries; assess efficiency of extraction method; flag affected data
References (lab control standard, lab control sample, or standard reference materials)	Metals	5% of total samples, minimum 1 per batch (spiked blank).	Evaluate lab duplicates/matrix spike recoveries; assess efficiency of extraction method; evaluate or qualify affected data
	Organics	5% of total samples, minimum 1 per batch (spiked blank).	
Surrogates	Organics	Surrogates frequency is 100%	Evaluate results; qualify or reanalyze or re-prep/reanalyze samples.
Internal Standards	Metals and Organics	Internal Standard frequency is 100% for GC/MS and ICPMS methods	Evaluate results; dilute samples, reassign internal standards or flag data.

¹ Quality control samples may be from different projects for frequencies on a per-batch basis.

² Frequencies may be determined from the study number of samples collected by the permittee.

³ The lab may use either a matrix spike duplicate or laboratory duplicate to evaluate precision based on the method.

Typical protocols to ensure the representativeness of lab data is to provide triplicates of every 20th sample, with a goal of <5% variability as the standard. This provides a high confidence that each sample accurately reflects a representative value of the measured parameter. Because each year's sampling under this program will include less than 20 samples, however, this guidance should be modified to randomly select one of those nine samples for triplicate measurement.

QC procedures for biological samples are currently limited to field replicates precision and laboratory duplicates for accuracy for benthic macroinvertebrates. Contract laboratories will make every effort to ensure accurate identification of specimens.

6.1.1 Instrument calibration

The instrumentation used by the chosen laboratories will meet or exceed manufacturers' specifications for use and maintenance. Maintenance of this equipment will be conducted in a manner specified by the manufacturer or by the QA guidelines established by the chosen laboratory.

6.1.2 Duplicate/splits

Laboratory duplicate samples will be analyzed regularly to verify that the laboratory's analytical methods are maintaining their precision. The laboratory should perform "random" duplicate selection on submitted samples that meet volume requirements. After a sample is randomly selected, the laboratory should homogenize the sample and divide it into two identical "split" samples. To verify method precision, identical analyses of these lab splits should be performed and reported. Some parameters may require a double volume for the parameter to be analyzed as the laboratory duplicate. Matrix spike duplicates may be used to satisfy frequencies for laboratory duplicates.

6.1.3 Matrix spikes and matrix spike duplicates

Matrix spike samples are triple-volume field samples (per parameter tested) to which method-specific target analytes are added or spiked into two of the field samples, and then analyzed under the same conditions as the field sample. A matrix spike provides a measure of the recovery efficiency and accuracy for the analytical methods being used. Matrix spikes can be analyzed in duplicate (matrix spike/matrix spike duplicate [ms/msd]) to determine method accuracy and precision. Matrix spikes will be prepared and analyzed at a rate of 1/20 (five percent) samples collected or one for each analytical batch, whichever is most frequent. Use of ms/msd at the frequency of 5% of the total number of samples is common practice. For the purposes of permit monitoring, these frequencies meet the expectations.

6.1.4 Blanks and standards

Laboratory blanks are useful for instrument calibrations and method verifications, as well as for determining whether any contamination is present in laboratory handling and processing of samples.

Laboratory standards

Laboratory standards (reference standards) are objects or substances that can be used as a measurement base for similar objects or substances. In many instances, laboratories using digital or optical equipment will purchase from an outside accredited source a solid, powdered, or liquid standard to determine high-level or low-level quantities of a specific analyte. These standards are accompanied by acceptance criteria and are used to test the accuracy of the laboratory's methods. Laboratory standards are typically used after calibration of an instrument and prior to sample analysis.

Surrogate and internal standards

Surrogate standards are used to process and analyze extractable organic compounds (PAHs). A surrogate standard is added before extraction, and it monitors the efficiency of the extraction methods. Internal standards are added to organic compounds and metal digests to verify instrument operation when using inductively coupled plasma mass spectrometry (ICP-MS) analysis and gas chromatography-mass spectrometry (GC-MS) analyses.

Method blanks

Method blanks are designed to determine whether contamination sources may be associated with laboratory processing and analysis. Method blanks are prepared in the laboratory using the same reagents, solvents, glassware, and equipment as the field samples. These method blanks will accompany the field samples through analysis.

Instrument blank

An instrument blank is used to “zero” analytical equipment used in the laboratory’s procedures. Instrument blanks usually consist of laboratory-pure water and any other method-appropriate reagents, and they are used to zero instrumentation.

6.1.5 Inter-laboratory comparison

There is a recognized need to conduct an inter-laboratory comparison study if multiple laboratories will be analyzing samples. If so, the study will target 10% of the total samples (sediment metals and PAHs) for inter-lab comparison sediment samples (given the number of samples to be collected under the present design per year, this will require just one such comparison per year).

6.2 Procedures for Benthic Macroinvertebrates

This section discusses the laboratory procedures for processing benthic macroinvertebrates that will be implemented to provide high quality data. Field QC procedures will be described in Section 7 of this report and monitored throughout the duration of the study. The quality of raw, unprocessed, and processed data is subject to review according to established protocols (below).

Taxonomic identification will be conducted by a lab that employs taxonomists certified by the Society for Freshwater Science with experience with the freshwater macroinvertebrates of the Pacific Northwest. Based on guidance from the Habitat Caucus and to be consistent with other regional monitoring programs, the target subsample size will be 500 and identification will be conducted according to Level 2 of the Northwest Standard of Taxonomic Effort <http://www.pnamp.org/project/4210>.

Macroinvertebrate Sorting Efficiency

Consistent with Ecology protocols, quality control procedures for initial sample processing and subsampling involves checking sorting efficiency (Ecology 2010). These checks are conducted on 100% of the samples by independent observers who microscopically re-examine 20% of sorted substrate from each sample. All organisms that were missed are counted. Sorting efficiency is evaluated by applying the following calculation:

$$SE = n_1/n_2 \times 100$$

where SE is the sorting efficiency, expressed as a percentage, n_1 is the total number of specimens in the first sort, and n_2 is the total number of specimens in the first and second sorts combined. Sorting efficiency is recorded on each benchsheet, and this data is entered into a database. If 95% sorting efficiency is not achieved for a given sample, a failure is recorded on the benchsheet and in the database. The sorted portion of that sample is then completely re-sorted before the sorting efficiency test is repeated for that sample. Sorting efficiency statistics for each technician and for the entire laboratory are reviewed monthly. Sorting efficiency for each sample in a project is reported to the client in the technical summary document. Technicians who do not maintain the target sorting efficiency are given remedial training, and larger portions of the samples they process are examined for the sorting efficiency test until they are able to maintain the target sorting efficiency. A second evaluation of the sub-sampling process is applied to a small proportion of samples processed in each month; typically one sample per week is subjected to the following test of precision of the sub-sampling process. The procedure is only applied to samples where the target number of organisms was achieved in less than half of the Caton grids. A sample is randomly selected, and a second sub-sample is re-sorted from the unprocessed sample remnant.

A second technician performs this sort. The resulting sub-sample is identified, and Bray-Curtis similarity index is calculated for the results of both sub-samples. Results that are less than 90% similar would indicate the need for more thorough distribution of sample materials in the subsampling tray or more special attention given to easily missed taxa when sorting (i.e. increased magnification).

Taxonomic Accuracy and Precision

Taxonomic misidentification results in inadequate biological characterization of a stream. Errors in identification should be less than 5% of the total taxa in the sample. Re-identification of samples is conducted for 10% of the total number of samples in each year. Secondary identification is conducted by experienced taxonomists in order to maintain confidence in the data set. Difficult taxa should be sent to museum curators whose specialty includes members of the order in question. A voucher collection has been maintained by Ecology and is being transferred to the Orma J. Smith Museum of Natural History in Caldwell, Idaho for curation. A voucher collection should be prepared from the set of samples for the year and shipped to the address below:

The Orma J. Smith Museum of Natural History College of Idaho
2112 Cleveland BLVD
Caldwell, ID 83605-4432

Documentation necessary for acceptance by the museum will be delivered to the successful bidder with the samples.

6.3 Procedures for Analysis of Landscape Indicators

Several of the monitoring questions and objectives of the Design Report invoked a “landscape” analysis:

- Question 5: Where on the landscape are key potential land-use activities occurring?
- Question 6: Are land-cover changes occurring at detectable rates across the Lower Columbia Region, and if so where are they occurring?

They were included in the Design Report because the results of such analyses provide necessary support to other monitoring objectives, and the stratification of sampling points by the dominant land cover in their contributing watersheds provides necessary context for much of the in-stream monitoring data being collected under both the Qa/Qx and habitat elements. In addition, characterizing the status and trends of key attributes in the surrounding landscape can help separate the regional influence of natural variability from the more localized impacts (both positive and negative) of human actions.

The most feasible of these landscape attributes to monitor systematically over time are those relating to land cover, which has been systematically characterized across the entire Lower Columbia Region by the National Land Cover Database, and has compiled categorized land-cover coverage for 1992, 2001, 2006, and (most recently) 2011 (Homer et al. 2015). This data set, fully downloadable from the Multi-Resolution Land Characterization Consortium (www.mrlc.gov), provides the basis for all landscape-level analyses conducted for the HSTM project.

6.3.1 List and rationale

To maximize the accuracy of land-cover categorization and because determining the influence of particular landscape-level attributes on in-stream conditions is not a goal of status and trends monitoring, the following coarse land-cover categories were used to process and analyze the NLCD data, hereafter termed the “aggregated 2011 NLCD” (see http://www.mrlc.gov/nlcd11_leg.php for the full list of categories):

- “Urban” includes NLCD categories 21 (“Developed, Open Space”), 22 (“Developed, Low Intensity”), 23 (“Developed, Medium Intensity”), and 24 (“Developed High Intensity”);
- “Agriculture” includes NLCD categories 81 (“Pasture/Hay”) and 82 (“Cultivated Crops”);
- “Forest” includes NLCD categories 41 (“Deciduous Forest”), 42 (“Evergreen Forest”), and 43 (“Mixed Forest”);
- “Other” includes all other categories, particularly water, wetlands, ice and snow, and barren land.

These indicators were used to address those objectives of the landscape questions (see Section 1.2.1) that are critical to the implementation of the HSTM program as described in this report. Other questions and their associated objectives that were raised in the Design Report could enhance the ultimate interpretation of the monitoring data but are not essential for the program’s implementation. The effort necessary to address those objectives is also substantial, and beyond both the scope of the current effort to develop the Implementation Plan and the resources presently available from project partners. Should such resources become available, however, the following list of monitoring questions and objectives articulated in the Design Report, and their associated technical approaches should be useful:

- Watershed landcover change: What areas of the 2011 NLCD are changed from the 2006 NLCD? What is the minimum magnitude of change so identified that is likely to constitute a “true” change, given unavoidable errors in classification? (Supports Objective 6.1. of the Design Report)

The process to make this analysis would be to (a) register both grids to one another so that pixels from both datasets overlay exactly; (b) compare the pixel change between both years (both total change and change between classes); and (c) include some error or uncertainty report either based on published information or selecting a set of points from detailed imagery from either year. There is a confidence value of 70% for changes between 2001 and 2011 NLCD (Fry et al. 2008).

- Stream buffer landcover change: What areas of the 2011 NLCD are changed from the 2006 NLCD within 60-m-wide buffer zones for 1 and/or 5 km upstream of identified sampling site? (Supports Objective 6.2.)

The process to make this analysis would be to (a) select a set of sampling sites, (b) identify its location on the NHD High dataset, (c) “travel” upstream 1 or 5 km and define the upstream point, (d) split and buffer the lines, and (e) overlay the buffers with the land cover change dataset obtained in (a).

- Discriminate “recent” (less than ~20 years) forest harvest areas using the NLCD. What watersheds have this as a dominant land cover? (Supports Objective 2.2.); identify “mature” (greater than ~20 years) forested areas using the NLCD (i.e., distinct from other “forested” areas? (Supports Objective 5.1.)

For these two evaluations, use of the 2002 NLCD dataset would be most appropriate to use. Using the Land Cover change developed in the first analysis, comparison of the two classified images would provide answers to these questions.

- Identify subwatersheds in the range of 2.5-50 km² with a single “dominant” land cover type (i.e., >50% urban, forested, or agriculture) over the entire Lower Columbia Region. (Supports Objective 5.1.)

This analysis has already been run on spatially restricted areas within the Lower Columbia Region to identify those Master Sample points draining watersheds with predominately “urban” or “agricultural” land cover. It has also been run on those points randomly selected for sampling. To comprehensively apply the same analysis to all 28,000 Master Sample points with drainage areas >0.6 km², prior experience suggests that it would require about one week of GIS processing time.

- Are there other potentially useful land-cover class aggregations that yield more information than our 4 basic categories? (Supports Objectives 6.1 and 6.2.)

There appears to be no identified applications for which more detailed land classification schemes would be warranted on a region-wide basis. The 20 categories of the NLCD coverage, from which our four aggregated land-cover categories were derived, could provide a readily generated greater level of detail; other approaches could provide even greater discrimination but would require airphoto interpretation and a substantial investment of time (e.g., Lucchetti et al. 2014).

6.3.2 Data sources

The NLCD coverages (all years) are available for free download at <http://www.mrlc.gov/finddata.php>. This was the source of all land-cover data used in the analyses for the HSTM project.

6.3.3 Known magnitude of classification/location errors

Extensive evaluation of land-cover classification accuracy typically returns values of up to 80% or better accuracy, with the best classifications found for the coarsest (i.e., most aggregated) classes, such as used in this report. For example, see Homer et al. (2007) and associated references for specific evaluations of the 2006 classification; Jin et al. (2013) offers some preliminary evaluations of the 2011 classification.

6.3.4 Analytical procedures

For the Design Report, a preliminary determination of the land cover associated with individual Master Sample points was made by evaluating the local land cover, as represented by the aggregated 2011 NLCD, at the location of the point itself. On this basis, some preliminary determinations were made regarding which strata combinations were likely to lack sufficient members (e.g., very large watersheds with a predominantly “urban” land cover) to require sampling. For actual implementation, however, the key attribute is the land cover of the *contributing watershed*, which requires a more extensive analysis. For this purpose, a script was written in ArcMap that delineated the entire watershed to a specified point, aggregated the

underlying NLCD pixels, and tabulated the percentage land cover in each of four categories (urban, agriculture, forest, other).

Since the original 2011 NLCD dataset was for the conterminous 48 US states, a subset for the Lower Columbia Region was extracted and pixel-matched to the original dataset. Watershed size comparisons included comparing the watershed-generated areas to those of each Master Sample point to which they included contributed the area. Small discrepancies occurred due to the need to snap to the DEM-generated stream networks to prevent false (and typically very small) watersheds from being generated.

For the stratifications required by the Qa/Qx and habitat sampling design, Master Sample points with predominant (i.e., >50%) watershed land coverage of “urban” or “agriculture” were identified by first visually outlining areas where these land cover types are present in sufficient area to provide the possibility of such an outcome (for each, this was <10% of the total area of the Lower Columbia Region) and then running the script on all Master Sample points so contained. Many such points do not have a dominant land cover of urban or agriculture; only those that do (275 for “urban” and 430 for “agriculture”) have been retained for subsequent inclusion in their appropriate strata).

Identifying “forest”-dominated points, however, requires a different procedure because the total number of points in the Lower Columbia Region is so large (>28,000 for just those draining watersheds larger than 0.6 km²), and simply running the watershed land-cover script for all such points is not feasible at present. Fortunately, the vast majority of such points have a dominant “forest” land cover, and so it is also not necessary. Thus, alternative methods were employed: for the strata combinations requiring “urban” or “agriculture” land covers, Master Sample points were drawn from their respective subsamples; but those requiring “forest” land cover were drawn from the entire Master Sample (as appropriately stratified for drainage area, channel slope, etc.) without pre-determination of land cover. Only those so selected were then evaluated as to their watershed land cover. Those that are not “forest” were discarded and replaced with additional randomly drawn points (which themselves were tested for watershed land cover, repeating as necessary until full complements of points meeting each strata combination were identified).

7 QUALITY CONTROL

7.1 Field Quality Control Procedures for Water Quality Sampling

The accuracy and instrument bias of each sensor will be verified through post-deployment calibration checks following the procedures described in Swanson (2007) and with deployment, retrieval, and monthly grab check samples collected as described in Ward (2007). Downloading of data from each sensor should follow the Standard Operating Procedures specific to the equipment selected (e.g., for stage recording using Campbell Scientific Data Loggers see http://www.ecy.wa.gov/programs/eap/qa/docs/ECY_EAP_SOP_CampbellScientificDataLoggerProcedures_v1_0EAP054.pdf).

For all downloaded data, the raw files should be inspected while still in the field for any obvious errors or omissions with the data. A field form should be filled out with the appropriate field-collected information (i.e., hand-held measurement probes of temperature and conductivity, and observed stage reading) and the time and date of the manual records. Ideally, these manual results should be compared immediately with the downloaded data to further evaluate whether all sensors are operating satisfactorily or if immediate remedial measures are needed.

7.2 Field Quality Control Procedures for Sediment and Benthic Macroinvertebrate Sampling

Sediment and benthic macroinvertebrate samples are the only samples that will need to be analyzed by a laboratory. To ensure the quality and consistency of sample collections, equipment maintenance and sample collection protocols described in the appendices of this report will be followed. Field data measurements will be recorded in the field on data sheets tailored to suite the prescribed protocols. These forms will be used as print documents and taken into the field for recording. Electronic copies of all field forms will be retained.

7.2.1 Sample holding times

Holding times are the maximum allowable length of time between sample collection and laboratory manipulation. Holding times are different for each analyte and are in place to maximize analytical accuracy and representativeness. Each sample collected will be packaged in a container and labeled accordingly. If necessary, sample collection should be coordinated with the analytical laboratory to ensure samples can be transported, received, and processed during non-business hours. Sample containers will be transported or sent by the field team to the analytical laboratory, following established sample handling and chain-of-custody procedures. At the laboratory, samples may be further divided for analysis or storage.

Table 5 lists sample volumes, holding times, containers, and preservation requirements for sediment and biological samples collected. Appendix B-2 elaborates on the bottles and other equipment needed for biological samples.

Table 5. Sample containers, amounts, holding times, and preservation for sediment and macroinvertebrate samples (reproduced from Table 12 of Ecology 2014).

Analysis	Container ¹	Holding time	Preservative ²
Metals (Ag, As, Cd, Cr, Cu, Pb, Zn)	4 oz glass ^[3] or HDPE jar	6 months	Cool to $\leq 6^{\circ}\text{C}$
PAHs	8 oz glass jar ³	14 days/1 year if frozen	Cool to $\leq 6^{\circ}\text{C}$; PSEP standard (1986): may freeze at $\leq -18^{\circ}\text{C}$ at lab
Macroinvertebrates	3.8 L wide-mouth poly jars	Indefinitely	Field preserved with ethanol, store in quiescent location.

¹ No additional sample volume is needed for analysis and QC samples if the jar is filled.

² Preservation needs to be done in the field, unless otherwise noted. Ice will be used to cool samples to approximately $4-6^{\circ}\text{C}$.

³ Glass containers with Teflon-lined lids, certified clean by manufacturer or laboratory in accordance with OSWER Cleaning Protocol #9240.0-05 (Manchester Environmental Laboratory. 2008).

7.2.2 Composite/grab field replicate samples

Replicates will be collected for the composited benthic macroinvertebrate and sediment field samples (Table 6). Field replicates will be collected by splitting composited samples. The sediment samples will undergo a rigorous field homogenization to ensure adequate sample mixing prior to splitting. All field replicates will be labeled similar to other samples, so that the

sample has its own unique number. These replicate samples will be submitted blind to the laboratory, with all other field samples.

Table 6. Field quality control schedule for benthic macroinvertebrate and sediment samples collected (reproduced from Table 14 of the RSMP QAPP).

Field sample collected	Frequency	Control limit	Corrective action
Composited benthic macroinvertebrate	Once	Qualitative control—Assess representativeness, comparability, and field variability	Review procedures; alter if needed
Composited sediment field replicates	10% of total samples	Qualitative control—Assess representativeness, comparability, and field variability	Review procedures; alter if needed

7.3 Quality Control for Landscape Indicators

Quality control of the underlying land-cover data relies on the processing that occurred prior to its posting on the Internet, and no additional evaluation was made for this project. A variety of quality-control procedures were made for the identification of watershed land-cover tallies, including visual comparisons of watershed outlines with land-cover layers in GIS and tabulation of watershed sizes with those having dominant urban or agriculture land covers (given the limited extent of these land uses throughout the Lower Columbia Region).

8 DATA MANAGEMENT

Effective data management is an essential component of a successful monitoring program. As recommended in the Roles and Responsibilities documents (Appendices A-1 and B-1 of the Implementation Plan, Part 1 of this report), the HSTM program manager will identify a data manager in charge of data QA, data entry, and data export to support the routine data analysis or in response to data requests.

8.1 Data Compilation

Final selection of a data management system is still pending. Following selection of a system, metadata, parameter formats and standard coding systems will be developed for the following:

- **Site and Geographic Data**—Sampling reaches will be identified with GPS coordinates at the upstream and downstream ends and with a narrative description of their location (e.g., East Fork Lewis River, extending 1,500 meters upstream from the NE 82nd Avenue/Daybreak Road bridge). Having both GPS coordinates and a narrative description will provide redundancy and insure that the sampling reaches can be re-located. A hand-held “recreational grade” GPS (± 25 ft horizontal accuracy) should prove sufficient for these purposes.
- **Field Data Collection and Transfer**—Draft data sheets will be developed and reviewed by all implementing agencies prior to the initiation of the first data collection event. This will ensure that all field crews are collecting the same data in the same way. Some

implementing agencies may choose to use an electronic platform for field data collection. These electronic tablet-based systems have advantages in that they can be designed in such a way that they include field QA/QC procedures insuring that all required data is collected (for instance, data collection fields can be designed so that crews cannot move on to the next field until data has been entered in the preceding field). Electronic data collection platforms also streamline data compilation and analysis, and eliminate transcription errors when transferring data into Microsoft Excel, Access, or other database programs. Should an implementing agency choose to use an electronic data collection platform, precautions must be taken to insure that all data included on the approved data sheets is collected in an identical way.

- Methods for collection and transfer of field information differ based on the selection of a data management system. Specific data transfer and handling methodologies will be developed upon the adoption of a data management system. Data manually transferred from paper data sheets will require more extensive QA/QC procedures, such as being entered and checked by two different people, or by entering twice and comparing the two data sets.
- Laboratory Analyses and Data Transfer—Accredited laboratories will be used for all data analysis. Such laboratories have rigorous data analysis and transfer methodologies, and offer reporting of water quality data (including sediment metals, sediment PAHs and benthic macroinvertebrate community metrics) in electronic form. These data will be reported using a standard set of information that addresses the needs for quality assurance checks, verification, and other auditing requirements. The format for reporting and recording of water quality information will follow a similar design to that of the Environmental Information Management system developed by Ecology. In this way, data generated in this monitoring program can be recorded simultaneously in Ecology's data management system.
- All field forms, photographs, electronic data, and laboratory data will be stored by the HSTM program manager in an organized filing system for electronic or paper files. Field forms, downloaded data files, and laboratory data deliverables will be sent to the HSTM program manager for storage in paper and electronic files. Location, measurement, and sample result data will be evaluated through the data verification process (see below). Results judged to be acceptable after all such steps are required to be entered into Ecology's EIM database. However, confirmation of the use of this permanent archive, and articulation of the specific steps needed to make use of it, have not yet occurred.
- Continuous data will be stored in a database format to be defined by the Program Coordinator and uploaded to data.wa.gov following implementation of data verification procedures described below.

8.2 Database Design for Long-Term Data Storage

Near-term storage will occur through an access database, with a long term vision to secure funding in order to develop and maintain an online database website. The database will store raw data, as well as calculated indicators and indices. This is a labor-intensive and thus expensive endeavor. If possible, database development could be streamlined by modeling or coupling with an existing database management system, ideally the Washington Department of Ecology's Environmental Information Management (EIM) database.

8.3 Data Management for GIS-based Landscape Indicators

The NLCD data and ArcGIS file geodatabases are stored on servers that are backed up daily. Metadata is written when a dataset is finalized and includes source datasets, methods and changes made to the original dataset. LCFRB and project partners have received copies of the finalized datasets with metadata, including the source data and descriptions of processes done on them to allow full understanding of how the final versions were derived.

8.4 Data Verification and Quality Assessment

Data verification and quality assessment involves examining the data for errors, omissions, and compliance with quality control (QC) acceptance criteria. Data verification should occur at multiple steps in the process of collecting and analyzing monitoring data, in order to minimize the likelihood of errors and to assess the quality of the final data.

8.4.1 Field

In the field, all data recording sheets should be reviewed by all crew members before leaving the site. The field lead will verify field data to ensure that:

- Data are consistent, correct, and complete, with no errors or omissions.
- Results of QC samples accompany the sample results.
- Established criteria for QC results were met.
- Data qualifiers are properly assigned where necessary.
- Data specified in the Sampling Process Design were obtained.
- Methods and protocols specified in this QAPP were followed.

An overarching focus for indicator selection has been to use only those indicators with relatively high levels of measurement precision and signal-to-noise ratios. For water quality indicators measured with on-site sensors (water temperature, conductivity, stage), typical values for data quality and bias are within a few percent. The accuracy and instrument bias of each sensor will be verified through post-deployment calibration checks following the procedures described in Swanson (2007) and with deployment, retrieval, and monthly grab check samples collected as described in Ward (2007).

Field-collected indicators are minimal for the base urban+NPDES program: wetted width, a stage reading at the gage site, and hand-held sensor readings for temperature and conductivity. For each, the data will be entered onto field data sheets. Both field team members will ensure that the forms are completed and check for any errors, on-site. Field sheets will be entered into Excel or Access spreadsheets, and a different team member will compare at least 50% of the field and laboratory data sheets with the Excel files. If any errors are found they will be corrected, and the project manager will check all of the remaining field and laboratory data sheets with the spreadsheet files. This process will be repeated until all errors are eliminated. Permanent records of all environmental data should be available, ideally through static online archives (i.e., EIM and data.wa.gov).

8.4.2 Laboratory

Sediment and benthic macroinvertebrate samples are the only samples that will need to be analyzed by a laboratory. To ensure the quality and consistency of sample collections, equipment

maintenance and sample collection protocols described in the appendices of this report will be followed. For the laboratory measurement of sediment PAH's and metals, bias and precision values should be less than 20–40% depending on the indicator and will be checked through replicate samples. All laboratories used for the analyses will have their own approved internal quality-control procedures, which will be confirmed and documented prior to sample submission. Lost laboratory samples are very uncommon for accredited labs, and in the context of the overall HSTM program any such event would be unlikely to compromise the validity of the overall results unless criteria for completeness are not achieved.

Both field and laboratory data records, following initial data entry should be verified against field forms and laboratory reports prior to final validation in the electronic database to verify consistency. Missing data are identified to ensure that values were not mistakenly overlooked during the data entry process. Printed copies of all stored environmental data should be made to ensure permanent records are available. The project manager at the taxonomic laboratory will verify all taxonomic results, and the laboratory will verify all analytical results prior to reporting.

Incomplete or missing data are not anticipated to be a significant problem if data verification procedures are followed. Lost field forms could require a site revisit, but once entered into the database and a digital back up created, the risk of lost information is minimized. Lost laboratory samples are also very uncommon for accredited labs, and in the context of the overall HSTM program any such event would be unlikely to compromise the validity of the overall results unless criteria for completeness are not achieved.

If, despite such efforts, discrepancies in the data are found, there are two options for correction, depending on when the problem is identified:

1. If the problem is identified before the end of the sampling period (normally July 1 to October 15 for sediment chemistry and benthic indicators), a review of the protocols and SOPs outlined in the appendices of this document is required. After this review, a repeat site visit may be made to re-collect the sample. This may occur if the data set is incomplete or incorrectly collected. Due to the inter-related nature of chemical and biological conditions, problems identified in the chemical or biological data should be addressed by again collecting the entire suite of chemical and biological indicators. Before the second sampling, the investigator must review the SOPs and the appendices of this document to understand the protocols. Equipment should be cleaned and recalibrated and checked for proper function.
2. If the problem is identified after the sampling period, the data should be flagged and the problem explained in a comment in the database. This will allow both internal and external users of these data to know how these data may be used in projects. If the data are incomplete, or if some data standard was not met, the data will not be used to meet the objectives of the study design.

For continuous parameters, if identified discrepancies are found that indicate sensor or data-logger malfunction, a site visit to correct the problem should occur as soon as possible. Suspect data prior to that time should be clearly flagged in the database and not be used in subsequent analyses.

8.5 Quality (Usability) Assessment

Following verification and validation, the variability, accuracy, and precision of the collected data will be compared with project objectives using professional judgment. If results do not meet

criteria established at the beginning of the project, this will be explicitly stated in the annual reporting. Based upon data accuracy criteria, some data may be discarded. If this is found to be necessary, then the problems associated with data collection and analysis, reasons data were discarded, and potential ways to correct sampling problems will be reported. In some cases project criteria for accuracy may be modified. Should that be necessary, the justification for modification, problems associated with collecting and analyzing data, as well as potential solutions will be reported.

9 AUDITS

Audits ensure that quality assurance (QA) monitoring plan elements are implemented correctly. The quality of the data must be determined to be acceptable, and corrective actions must be implemented in a timely manner. There are two components of the auditing process:

- The Technical Systems Audit is a qualitative audit of conformance to the QA monitoring plan. The audit will be conducted by an independent party (e.g. state agency staff) to be identified by the project management and approved by the Steering Committee soon after work has commenced so that corrective actions can be implemented early in the project. These evaluations include field collection activities, sample transport, laboratory processing, and data management components of the program.
- Proficiency Testing is the quantitative determination of an analyte in a blind standard to evaluate the proficiency of the analyst or laboratory. This audit is included for analysis of water quality samples as a routine procedure in the accredited laboratory.

10 REPORTING

Compiling results and disseminating reports will be the responsibility of the data analysis and reporting manager. Once complete, the reports will be sent to the Program Manager for dissemination among the Technical Review committee for their review and comment prior to posting online and dissemination to the Steering Committee and interested parties.

The HSTM program manager will post annual status updates and 5-year status and trends reports to the program webpage. Findings will be disseminated by the program manager to NOAA, the Salmon Recovery Funding Board, Ecology, and other interested parties identified during the implementation phase of program development through distribution of an email with links. Links or copies of the reports will be posted on the PNAMP website to reach a broader regional audience.

Annual status updates will be generated by the data analysis and reporting manager between December and April of the year following data collection and transmitted to Ecology. This will allow some time for adaptive responses to the monitoring protocol before the coming field season. Five-year Status and Trends reports will be generated by the data analysis and reporting manager(s) between December and July following every 5th year of data collection.

A more detailed report of both year-5 status and overall trends (from inception of monitoring to current year) on a regional basis will be generated between December and July every 5 years, consistent with the guidance in the implementation plan. Final updates and reports should be submitted by the program manager for review by the Technical Review committee. Upon incorporation of the Technical Review committee's comments, the program manager will finalize

the document, post online (HSTM program webpage and PNAMP), and send email notification to the Steering Committee and interested parties.

11 REFERENCES

- Dutch, M., V. Partridge, S. Weakland, K. Welch, E. Long, 2010. 2010 Addendum to Quality Assurance Project Plan: The Puget Sound Assessment and Monitoring Program Sediment Monitoring Component. Washington State Department of Ecology, Olympia, WA. Publication No. 09-03-121-Addendum1. <https://fortress.wa.gov/ecy/publications/summarypages/0903121Addendum1.html>
- Ecology (Washington Department of Ecology). 2004. Guidelines for preparing quality assurance project plans. Ecology Publication No. 04-03-003.
- Ecology. 2006. Status and trends monitoring for watershed health and salmon recovery—Quality Assurance Monitoring Plan. Ecology Publication No. 06-03-203.
- Ecology. 2010. Quality assurance monitoring plan - ambient biological monitoring in rivers and streams: benthic macroinvertebrates and periphyton. Ecology Publication No. 10-03-109.
- Ecology. 2014. Quality assurance project plan for status and trends monitoring of small streams in the Puget Lowlands ecoregion for monitoring conducted using pooled RSMP funds contributed by western Washington municipal stormwater permittees. Ecology Publication no. 14-10-054.
- Fry, J. A., M. J. Coan, C. G. Homer, D. K. Meyer, and J. D. Wickham. 2008. Completion of the National Land Cover Database (NLCD) 1992–2001 land cover change retrofit product. USGS OFR 2008-1379.
- Homer, C. G., J. Dewitz, J. Fry, M. Coan, N. Hossain, C. Larson, N. Herold, A. McKerrow, J. N. VanDriel, and J. Wickham. 2007. Completion of the 2001 National Land Cover Database for the conterminous United States. *Photogrammetric Engineering and Remote Sensing* 73: 337–341.
- Homer, C. G., J. A. Dewitz, L. Yang, S. Jin, P. Danielson, G. Xian, J. Coulston, N. D. Herold, J. D. Wickham, and K. Megown. 2015. Completion of the 2011 National Land Cover Database for the conterminous United States- representing a decade of land cover change information. *Photogrammetric Engineering and Remote Sensing* 81: 345–354.
- Jin, S., L. Yang, P. Danielson, C. Homer, J. Fry, J., and G. Xian. 2013. A comprehensive change detection method for updating the National Land Cover Database to circa 2011. *Remote Sensing of Environment* 132: 159–175.
- Johnson, A. 2005. Quality Assurance Project Plan: Toxics in Stormwater Runoff from Puget Sound Boatyards. Washington State Department of Ecology, Olympia, WA. Publication No. 05-03-118. <https://fortress.wa.gov/ecy/publications/SummaryPages/0503118.html>
- Kaufmann, P. R., P. Levine, E. G. Robison, C. Seeliger, and D. V. Peck. 1999. Quantifying physical habitat in wadeable streams. EPA/620/R-99/003. U.S. Environmental Protection Agency, Washington, D.C.

Larson, C. 2015. Standard Operating Procedures and Minimum Requirements for the Collection of Freshwater Benthic Macroinvertebrates in Streams and Rivers, Version 2.0, 13 pp. Available at http://www.ecy.wa.gov/programs/eap/qa/docs/ECY_EAP_SOP_BenthicMacroinvertebrateDataCollection_v2_0EAP073.pdf.

Lucchetti, G., J. Burkey, C. Gregersen, L. Fore, C. Knutson, J. Latterell, P. McCombs, R. Timm, J. Vanderhoof, and J. Wilhelm. 2014. Assessing land use effects and regulatory effectiveness on streams in rural watersheds of King County, Washington. Prepared by Water and Land Resources Division. Seattle, Washington. <http://your.kingcounty.gov/dnrp/library/water-and-land/critical-areas/CAO-Report-Final-for-Web.pdf>

Manchester Environmental Laboratory. 2008. Manchester Environmental Laboratory Lab Users Manual, Ninth Edition. Manchester Environmental Laboratory, Washington State Department of Ecology, Manchester, WA.

Mathieu, N., 2007. Standard operating procedure for measuring dissolved oxygen in surface water. Version 1.1. Washington Department of Ecology, Olympia, Washington. <http://www.ecy.wa.gov/programs/eap/quality.html>

Schuett-Hames, D., A. E. Pleus, E. Rashin, and J. Mathews. 1999. TFW Monitoring Program method manual for the stream temperature survey. Prepared for the Washington State Department of Natural Resources under the Timber Fish and Wildlife Agreement, Olympia, Washington.

Swanson, T., 2007. Standard Operating Procedures for Hydrolab® DataSonde® and MiniSonde® Multiprobes. EAP 033, Version 1.0. Washington State Department of Ecology, Olympia, Washington. Approved June 19, 2007. <http://www.ecy.wa.gov/programs/eap/quality.html>

Tetra Tech. 2013. Lower Columbia habitat status and trends Project. Technical Report 3. Prepared by Tetra Tech, Sitka Technology Group, and Stevens Environmental Statistics for Lower Columbia Fish Recovery Board.

USEPA (U.S. Environmental Protection Agency). 1982. Handbook for sampling and sample preservation of water and wastewater. EPA Number: 600/4-82-029. <http://nepis.epa.gov/Exe/ZyPURL.cgi?Dockkey=30000QSA.txt>

USEPA. 2010. Laboratory Program National Functional Guidelines for Inorganic Superfund Data Review. U.S. Environmental Protection Agency. EPA-540-R-10-011. January 2010.

USGS (United States Geological Survey). 1994. Shelton, L. R. and P. D. Capel. Guidelines for collecting and processing samples of stream bed sediment for analysis of trace elements and organic contaminants for the National Water-Quality Assessment Program. U.S. Geological Survey. Sacramento, California.

USGS. 2005. D. Radtke. Techniques of water-resources investigations. Book 9. Handbooks for Water-Resources Investigations. National Field Manual for the Collection of Water-Quality Data. Chapter A8. Bottom-material samples. Version 1.1. <http://water.usgs.gov/owq/FieldManual/Chapter8/508Chap8final.pdf>

Ward, W. 2003. Continuous temperature sampling protocols for the environmental monitoring and trends section. Washington State Department of Ecology, Olympia, Washington.

Ward, W. 2007. Standard operating procedures for the collection, processing, and analysis of stream samples. Version 1.3. Washington State Department of Ecology, Olympia, Washington. www.ecy.wa.gov/programs/eap/quality.html

WDNR (Washington Department of Natural Resources). 2010. Boundaries of state-owned aquatic lands. WDNR, Olympia, Washington. http://www.dnr.wa.gov/Publications/aqr_aquatic_land_boundaries.pdf

Appendices

Appendix A-2

Candidate Qa/Qx Monitoring Sites

Locations for urban+NPDES Sampling

Four different sources of information were ultimately used to identify the final list of 22 stream segments for urban+NPDES sampling:

1. Preexisting legacy sites: these locations were identified by the City of Vancouver and Clark County. Six met all criteria established in the Design Report for sites (drainage area, >50% watershed urban land cover, independence from one another).
2. Preexisting legacy sites that do not satisfy all criteria: only one site fell into this category, but given its long history of data collection and the likelihood that future development could rectify its current status of <50% watershed urban land cover as of 2011), it was added.
3. Other independent stream segments in Clark County that met all criteria for inclusion: 11 sites fall into this category.
4. Sites for monitoring in Cowlitz County: 4 sites were recommended by the Stormwater Caucus, and although three of the four lack a predominant urban land cover (and two of those are smaller than the 2.5 km² threshold of the Design Report), the paucity of suitable sites warranted their inclusion.

The sites within each of these four categories are listed on the next page and mapped on the two pages following.

Table A-2.1. List of recommended sites for urban+NPDES sampling. Site ID's correspond to maps on the following two pages.

LEGACY ("TREND") SITES								TOTAL # SITES: 22
	Land Cover							
Site #	Agriculture	Forested	Other	Urban	Water	Total area (km ²)	EXISTING LEGACY SITE #	
3	4.0%	0.7%	1.1%	94.3%		47.7	28BBC10.2	
4	17.8%	1.7%	3.8%	76.7%	0.0%	35.3	CUR020	
8	14.7%	22.4%	9.6%	52.7%	0.5%	19.4	WDN010	
36	0.1%		0.3%	99.6%		9.5	CLD010	
37		2.3%	0.7%	97.0%		7.3	CGR020	
42	12.8%	13.2%	7.5%	66.5%		8.7	WPL065	
								Sites: 6
OTHER LEGACY/TREND SITES:								
Site ID	NAME	Flow? # yrs	Bugs? # Yrs	WQ? # yrs		LAT	LONG	Comments
MIL010	Mill Ck US of Salmon Ck Ave	Yes/8	Yes/10	Yes/10		45.73111141	-122.6275354	CC Long Term Index Site at WSU; <50% urban
								Sites: 1
"STATUS" SITES WITH >50% URBAN WATERSHEDS (CLARK COUNTY)								
	Land Cover							
Site #	Agriculture	Forested	Other	Urban	Water	Total area (km ²)		
2	11.2%	11.0%	12.3%	65.5%	0.0%	14.7		
26	2.0%	0.0%	0.4%	97.6%	0.0%	7.0		
31		2.8%	0.5%	95.0%	1.7%	3.6		
32	17.7%	1.0%	1.7%	79.5%		5.5		
38			0.8%	99.2%		3.4		
39			1.2%	98.8%		4.1		
40	2.9%	4.9%	4.5%	87.8%		3.1		
43	13.8%	3.8%	3.7%	78.7%		5.3		
45	34.8%	5.4%	8.1%	51.7%		10.9		
46	25.6%	8.2%	6.0%	60.1%	0.1%	7.0		
85	0.9%		2.7%	94.6%	1.9%	6.9		
								Sites: 11
SW CAUCUS-RECOMMENDED STATUS SITES IN COWLITZ COUNTY								
Site name				LAT	LONG	Total area (km ²)	Comments	
Indian Creek				46.165195	-122.96472	2.3	<50% urban	
Westover Creek				46.160826	-122.918524	4.8		
N branch Ostrander Creek				46.194968	-122.896982	7.2	<50% urban	
Unnamed Creek--Burcham Street trib. E of I-5				46.149956	-122.898214	1.0	<50% urban	
								Sites: 4




Figure A-2.1. Map of recommended sites for urban+NPDES sampling in Cowlitz County.




Figure A-2.2. Map of recommended sites for urban+NPDES sampling in north Clark County. Trend/legacy sites marked with yellow pushpin; status sites marked by turquoise balloon.




Figure A-2.3. Map of recommended sites for urban+NPDES sampling in south Clark County and the City of Vancouver. Trend/legacy sites marked with yellow pushpin; status sites marked by turquoise balloon.

Appendix B-2

Detailed Field-collection Protocols

APPENDIX B-2

Table of Contents – Field Protocol

Protocol are bookmarked using the indicator number and include the source from which the protocol is taken.

Indicators	Pages
1. Temperature	1
2. Sediment Metals and PAH's	5
3. Conductivity	6
4. Stage	7
5. Benthic Macroinvertebrates	8
6. Bankfull width and depth	21
7. Wetted width and depth	24
8. Substrate particle size	25

FIELD PROTOCOLS FOR TEMPERATURE

Extracted from “Salmonid Habitat Protocol for CHaMP”

9.5 Water Temperature

Reference: Isaak et al. (2010).

Equipment: Onset TidbiT, PVC housing material/cables, epoxy, rubber gloves, underwater viewer.

Objective: Install year round water temperature sensors at sites using one of two installation methods.

Water temperature sensors will be placed at all annual and rotating panel sites within each CHaMP subbasin. At new sites where sensors have not been established, it is important that watershed leads make a concerted effort to install all sensors before high summer temperatures (approx. July 15). When early flow conditions do not permit installation with the epoxy method, use the wire method initially and have the crew members apply the epoxy method (where applicable) after flows have subsided. Temperature data should be downloaded in the fall and before high spring flows.

9.5.1 Establishing New Sensors

Step 1. Identify sensor placement location.

- i. Epoxy Method: Search for a large rock or boulder (charismatic megaboulders are best) that will be immobile during large floods and is easy for others to identify on subsequent site visits. Finding a good rock is the most important step to a successful sensor installation. If a suitable rock is not available, consider placement using the wire method.
 - a. Optimal placement locations for rock and boulder secured sensors include:
 - i. Rocks, boulders, or structures that will not move or be disturbed at high flows.
 - ii. Boulders large enough that they protrude above the low flow water surface and wide enough that they can effectively shield the sensor from moving rocks or debris during high flows.
 - iii. Areas downstream of large rocks in pockets of relatively calm water with smaller substrate sizes.
 - iv. A relatively flat downstream attachment surface that is deep enough to remain submerged in flowing water for the entire year.
- ii. Cable Method: If there is not a suitable rock or boulder within or in close proximity (100 m) to the site, identify a secure location such as the base of a tree or root wad to attach the sensor using a metal cable.
 - a. Optimal placement locations for cable secured sensors include:
 - i. Areas with sufficient stream flow that will maintain year-round flow, but outside of strong currents. Also consider whether the sensor attached to the wire will move at high flows and place sensor so that it will not get hung up in vegetation or left on the bank.
 - ii. Locations away from seeps or steep banks on the side of stream in order to avoid groundwater influences.

- iii. Camouflaged or inconspicuous locations at sites with high public use. In these instances, vegetation, grasses, or cobbles may be used to cover wire or hold wire in place.
- b. Suitable locations for attaching sensors may be relatively rare within low-gradient, meadow reaches. In these instances, examine potential placement locations no more than 100 m upstream or downstream of the site and away from tributary influences.

Step 2. Install and record sensor location details.

- i. After identifying a suitable sensor placement location:
 - a. Record sensor serial number.
 - b. Install sensor.
 - c. Take a GPS reading. Record UTM coordinates, accuracy, and the date and time installed.
 - d. Record the stream bank that the sensor is nearest to and the distance from that stream bank. If cable is attached to a tree on the bank, record the distance from bank as 0.
 - e. Record the attachment method as cable or epoxy.
 - f. Take a photo of the sensor location. Include enough of the surrounding environment in the photo to relocate the sensor.
 - g. Write a detailed description of the sensor location in the placement location field. Description should include distance from site bottom and any other pertinent information for relocating sensor at subsequent visits. The more detail the better. For example: Sensor attached to grey, rectangular boulder 1 m in diameter near river left (~1.5 m from bank), 5 m upstream from transect 12 OR Sensor is attached to the base of a small willow, ~ 6 m downstream from top of site on river right.
 - h. Note sensor location on site map.
 - i. After sensor has been in the water for approximately 1 hour, measure and record the instantaneous water temperature near the sensor using a handheld thermometer. Record the date and time instantaneous temperature is measured. It is preferable to measure the instantaneous water temperature at the top of the hour when the installed sensor will be recording information.

9.5.2 Previously Installed Sensors

Step 1. Locate previously installed sensor.

- i. Use existing photographs, GPS coordinates, and site maps to locate the previously installed water temperature sensor.
 - a. If sensor location is found but sensor is missing, search downstream to see if sensor can be found. Note if sensor cannot be located. Establish a new sensor using the criteria outlined above.

Step 2. Download sensor data and record information

- i. Remove the sensor from the housing unit and confirm that the correct sensor serial number was recorded when originally installed. Avoid removing sensor from the water when it will be recording one of its hourly temperature measurements (on the hour).
 - a. Download sensor using the sensor shuttle (Appendix G).
 - b. Note whether the red light on the sensor is blinking. If there is no blinking light, replace the sensor and notify the watershed lead.
 - c. Record in the sensor condition field the current condition of the sensor as being submerged in flowing water, submerged in non-flowing water, dry, or missing.
 - d. Record if the sensor has been left in place, removed, or moved to a more suitable location. Move the sensor if it is in non-flowing water or buried in sediment. Replace sensor with a new one if it is missing. Record action in the action field.
 - e. Take a new GPS reading. Record UTM coordinates, accuracy, and the date and time sensor was downloaded or checked.
 - f. Verify and update sensor location information as needed such as stream bank, distance from bank, attachment method, and location description.
 - g. Take a new photo of the sensor.
 - h. Measure and record the instantaneous water temperature near the sensor using a handheld thermometer. Record the date and time instantaneous temperature is measured. It is preferable to measurement the instantaneous water temperature at the top of the hour when the installed sensor will be recording information.
 - i. Note the sensor location in the site map.

FIELD PROTOCOLS FOR SEDIMENT METALS AND PAH'S

From Richard Sheibley, US Geological Survey (written comm., 2015)

Identify one or more depositional zones in the immediate vicinity of the sensor location in the reach; proximity to the sensor is less important than finding several accumulations of suitably fine sediment for sampling. Sediment should be collected using teflon scoops/beakers and composited into a large pyrex or glass jar. The material can be processed either on site, in the lab, or a combination of both.

All of the sieving can be done onsite, with one person dedicated to collecting and processing the sediment while the other folks did the other measurements. If a limited number of people are available, the sediment can be collected and then processed in the lab later the same day, or ice-chilled in a cooler and processed the following day in the lab. Alternatively, field-sieve all the 2-mm sediment in the field (see below) and sieve the 63- μ m sample later in the lab. Any of these methods are acceptable.

For the 63- μ m sample (metals), use a wet sieving method (the “tea bag” method), as follows: take pieces of 63 μ m nitex mesh (about 12 by 12 inches) and put the sediment into the mesh, wrap it up, and dip it into a smaller pyrex containing native stream water. Repeatedly dip/squeeze/rearrange/rewrap the sediment until sufficient fines (contact the chosen analytical laboratory for minimum volumes) have come through the mesh and into a smaller pyrex container with the native stream water. Let the sediment settle in a cooler or refrigerator, decant the water and put sample into a jar. Assume about 15 min to get enough fines.

For the 2-mm sample (PAH's), use a stainless steel 2-mm sieve to wet-sieve sediment directly into the sample jar, using native stream water to process the sediment. Check with the chosen analytical laboratory beforehand to determine the minimum volume of sample needed.

General considerations:

- 1) All sediment should be collected with teflon scoops/beakers and stored in glass.
- 2) All equipment must be cleaned for organics (scrub/soak in detergent, rinse with DI, HCl or nitric acid for 30 min at least, rinse with DI, rinse with organic blank water, rinse with methanol or acetone, let air dry).
- 3) The 63- μ m sample (for metals) must not touch the stainless steel sieves.

FIELD PROTOCOLS FOR CONDUCTIVITY

Extracted from the Regional Stormwater Monitoring Program QAPP, Appendix E

During every field visit, multiprobe meters may be used to make in-situ field measurements for comparison and calibration checks of the continuously recorded data. Methods for the use of meters will follow the manufacturer's website instructions for the most up-to-date guidelines.

On the day of sampling, field staff will calibrate the meters/probes using a one-point calibration with NIST-certified 100 uS/cm conductivity standards. A zero conductivity check will also be performed.

The downloading of data and the maintenance of the pressure transducer will be specific to each piece of equipment. Follow the manufacturers' directions for these procedures.

FIELD PROTOCOLS FOR STAGE

Extracted from the Regional Stormwater Monitoring Program QAPP, Appendix E

At every field visit, a visual stage height measurement will be made to supplement the data from the continuously recording pressure transducer. A measurement of the stage is best done by installing a staff gage at the site at the same time as the initial installation of the pressure transducer. Any stable measurement point you can either install (rebar, T-post, staff gage, etc.) or is already there (bridge deck or railing, vertical armored wall, large rock, etc.) will work. Most important is that the measurement of stage is relative to the same point every time. Note that stream depth is generally not a reliable measure of stage since the stream bed can change over time. However, if there is a stable in-channel feature that acts as a control (bedrock or a cement weir, or culvert for example) where you can measure the depth in the same place every time, then that is an acceptable alternative.

The downloading of data and the maintenance of the pressure transducer will be specific to each piece of equipment. Follow the manufacturers' directions for these procedures.

FIELD PROTOCOLS FOR BENTHIC MACROINVERTEBRATES

Pages extracted from Larson (2015):

Washington State Department of Ecology

Environmental Assessment Program

Standard Operating Procedures and Minimum Requirements for the Collection of
Freshwater Benthic Macroinvertebrates in Streams and Rivers

Version 2.0

Author – Chad Larson

Date – April 2015

Reviewers – Brandee Era-Miller, Jennifer Wolfe, Chris Hartman & Glenn Merritt,
George Onwumere

Date – April 2015

QA Approval - William R. Kammin, Ecology Quality Assurance Officer

Date – 3/28/2016

EAP073

Recertified: 03/28/2016

Please note that the Washington State Department of Ecology's Standard Operating Procedures (SOPs) are adapted from published methods, or developed by in-house technical and administrative experts. Their primary purpose is for internal Ecology use, although sampling and administrative SOPs may have a wider utility. Our SOPs do not supplant official published methods. Distribution of these SOPs does not constitute an endorsement of a particular procedure or method.

Any reference to specific equipment, manufacturer, or supplies is for descriptive purposes only and does not constitute an endorsement of a particular product or service by the author or by the Department of Ecology.

Although Ecology follows the SOP in most instances, there may be instances in which Ecology uses an alternative methodology, procedure, or process. X:\EA PROGRAM\ECYEAPSOP\Approved

SOP Revision History

Revision Date	Rev number	Summary of changes	Sections	Reviser(s)
April 2015	2.0	Version has changed because the scope of the SOP has been changed to incorporate more streams. Current version distinguishes between narrow and wide protocols.	throughout	Chad Larson

Environmental Assessment Program

Standard Operating Procedure and Minimum Requirements for the Collection of Freshwater Benthic Macroinvertebrates in Streams and Rivers

1.0 Purpose and Scope

- 1.1 This document is the Environmental Assessment Program (EAP) Standard Operating Procedure (SOP) for the collection of freshwater benthic macroinvertebrate (BMI) data. Collection of BMI in wadeable streams and rivers (< 25 m average bankfull width) and larger rivers ($\geq$ 25 m average bankfull width) using narrow and wide protocols, respectively is discussed. It provides minimum requirements for the standardized methods of collecting and preserving aquatic insects, as well as for the taxonomic identification and reporting of the contents of BMI samples.
- 1.2 The methods described here are compatible with those used by other federal and state agencies in the Pacific Northwest Region (Hayslip, 2007). Data collected using these methods allows us to share data with other agencies, thereby allowing for more efficient use of time in the field and potentially more extensive sampling of the streams and rivers in Washington.


2.0 Applicability

- 2.1 The procedures outlined here are used by EAP staff when collecting macroinvertebrates during a data collection event (DCE) from rivers and streams in Washington State. In addition, to allow for comparable results, any data submitted for analysis using Ecology's bioassessment models by outside entities should be conducted in this manner.
- 2.2 The methods outlined here are employed by several of EAP's programs conducting status and trends monitoring for the state, which is carried out by the Watershed Health Monitoring (WHM), Ambient Freshwater Biological Monitoring and Sentinel programs. However, these methods also pertain to biological assessment conducted for potential regulatory purposes, i.e. directed studies (e.g. TMDL studies) or outside entities assessing sites for potential listing on the state's 303(d) list for 'biological impairment' (see Ecology's Water Quality Program Policy 1-11: Bioassessment).

3.0 Definitions

- 3.1 **Narrow Protocol:** The set of SOPs that describes the sample and data collection at wadeable sites with an average bankfull width less than 25 m.
- 3.2 **Wide Protocol:** The set of SOPs for collecting data and samples at non-wadeable sites or sites wider than 25 m bankfull width. It is an abbreviated version of the Narrow Protocol.
- 3.3 **D-Frame Kicknet** – A light weight, packable net used for the collection of aquatic macroinvertebrates composed of a 3-4 foot pole with a D-shaped frame attached to the bottom such that the flat side can be placed against the substrate. The frame is 1 foot wide

and 1 foot tall. A 500 micron mesh net is attached to the frame. With the ability to be deployed across most diverse types of substrates, this is the required sampling device for status and trends monitoring.



- 3.4 Hess Sampler – A cylindrical shaped mesh frame that is open on either end to allow access to bottom substrates through the top of the cylinder. This cylinder has a 500 micron mesh net attached to part of the wall for sample collection. This sampler prevents escape of sample organisms, and prevent outside materials and organisms from drifting into the net.




Image taken from <http://www.ilmb.gov.bc.ca/risc/pubs/aquatic/freshwaterbio/assets/freshwaterbio.pdf> page 29 Figure 8

- 3.5 Surber Sampler – A net used for sampling aquatic insects that is composed of a 12 x 12 inch square frame with a 500 micron mesh net attached. It has another 12 x 12 inch square frame that sits on the substrate to border your sampling area.




Image taken from <http://www.ilmb.gov.bc.ca/risc/pubs/aquatic/freshwaterbio/assets/freshwaterbio.pdf> page 29 Figure 8

- 3.6 Reach-wide Composite Sample – A reach wide sample represents a standard stream site in which the BMI sample is composited from 8 predefined stations. Each station is located on a separate transect. Each station is selected without regard to whether it is in a pool, riffle, or other habitat type. Invertebrate distribution is usually patchy, so sampling from multiple, dispersed locations, helps to provide a more representative sample.
- 3.7 Reach-wide Station – This is one of 8 locations from which a reach wide sample is composited. Locations are predetermined by randomly choosing 8 of 11 transects from a Standard Stream Site.
- 3.7.1 **Narrow protocol stations** – Sampling BMI for the narrow protocol occurs in a zig-zag sequence (Table 1) when moving upstream.

Table 1. Pre-determined station locations on each transect of a Standard Stream Site.

Station	% Transect Distance Left to Right
1	25
2	50
3	75
4	50
5	25
6	50
7	75
8	50

- 3.7.2 **Wide protocol stations** – For the wide protocol, sampling at each of the 8 transects occurs on the side of the stream/river where habitat is also surveyed. At each of the selected transects, a sample is collected from a representative portion (as much as practical) of a littoral zone extending 10 meters into the stream/river from the wetted bank and 10 meters upstream and downstream, respectively from the transect. The sample should also be collected in an area shallow enough to deploy the kicknet and in an area away from backwaters, eddies, or other edge habitat.
- 3.8 Targeted Riffle Sampling – A targeted sample represents sampling a single habitat type from a stream reach that extends at least twice its bankfull width. A targeted sample is composed of 8 feet of surface area sampled across multiple riffles or pools. Targeted sampling from a single habitat type can help to reduce the variation in the data and to provide a clear response signal. Individual directed studies may decide on the utility of using targeted riffle sampling; however, projects involved in status and trends monitoring employ only reach-wide composite sampling.
- 3.9 MSDS – Material Safety Data Sheets provide both workers and emergency personnel with the proper procedures for handling or working with a particular substance. An MSDS includes information such as physical data (melting point, boiling point, flash point, etc.), toxicity, health effects, first aid, reactivity, storage, disposal, protective equipment and spill/leak procedures.

4.0 Personnel Qualifications/Responsibilities

- 4.1 For collection of the sample, personnel should at a minimum review the Quality Assurance Monitoring Plans for the status and trends monitoring programs (e.g. [Ambient Biological Monitoring, WHM](#)) and the training tutorial [Sampling Macroinvertebrates in Wadeable Streams in Washington State](#). Alternatively, they may receive formal training from staff who have themselves been formally trained. EAP has been holding formal training sessions for Watershed Health monitoring during June of each year. These sessions are open to the public.
- 4.2 For taxonomic analysis of the sample, the personnel should be certified for identification of Western United States taxa to the Genus or Species level by the Society for Freshwater Science (<http://www.nabstep.com/>). Sample identification and enumeration should be to the lowest practical level as outlined in: [Quality Assurance Monitoring Plan: Ambient Biological Monitoring in Rivers and Streams: Benthic Macroinvertebrates and Periphyton](#)
- 4.3 All staff must comply with the requirements of the EA Safety Manual (EA Program, 2012). A full working knowledge of the procedures in Chapter 1 is expected.
- 4.4 All staff must be familiar and comply with the requirements of Ecology's Chemical Hygiene Plan and Hazardous Materials Management Plan (EA Program 2011). [h](#)
- 4.5 Field staff must be annually trained to minimize the spread of invasive species. See SOP EAP070: <http://www.ecy.wa.gov/programs/eap/quality.html>
- 4.6 Read this standard operating procedure and discuss any questions with your supervisor or task team leader.
- 4.7 Read the Material Safety Data Sheets (MSDS) for ethanol before beginning the sorting/taxonomic procedures. The MSDS are available in the Ecology Headquarters benthic laboratory. Use proper protective clothing and equipment as indicated.
- 4.8 Immediately report to your supervisor any symptoms or reactions that might be related to Ethanol exposure.

5.0 Minimum Equipment, Reagents, and Supplies for Sample Collection

- 5.1 Wide-mouth polyethylene jar (128 oz or 3.8 L is a recommended size)
- 5.2 D-Frame kick net (pre-cleaned of organisms) with these characteristics:
 - 5.2.1 Frame mouth that is 1 ft (30.5 cm) wide by 1 ft tall
 - 5.2.2 500-µm mesh net
- 5.3 95% Ethanol (add 3 parts by volume for each part sample)
- 5.4 Label (waterproof) for jar exterior
- 5.5 Label (waterproof) for jar interior
- 5.6 Soft-lead pencil

- 5.7 Clear tape
- 5.8 Electrical tape
- 5.9 Pocket knife
- 5.10 Wading gear (pre-cleaned of organisms)

6.0 Summary of Procedure

6.1 Details of the procedure are determined by the purpose for monitoring (Table 2).

Table 2. Details of benthic sampling based on monitoring purpose.

Monitoring Purpose	Status & Trends (narrow protocols)	Status & Trends (wide protocols)	Regulatory
Device	D-frame Kicknet	D-frame Kicknet	D-frame Kicknet, or Surber, or Hess
Mesh	500 µm	500 µm	500 µm
Site length	20 bankfull widths (150-500 m)	20 bankfull widths (150-2000 m)	2 bankfull widths (or more)
Sample area	8 ft ²	8 ft ²	8 ft ²
Station distribution	8 transects, 4 margins + 4 central	8 transects, littoral zone on side of stream where habitat is surveyed	Multiple riffles or 8 transects
Time to suspend	30 seconds	30 seconds	30-120 seconds
Sample	Reach-wide composite	Reach-wide composite	Reach-wide or Targeted-Riffle composite
Season	July 1-Oct 15	July 1-Oct 15	July 1-Oct 15
Subsample goal	500+ organisms	500+ organisms	500+ organisms
Taxonomic resolution	Lowest practical	Lowest practical	Lowest practical

6.2 Field Sampling

- 6.2.1 For status and trends monitoring purposes (e.g. WHM), the sampling season extends from July 1 to October 15. For regulatory monitoring purposes, sampling should be conducted during the same period.
- 6.2.2 Samples should be collected with a device that uses 500 micron mesh, including D-frame kick nets, Surber samplers, or Hess Samplers. Samples collected for status and trends monitoring, i.e. WHM, Ambient Stream Biological Monitoring and Sentinel programs should use a D-frame kick net.
- 6.2.3 Samples should be collected from 8 square feet of stream bottom surface area and composited in the same jar. These samples should come from multiple locations across the study site.
- 6.2.3.1 Samples taken for the purpose of monitoring status and trends of stream health (e.g. WHM) should be composited (regardless of habitat) from 8 randomly-selected transects dispersed across a site at least 150 m long. See the WHM SOP for Verification and Layout (in production) or Adams (2010) for a description of the site layout procedures.

- 6.2.3.2 Samples taken for the purpose of regulatory assessment should be composited from 8 feet of surface area taken from multiple fast water habitats in the study reach. Aliquots may be from either turbulent (e.g. riffles) or non-turbulent habitat (e.g. glides), as long as flow is sufficient to carry organisms into the net.
- 6.2.4 For aliquots from **fast-water**, place the sampling device firmly against the stream bottom to eliminate gaps under the frame with the opening of the collection net facing the flow of water. Identify the surface area to be sampled. Gently scrub large substrate particles (larger than 5 cm in diameter) in front of the sampling device to remove any organisms that cling to the substrates and allow the flow to carry them into the mesh. After each particle in the sample surface area is cleaned, inspect it for any remaining organisms, and then set it outside of the sample area.
- 6.2.5 Suspend the substrate into the water column from the specified surface area and allow the flow of the water to carry the BMI into the mesh. This may be accomplished by kicking or using a trowel, for a minimum of 30 seconds, to stir up and suspend the substrate in front of the net.
- 6.2.6 If the aliquot is being taken in a **slack water** habitat, where flow is unable to carry the BMI's into the mesh, a different approach should be taken. First, visually inspect the stream bottom for any heavy or large organisms such as mussels and snails and place them in the sample jar. Pick up any loose rocks or large substrate particles and scrub them over the net, allowing the organisms to fall into the mesh and then set aside. After scrubbing, vigorously kick the remaining finer substrate within your sampled surface area and drag the net repeatedly (for 30-120 seconds) through the disturbed area just above the bottom. Keep moving the net all the time so the organisms remain trapped in the net and do not escape, and continue kicking. On completion of sampling, remove the net from the water with a quick upward/upstream motion to wash the organisms to the bottom of the net.
- 6.2.7 Wash the contents of the net down to the bottom for ease of placing the sample aliquot into a jar. Remove relatively large debris, i.e. pieces of wood or rocks from the net following inspection for attached invertebrates. Once the bulk of the aliquot is in the jar, carefully inspect the mesh itself and remove any remaining insects that may be stuck to the net. Adding a small amount of ethanol to the jar prior to sample collection helps to reduce the number of insects sticking to the net and minimizes sample degradation during the sampling event.
- 6.2.8 Add 95% non-denatured ethanol to equal 2/3 of the volume of the total sample and add a label printed on waterproof paper to the contents of the jar (ratio is 3:1). Sufficient ethanol is necessary to preserve the contents of the jar until taxonomic enumeration.
- 6.2.9 Seal the jar securely, wrap the lid with electrical tape at the junction with the bottle, and affix a second label printed on waterproof paper to the outside of the jar. Contents are now ready to be delivered to the taxonomist for identification and enumeration.
- 6.2.10 To help minimize the risk of spreading invasive species before sampling in another stream/river, treat boots, boats, and nets according to EAP070 Environmental Assessment Procedure 01-15. <http://www.ecy.wa.gov/programs/eap/quality.html>

6.3 Data Reporting

- 6.3.1 At a minimum, a target of 500 organisms should be identified by the lab for each sample. There are occasional situations that lead to fewer than 500 organisms per sample and do not meet this target. In these cases, the lab should identify the entire sample. Acceptance of smaller count (<500 organisms identified) data into our database for assessment purposes will be allowed at Ecology's discretion.
- 6.3.2 Each organism should be identified to the "lowest practical level". "Lowest practical level" is generally to genus or species, unless the specimen is under-developed or has been damaged, preventing identification to this level. Adams (2010) outlined the standard taxonomic effort employed by EAP's status and trends monitoring projects (appendices G & H on <https://fortress.wa.gov/ecy/publications/summarypages/1003109.html>).
- 6.3.3 Lab data reported should include at a minimum:
 - 6.3.3.1 Lab Name/Taxonomist
 - 6.3.3.2 Integrated Taxonomic Information System (ITIS) Taxa Number
 - 6.3.3.3 Scientific name of taxa
 - 6.3.3.4 Collection date
 - 6.3.3.5 Sampling device
 - 6.3.3.6 Habitat sampling scheme (reach wide or targeted)
 - 6.3.3.7 Protocol used (narrow or wide)
 - 6.3.3.8 Number of organisms identified
 - 6.3.3.9 Density of taxa per meter square
 - 6.3.3.10 Number of each taxa by life stage
 - 6.3.3.11 Report number of damaged taxa and indicate if unable to identify to lowest level
 - 6.3.3.12 Report taxa uniqueness for non-specific identifications (to estimate diversity)

7.0 Records Management

- 7.1 List every sample on a Chain-of-Custody form submitted to the taxonomist. This form should include location, date, and sampling information.
- 7.2 The taxonomist will submit data to Ecology's EIM database at <http://www.ecy.wa.gov/eim/> or to [Puget Sound Stream Benthos](#). Arrangements should be made with King County DNR to give permissions for the taxonomist to submit data to the Puget Sound Stream Benthos website.

8.0 Quality Control and Quality Assurance Section

8.1 Field Quality Assurance

- 8.1.1 *Visit precision* measures variability in the sampling method and is related to the variability of collecting a composite sample in a reach. *Visit precision* is estimated by

collecting side-by-side duplicate composite samples of the invertebrate communities within the same reach during the same day at 10% of the reaches sampled annually. *Visit precision* is calculated using the relative standard deviation (RSD) from two replicate composite samples and should be <20% in reference streams when using the taxa richness metric.

- 8.1.2 For additional information see the Quality Assurance Monitoring Plan for Ambient Biological Monitoring in Rivers and Streams: Benthic Macroinvertebrates and Periphyton (Adams, 2010). Appendix C in <https://fortress.wa.gov/ecy/publications/summarypages/1003109.html>

8.2 Macroinvertebrate Sorting Efficiency

- 8.2.1 Quality control procedures for initial sample processing and subsampling involves checking *sorting efficiency*. These checks are conducted on 10% of the samples by independent observers who microscopically re-examine the sorted substrate from each sample. All organisms that were missed are counted. *Sorting efficiency* is evaluated by applying the following calculation:

$$SE = n_1/n_2 \times 100$$

where SE is the sorting efficiency, expressed as a percentage, n_1 is the total number of specimens in the first sort, and n_2 is the total number of specimens in the first and second sorts combined. *Sorting efficiency* is recorded on each benchsheet by the person/lab enumerating the sample. If 95% sorting efficiency is not achieved for a given sample, a failure is recorded on the benchsheet and in the database. The sorted portion of that sample is then completely resorted before the sorting efficiency test is repeated for that sample. *Sorting efficiency* statistics for each technician and for the entire laboratory are reviewed monthly. Sorting efficiency for each sample in a project is reported to the client in the technical summary document. Technicians who do not maintain the target sorting efficiency are given remedial training, and larger portions of the samples they process are examined for the sorting efficiency test until they are able to maintain the target sorting efficiency.

- 8.2.2 A second evaluation of the sub-sampling process is applied to a small proportion of samples processed in each month; typically one sample per week is subjected to the following test of *precision of the sub-sampling process*. The procedure is only applied to samples where the target number of organisms was achieved in less than half of the Caton grids. A sample is randomly selected, and a second sub-sample is re-sorted from the unprocessed sample remnant. A second technician performs this sort. The resulting sub-sample is identified, and Bray-Curtis similarity index is calculated for the results of both sub-samples. Results that are less than 90% similar would indicate the need for more thorough distribution of sample materials in the sub-sampling tray or more special attention given to easily missed taxa when sorting (i.e. increased magnification).

8.3 Taxonomic Accuracy and Precision

- 8.3.1 Taxonomic misidentification results in inadequate biological characterization of a stream. Errors in identification should be less than 5% of the total taxa in the sample. Re-

identification of samples is conducted for 10% of the total number of samples in each year. Secondary identification is conducted by experienced taxonomists in order to maintain confidence in the data set. Difficult taxa should be sent to museum curators whose specialty includes members of the order in question. Voucher collections are maintained by the Orma J. Smith Museum of Natural History in Caldwell, Idaho. A voucher collection should be prepared from the set of samples for the year and shipped to the address below:

The Orma J. Smith Museum of Natural History
College of Idaho
2112 Cleveland BLVD
Caldwell, ID 83605-4432

9.0 Safety

9.1 Field Safety

All field staff must comply with the requirements of the EA Safety Manual (EA Program, 2012).

- 9.1.1 Sampling will not take place if the stream is not safe to enter.
- 9.1.2 Field work should be conducted by a team of two people at a minimum to ensure the safety of the sampler.
- 9.1.3 If a given sampling location within a study site/reach appears unsafe (such as too deep, too steep, or covered with loose material as a log jam), it may be shifted to allow sampling in nearby portion of the same or similar habitat conditions to the one avoided.
- 9.1.4 Proper field gear should be worn, including shoes with adequate lugging, felting, or studs to allow for traction on slick surfaces.

9.2 Chemical Safety

- 9.2.1 All employees should read this standard operating procedure and discuss any questions with her/his supervisor or task team leader.
- 9.2.2 Ethanol should be kept in small quantities in a tightly sealed container out of direct sunlight.
- 9.2.3 Read all relevant Material Safety Data Sheets (MSDS) before beginning this procedure. The MSDS are available in the Ecology benthic laboratory located at the EAP Operations Center.
- 9.2.4 Report to supervisor immediately any symptoms or reactions that might be related to Ethanol exposure.


10.0 References

- 10.1 Adams, K., 2010. Ambient Biological Monitoring in Rivers and Streams: Benthic Macroinvertebrates and Periphyton – Quality Assurance Monitoring Plan. Publication No. 10-03-109. Washington State Department of Ecology, Olympia, WA.
<https://fortress.wa.gov/ecy/publications/summarypages/1003109.html>
- 10.2 Environmental Assessment Program, 2012. Environmental Assessment Program Safety Manual. Washington State Department of Ecology. Olympia, WA.
- 10.3 Environmental Assessment Program 2011. Environmental Assessment Program Chemical Hygiene Plan and Hazardous Materials Management Plan. Washington State Department of Ecology, Olympia, WA.
- 10.4 Hayslip, Gretchen, editor. 2007. Methods for the collection and analysis of benthic macroinvertebrate assemblages in wadeable streams of the Pacific Northwest. Pacific Northwest Aquatic Monitoring Partnership, Cook, Washington.
<http://www.pnamp.org/document/1359>

FIELD PROTOCOLS FOR BANKFULL WIDTH AND DEPTH

Extracted from Aquatic Inventories Project, Methods for Stream Habitat and Snorkel Surveys (Oregon Department of Fish and Wildlife, Version 26.1, May 2016)


GUIDE TO MEASURING CHANNEL METRICS



Step 1: Clinometer (CLINO) identifies his eye height on the depth staff.




Step 2: CLINO and survey partner (TAPE) discuss and agree on the active channel scour or margin on either side of the stream. **NOTE:** Channel metrics are to be conducted at the pool tail crest or at the top or bottom of a fast water unit type.




Step 3: TAPE places depth staff at top of the active channel. CLINO stands at the water surface. TAPE slides her hand down the depth staff until CLINO sees the hand come into view while keeping the clinometer on 0% slope.

Step 4: Subtract the height where CLINO saw the hand on the depth staff (Step 3) from the eye height established in Step 1. This is the height above the water surface ("A" in Step 3).



Step 5: CLINO takes the end of the tape measure and starts across the channel while TAPE stays at the active channel margin. CLINO takes 3 depth measurements at $\frac{1}{4}$, $\frac{1}{2}$, and $\frac{3}{4}$ distance of the active channel width while crossing the channel (the measurements are usually the water depth but occasionally can be an exposed gravel bar above the water surface - thus a negative value).

Step 6: Take the average of the three measurements. The example in Step 5 has the measurements 0.15, 0.30, and -0.15 (average = 0.10). Add this value to the measurement "A" obtained in Step 3. This sum is the Active Channel Height (ACH). It is also equivalent to the bankfull depth.



Step 7: TAPE repositions her hand at CLINO's eye height on the depth staff. On the other side of the stream, CLINO backs up the bank until his eye is level with TAPE's hand on the depth staff (using the clinometer at 0% slope). CLINO has now established the active channel margin on the other bank. The distance between CLINO and TAPE is the Active Channel Width (ACW) as x depicts above. It is also equivalent to the bankfull width.

FIELD PROTOCOLS FOR WETTED WIDTH AND DEPTH

The purpose of these measurements are to provide a general context for site conditions at the time of each field visit, and for comparison of overall flow conditions between successive site visits. A single measurement of the width of the wetted channel at the time of each visit should be taken as close to the location of the sensor installation as possible but avoiding any vertical or near-vertical artificial streambanks (e.g., under a bridge or inside a culvert). Measurements should be made with a tape measure at each transect.

The depth measurement should be taken at the deepest point along the transect with a ruler or stadia rod. Width, depth, and location of the depth measurement should be recorded on the same form used for the visual observation of stage.

FIELD PROTOCOLS FOR SUBSTRATE COMPOSITION

Pages extracted from Salmonid Habitat Protocol for CHaMP

8.6 Particle Size Distribution and Cobble Embeddedness

Equipment: Gravelometer, depth rod.

Objective: Quantify the size distribution of substrate in fast water habitats and to estimate cobble embeddedness.

8.6.1 Particle Size Distribution

Step 1. Determine where to place cross-sections.

- i. Count the number of Tier II riffle channel units that occur within the main channel and large side channels.
 - a. If there are ≥ 10 riffles, place one cross-section in each of the first 10 riffles (working upstream).
 - b. If there are less than 10 riffles, evenly distribute additional cross-sections into riffles according to the proportion of stream length that each unit comprises relative to the other riffles. If there is not enough space to conduct all measurements in riffles (see Step 1, ii, c), then evenly distribute remaining cross-sections into non-turbulent units (working upstream). If there is not enough space to conduct all measurements in riffles and non-turbulent units, then distribute remaining cross-sections into rapids.
- ii. Cross-section location and spacing.
 - a. When there is only one cross-section in a unit, place the cross-section at the midpoint of the unit.
 - b. When there are multiple cross-sections in a unit, equally space the cross-sections throughout the unit (Figure 29). Cross-sections should be oriented perpendicular to the bankfull channel.
 - c. Cross-sections should not be closer than $1/100^{\text{th}}$ of the site length apart. Move additional cross-sections to the next largest unit if too crowded. For example, the minimum spacing between cross-sections at a 120 m long site would be 1.2 m.
 - d. Cross-sections should not cross two or more laterally adjacent channel units.




Figure 29. Example of how to distribute pebble count cross-sections at a site.

Step 2. Select 11 sampling points at each cross-section.

- At each cross-section, visually divide the cross-section into 11 equally spaced sampling points running perpendicular to the stream channel, and spanning the width of the bankfull channel. (Figure 30).




Figure 30. Example of a cross-section layout. In this example, distance between samples is 1 m, because the bankfull width is 12 m. Particle sample location is shown with a circle and crosshairs.

Step 3. Select and measure particles.

- i. Select particles at sample points by turning your eye away and extending your finger down and picking up the first particle that you feel at the tip of your boot.
 - a. Use a gravelometer (Figure 31) to classify the b-axis of each particle. Record the size category (Table 8) for the largest square opening that the particle does not fit through. For example, if the particle fits through the 180 mm square but does not fit through the 128 mm square it is classified as the 128-180 mm size class.
 - b. Record silt and clay particles that are < 0.06 mm in the 0.0002-0.06 mm size class. Silt and clay particles are smooth when rubbed between the thumb and fingers whereas sand rolls between the fingers (is gritty).
 - c. Use the thin edge of the gravelometer to determine sand particles between 0.06 and 2 mm. (Note the thin edge of the gravelometer is 2 mm wide).
 - d. For particles > 128 mm and < 512 mm, measure the b-axis using the notches at the top of the gravelometer.
 - e. For particles > 512 mm, measure and record the length of the b-axis using the top edge of the gravelometer or a depth rod.
 - f. Record “bedrock” when encountered at sample points.
 - g. If your finger touches a thin layer of fine sediment covering a larger particle, then measure the fine sediment, not the larger particle. Conversely, if your finger touches a rock covered by individual fine sediment particles; measure the rock.
 - h. **Do not measure stream bank particles.**
 - i. For embedded particles that cannot be removed from the stream bed, use the notched edge of the gravelometer or the depth rod to measure the b-axis, and record the appropriate size class.



Figure 31. Gravelometer used to classify the b-axis of particles.

Table 8. Size categories for sediment in the range of silt/clay to bedrock. Record the size range that the particle falls within (e.g., 45-64).

Description of particle size		Size Range (mm)	
		Lower	Upper
Bedrock		n/a	n/a
Boulder	mega	> 4000	n/a
	very large	2896	4000
		2048	2896
	large	1448	2048
		1024	1448
	medium	724	1024
		512	724
	small	362	512
256		362	
Cobble	large	180	256
		128	180
	small	90	128
		64	90
Gravel	very coarse	45	64
		32	45
	coarse	22.6	32
		16	22.6
	medium	11.3	16
		8	11.3
	fine	5.7	8
		4	5.7
very fine	2	4	
Sand		0.06	2
Silt/Clay		0.0002	0.06

FINAL TECHNICAL REPORT • SEPTEMBER 2016

Habitat Status and Trends Monitoring for the Lower Columbia Region: Quality Assurance Project Plan for the Regional Monitoring Program



PREPARED FOR

Lower Columbia Fish Recovery Board
2127 8th Ave.
Longview, WA 98632

PREPARED BY

Stillwater Sciences
108 NW Ninth Ave., Suite 200
Portland, OR 97209

- Part 1: Implementation Plan Report
- Part 2: Quality Assurance Project Plan for
the Urban Monitoring Program
(Urban HSTM QAPP)
- Part 3: Quality Assurance Project Plan for
the Regional Monitoring Program
(Regional HSTM QAPP)

Cover photos clockwise from top left: Monitoring on Burnt Bridge Creek (photo provided by City of Vancouver); Stillwater staff monitoring dissolved oxygen; LCFRB staff assessing habitat in the Hamma Hamma River (photo provided by LCFRB); turbidity sampling in Longview (photo provided by City of Longview).

Habitat Status and Trends Monitoring in the Lower Columbia Region

Part 3: Quality Assurance Project Plan for the Regional Monitoring Program

Prepared by:
Stillwater Sciences
for the Lower Columbia Fish Recovery Board and the City of Longview
Funded by Washington Department of Ecology Grant G1400531
July 2016

APPROVED BY:

Signature: _____ Steve Manlow, Project Manager Lower Columbia Fish Recovery Board	Date: _____
Signature: _____ Karen Dinicola, Washington Department of Ecology	Date: _____
Signature: _____ Chad Larson, Washington Department of Ecology	Date: _____
Signature: _____ Jeff Breckel, Director Lower Columbia Fish Recovery Board	Date: _____
Signature: _____ Jody Lando, Stillwater Sciences	Date: _____
Signature: _____ Derek Booth, Stillwater Sciences	Date: _____
Signature: _____ <i>To Be Determined</i> , Lab Director	Date: _____
Signature: _____ <i>To Be Determined</i> , Organization Quality Assurance Officer/Manager	Date: _____

Table of Contents - Part 3: Quality Assurance Project Plan for the Regional Monitoring Program

1	PROJECT DESCRIPTION	5
1.1	Summary of Tasks Needed to Begin Collecting Data	5
2	ORGANIZATION AND SCHEDULE.....	6
2.1	Project Schedule and Limitations	6
2.2	Budget Information for the Project.....	6
3	QUALITY OBJECTIVES.....	6
3.1	Decision Quality Objectives	6
3.2	Measurement Quality Objectives.....	7
4	SAMPLING PROCESS DESIGN	8
4.1	Experimental Design and Sampling Locations.....	8
4.2	Mid-study Changes Affecting Site Suitability.....	9
4.3	Field Criteria for Selecting a Suitable Sampling Site	9
4.3.1	Accessibility criteria.....	9
4.3.2	Flow, physical, and salinity criteria.....	10
4.3.3	Location criteria	11
4.4	Representativeness of Field Measurements.....	11
4.5	Comparability	12
4.6	Completeness.....	12
4.7	Candidate Site List for Monitoring Sites	12
5	SAMPLING PROCEDURES FOR REGIONAL MONITORING.....	12
5.1	Physical Habitat Indicators	12
5.1.1	List and rationale	12
5.1.2	Field sampling procedures for habitat indicators	14
5.2	Field Sampling Procedures for Continuous Temperature Measurements.....	33
5.3	Sampling Procedures for Benthic Macroinvertebrates	33
5.4	Field Safety Considerations	34
6	MEASUREMENT PROCEDURES FOR BENTHIC MACROINVERTEBRATES.....	35
7	QUALITY CONTROL FOR FIELD DATA COLLECTION.....	36
7.1	Field Quality Control for Habitat Indicators.....	37
7.2	Field Quality Control Procedures for Temperature Measurements	37
7.3	Field Quality Control Procedures for Benthic Macroinvertebrate Sampling.....	38
7.3.1	Sample holding times	38
7.3.2	Composite/grab field replicate samples.....	38
8	DATA MANAGEMENT PROCEDURES.....	39
8.1	Data Compilation.....	39
8.2	Database Design	40
8.3	Data Management for Habitat Indicators.....	40
8.4	Data Verification and Validation	41
8.5	Data Quality Assessment	42
8.5.1	Field.....	42
8.5.2	Laboratory	42
8.6	Quality Assessment.....	42
9	AUDITS	43
10	REPORTING	43
11	REFERENCES.....	44

Tables

Table 1.	Accuracy and precision limits.	7
Table 2.	Habitat indicators and their associated metrics.	13
Table 3.	Habitat and water quality indicators, data to be collected, recommended protocols, and programs with potentially shareable data.	14
Table 4.	Bank condition categories.	28
Table 5.	Half-phi intervals to be used when characterizing substrate particle size.	31
Table 6.	Sample containers, amounts, holding times, and preservation for samples	38
Table 7.	Field quality control schedule for benthic macroinvertebrate samples collected.	38

Figures

Figure 1.	Diagrams showing cross sectional and longitudinal concavity of pools	21
Figure 2.	Step pools are a series of pools separated by short riffles or cascades.....	21
Figure 3.	Riffles are shallow reaches with swiftly flowing, turbulent water with some partially exposed substrate.	22
Figure 4.	Run/glide habitat generally has a uniform to slightly varied stream bed and low to moderate velocities, lacking pronounced turbulence.....	22
Figure 5.	Cascades are steep riffle habitat, with a gradient of 4–8%, and boulder or bedrock substrate.....	23
Figure 6.	Example numbering scheme for a sample reach, in this case on the East Fork Lewis River.	24
Figure 7.	Illustration of bankfull width and other stream features.....	25
Figure 8.	Measuring bankfull depth and bankfull and flood-prone widths.....	26

Appendices

Appendix A-3.	Candidate Regional Monitoring Sites
Appendix B-3.	Detailed Field-collection Protocols
Appendix C-3.	Example Data Sheets

1 PROJECT DESCRIPTION

This QAPP is for the regional component of the Lower Columbia Habitat Status and Trends Monitoring (HSTM) Program, whose primary focus is on characterizing the status and trends of physical habitat in the rivers and streams of the Lower Columbia Region. A detailed project description and background information are provided in Part 1: Implementation Plan Report. The information below is provided to ensure quality data collection and analysis to meet the HSTM objectives, which broadly seek to characterize the status and trends of stream conditions across the Lower Columbia Region. A set of indicators will need to be measured with sufficient precision and statistical rigor to adequately characterize “status,” and over a sufficient period of time to discern any “trends.” Developing the specific approaches to meet these requirements was the primary task of the Design Report; specifying the procedures, timing, and locations for executing those approaches is the primary task of this QAPP.

This QAPP will be finalized and approved by the key signatories indicated at the beginning of this document in preparation for conducting the monitoring.

1.1 Summary of Tasks Needed to Begin Collecting Data

Candidate monitoring sites were identified in a previous HSTM program effort. The sites need to be confirmed, project staff must be identified, and equipment must be procured, accredited laboratories must be identified and selected, and the field sampling effort must be planned. The sequence of tasks required in advance of collecting data can be broadly summarized as follows:

- Identify a project manager and project staff.
 - Conduct staff training.
- Confirm the specific list of sites at which monitoring will occur.
 - Field evaluate the sites and assign site identification numbers.
 - Identify the 5-year sampling schedule.
 - Field-evaluate candidate sites for a given year based on access logistics and site security (for equipment deployment). Fifteen viable sites per strata should be identified.
- Plan field sampling and maintenance visits
 - Acquire all required field sampling equipment and permanently installed sensors.
 - Develop needed field forms for monthly and summer site visits.
 - Deploy sensors for continuous temperature monitoring, and initiate regular monthly maintenance schedule.
 - Plan and implement summer-season visits to collect habitat indicators and stream benthos.
- Select qualified laboratories.
 - Acquire necessary sample collection containers and chain of custody sheets.
- Complete final QAPP and submit for approval.

2 ORGANIZATION AND SCHEDULE

2.1 Project Schedule and Limitations

A detailed program schedule will be developed by Program Managers responsible for water quality, habitat and biological monitoring. Section 1.3 of the Implementation Plan (Part 1 of this report) provides a useful example of what should result from this forthcoming effort:

The recommended schedule for this effort is:

- Site reconnaissance—begin in March 2019 to ensure landowner approval, site access, and monitoring feasibility.
- Field training workshop—prepare field crews by the end of May 2019. All field personnel should participate in trainings every year.
- Continuous data collection—begins October 1, 2019 (the beginning of the water year).
- Summer season data collection—July 1–September 30 annually to capture low flow conditions, ensure field crew safety and avoid spawning fish and emerging fry in Lower Columbia tributaries. Sites at higher elevation should be sampled later in the season to allow flows to decrease following snowmelt.

2.2 Budget Information for the Project

As detailed in the Implementation Report, the anticipated total cost of the regional monitoring program is ~\$709,000. However, costs are expected to adjust by the time this program is implemented. There will be increases in rates and also anticipated cost savings via stakeholder support in the form of staffing and equipment. The final QAPP will make necessary adjustments to the scope to stay within the budget that is actually available as program implementation is initiated.

3 QUALITY OBJECTIVES

3.1 Decision Quality Objectives

“At the level of the decision, there is a need to specify tolerable limits of making decision errors. These tolerable limits are required, along with other information, to determine the numbers and locations of samples from the site that must be collected and analyzed.” (from Ecology 2004, page B-2) [<http://www.ecy.wa.gov/biblio/0403030.html>]

Principles established during Phase 1 of the HSTM project have specified that basing future management on the results of monitoring will require a robust statistical design. This is being accomplished through: (1) use of the Master Sample for the Lower Columbia Region, which applied a probabilistic site selection algorithm to generate a spatially-balanced set of sites, to implement status and trends monitoring; and (2) ensuring a sufficient number of sites in each unique monitoring strata combination that that a specified level of statistical confidence can be achieved (95% confidence and 80% power for water quality and 90% confidence and 80% power for habitat and biological indicators). In addition to these two criteria, a third has been added, namely that individual indicators should have a signal to noise ratio that is at least of “moderate” precision (Kaufmann et al. 1999), in order to improve the statistical likelihood that identified

trends in the data are reflecting true changes in environmental variables and not just random fluctuations or errors in measurement.

3.2 Measurement Quality Objectives (MQOs)

MQOs specifically are used to address instrument and analytical performance. “At the level of measurements used to support the decision or study question, quality objectives are expressed as measurement quality objectives or MQOs. The MQOs are performance or acceptance criteria for the data quality indicators precision, bias, and sensitivity” (from Ecology 2004, page B-2).

Because the HSTM program includes a wide variety of indicators, measurement quality objectives vary significantly between the various categories. An overarching focus for indicator selection has been to use only those metrics with relatively high levels of measurement precision and signal-to-noise. For the habitat indicators, commonly reported values for the precision of replicate values for those indicators recommended for inclusion in this program are on the order of 10% (e.g., Kaufmann et al. 1999). For the parameter measured with on-site sensors (i.e., temperature), typical values are within a few percent.

In addition, deployment, mid-deployment, and retrieval measurements using hand-held probes at the deployment location will be used to evaluate the accuracy criteria in Table 1. Note that the accuracy criteria also include errors associated with the instantaneous measurement results.

Table 1. Accuracy and precision limits.

Parameter	Accuracy	Precision (% relative standard deviation)
Temperature	±0.4°C	10

Continuous temperature data will be compared to post-calibration checks and grab sample results. Differences not meeting criteria in Table 1 may result in the affected data set being qualified or rejected, depending on the amount of difference and the number of checks that failed to meet the criterion. Precision MQOs are to be compared against the average relative standard deviation of data pairs collected during a deployment (Mathieu 2006).

Measurements of stream habitat indicators will be taken by field staff during each site visit. All field staff will follow the collection methods, reporting requirements, and quality control (QC) procedures summarized in this QAPP. This approach will provide field measurement data that meet measurement quality objectives for status and trends monitoring for small streams as described in this section.

Field staff will make a good faith effort to collect monitoring data described per QAPP requirements. If a measurement is missed on occasion, a second effort will be made to collect the sample within the same month. If a second attempt is also unsuccessful, then the Program Manager will be notified, and a third attempt is not required.

Reasons a sample or measurement may not be made include, but are not limited to: a stream goes dry; the stream site cannot be accessed due to high flow conditions, vandalism, extreme climatic conditions, or monitoring equipment has a sudden failure. Measurements made during very high flows may be made from anywhere within the site reach.

4 SAMPLING PROCESS DESIGN

4.1 Experimental Design and Sampling Locations

Sample site selection and evaluation occurs at two levels in this program. The first level involved the stratification of the target population into physically meaningful strata, appropriate to the monitoring activities and intended uses of the data, by use of GIS characterization of the stream and watershed characteristics associated with each point in the Master Sample. The second level, the actual determination of whether monitoring can occur at the designated location, is covered below.

Within each unique strata combination (termed a “bin”) for the regional monitoring program, 15 viable monitoring sites are needed to meet the statistical objectives. Because of recognized challenges with site access, a working assumption based on experience in the RSMP program is that about twice as many “provisional” sites need to be identified and evaluated in order to meet the final target number. In other words, individual strata combinations should have at least 30 points initially identified. To be conservative, we increased that recommendation and identified 45 candidate sites from the Master Sample for each bin (Appendix A-3). The 45 “provisional” sites should be sufficient to identify 15 viable monitoring sites within a bin. A bin must have at least 15 possible candidate sites in order to be included in the random draw. It is also important to consider the fact that sites must be physically independent of one another. This is unlikely to be an issue for the forested parts of the Region, given the vast number of channel segments. Due to a small number of sites that drain watersheds with predominately urban or agricultural land cover, however, it is likely that more than one regional monitoring site could be selected within the same stream segment. To avoid such clustering of sample locations and ensure the best possible distribution of sites, only one regional monitoring site will be sampled per stream segment. A detailed list will be kept of the sites not sampled and reasons for not sampling. This list will be used when adjusting the sample weights prior to statistical data analysis.

Across the regional sites, access to sites will undoubtedly be a limiting (or at least logistically challenging) factor for many of those that are selected by random draw from their respective strata. This may require a revisit and augmented selection from the Lower Columbia Master Sample to acquire a sufficient number of actual monitoring sites. The process of initial random selection, the outcome of site evaluations, and any subsequent re-drawing of additional points from the Master Sample will be documented in the initial report write-ups for the first year’s implementation of the program. In particular, the basis for site rejection will be highlighted.

Site evaluations, including a field visit to each candidate site, will be used to determine the suitability of each site for monitoring to meet the HSTM goals. Site suitability will be determined by selection criteria related to accessibility, hydrologic and geomorphic characteristics (flow, physical features, and salinity), and location relative to a candidate sites’ original coordinates (see below).

In order to maximize the statistical rigor of the monitoring program and to be consistent with other regional monitoring designs (e.g. AREMP, the Aquatic and Riparian Effectiveness Monitoring Program for the Northwest Forest Plan), regional monitoring sites will be visited in a rotating panel design as illustrated in the graphic below such that 1/5th of the sites would be visited each year and the full region will be sampled within a 5-year time period. To enable “repeat visits”, the sites monitored in years 1-5 will be resampled according to the same annual schedule in years 6–10, 11–15 and so on. Given this implementation approach, regional status can

be assessed annually for sites sampled in any given year, whereas trends will be evaluated at “repeat sites” on a 5-year rotation beginning in year 6.

	Year									
	1	2	3	4	5	6	7	8	9	10
Group A	X					X				
Group B		X					X			
Group C			X					X		
Group D				X					X	
Group E					X					X

Desktop evaluation of candidate regional sites will be performed in advance of the initial site evaluation visit, and will include comparing candidate site coordinates to existing information on such items as surficial geology, parcel/property ownership, NHD waterbody type, historical stream flow and/or water quality data, and aerial photographs. For all of the initial candidate sites deemed unsuitable for monitoring, additional candidate sites for the relevant assessment region will be evaluated in the numerical order listed in the Master Sample Site list (from lowest to highest in the SITE-ID column whose numbers are prefixed with “WAM”).

The locations of potential sampling sites is difficult to display because the full population of >100,000 Master Sample points cannot be shown on a single page. Thus, only partial representations are possible in a written report. Several such examples are shown in Section 2.1.2 of Part 1 of this report; specific sampling locations are provided as separate digital files as part of the Implementation Plan.

4.2 Mid-study Changes Affecting Site Suitability

If a site becomes unsuitable for sampling during the course of the study, the Monitoring Coordinator will be notified. Reasons a site may become unsuitable include, but are not limited to: a stream goes dry; the adjacent parcel(s) change ownership, and the new owner does not grant permission; or natural causes such as mudslides or animals make the site no longer safe to access. A decision about whether to simply discontinue the site or to identify a replacement site within the same strata combination will be made by project partners on the basis of its position in the rotating panel design, the amount of data already collected, and whether the strata combination would become underrepresented if the site (and, potentially others) were simply discontinued without replacement.

4.3 Field Criteria for Selecting a Suitable Sampling Site

The process may need to continue through the sampling season as necessitated by potential changes in site conditions that affect suitability for sampling. Selection criteria for determining the suitability of a candidate site for monitoring to meet the HSTM goals are described below.

4.3.1 Accessibility criteria

These criteria concern whether land owners permit access to a site, and if the site can be safely accessed and sampled throughout the year. A site may also be deemed unsuitable or impractical

for sampling certain if more than one hour is required to access the site from the nearest parking location.

If a candidate site is not obviously accessible through public property, property owners and/or tenants whose property will need to be accessed will, if feasible, be contacted prior to site evaluation. Parcel information gained from the desktop evaluation will be researched and a good faith effort to contact owners or tenants will be made. A site will be deemed unsuitable for sampling if permission has been denied by all land owners, tenants, or resource managers along the entire hydrologic reach. The Washington State Department of Ecology (Ecology 2014) describes how to discern public and state-owned waters.

Overall safety conditions for access and sampling will be assessed prior to sampling, based on state and federal law and organizational policy. But it is ultimately the responsibility of the field crew at each time of arrival to decide if it is safe to enter the stream to conduct the sampling. Appropriate reasons for disqualifying a site from sampling may include:

- flow is too swift or too deep;
- route of entry is unstable;
- hostile people or animals are present.

Site security for installation of long-term continuous sampling equipment is also a consideration. The field crew will make a judgment call as to whether equipment is likely to be subject to tampering or vandalism.

4.3.2 Flow, physical, and salinity criteria

These criteria concern the conditions of the stream and streambed with regard to the specific types of data desired. To be considered a suitable sampling site, the waterbody at the candidate site coordinates must be on a stream or small wadeable river, and not on a lake, pond, wetland, or estuary. Specifically, the waterbody must have:

- a net flow of water that is unidirectional;
- defined left and right banks readily discernible from mid-stream;
- uninterrupted surface-water flow for more than half the length of approximately 20 bankfull widths or a minimum of 150 meters surrounding the candidate site coordinates;
- perennial flow (as best as can be determined at the time of the site visit);
- flow in a natural channel that might have been highly modified, but was not constructed (such as canals, ditches, or pipelines);
- natural substrate on the channel bottom; and
- Freshwater, as defined by a water column with more than 95 percent of its depth with less than 1 part per thousand salinity at any time during the year.
 - Multiple lines of evidence may be used to make this estimation (e.g., vegetation, proximity to a known estuary, or salinity measurement).
 - As noted in the Design Report, streams subject to backwater from the Columbia River are not considered suitable sampling sites for this program.

4.3.3 Location criteria

The following location rules apply such that the site reflects the intended probabilistic stream characteristics. During the site evaluation field visit, the field crew will attempt to access the site at the given coordinates or as nearby as possible, with recognition of the challenges of sampling in urban areas, particularly in gaining access to discretely defined locations.

Ideally, for habitat monitoring, a suitable sampling location will be located within 250 meters of the given candidate site coordinates. If access, flow, physical, and chemical criteria are not met within this distance, the field crew may continue to investigate locations upstream and downstream of the initial reach with the objective finding a suitable site that maintains the original candidate site characteristics.

Suitable habitat sampling sites upstream and downstream of the candidate site coordinates must fall within these constraints:

- the final site is the same size class of the original candidate site;
- there are no continuous surface-water inflows in excess of approximately 25 percent of the flow already in the reach; and either:
 - there is no substantial, abrupt change in adjacent land use such as from residential to industrial, or from native vegetation to developed conditions; or
 - the final site is less than 500 m from the original candidate site coordinates.

4.4 Representativeness of Field Measurements

“Representativeness” is a property of both the region being assessed and the parameter being measured (Ecology 2006). The probabilistic sampling design is intended to achieve statistically valid spatial representations of stream status and trends at the scale of the entire Lower Columbia Region. Field measurements (except for those made by continuous data-collecting sensors) will be conducted in the summer, a period when hydrologic, physical, and biological conditions are most stable and the likelihood of confounding high flows is low. Ensuring that the laboratory measurements of field-collected samples are representative of those field conditions, established procedures for sample holding time, equipment calibration, and analytical duplicates as described for each parameter below.

Most of the field measurements conducted at habitat sampling locations are conducted throughout the entire 20×-bankfull-width-long reach, ensuring that results are truly “representative” of the reach. This distance is designed to include multiple pool-riffle or step-pool sequences in an alluvial channel coupled with measurements at 11 transects to avoid overrepresenting unique characteristics of any one segment. Variability will be reduced through refinement of site selection and rotating panel designs. Field personnel will record where samples are measured and note general descriptions of physical conditions of the channel, gradient, habitat types, water velocity, weather, and other parameters or unique local features that could influence data quality. These narrative field notes can be used to qualitatively assess how well the data represent the conditions characterized by this study, should any questions later arise about the representativeness and accuracy of the measured indicators.

4.5 Comparability

All sites with once-per-year measurements will be visited during summer low-flow conditions, and the field methods will be documented in sufficient detail to ensure comparable results. The selection of indicators has been guided by the need to avoid those with recognized high levels of observer variability, and so many of the problems of (in) comparability that plague other such monitoring efforts have been addressed through the initial design. For the continuous measurement of temperature, field sensors will be similar or identical at all sites, and episodic calibration with hand-held thermometers will ensure that the data are equivalent across all sites.

4.6 Completeness

Completeness will be calculated as a percentage of the number of valid samples that should have been collected relative to the number that actually are obtained. The standard for completeness is 90% in order that the data can be determined as valid in proportion to the goals for the project as a whole.

4.7 Candidate Site List for Monitoring Sites

A candidate habitat site list is provided in Appendix A-3, which includes 45 sites for each viable strata combination. Sites will be evaluated according to selection criteria for suitability (see above). The first 15 sites of the listed 45 that meet sampling criteria will be selected as the monitoring sites for a given strata combination.

5 SAMPLING PROCEDURES FOR REGIONAL MONITORING

5.1 Physical Habitat Indicators

5.1.1 List and rationale

Habitat indicators proposed in the Monitoring Design were carefully vetted by the Habitat Caucus to determine the most appropriate protocols based on a desire to balance efficiency, accuracy and shareability. In the process of making such decisions, two of the recommended indicators were deemed non-essential (embeddedness and thalweg depth) given the cost of measurement and their value relative to other indicators. The remaining indicators were determined to be the minimum set necessary to document and track the status and trends of habitat conditions in the Lower Columbia Region. The indicators also include a subset of contextual data to characterize the monitoring site, but not expected to change over time. In an effort to be consistent with other regional monitoring programs, we advised following existing protocols to the extent possible.

Table 2. Habitat indicators and their associated metrics.

Indicators*	Contextual data	Metric
1. Sample reach length ^{W,NW}	X	NA
2. Channel type ^{W,NW}	X	NA
3. Reach slope ^{W,NW}	X	Length-weighted average of individual slope measurements
4. Sinuosity ^{W,NW}	X	Ratio of centerline/straight-line lengths
5. Bank modification ^{W,NW}		Percent total
6. Density of habitat types ^W		Percent habitat for each type
7. Bankfull width/depth ^{W,NW}		Average of the unambiguous measurements for both bankfull width and bankfull depth
8. Pools per unit length ^W		Pools per unit length
9. Floodplain width ^{W,NW}		Categorize the floodplain width into categories scaled by bankfull width (e.g., 0-1 W_{bkt} ; >1 W_{bkt}) (bins TBD)
10. Side channel habitat ^{W,NW}		Qualifying channels – side channel length in meters; width and temperature measurements (upstream, midpoint and downstream); degree of connectivity to the mainstem (%). Nonqualifying—document presence only
11. Flow category ^{W,NW}		dry, puddled, low, moderate, high, bankfull, flood as defined by ODFW protocols. Modify “Low Flow” to include surface water flowing across <75% of active channel surface
12. Benthic Macroinvertebrates ^W		Samples processed to provide summary statistics/models (e.g., O/E and BIBI) to the lowest practical taxonomic level (Larson 2015).
13. Residual Pool depth ^W		Maximum pool depth minus pool crest depth
14. Bank stability ^W		Median of the 22 transect-specific measurements. The result is a categorical (not a decimal) value for the entire reach
15. Relative bed stability ^W		Ratio of reach D_{50} to [(average bankfull depth) $\times$ (reach slope)]; apply roughness correction if/as indicated by selected protocol
16. Density / distribution instream wood ^{W,NW}		Number of pieces and total wood volume (m^3) per unit length
17. Substrate particle size ^W		Median grain size (D_{50}); also D_{84} , D_{16} for the entire reach
18. Shade ^W		Shade score; could be reported as percent shade
19. Riparian canopy ^{W,NW}		% cover of vegetation > 5 m height
20. Riparian understory ^W		% cover of vegetation 0.5–5 m height
21. Temperature ^{W,NW}		7-day moving average maximum temp, daily maximum temp, average daily temp

* Indicators previously labeled “metrics” in the Monitoring Design Report.

W Wadeable

NW Non-wadeable

During the first or initial 5-year monitoring cycle, data on all 21 habitat indicators would be collected at each site. Four of these indicators (sample reach length, channel type, reach slope, sinuosity) are contextual and would be collected only during the initial 5-year monitoring cycle. During the second and subsequent 5-year monitoring cycles, the same sites would be revisited in the same sequence utilized during the first 5-year cycle. Only data on the 17 non-contextual indicators would be collected during these subsequent monitoring cycles.

5.1.2 Field sampling procedures for habitat indicators

Field sampling procedures are based on existing protocols. In some cases, the existing protocols are used without modification; in some cases existing protocols were modified to meet specific project goals; and in some cases entirely new protocols were developed when applicable pre-existing protocols were not available. Table 3 outlines the proposed indicators, a description of the data to be collected, the programs with similar (and potentially cross-shareable) data collected, and the protocol that serves as the basis for the data collection procedures. Text following Table 3 provides additional specifics on the collection methodologies for each indicator.

Table 3. Habitat and water quality indicators, data to be collected, recommended protocols, and programs with potentially shareable data.

Indicators**	Method/Measurement	Recommended protocols and programs with potentially shareable data
1. Sample reach length ^{W,NW}	Reach length (m). 20x BFW, 150m minimum, 500 m ^W /2000 m ^{NW} maximum. Use air photo for initial designation, followed by field confirmation	AREMP, CHaMP, EMAP, ODFW, SRFB, Ecology*
2. Channel type ^{W,NW}	Bedrock, colluvial, cascade, step pool, forced step pool, plane bed, pool-riffle, forced pool-riffle, regime (Montgomery and Buffington 1997)	Ecology*
3. Reach slope ^{W,NW}	Direct reading(s) of water-surface slopes using hand-held clinometer from top of reach to bottom (minimum number of segments as needed to visually span reach)	AREMP, CHaMP, EMAP*, ODFW, SRFB, Ecology
4. Sinuosity ^{W,NW}	Calculated ratio of (1) centerline channel length of the entire reach (measured by airphoto if possible; using field-measured thalweg profile [see below] if not), and (2) straight-line distance between the starting and ending points of the thalweg/centerline measurement	AREMP, EMAP, ODFW
5. Bank modification ^{W,NW}	% of human modified bank—both sides	EMAP*
6. Density of habitat types ^W	Length and width for distinct habitat types meeting minimum size criteria—pool, step pool, riffle, cascade habitat, falls, run/glide, dry channel	CHaMP, EMAP, ODFW, Ecology
7. Bankfull width/depth ^{W,NW}	Lengths of the bankfull width and depth, as identified using standard field indicators, at each of the 11 transects in a reach (measurements should be omitted at transects with ambiguous indicators)	AREMP, CHaMP, EMAP, ODFW*, SRFB, Ecology

Indicators**	Method/Measurement	Recommended protocols and programs with potentially shareable data
8. Pools per unit length ^W	Number of minimum-sized pools identified during habitat mapping, and total reach length	AREMP, CHaMP, EMAP, ODFW, Ecology*
9. Floodplain width ^{W,NW}	Employ field-based estimates; supplement with air photos for non-wadeable streams. Estimate width of the alluvial surface beyond the bankfull channel ^{W,NW} ; document presence of additional off-channel features such as scroll bars, oxbow lakes, etc.	EMAP, ODFW* Rapp and Abbe (2003)
10. Side channel habitat ^{W,NW}	Determine “qualifying” vs. “nonqualifying” side channels (defined by CHaMP) Length, width, temperature, connectivity to mainstem	CHaMP*
11. Flow category ^{W,NW}	Visual estimate of flow conditions at time of survey	ODFW*
12. Benthic Macroinvertebrates ^W	Employ Ecology’s transect-based methods—one kick sample at 8 of the 11 transects for either flowing or slack water. Details found in https://fortress.wa.gov/ecy/publications/documents/1003109.pdf	Ecology*, AREMP, CHaMP, EMAP, ODFW, SRFB
13. Residual Pool depth ^W	Maximum pool depth, pool crest depth	AREMP, CHaMP, EMAP, ODFW*, SRFB, Ecology
14. Bank stability ^W	Categorize bank condition at each end of each transect, integrating the conditions observed along the bank from the transect point up- and downstream half-way to the next adjacent transect (22 measurements)	EMAP*
15. Relative bed stability ^W	None, computation based on data from substrate particle size, bankfull depth, and reach slope	EMAP and Ecology
16. Density/distribution instream wood ^{W,NW}	Number and size of individual qualifying logs (AREMP protocol-minimum 15 cm dia., 3 m length). 1st ten pieces measured, then every 5th up to 35 pieces, then every 10th piece, size and location of accumulations and jams. Other pieces visually estimated; location of wood recorded (mid, bar, side, etc.)	AREMP*, CHaMP, EMAP, ODFW, SRFB, Ecology
17. Substrate particle size ^W	Randomly selected, “first-touch” grains across the entire bankfull channel along fast-water (i.e., riffle) transects only. Count number of grains per transect to achieve at least 200 grains counted per entire reach. Record b-axis length in 1/2-phi intervals; subdivide <4 mm grains into “sand” and “fines”	CHaMP*
18. Shade ^W	Canopy cover measured with densiometer (Mulvey et al. 1992 as cited by Ecology) on left bank and right bank for 11 transects and in 4 directions at each location	EMAP, SRFB, Ecology*
19. Riparian canopy (% cover) ^{W,NW}	Visually estimated for different vegetation types (see Ecology protocol) in a 10 x 10 m plot at 11 transects	CHaMP, EMAP, ODFW, SRFB, Ecology*

Indicators**	Method/Measurement	Recommended protocols and programs with potentially shareable data
20. Riparian understory (% cover) ^W	Visually estimated for different vegetation types (see Ecology protocol) in a 10 x 10 m plot on both banks at 11 transects	CHaMP, EMAP, ODFW, SRFB, Ecology*
21. Temperature ^{W,NW}	Temperature logged with hobo or similar data loggers at one representative location in the reach at half-hour intervals	AREMP, CHaMP*, EMAP, ODFW, SRFB, Ecology

* Asterisked program names reflect recommended protocols to be employed. If no program is identified, the method is specified in the table.

** Indicators previously labeled “metrics” in the Monitoring Design Report

W Wadeable

NW Non-wadeable

The specific field methods for each of the indicators above are provided below. In some cases, additional detail from the source protocols is provided in Appendix B-3 as needed. However, the source protocols are not reproduced in their entirety in Appendix B-3.

- 1) **Sample reach length.** Methods for determining the sample reach length are based on the Washington Department of Ecology (Ecology) protocols (for wadeable and non-wadeable streams), which are included in Appendix B-3. The sample reach length is based on the bankfull width. Bankfull width (see number 7 below) should be estimated off of aerial photographs prior to the initiation of field work. That way, crews will have an estimate of the length of the survey reach (and thus the level of effort) prior to deploying. Once in the field, first establish an “index station” and record its GPS coordinates. The index station is a transect near the access point or near the center of the survey reach. Measure the bankfull width (see number 7 below for methods of measuring bankfull width) at five locations near the index station:
 - a) The Index Station (X)
 - b) 1 bankfull width upstream from X
 - c) 2 bankfull widths upstream from X
 - d) 1 bankfull width downstream from X
 - e) 2 bankfull widths downstream from X

Record the average (nearest meter) of these 5 bankfull width measurements. Width measurements can be made using either a 50-m tape, a measuring rod, or (if the channel is wide, and/or non-wadeable) with a laser rangefinder.

Establish the length of the sample reach by multiplying the average bankfull width by 20. If the resultant length is less than 150 m or more than 500 meters (wadeable streams)/2000 meters (nonwadeable streams), set the reach length to those minimum (150 m) or maximum (500/2000 m) values.

Once the sample reach length has been determined, establish 11 transects (A-K) across the main channel only. Use orange flagging and a permanent marker to mark each of the 11 equidistant transects. Measure the distance between transects using either a 50-m tape, a

range finder, or a measuring rod, by following the thalweg of the stream. The distance between flags should be 1/10th of the site length (or 2 times the estimated bankfull width at the index station). GPS coordinates should be recorded for the upstream and downstream ends of each sampling reach.

- 2) **Channel type.** Determination of channel type is based on Ecology protocols and Montgomery and Buffington (1997), both included in Appendix B-3. Investigators will need to be familiar with the definitions of the below terms and channel classifications from Montgomery and Buffington (1997).

First decide whether the sample reach is predominantly colluvial, bedrock, or alluvial.

- a) Colluvial streams have a low chance of being sampled by this Status and Trends program, because we are limiting our sample to perennial streams.
 - b) Bedrock streams are confined locations with little depositional material present.
 - c) Alluvial streams transport and sort sediment supplied from upslope, and can have many different channel forms. If the site is predominantly alluvial, decide which one of the following sub-classifications can be used to describe the site.
 - i) Cascade: cascade channel types have boulder substrates and tumbling flow. They occur on steep slopes, in narrow valleys. Pool spacing tends to be <1 channel width.
 - ii) Step-pool: step pool channels have cobble and boulder substrates, and are characterized by longitudinal steps formed by large clasts in discreet channel spanning accumulations. Pool spacing is every 1–4 channel widths.
 - iii) Forced step-pool: A forced step-pool morphology is one in which LWD forms most channel spanning steps that define the stream morphology (rather than the steps being formed by boulder and cobble).
 - iv) Plane-bed: plane-bed channels have gravel and cobble substrates, and typically do not contain pools. Instead, they tend to have long stretches of generally featureless beds.
 - v) Pool-riffle: Pool-riffle channels have an undulating bed with a sequence of bars, pools and riffles. They have gravel substrates, and pools every 5 to 7 channel widths.
 - vi) Forced pool-riffle: A forced pool-riffle morphology is one in which most pools and bars are forced (formed) by large woody debris, rather than being geologically formed.
 - vii) Dune ripple: dune-ripple morphology is most often associated with large, low-gradient, sand-bed channels (and are unlikely to be encountered at most sites in this monitoring program). The morphology is depth- and flow-dependent, but can have sand waves, dunes, and plane beds. Pools typically occur every 5 to 7 channel widths.
- 3) **Reach slope.** The reach slope methodology is a modification of the EMAP and Ecology protocols. These protocols record both slope and bearing, and thus, references to measuring bearing in Appendix B-3 should be disregarded. In non-wadeable streams, slope will be estimated using a GIS-based approach.

Slope is measured by two people, each having a surveyor's rod or pole that is marked at the same height. Alternatively, the second person can be "flagged" on their person at the eye

level of the person doing the backsighting (the “surveyor”). The surveyor’s eye height must be marked on the other person prior to commencing the survey, while standing on level ground. The surveyor must sight their eye height when backsighting to their coworker or coworker’s survey rod. When two marked poles are used, the surveyor should site from the mark on one pole (which is not necessarily set at their eye height) to the mark on the other. Also, be sure that the second person is standing (or holding the marked pole) at the water’s edge or in the same depth of water as the surveyor. The intent is to get a measure of the **water surface slope**, which may not necessarily be the same as the bottom slope.

The surveyor reads both percent slope and degrees of the slope angle off the clinometer; being careful to read and record percent slope. Percent slope is the scale on the right-hand side as you look through most clinometers. Verify this by comparing the two scales. Percent slope is always a higher number than degrees of slope angle (e.g., 100% slope=45° angle). For slopes > 2%, read the clinometer to the nearest 0.5%. For slopes < 2%, read to the nearest 0.25%. If the clinometer reading is 0%, but water is moving, record the slope as 0.1%. If the clinometer reading is 0% and water is not moving, record the slope as 0%.

It may not be possible to read the water surface slope along the entire reach length from one position. In such a case, the crew should record the slope for the minimum number of segments needed to visually span the reach. Backsites should be done from one pre-determined transect to another downstream transect (measurements need not be taken between each transect). Record the distance and percent slope for each reading. During data processing and analysis, the slope of the entire reach will be calculated as a length-weighted average of the individual slope measurements.

- 4) **Sinuosity.** Sinuosity is a desk-top calculation conducted during data analysis and processing. It is measured as the centerline channel length of the entire reach (measured by aerial photograph if possible; or alternatively from the field-measured thalweg lengths of all habitat units combined); divided by the straight-line distance between the starting and ending points of the sample reach (based on an aerial photo measurement).
- 5) **Bank modification.** The bank modification measure is the % (based on visual estimates) of the bank with human modification and is based on the EMAP protocol. For the left and right banks at each of the 11 detailed Channel and Riparian Cross-Sections, evaluate the presence/absence and the proximity of 11 categories of human influences:
 - a) walls, dikes, revetments, riprap, and dams
 - b) buildings
 - c) pavement (e.g., parking lot, foundation)
 - d) roads or railroads
 - e) inlet or outlet pipes
 - f) landfills or trash (e.g., cans, bottles, trash heaps)
 - g) parks or maintained lawns
 - h) row crops
 - i) pastures, rangeland, or hay fields
 - j) logging
 - k) mining (including gravel mining)

Additional detail is provided by the EMAP protocol (Appendix B-3). Field crews will relate their observations and proximity evaluations to the stream and riparian area within 5 m upstream and 5 m downstream from the transect. Four proximity classes are used:

- In the stream or on the bank within 5 m upstream or downstream of the cross-section transect
- Present within the 10 m × 10 m riparian plot but not in the stream or on the bank
- Present outside of the riparian plot
- Absent.

If a disturbance is within more than one proximity class, crews will record the one that is closest to the stream. A particular influence may be observed outside of more than one riparian observation plot (e.g., at both transects “D” and “E”). Record it as present at every transect where you can see it without having to sight through another transect or its 10 m × 10 m riparian plot (see number 19 below).

- 6) **Density of habitat types/units.** Channel/habitat units are relatively homogeneous lengths of stream channel with consistent water surface gradient, bedform profile (channel topography), substrate composition, and flow characteristics. The identification of habitat units provides the context for the survey of fish habitat attributes and channel topography. The proposed habitat typing methodology has elements of the EMAP, Ecology, and ODFW protocols, but is not identical to any of them. Unlike the EMAP and Ecology protocols, habitat typing is NOT to be done in conjunction with a thalweg protocol. The proposed methodology is most aligned with the ODFW protocol, but has fewer habitat type categories. The proposed habitat types and their definitions are as follows:

Habitat type	Defining characteristics
Pool (P)	Pools (Figure 1) are laterally and longitudinally concave, with sorted finer substrate or bedrock, and laminar (non-turbulent) flow. Pools differ from runs/glides in being more concave, with a clear control feature (shallow “tail crest”) on the downstream end. Pools are typically broken into multiple sub-types (scour pools, dammed pools, trench pools, etc.), but for this protocol, any concave feature with a smooth water surface and generally finer substrates than adjacent units, will be typed simply as a “pool,” regardless of how and where they are formed. In order to qualify as a pool, the maximum depth must be at least 1.5 times the tail crest depth.
Step pool (STP)	Step pools (Figure 2) are a series of three or more steplike pools separated by short turbulent water. The length of the turbulent water cannot exceed the average wetted width. If the stretches of the turbulent water separating the pools are longer than they are wide, both the turbulent water and pools are typed and measured separately. Step pools were adopted as the only subtype of pool because the short intervening cascades are difficult and time consuming to measure.
Riffle (RFL)	Riffles (Figure 3) are fast, turbulent, shallow water, over submerged or partially submerged substrates. They are generally broad and uniform in cross section. The gradient of riffles is < 4%.
Run/glide (RG)	Runs/glides (Figure 4) have uniform depth, low gradients, and low morphological complexity. They generally have small cobble, gravel, or fine substrate, along with smooth, even (laminar) flow, and no surface turbulence. Runs/glides differ from riffles in their greater depth and lack of surface turbulence, and differ from pools in being not convex and lacking in an obvious downstream control feature.
Cascade (CAS)	Cascades (Figure 5) are high gradient riffles with large substrate, and often high water velocities. The gradient of cascades is typically 4-8% or more. Cascades differ from step pools in that they lack defined intervening “steps.”
Falls (FLS)	Falls differ from cascades in that they have a single hydraulic drop, whereas cascades have multiple hydraulic drops, often separated grouped or individual boulders.
Dry channel (DC)	A dry channel is a channel of any morphology, lacking water at the time of the survey. During high flows, dry channels could possess any of the other geomorphological units.




Figure 1. Diagrams showing (A) cross sectional (lateral) and (B) longitudinal concavity of pools (from CHaMP 2013).




Figure 2. Step pools are a series of pools separated by short riffles or cascades. Generally found in high- gradient, confined mountain streams dominated by boulder substrate. (from Flosi et al. 2010).




Figure 3. Riffles are shallow reaches with swiftly flowing, turbulent water with some partially exposed substrate. Gradient $< 4\%$, substrate is usually cobble dominated. (from Flosi et al. 2010).




Figure 4. Run/glide habitat generally has a uniform to slightly varied stream bed and low to moderate velocities, lacking pronounced turbulence. Substrate usually consists of cobble, gravel, and sand (from Flosi et al. 2010).




Figure 5. Cascades are steep riffle habitat, with a gradient of 4-8%, and boulder or bedrock substrate. (from Flosi et al. 2010).

Field crews will begin habitat typing at the downstream end of the survey reach. The reach will be delineated into the above habitat unit types and each unit will be assigned a unique number as crews proceed upstream. Streams will be given a unique identifier, which will be easily recognizable. Generally this will be the first few letters of the stream name, but the specific naming scheme is left up to the discretion of the implementing agencies. The habitat unit numbering scheme will simply be sequential from downstream to upstream, followed by the 1- to 3-letter code for the habitat unit type. Figure 6 illustrates the numbering scheme for the East Fork Lewis River.




Figure 6. Example numbering scheme for a sample reach, in this case on the East Fork Lewis River. The qualifying side channel (in yellow) is not delineated into habitat units. Stream flow is from right to left.

In the habitat units crews will collect:

- a) Length of the unit down the thalweg
- b) Three wetted width measurements
- c) Depth at thalweg at each wetted width transect
- d) Maximum depth (pool units only)
- e) Pool tail crest depth (pool units only)

Measurements are to be made with a 50-meter tape or a laser range finder (accurate to within one meter), and a metric surveyor's rod. In narrow channels (less than 20 meters) a tape or range finder with a higher degree of accuracy (than one meter resolution) should be used.

The mean wetted width and mean depth of all units will be calculated, along with the residual pool depth (see Number 13 below), and number of pools per unit length during data processing and analysis. The percentage by surface area of each habitat unit type present in the reach will also be calculated.

- 7) **Bankfull width and depth.** Bankfull width and depth will be collected at each of the eleven transects established in Number 1 above. This protocol is a modification of the ODFW protocol for bankfull width and depth (note that ODFW refers to the bankfull level as the "active channel height" and includes some additional measurements).

In unconstrained channels, bankfull level is the point where over bank flow begins during a flood event (with a 1.5- to 2-year recurrence interval). This level can be identified by

interpreting evidence of bankfull flow atop the stream's banks (Figure 7). The most consistent indicators of bankfull flow are areas of deposition, as the top of these deposits (i.e., gravel bars) typically define the active floodplain (USDA Forest Service 2006). Other bankfull indicators include:

- a change in vegetation (i.e., from none to some, or from herbaceous to woody);
- a change in bank topography (a change in slope of the bank above the water's edge);
- a change in the particle size of bank material, such as the boundary between coarse cobble or gravel and fine-grained sand or silt;
- a line defining the lower limit of lichen colonization on boulders or bedrock;
- a stain line visible on bare substrate such as bedrock;
- a defined scour line (exposed roots, etc.); and
- a line of organic debris on the ground (but not debris hanging in vegetation) (USDA Forest Service 2006).




Figure 7. Illustration of bankfull width and other stream features (adapted from Groenier and Gubernick 2010).

Refer to Harrelson et al. (1994) for additional discussion of bankfull indicators.

Bankfull depth will be measured with a clinometer or laser rangefinder (equipped with a level) and a survey rod. One crew member (the surveyor) will record elevations (or rod heights) of the channel thalweg and bankfull level, while the other crew member (the rod holder) holds the rod. Steps for estimating bankfull depth include:

- Identify locations of the thalweg and bankfull elevation at the transect using the indicators described above.
- The surveyor will then stand straight-up, in a location higher than the bankfull elevation where he or she can see both the bankfull elevation and the adjacent thalweg of the transect.
- The rod holder will then place the survey rod on the stream bottom at the thalweg and hold it vertically (#1 in Figure 8).

- d. The surveyor will view the survey rod through a clinometer or rangefinder and record the height of the rod that is level with their eye height.
- e. Next, the rod holder will move and place the survey rod at the bankfull elevation of the transect (#2 in Figure 8).
- f. Without moving, the surveyor will look at the rod through a clinometer or rangefinder and record the rod height at the bankfull elevation that is level with their eye height.
- g. Finally, the bankfull depth will be calculated by subtracting the rod height at bankfull elevation from the rod height at the thalweg elevation.
- h. Measure the bankfull width with a tape or laser range finder. Bankfull width is the distance between the left bank and right bank at the point where over-bank flow begins during a flood event (bankfull elevation), or at the OHW level in a constrained channel.




Figure 8. Measuring bankfull depth and bankfull and flood-prone widths (modified from Rosgen and Silvey 1998).

- 8) **Pools per unit length.** The number of pools (excluding step pool sequences) per unit length (entire sample reach length) will be calculated from data collected during #6 above. This calculation will be done during data analysis and processing.
- 9) **Floodplain width.** If LiDAR imagery is available, the floodplain width will be estimated based on visible erosional or depositional features, such as side channels and scroll bars at elevations similar to that of the main river. The field measurement of floodplain width, feasible only on small wadeable channels, is a modification of the ODFW protocol (Appendix B-3; note that in ODFW terminology, Bankfull depth = Active Channel Height), which presumes that the floodplain (i.e., the flat depositional geomorphic surface adjacent to the river) can be approximated by the *floodprone* area. This is commonly defined as the portion of the valley floor submerged during a 50-year flood, approximated by all areas adjacent to the channel at an elevation above the channel bottom no more than two times the bankfull depth (i.e., submerged by flows that are twice as deep as the bankfull flow). Estimating the floodprone width in the field is accomplished by first moving up or down the bank until the surveyor's eye height (as viewed through a clinometer held level) is twice their eye height on level ground, and then using a laser range finder (or tape) and a clinometer to identify its boundaries. During data processing, the ratio of floodprone to bankfull width is determined to quantify entrenchment: <2.5 for narrow valley floor channel types and >2.5 for

broad valley floor streams. This measurement is akin to the ODFW Valley Width Index [VWI].

Particularly on large, non-wadeable channels, the floodplain width is best determined from aerial photographs or LiDAR imagery if available.

10) **Side channel habitat.** The determination of whether a side channel is “qualifying” or “non-qualifying” is based on definitions in CHaMP, and discussed in detail in Appendix B-3. The below is a simplification of the CHaMP protocol; if more detail is needed, refer to Appendix B-3:

- a) First, Identify side channels.
 - i) Side channel: To be considered a side channel, the channel must be separated from another channel by an island that is $\geq$ the bankfull elevation for a length $\geq$ the average bankfull width. Side channels that do not meet these qualifications should be considered part of the main channel
- b) Second, identify side channel type.
 - i) Determine if side channel is qualifying or non-qualifying.
 - (1) Qualifying side channel: Channel is located within the active bankfull channel and separated from another channel by an island $\geq$ the average bankfull width.
 - (2) All other side channels are “non-qualifying.” Non-qualifying side channels may lack a defined streambed, contain terrestrial vegetation, or be above the bankfull width of the main channel.
- c) Determine whether qualifying side channel is large or small based on its portion of total stream discharge.
 - i) Visually estimate stream flow at both the upstream and downstream ends of the side channel as a percentage of the total flow at the site.
 - (1) Large side channel: Has between 16% and 49% flow at either end.
 - (2) Small side channel: Has $< 16\%$ flow at both ends.

For all small qualifying side channels, crews will record the following:

- Length (along the thalweg)
- Width (in three locations: near the head, confluence, and mid-distance)
- Connectivity to the mainstem (as an estimated percentage of total stream discharge)
- Temperature. Spot temperatures will be taken in three locations (at each width transect) in the side channel. The downstream width transect should be far enough upstream to avoid any back-water effects from the mainstem. These temperatures will be compared to the mainstem temperatures collected by the long-term data loggers.

11) **Flow category.** The flow at the time of the survey will be binned into one of the following categories (modified from ODFW):

- a) Dry
- b) Puddled (series of isolated pools connected by surface trickle or subsurface flow)
- c) Low (surface water flowing across less than 75% of the water-scoured [i.e., “active”] channel surface)
- d) Moderate (surface water flowing across 75-90 percent of the active channel surface)
- e) High (Stream flow completely inundating the active channel surface)

Sample reach surveys will ideally be conducted during summer low flow periods and should be avoided at flows above “moderate.”

- 12) **Benthic macroinvertebrates.** Benthic macroinvertebrates will be collected using the Ecology protocol (kick samples taken at 8 of the 11 transects in either flowing or slack water).
- 13) **Residual pool depth.** Residual pool depth will be calculated for all pools based on the maximum depth and pool tail crest depth recorded during Number 6 above. The minimum, maximum, and average residual pool depth for the sampling reach will be calculated and reported.
- 14) **Bank stability.** Bank stability is defined by the degree of erosion and is based on the characterization in the EMAP protocol. Steep banks are more likely to collapse and suffer from erosion than are gently sloping banks and are therefore considered to be unstable. Signs of erosion include crumbling, unvegetated banks, exposed tree roots, and exposed soil. The banks will be categorized at each end of each transect, and each measurement will be indicated with the transect letter (A-K from downstream to upstream) followed by an “LB” or “RB” for left bank and right bank (note that left and right are determined while facing downstream). The bank conditions will be characterized for a segment halfway between each of the two adjacent transects. . Bank condition will be characterized in one of four qualitative categories (poor, marginal, sub-optimal and optima) based on a visual estimate (see Table 4).

Table 4. Bank condition categories.

Optimal	Sub-optimal	Marginal	Poor
Banks stable; no evidence of erosion or bank failure.	Banks moderately stable; infrequent, small areas of erosion mostly healed over.	Moderately unstable; up to 60% of banks in reach have areas of erosion.	Unstable; many eroded areas; "raw" areas frequent along straight sections and bends; on side slopes, 60 to 100% of bank has erosional scars.

- 15) **Relative bed stability (RBS).** RBS is calculated as a ratio of the observed bed surface particle geometric mean diameter divided by the average critical diameter at bankfull flow (i.e., D_{gm}/D_{cbf} using the notation of Kauffmann et al. 2008). D_{gm} is the geometric mean particle diameter, which for most distributions can be approximated by the median particle diameter D_{50} (see Number 17 below). D_{cbf} is the critical (or maximum) diameter of particles that can be transported at bankfull flow, based on an equation for the threshold of motion based on the shear stress of the flow under bankfull conditions. This ratio expands to:

$$RBS = D_{gm} / (13.7 \cdot R_{bf} S)$$

where RBS is the relative bed stability index, R_{bf} is the hydraulic radius of the flow under bankfull conditions (well approximated by the bankfull depth in channels with width-to-depth ratios greater than about 10), and S is the water-surface slope. For a complete derivation of this formula and its modification where significant roughness elements (e.g., logs) are present see Kauffmann et al. (2008).

- 16) Roughness correction based large woody debris volume will be applied as necessary (see Kaufmann et al. 2008).
- 17) **Density/distribution of instream wood.** The Large Woody Debris (LWD) protocol is unmodified from the AREMP protocol in Appendix B-3, with two exceptions: 1) wood in qualifying side channels will not be tallied, and 2) as listed in Appendix B-3, the minimum size for a qualifying piece of LWD in the published AREMP protocol is 30 cm. AREMP modified this criteria downward to 15 cm. Therefore for this QAPP, qualifying pieces of LWD are defined as those at least 15 cm in diameter and at least 3 meters in length. LWD will be assessed/tallied within the whole sample reach; **not** independently within each habitat unit.

The sampling method for assessing LWD follows (refer to Appendix B-3 for figures illustrating the methodology described below):

- a) In order to be counted, each piece must meet all of the following criteria.
 - i) Each piece must be greater than 3 meters in length and at least 15 cm in diameter for one-third of its length, as measured from its base or largest end.
 - ii) Only include standing trees that lean within the bankfull channel if they are dead. Dead trees are defined as being devoid of needles or leaves, or where ALL of the needles and leaves have turned brown. Consider it living if the leaves or needles are green.

(1) *Note: Use caution when assessing the condition of a tree or fallen log. Nurse logs can appear to have living branches when seedlings or saplings are growing on them.*
 - iii) Wood that is embedded within the stream bank is counted if the exposed portion meets the length and width requirements.
 - iv) Do not count a piece if only the roots (but not the stem/bole) extend within the bankfull channel.
 - v) Some pieces crack or break when they fall. Include the entire length when the two pieces are still touching at any point along the break (Only count as one piece if they are from the same original piece of wood). Treat them separately if they are no longer touching along the break. Count only the portion within the bankfull channel when they are no longer touching.
- b) Record the piece number, length (nearest 10 cm) and width (nearest cm) of all pieces in in the sample reach.
- c) While the size of all wood pieces will be recorded, length and diameter will not always be measured for each piece, but may instead be estimated based on the procedure below. The same person should always be the estimator. A subset of pieces will be measured at sites with more than 10 qualifying pieces of wood (with the remainder estimated).
 - i) For sites estimated to have between 11 and 100 pieces, measure the first 10 pieces of wood encountered. Starting at piece number 11, measure every 5th piece of wood up to and including the 35th piece of wood. All subsequent pieces of wood will be measured every 10th piece (starting with number 45).
 - ii) For sites estimated to have over 100 pieces, measure the first ten pieces, then starting at the 11th piece only measure every 10th piece.
- d) If the piece of wood designated for measurement cannot be measured safely; then measure the next piece of qualifying wood. Then continue measuring as specified above.

- e) Measure the length of the main trunk and not branches or roots. Begin measurements where the roots attach to the base of the trunk when the roots are still connected.
- f) Do not measure (just estimate) standing dead trees, pieces buried in log jams, or pieces that are unsafe to measure.
- g) In assemblages, begin counting from the bottom up when pieces are stacked on each other.
- h) Wood in qualifying side channels **will not** be tallied.
- i) The percent of the wood submerged at bankfull is an estimate of how much of the piece of wood will be underwater when the stream reaches its bankfull height.
- j) Record the number of pieces touching, wood location and wood type. Evaluate wood location relative to the bankfull channel (refer to Appendix B-3 for diagrams and data collection sheets).

18) **Substrate particle size.** Bed surface substrate is measured using a modified Wolman Pebble Count procedure described in Harrelson et al. (1994). Of the protocols reviewed and used as a basis for this implementation plan, CHaMP using a modified pebble count to characterize substrate particle size. However, the CHaMP procedure differs significantly from that in Harrelson et al. (1994) and from that proposed in this QAPP. Pebble counts will be conducted at each of the 11 transects that crosses a riffle. At least one pebble count must be conducted per reach. If no riffles are present in the reach, pebble counts will be conducted in at least one other unit. Unit types for pebble counts in order of preference include: riffles, runs/glides, and pools. To conduct the pebble count, a two-person crew (a measurer and a note taker) start at a randomly selected point on the riffle transect by tossing a pebble into the stream from one of the bankfull elevations (not necessarily the present water level). With the measurer averting their gaze, he/she should pick up the first particle touched by the tip of their index finger at the toe of their boot. Using a ruler or gravelometer, measure the intermediate axis (neither the longest nor shortest of the three mutually perpendicular sides of each particle picked up). Measure embedded particles or those too large to be moved in place. For these, measure the smaller of the two exposed axes. The measurer will call out the measurement, and a note taker will tally the measurement by size class (1/2 phi intervals, Table 5). Particles <4 mm will be subdivided into “sand” and “fines” (silt and clay) on the basis of their “grittiness” between the fingers. The measurer will then take one step across the channel in the direction of the opposite bank and repeat the process, continuing until they reach the bankfull elevation on the opposite bank. All riffle transects should be assessed until at least 200 particles have been measured. If not enough riffle transects are present to collect 200 particle measurements, the measurer should double back across the transect. Be sure that all elevations are representatively sampled. The measurer may have to duck under bank-top vegetation or reach down through brush to get a spatially representative count. The measurer should move upstream or and make additional transects to sample a total of at least 200 particles. During data analysis and processing, the data will be plotted by size class and frequency to determine the D_{16} , D_{50} and D_{84} for the entire reach.

Table 5. Half-phi intervals to be used when characterizing substrate particle size.

Category	Size (mm)
Silt/clay	<0.062
Sand	0.062–4.0 (appx)
Gravels	4–5.6
	5.6–8
	8–11
	11–16
	16–22
	22–32
	32–45
	45–64
Cobbles	64–90
	90–128
	128–180
	180–256
Boulders	256–362
	362–512
	512–1,024
	1,024–2,048
	2,048–4,096
Bedrock	

19) **Shade.** Canopy cover will be measured as a proxy for shade using a densiometer facing upstream, downstream, left and right on the right and left banks at each of the 11 transects. This methodology is modified from the Ecology protocol in Appendix B-3. Changes made to the ecology protocol include only taking densiometer readings only on the stream banks (rather than the stream banks and in the center of the channel), and including four directional readings at each bank (rather than just two). The specific sampling methodology follows:

- a) Hold a modified convex densiometer (modified such that just 17 of the grid intersections are contained within a taped “V” – see Appendix B-3) 30 cm above the ground or wetted surface at the bankfull location. Readings are taken close to the ground so that they will record shade provided by low-growing vegetation
- b) Record how many of the 17 cross-hairs have shade over them. Do this for each of four directions at the bankfull elevation on both the right and left banks at each transect:
 - i) Facing left
 - ii) Facing right
 - iii) Facing upstream
 - iv) Facing downstream

- 20) **Riparian canopy cover.** The percentage of riparian canopy and understory cover (Indicator 20) will be recorded using an un-modified Ecology protocol, included in Appendix B-3. On each transect of the main channel, assess a plot on each bank. Each plot extends 5 meters downstream, 5 meters upstream, and 10 meters back from the bankfull margin. The riparian plot dimensions can be estimated rather than measured. On steeply sloping channel margins, plot boundaries are defined as if they were projected down from an aerial view. The specific sampling methodology includes:
- a) Conceptually divide the riparian vegetation into three layers:
 - i) Canopy (> 5 m high),
 - ii) Understory (0.5 to 5 m high),
 - iii) Ground Cover layer (< 0.5 m high).
 - b) Within each layer, consider the type of vegetation present and the amount of cover provided. Do this independently of what is contained in higher layers.
 - i) Cover quantity is coded as follows:
 - (1) 0—absent
 - (2) 1—sparse (< 10% cover)
 - (3) 2—moderate (10–40% cover)
 - (4) 3—heavy (40–75% cover)
 - (5) 4—very heavy (> 75% cover)
 - ii) The maximum cover in each layer is 100%, so the sum of the cover for the combined three layers could add up to 300%.
 - c) Determine the type and quantity of cover for each of the three layers: Canopy, Understory and Ground Cover:
 - i) Canopy
 - (1) Determine appropriate dominant vegetation type (Deciduous, Coniferous, Broadleaf Evergreen, Mixed or None)
 - (2) Indicate the appropriate cover quantity code (0—absent, 1—sparse [<10%], 2—moderate [10–40%], 3—heavy [40–75%], or 4—very heavy [>75%]) for each of 2 classes:
 - (a) Big trees—trees having trunks larger than 0.3 m diameter (at breast height)
 - (b) Small trees—trees having trunks smaller than 0.3 m diameter (at breast height)
 - ii) Understory
 - (1) Determine appropriate dominant vegetation type code (Deciduous, Coniferous, Broadleaf Evergreen, Mixed or None)
 - (2) Indicate the appropriate cover quantity code (0—absent, 1-sparse [<10%], 2—moderate [10–40%], 3—heavy [40–75%], or 4—very heavy [>75%]) for each of 2 classes:
 - (a) Woody vegetation—such as shrubs or saplings
 - (b) Non-woody vegetation—such as herbs, grasses, or forbs
 - iii) Ground Cover
 - (1) Indicate the appropriate cover quantity code (0—absent, 1-sparse [<10%], 2—moderate [10–40%], 3—heavy [40–75%], or 4—very heavy [>75%]) for each of 2 classes:

- (a) Woody (living)
- (b) Non-woody (living)
- (c) Bare dirt (or decomposing debris)
- iv) The sum of cover quantity ranges for these 3 types of ground cover should include 100%.

21) **Riparian understory.** (see above)

22) **Temperature.** The methodology for collecting long-term temperature data is included above.

5.2 Field Sampling Procedures for Continuous Temperature Measurements

Even before field measurements are taken, established procedures are required to ensure the highest degree of data quality. Field equipment will undergo routine cleaning, calibrations, and maintenance at the recommended frequency specified by each manufacturer and described in SOPs.

The sampling procedures will follow the detailed descriptions in Appendix B-3. Loggers will be deployed in locations where representative data may be obtained throughout the entire monitoring period. All loggers will be deployed inside a ~2-foot-long piece of 1.5-inch camouflage-painted PVC pipe to shade them from sunlight and to prevent them from being found and vandalized. In addition, each deployment location will be photographed and have site-specific survey information documented on a standardized form. Temperature loggers (e.g., VEMCO Minilog-II-T-351133) will be installed following manufacturer's instructions and downloaded on a regular basis, as determined by battery life and memory capacity. Spot checks during each visit will be made of temperature using a hand-held thermometer, with the time and temperature recorded in a field notebook for subsequent checking with the downloaded data to ensure that data-quality objectives are being met. The sampling protocols will follow the procedures described in the *Continuous Temperature Sampling Protocols for the Environmental Monitoring and Trends Section* (Ward, 2003) and in the *TFW Stream Temperature Survey Manual* (Schuett-Hames et al. 1999).

5.3 Sampling Procedures for Benthic Macroinvertebrates

Sampling will follow established State of Washington protocols (Larson 2015). This method describes how to collect benthic macroinvertebrate samples for conducting community-level assessments in Washington's Status and Trends Program.

Invertebrate sampling is one of the first methods to be performed on-site, after site verification and layout. Working upstream, one kick sample is collected at each of 8 randomly selected transects, half of which are located mid-channel and half located within the margins of the stream. Each kick sample will be added to a composite sample for the site.

A different procedure is needed for the collection of each kick sample depending upon whether the station sits within flowing water or slack water. Flowing water is where the stream current can sweep organisms into the net; slack water is where water is so slow that active net movement is required to collect organisms.

- For sampling at flowing water stations, position a D-frame kick net and quickly and securely on the stream bottom to eliminate gaps under the frame. Collect benthic macroinvertebrates from a 1 ft² (0.9 m²) quadrat located directly in front of the frame mouth. Work from the upstream edge of the quadrat backward and carefully pick up and rub stones directly in front of the net to remove attached animals. Quickly inspect each stone to make sure you have dislodged everything and then set it aside.
- For sampling at slack water stations, visually define a rectangular quadrat with an area of 1 ft² (0.09 m²). Inspect the stream bottom within the quadrat for any heavy organisms, such as mussels and snails. Remove these organisms by hand and place them into the sample jar. Pick up any loose rocks or other larger substrate particles within the quadrat and rub any clinging organisms off of rocks or other pieces of larger substrate (especially those covered with algae or other debris) into the net. Vigorously kick the remaining finer substrate within the quadrat with your feet while dragging the net repeatedly through the disturbed area just above the bottom.

For preservation, ethanol will be added to each sample jar so that the resulting solution consists of 1/3 sample and 2/3 ethanol. The sample jars will be stored by field crews and delivered *en masse* to the analytical laboratory at the end of the field season.

Scientific collection permits

The necessary permits for sampling macroinvertebrates will be obtained from the Washington Department of Fish and Wildlife (<http://wdfw.wa.gov/licensing/scp>). None of the other sampling recommended in this Implementation Plan is anticipated to require collection permits.

5.4 Field Safety Considerations

In any field data collection effort, there can be significant risks. It is the responsibility of each crew member, not just the crew lead, to insure the health and safety of crew members. A written health and safety plan must be prepared prior to the commencement of field activities. The health and safety plan must include at a minimum: phone numbers and a communication tree for notification should an emergency occur; maps to the nearest hospital, fire station, and/or emergency response facility; and the enumeration of the anticipated potential hazards.

All crew members must review and sign the health and safety plan during a field work “tailgate” kick-off meeting. During the tailgate meeting, the crew lead will summarize the potential hazards and ensure that all crew members are aware of safety procedures and appropriate lines of communication.

At least two crew members must be present during all field sampling activities. In areas where water or sediment contamination is known or suspected, exposure to water and sediments should be minimized. Crews may encounter hazardous materials, or sample preservatives may be hazardous if handled inappropriately. Crews should not disturb or retrieve improperly disposed hazardous materials. Field personnel should be familiar with the signs of heat stroke and hypothermia, and there should always be at least one person trained in first aid and CPR on every field crew.

Wadeable streams

Common hazards in wadeable streams include slip, trip and fall hazards; submerged objects; poisonous snakes, insects, and plants; and adverse weather conditions.

- Field crews must wear appropriate personal protective equipment (PPE), including waders (or at a minimum neoprene booties), hats, sunglasses (or safety goggles as needed), and should use sunscreen on exposed skin.
- When waders are worn, they must be equipped with a belt
- Extreme care should be used when walking on rip rap as rocks can easily shift
- Large woody debris (LWD) must be navigated carefully to avoid falls or getting pinned between pieces of debris
- First aid kits must be available at all times
- Appropriate gloves must be worn when agitating substrate for the collection of benthic macroinvertebrates
- Personnel with allergies to bees, other insects, poison oak, etc., must take proper precautions and have needed medications at the ready
- Motor vehicles must be operated with care and in observance of all applicable laws and regulations.
- Crews in remote locations must be equipped with radios or satellite phones.
- Crew leads must ensure that all equipment is in safe working order
- Sampling should be discontinued during thunderstorms

Non-wadeable streams

In addition to the above hazards, non-wadeable streams present an additional level of danger.

- All crew members must wear a personal flotation device (PFD) when operating or working from a boat.
- The boat operator should have a “kill switch” clipped to their person to avoid a runaway boat should they fall overboard.
- All boats must be equipped with fire extinguishers, horns (on-board or compressed air), flares, and floatation cushions or ring buoys.

6 MEASUREMENT PROCEDURES FOR BENTHIC MACROINVERTEBRATES

This section discusses the laboratory procedures for processing benthic macroinvertebrates that will be implemented to provide high quality data. Field QC procedures will be described in Section 7 of this report and monitored throughout the duration of the study. The quality of raw, unprocessed, and processed data is subject to review according to established protocols (below).

Taxonomic identification will be conducted by a lab that employs taxonomists certified by the Society for Freshwater Science with experience with the freshwater macroinvertebrates of the Pacific Northwest. Based on guidance from the Habitat Caucus and to be consistent with other regional monitoring programs, the target subsample size will be 500 and identification will be conducted according to Level 2 of the Northwest Standard of Taxonomic Effort

<http://www.pnamp.org/project/4210>.

Macroinvertebrate Sorting Efficiency

Consistent with Ecology protocols, quality control procedures for initial sample processing and subsampling involves checking sorting efficiency (Ecology 2010). These checks are conducted on

100% of the samples by independent observers who microscopically re-examine 20% of sorted substrate from each sample. All organisms that were missed are counted. Sorting efficiency is evaluated by applying the following calculation:

$$SE = n_1/n_2 \times 100$$

where SE is the sorting efficiency, expressed as a percentage, n_1 is the total number of specimens in the first sort, and n_2 is the total number of specimens in the first and second sorts combined. Sorting efficiency is recorded on each benchsheet, and this data is entered into a database. If 95% sorting efficiency is not achieved for a given sample, a failure is recorded on the benchsheet and in the database. The sorted portion of that sample is then completely re-sorted before the sorting efficiency test is repeated for that sample. Sorting efficiency statistics for each technician and for the entire laboratory are reviewed monthly. Sorting efficiency for each sample in a project is reported to the client in the technical summary document. Technicians who do not maintain the target sorting efficiency are given remedial training, and larger portions of the samples they process are examined for the sorting efficiency test until they are able to maintain the target sorting efficiency. A second evaluation of the sub-sampling process is applied to a small proportion of samples processed in each month; typically one sample per week is subjected to the following test of precision of the sub-sampling process. The procedure is only applied to samples where the target number of organisms was achieved in less than half of the Caton grids. A sample is randomly selected, and a second sub-sample is re-sorted from the unprocessed sample remnant. A second technician performs this sort. The resulting sub-sample is identified, and Bray-Curtis similarity index is calculated for the results of both sub-samples. Results that are less than 90% similar would indicate the need for more thorough distribution of sample materials in the subsampling tray or more special attention given to easily missed taxa when sorting (i.e. increased magnification).

Taxonomic Accuracy and Precision

Taxonomic misidentification results in inadequate biological characterization of a stream. Errors in identification should be less than 5% of the total taxa in the sample. Re-identification of samples is conducted for 10% of the total number of samples in each year. Secondary identification is conducted by experienced taxonomists in order to maintain confidence in the data set. Difficult taxa should be sent to museum curators whose specialty includes members of the order in question. A voucher collection has been maintained by Ecology and is being transferred to the Orma J. Smith Museum of Natural History in Caldwell, Idaho for curation. A voucher collection should be prepared from the set of samples for the year and shipped to the address below:

The Orma J. Smith Museum of Natural History College of Idaho
2112 Cleveland BLVD
Caldwell, ID 83605-4432

Documentation necessary for acceptance by the museum will be delivered to the successful bidder with the samples.

7 QUALITY CONTROL FOR FIELD DATA COLLECTION

Field data measurements will be recorded in the field; example data sheets are provided in Appendix C-3 for the regional monitoring indicators. Forms such as these will be used as print

documents and taken into the field for recording. Electronic copies of all field forms will be retained. Other considerations for the different monitoring types are specified below.

7.1 Field Quality Control for Habitat Indicators

Most of the field measurements conducted at habitat sampling locations are conducted throughout the entire 20x-bankfull-width-long reach, ensuring that results are truly “representative” of the reach. This distance lies at the high end of typically specified reach lengths (10–20x bankfull widths are common in the literature), which is designed to include multiple pool-riffle or step-pool sequences in an alluvial channel and so avoid over representing any unique characteristics of any one segment. Variability will be reduced through refinement of site selection and local phenomenon based on physical criteria. Field personnel will record where samples are measured and note general descriptions of physical conditions of the channel, gradient, habitat types, water velocity, weather, and other parameters or unique local features that could influence data quality. These narrative field notes can be used to qualitatively assess how well the data represent the conditions characterized by this study, should any questions later arise about the representativeness and accuracy of the measured indicators.

Specific quality control procedures will include having a crew member other than the initial recorder review the data sheets prior to crews leaving the field. It is important to QC the data sheets in the field prior to leaving, in order to insure that all required data has been collected. When data collection requires crews to make visual estimates (for instance on riparian and understory cover percentages), individual crew members will independently make estimates, compare their results at the start of each day, and evaluate the level of consensus. If consensus cannot be achieved, the visual estimate from the crew lead will be used and additional staff training required to reduce measurement error.

Forms and documentation will include the station visit/maintenance sheet, meter calibration, and chain-of-custody forms. All entries on field documents will be made in pencil or permanent pen and will list the field technician name(s). Any errors or typos will be crossed out and rewritten by the technician who recorded the data. All corrections will be initialed and dated when made. Paper documents will be stored in an organized central filing location.

If field sampling or procedural errors are discovered, action will be taken to manage and correct those errors. Corrections may occur with corrective editing, relabeling, or, if warranted, flagging, discarding, and re-sampling. If a consistent error persists, an amendment to the sampling procedures may be required.

7.2 Field Quality Control Procedures for Temperature Measurements

The accuracy and instrument bias of each temperature sensor will be verified through post-deployment calibration checks following the procedures described in the *Continuous Temperature Sampling Protocols for the Environmental Monitoring and Trends Section* (Ward 2003) and in the *TFW Stream Temperature Survey Manual* (Schuett-Hames et al. 1999).

7.3 Field Quality Control Procedures for Benthic Macroinvertebrate Sampling

Benthic macroinvertebrate samples are the only samples that will need to be analyzed by a laboratory. To ensure the quality and consistency of sample collections, sample collection protocols described in the appendices of this report will be followed.

7.3.1 Sample holding times

Holding times are the maximum allowable length of time between sample collection and laboratory manipulation. Holding times are different for each analyte and are in place to maximize analytical accuracy and representativeness. Each sample collected will be packaged in a container and labeled accordingly. If necessary, sample collection should be coordinated with the analytical laboratory to ensure samples can be transported, received, and processed during non-business hours. Sample containers will be transported or sent by the field team to the analytical laboratory, following established sample handling and chain-of-custody procedures. At the laboratory, samples may be further divided for analysis or storage. Table 6 lists sample volumes, holding times, containers, and preservation requirements for biological samples.

Table 6. Sample containers, amounts, holding times, and preservation for samples (from Table 12 of the RSMP QAPP).

Analysis	Container ¹	Holding time	Preservative ²
Macroinvertebrates	3.8 L wide-mouth poly jars	Indefinitely	Field preserved with ethanol, store in quiescent location.

¹ No additional sample volume is needed for analysis and QC samples if the jar is filled.

² Preservation needs to be done in the field, unless otherwise noted. Ice will be used to cool samples to approximately 4-6°C.

7.3.2 Composite/grab field replicate samples

Replicates will be collected for the composited benthic macroinvertebrate field samples (Table 7). Field replicates will be collected by splitting composited samples. The sediment samples will undergo a rigorous field homogenization to ensure adequate sample mixing prior to splitting. All field replicates will be labeled similar to other samples, so that the sample has its own unique number. These replicate samples will be submitted blind to the laboratory, with all other field samples.

Table 7. Field quality control schedule for benthic macroinvertebrate samples collected (from Table 14 of the RSMP QAPP).

Field sample collected	Frequency	Control limit	Corrective action
Composited benthic macroinvertebrate	Once	Qualitative control—Assess representativeness, comparability, and field variability	Review procedures; alter if needed

8 DATA MANAGEMENT PROCEDURES

Effective data management is an essential component of a successful monitoring program. As recommended in the Roles and Responsibilities documents (Appendices A-1 and B-1 of the Implementation Plan, Part 1 of this report), the HSTM program manager will identify a data manager in charge of data QA, data entry, and data export to support the routine data analysis or in response to data requests.

8.1 Data Compilation

Final selection of a data management system is still pending. Following selection of a system, metadata, parameter formats and standard coding systems will be developed for the following:

- **Site and Geographic Data**—Sampling reaches will be identified with GPS coordinates at the upstream and downstream ends and with a narrative description of their location (e.g., East Fork Lewis River, extending 1,500 meters upstream from the NE 82nd Avenue/Daybreak Road bridge). Having both GPS coordinates and a narrative description will provide redundancy and insure that the sampling reaches can be re-located.
- **Field Data Collection and Transfer**—Draft data sheets will be developed and reviewed by all implementing agencies prior to the initiation of the first data collection event. This will ensure that all field crews are collecting the same data in the same way. Some implementing agencies may choose to use an electronic platform for field data collection. These electronic tablet-based systems have advantages in that they can be designed in such a way that they include field QA/QC procedures insuring that all required data is collected (for instance, data collection fields can be designed so that crews cannot move on to the next field until data has been entered in the preceding field). Electronic data collection platforms also streamline data compilation and analysis, and eliminate transcription errors when transferring data into Microsoft Access or other database programs. Should an implementing agency choose to use an electronic data collection platform, precautions must be taken to insure that all data included on the approved data sheets is collected in an identical way.
- **Methods for collection and transfer of field information** differ based on the selection of a data management system. Automated systems exist (and are in use by Ecology) that scan paper data sheets and automatically enter the scanned data into a database. Specific data transfer and handling methodologies will be developed upon the adoption of a data management system. Data manually transferred from paper data sheets will require more extensive QA/QC procedures, such as being entered and checked by two different people, or by entering twice and comparing the two data sets.
- **Laboratory Analyses and Data Transfer**—Accredited laboratories will be used for all data analysis. Ecology's Laboratory Accreditation Program maintains a searchable database of accredited laboratories that may be accessed from this website: <http://www.ecy.wa.gov/programs/eap/labs/lab-accreditation.html>. Such laboratories have rigorous data analysis and transfer methodologies, and offer reporting in electronic form. These data will be reported using a standard set of information that addresses the needs for quality assurance checks, verification, and other auditing requirements. The format for reporting and recording of data will follow a similar design to that of the Environmental Information Management system developed by Ecology. In this way, data generated in this monitoring program can be recorded simultaneously in Ecology's data management system.

8.2 Database Design

Near-term storage will occur through an access database, with a long term vision to secure funding in order to develop and maintain an online database website. The database will store raw data, as well as calculated indicators and indices. This is a labor-intensive and thus expensive endeavor. If possible, database development could be streamlined by modeling or coupling with an existing database management system such as the Washington Department of Ecology's Environmental Information Management (EIM) database.

8.3 Data Management for Habitat Indicators

For field-collected indicators, data will be entered onto field data sheets. Both field team members will ensure that the forms are completed and check for any errors, on-site. Field sheets will be entered into Excel spreadsheets, and a different team member will compare at least 50% of the field and laboratory data sheets with the Excel files. If any errors are found they will be corrected, and the project manager will check all of the remaining field and laboratory data sheets with the Excel files. This process will be repeated until all errors are eliminated. For laboratory-reported indicators, original electronic spreadsheets will be archived and then re-formatted, as needed, for subsequent analyses. Final results will be cross-checked against the original archived lab forms to verify consistency.

Specific data management review and validation procedures include:

Raw Data

- Data entry and QA will occur between July and December of each year.
- Each organization collecting data will QA their data sheets in the field before departure from the site (see above).
- Organizations will submit the datasheets on an at least weekly basis to the program manager in digital format for distribution to the data manager. Submittals can include scanned images from the data sheets, data from the data sheets entered into a database program, or digital files from a field tablet or other electronic data collection platform. If paper datasheets are used, original datasheets should be mailed to the program manager for archiving on a weekly basis.
- The program manager will forward the data to the data manager, who will either enter the data into the database upon arrival. Or (in the case of digital files) check the data for completeness and accuracy. Any discrepancies will be reported as they are encountered to the program manager.
- The data manager will QA the data upon entry.

Calculation of Indicators

- Data entry will occur between December and April of each year.
- The analysis manager will provide any calculated indicators to the data manager for entry into the database and inclusion in reports. The analysis manager should automate the calculation of Indicators from the field data as much as possible so that as data accumulates from each year to the next, the analysis is consistent across years and reporting organizations.

8.4 Data Verification and Validation

Data verification involves examining the data for errors, omissions, and compliance with quality control (QC) acceptance criteria.

Data verification should occur at multiple steps in the process of collecting and analyzing monitoring data. In the field, all data recording sheets should be reviewed by all crew members before leaving the site.

The field lead will verify field data to ensure that:

- Data are consistent, correct, and complete, with no errors or omissions.
- Results of QC samples accompany the sample results.
- Established criteria for QC results were met.
- Data qualifiers are properly assigned where necessary.
- Data specified in the Sampling Process Design were obtained.
- Methods and protocols specified in this QAPP were followed.

Analyses performed by an environmental laboratory will follow their own established procedures to ensure that results being reported are accurate. Both field and laboratory data records, following initial data entry should be verified against field forms and laboratory reports prior to final validation in the electronic database. Missing data are identified to ensure that values were not mistakenly overlooked during the data entry process. Printed copies of all stored environmental data should be made to ensure permanent records are available. The project manager at the taxonomic laboratory will verify all taxonomic results.

Incomplete or missing data are not anticipated to be a significant problem if data verification procedures are followed. Lost field forms could require a site revisit, but once entered into the database and a digital back up created, the risk of lost information is minimized. Lost laboratory samples are also very uncommon for accredited labs, and in the context of the overall HSTM program any such event would be unlikely to compromise the validity of the overall results unless criteria for completeness are not achieved.

If, despite such efforts, discrepancies in the data are found, there are two options for correction, depending on when the problem is identified:

1. If the problem is identified before the end of the summertime sampling period (normally July 1 to October 15 for sediment chemistry and benthic indicators), a review of the protocols and SOPs outlined in the appendices of this document is required. After this review, a repeat site visit may be made to re-collect the sample. This may occur if the data set is incomplete or incorrectly collected. Before the second sampling, the investigator must review the SOPs and the appendices of this document to understand the protocols. Equipment should be cleaned and recalibrated and checked for proper function.
2. If the problem is identified after the index period, the data should be flagged and the problem explained in a comment in the database. This will allow both internal and external users of these data to know how these data may be used in projects. If the data are incomplete, or if some data standard was not met, the data will not be used to meet the objectives of the study design.

8.5 Data Quality Assessment

Data verification should occur at multiple steps in the process of collecting and analyzing monitoring data, in order to minimize the likelihood of errors and to assess the quality of the final data.

8.5.1 Field

An overarching focus for indicator selection has been to use only those indicators with relatively high levels of measurement precision and signal-to-noise ratios. For the water quality indicator measured with on-site sensors (water temperature), typical values for data quality and bias are within a few percent.

For those samples that are field-collected and transported to a laboratory (benthic macroinvertebrates), established procedures for preservation, holding times, and chain-of-custody will be followed. Field replicates for 10% of sites will be used to evaluate the representativeness of the data. Habitat indicators will be measured using established, field-tested protocols by trained crews, with multiple checks during the recording, transferring, and data entry of field-collected information.

For all data types, all data recording sheets should be reviewed by all crew members before leaving the site. Both field and laboratory data records, following initial data entry, should be verified against field forms and laboratory reports prior to final validation in the electronic database. Missing data are identified to ensure that values were not mistakenly overlooked during the data entry process. Printed copies of all stored environmental data should be made to ensure permanent records are available.

Incomplete or missing data are not anticipated to be a significant problem if data verification procedures are followed. Lost field forms could require a site revisit, but once entered into the database and a digital backup created, the risk of lost information is minimized.

8.5.2 Laboratory

Benthic macroinvertebrate samples are the only samples that will need to be analyzed by a laboratory. To ensure the quality and consistency of sample collections, equipment maintenance and sample collection protocols described in the appendices of this report will be followed. All laboratories used for the analyses will have their own approved internal quality-control procedures, which will be confirmed and documented prior to sample submission. Lost laboratory samples are very uncommon for accredited labs, and in the context of the overall HSTM program any such event would be unlikely to compromise the validity of the overall results unless criteria for completeness are not achieved.

8.6 Quality (Usability) Assessment

Following verification and validation, the variability, accuracy, and precision of the collected data will be compared with project objectives using professional judgment. If results do not meet criteria established at the beginning of the project, this will be explicitly stated in the annual reporting. Based upon data accuracy criteria, some data may be discarded. If this is found to be necessary, then the problems associated with data collection and analysis, reasons data were discarded, and potential ways to correct sampling problems will be reported. In some cases project criteria for accuracy may be modified. Should that be necessary, the justification for

modification, problems associated with collecting and analyzing data, as well as potential solutions will be reported.

9 AUDITS

Audits ensure that quality assurance (QA) monitoring plan elements are implemented correctly. The quality of the data must be determined to be acceptable, and corrective actions must be implemented in a timely manner. There are two components of the auditing process:

- The Technical Systems Audit is a qualitative audit of conformance to the QA monitoring plan. The audit will be conducted soon after work has commenced so that corrective actions can be implemented early in the project. These evaluations include field collection activities, sample transport, laboratory processing, and data management components of the program.
- Proficiency Testing is the quantitative determination of an analyte in a blind standard to evaluate the proficiency of the analyst or laboratory. This type of testing is not possible for measurement of physical habitat variables using the suggested protocols.

10 REPORTING

Compiling results and disseminating reports will be the responsibility of the data analysis and reporting manager. Once complete, the reports will be sent to the Program Manager for dissemination among the Technical Review committee for their review and comment prior to posting online and dissemination to the Steering Committee and interested parties.

The program manager will post annual status updates and 5-year status and trends reports to the program webpage. Findings will be disseminated by the program manager to NOAA, the Salmon Recovery Funding Board, Ecology, and other interested parties identified during the implementation phase of program development through distribution of an email with links. Links or copies of the reports will be posted on the PNAMP website to reach a broader regional audience.

Annual status updates will be generated by the data analysis and reporting manager between December and April of the year following data collection. This will allow some time for adaptive responses to the monitoring protocol before the coming field season. Five-year Status and Trends reports will be generated by the data analysis and reporting manager(s) between December and July following every 5th year of data collection.

A more detailed report of both year-5 status and overall trends (from inception of monitoring to current year) on a regional basis will be generated between December and July every 5 years, consistent with the guidance in the implementation plan. Final updates and reports should be submitted by the program manager for review by the Technical Review committee. Upon incorporation of the Technical Review committee's comments, the program manager will finalize the document, post online (HSTM program webpage and PNAMP), and send email notification to the Steering Committee and interested parties.

11 REFERENCES

- CHaMP. 2013. Scientific protocol for salmonid habitat surveys within the Columbia Habitat Monitoring Program. Prepared by the Columbia Habitat Monitoring Program.
- Ecology (Washington Department of Ecology). 2004. Guidelines for preparing quality assurance project plans. Ecology Publication No. 04-03-003.
- Ecology. 2006. Status and trends monitoring for watershed health and salmon recovery—Quality Assurance Monitoring Plan. Ecology Publication No. 06-03-203.
- Ecology. 2010. Quality assurance monitoring plan - ambient biological monitoring in rivers and streams: benthic macroinvertebrates and periphyton. Ecology Publication No. 10-03-109.
- Ecology. 2014. Quality Assurance Project Plan for Status and Trends Monitoring of Small Streams in the Puget Lowlands Ecoregion for Monitoring Conducted by Permittee to Comply with NPDES Stormwater Permit Special Condition S8.B Requirements
- Flosi, G., S. Downie, J. Hopelain, M. Bird, R. Coey, and B. Collins. 2010. California salmonid stream habitat restoration manual. Fourth Edition. California Department of Fish and Game. Sacramento, California.
- Groenier, J. S., and R. A. Gubernick. 2010. Locating your trail bridge for longevity. USDA Forest Service.
- Harrelson, C. C., C. L. Rawlins, and J. P. Potyondy. 1994. Stream channel reference sites: an illustrated guide to field technique. Gen. Tech. Rep. RM-245. U.S. Department of Agriculture, Forest Service. Rocky Mountain Forest and Range Experiment Station. Fort Collins, Colorado.
- Kaufmann, P. R., P. Levine, E. G. Robison, C. Seeliger, and D. V. Peck. 1999. Quantifying physical habitat in wadeable streams. EPA/620/R-99/003. U.S. Environmental Protection Agency, Washington, D.C.
- Larson, C. 2015. Standard Operating Procedures and Minimum Requirements for the Collection of Freshwater Benthic Macroinvertebrates in Streams and Rivers, Version 2.0, 13 pp. Available at http://www.ecy.wa.gov/programs/eap/qa/docs/ECY_EAP_SOP_BenthicMacroinvertebrateDataCollection_v2_0EAP073.pdf.
- Mathieu, N., 2006. Standard operating procedure for measuring dissolved oxygen in surface water. Version 1.1. Washington Department of Ecology, Olympia, Washington. <http://www.ecy.wa.gov/programs/eap/quality.html>
- Montgomery, D. R., and J. M. Buffington. 1997. Channel-reach morphology in mountain drainage basins. Bulletin of the Geological Society of America 109: 596–611.
- Rosgen, D., and L. Silvey. 1998. Field guide for stream classification. Wildland Hydrology.
- Schuett-Hames, D., A. E. Pleus, E. Rashin, and J. Mathews. 1999. TFW Monitoring Program method manual for the stream temperature survey. Prepared for the Washington State Department of Natural Resources under the Timber Fish and Wildlife Agreement. Olympia, Washington.

USDA Forest Service. 2006. Stream inventory handbook. Level I & II. Pacific Northwest Region. Version 2.6.

Ward, W. 2003. Continuous temperature sampling protocols for the environmental monitoring and trends section. Washington State Department of Ecology, Olympia, Washington.

Appendices

Appendix A-3

Candidate Habitat Monitoring Sites

**Randomly selected sites from the Lower Columbia Master Sample
(sites identified by unique SiteID)**

Region	within Urban + NPDES area	within Urban + NPDES area	within Urban + NPDES area	within Urban + NPDES area	within Urban + NPDES area	within Urban + NPDES area
Drainage Area	0.6-2.5 km ²	0.6-2.5 km ²	0.6-2.5 km ²	0.6-2.5 km ²	2.5-50 km ²	2.5-50 km ²
Stream Gradient Groups	<1.5%	<1.5%	1.5-3%	3-7.5%	<1.5%	<1.5%
Predominant watershed land cover	forested	urban	urban	urban	forested	urban
Number of Primary Populations in the sub-basin	N/A	N/A	N/A	N/A	N/A	N/A
1	LCR00001-056238	LCR00001-048426	LCR00001-084952	LCR00001-019565	LCR00001-047194	LCR00001-113486
2	LCR00001-015283	LCR00001-079966	LCR00001-109427	LCR00001-051305	LCR00001-100577	LCR00001-044843
3	LCR00001-066841	LCR00001-026717	LCR00001-041563	LCR00001-076102	LCR00001-009076	LCR00001-089760
4	LCR00001-136555	LCR00001-004207	LCR00001-089508	LCR00001-075546	LCR00001-119886	LCR00001-122964
5	LCR00001-111108	LCR00001-105739	LCR00001-047535	LCR00001-010335	LCR00001-014579	LCR00001-115144
6	LCR00001-108889	LCR00001-021085	LCR00001-039792	LCR00001-130872	LCR00001-068979	LCR00001-012079
7	LCR00001-124937	LCR00001-053849	LCR00001-059821	LCR00001-103213	LCR00001-030577	LCR00001-064855
8	LCR00001-044404	LCR00001-070883	LCR00001-124415	LCR00001-140586	LCR00001-106603	LCR00001-057129
9	LCR00001-060785	LCR00001-023901	LCR00001-118098	LCR00001-109682	LCR00001-111030	LCR00001-131814
10	LCR00001-032117	LCR00001-007519	LCR00001-048131	LCR00001-074266	LCR00001-035056	LCR00001-016989
11	LCR00001-048499	LCR00001-078446	LCR00001-126952	LCR00001-085124	LCR00001-126526	LCR00001-040368
12	LCR00001-111100	LCR00001-000607	LCR00001-073830	LCR00001-036272	LCR00001-010484	LCR00001-122754
13	LCR00001-010844	LCR00001-127140	LCR00001-084484	LCR00001-126632	LCR00001-082259	LCR00001-097852
14	LCR00001-123130	LCR00001-052569	LCR00001-042244	LCR00001-117128	LCR00001-073198	LCR00001-014771
15	LCR00001-081076	LCR00001-093935	LCR00001-079504	LCR00001-066773	LCR00001-055534	LCR00001-043440
16		LCR00001-102525	LCR00001-085070	LCR00001-002312	LCR00001-063724	LCR00001-007604
17		LCR00001-002932	LCR00001-029253	LCR00001-060673	LCR00001-130954	LCR00001-073506
18		LCR00001-070985	LCR00001-035380	LCR00001-058673	LCR00001-117674	LCR00001-140612
19		LCR00001-059245	LCR00001-001592	LCR00001-061744	LCR00001-047343	LCR00001-082363
20		LCR00001-135803	LCR00001-121724	LCR00001-062562	LCR00001-096137	LCR00001-031153
21		LCR00001-000264	LCR00001-017974		LCR00001-087284	LCR00001-010676
22		LCR00001-102741	LCR00001-119372		LCR00001-071789	LCR00001-093983
23		LCR00001-098098			LCR00001-011592	LCR00001-052654
24		LCR00001-082269			LCR00001-000180	LCR00001-115560
25		LCR00001-064512			LCR00001-049007	LCR00001-027058
26		LCR00001-034052			LCR00001-076250	LCR00001-076276
27		LCR00001-092781			LCR00001-019842	LCR00001-131298
28		LCR00001-094445			LCR00001-102809	LCR00001-011124
29		LCR00001-061696			LCR00001-085100	LCR00001-122446
30		LCR00001-001288			LCR00001-036224	LCR00001-056174
31		LCR00001-090188			LCR00001-129372	LCR00001-088898
32		LCR00001-045635			LCR00001-088980	LCR00001-027506
33		LCR00001-116746			LCR00001-059773	LCR00001-115456
34		LCR00001-135979			LCR00001-097828	LCR00001-106951
35		LCR00001-082855			LCR00001-116298	LCR00001-026866
36		LCR00001-101255			LCR00001-040708	LCR00001-043248
37		LCR00001-136733			LCR00001-112042	LCR00001-010100
38		LCR00001-033968			LCR00001-008264	LCR00001-042864
39		LCR00001-119298			LCR00001-072206	LCR00001-023410
40		LCR00001-044416			LCR00001-048899	LCR00001-093669
41		LCR00001-138471			LCR00001-127366	LCR00001-069325
42		LCR00001-023094			LCR00001-140832	LCR00001-007028
43		LCR00001-086860			LCR00001-095445	LCR00001-059629
44		LCR00001-071229			LCR00001-104295	LCR00001-132610
45		LCR00001-039476			LCR00001-031093	LCR00001-006388

Region	within Urban + NPDES area	within Urban + NPDES area	within Urban + NPDES area	within Urban + NPDES area	Regional Area	Regional Area
Drainage Area	2.5-50 km ²	50-200 km ²	200-1000 km ²	>1000 km ²	0.6-2.5 km ²	0.6-2.5 km ²
Stream Gradient Groups	1.5-3%	<1.5%	<1.5%	<1.5%	<1.5%	<1.5%
Predominant watershed land cover	urban	forested	forested	forested	forested	forested
Number of Primary Populations in the sub-basin	N/A	N/A	N/A	N/A	0-2	3+
1	LCR00001-106709	LCR00001-034395	LCR00001-020829	LCR00001-098614	LCR00001-072129	LCR00001-090539
2	LCR00001-031749	LCR00001-018013	LCR00001-103342	LCR00001-016174	LCR00001-058096	LCR00001-125952
3	LCR00001-082685	LCR00001-132257	LCR00001-106523	LCR00001-028461	LCR00001-034547	LCR00001-002255
4	LCR00001-029957	LCR00001-012894	LCR00001-053593	LCR00001-026290	LCR00001-050929	LCR00001-102159
5	LCR00001-046339	LCR00001-008799	LCR00001-061224	LCR00001-009908	LCR00001-097474	LCR00001-134803
6	LCR00001-108277	LCR00001-074710	LCR00001-010351	LCR00001-039344	LCR00001-059120	LCR00001-046538
7	LCR00001-058625	LCR00001-083561	LCR00001-118950	LCR00001-086788	LCR00001-009975	LCR00001-071767
8	LCR00001-141096	LCR00001-118282	LCR00001-037211	LCR00001-095641	LCR00001-106328	LCR00001-107182
9	LCR00001-013575	LCR00001-048474	LCR00001-140836	LCR00001-131058	LCR00001-130680	LCR00001-076194
10	LCR00001-055554	LCR00001-098364	LCR00001-135849	LCR00001-077936	LCR00001-007927	LCR00001-019741
11	LCR00001-051458	LCR00001-141266	LCR00001-129905	LCR00001-069083	LCR00001-085304	LCR00001-036123
12	LCR00001-101637	LCR00001-015710	LCR00001-000351	LCR00001-022962	LCR00001-135657	LCR00001-062151
13	LCR00001-141346	LCR00001-003423	LCR00001-121048	LCR00001-076172	LCR00001-122516	LCR00001-038603
14	LCR00001-098868	LCR00001-019805	LCR00001-027741	LCR00001-036080	LCR00001-011255	LCR00001-056009
15	LCR00001-028034	LCR00001-102789	LCR00001-125982	LCR00001-052462	LCR00001-140646	LCR00001-044235
16	LCR00001-105023	LCR00001-120496	LCR00001-099426	LCR00001-085024	LCR00001-118516	LCR00001-121804
17		LCR00001-111642	LCR00001-062720	LCR00001-003316	LCR00001-027977	LCR00001-102435
18		LCR00001-019890	LCR00001-097206	LCR00001-135375	LCR00001-114110	LCR00001-048330
19		LCR00001-102833	LCR00001-018694	LCR00001-067319	LCR00001-096405	LCR00001-081963
20		LCR00001-135481	LCR00001-075628	LCR00001-122652	LCR00001-141228	LCR00001-063175
21		LCR00001-063916	LCR00001-119896	LCR00001-056558	LCR00001-139681	LCR00001-017613
22		LCR00001-136541	LCR00001-021766	LCR00001-096091	LCR00001-087757	LCR00001-053105
23		LCR00001-003508	LCR00001-077290	LCR00001-011508	LCR00001-080812	LCR00001-067299
24		LCR00001-066763	LCR00001-038148	LCR00001-080602	LCR00001-115422	LCR00001-129550
25		LCR00001-018674	LCR00001-121556	LCR00001-109407	LCR00001-016646	LCR00001-135173
26		LCR00001-062700	LCR00001-106061	LCR00001-015671	LCR00001-103295	LCR00001-097082
27		LCR00001-090558	LCR00001-086696	LCR00001-003384	LCR00001-064768	LCR00001-066647
28		LCR00001-042224	LCR00001-009480	LCR00001-131542	LCR00001-100530	LCR00001-018461
29		LCR00001-088344	LCR00001-039172	LCR00001-011576	LCR00001-086096	LCR00001-077718
30		LCR00001-139772	LCR00001-130410	LCR00001-016950	LCR00001-075214	LCR00001-060336
31		LCR00001-029937	LCR00001-114362	LCR00001-065833	LCR00001-117325	LCR00001-051801
32		LCR00001-013555	LCR00001-123215	LCR00001-049714	LCR00001-000902	LCR00001-008375
33		LCR00001-086684	LCR00001-078950	LCR00001-127806	LCR00001-048451	LCR00001-120082
34		LCR00001-003336	LCR00001-077844	LCR00001-074690	LCR00001-010950	LCR00001-094259
35		LCR00001-091122	LCR00001-024838	LCR00001-006712	LCR00001-042690	LCR00001-094399
36		LCR00001-063744	LCR00001-081163	LCR00001-051762	LCR00001-107999	LCR00001-078908
37		LCR00001-126538	LCR00001-104399	LCR00001-120060	LCR00001-088078	LCR00001-073994
38		LCR00001-014599	LCR00001-132070	LCR00001-021814	LCR00001-044548	LCR00001-036187
39		LCR00001-133176	LCR00001-006408	LCR00001-092807	LCR00001-073480	LCR00001-130284
40		LCR00001-073416	LCR00001-107723	LCR00001-050482	LCR00001-123803	LCR00001-070051
41		LCR00001-040260	LCR00001-056642	LCR00001-110512	LCR00001-041732	LCR00001-083161
42		LCR00001-105289	LCR00001-053762	LCR00001-081189	LCR00001-022852	LCR00001-066557
43		LCR00001-008052	LCR00001-140188	LCR00001-045363	LCR00001-116160	LCR00001-034672
44		LCR00001-118018	LCR00001-063792	LCR00001-030823	LCR00001-077877	LCR00001-001908
45		LCR00001-065388	LCR00001-069567	LCR00001-073331	LCR00001-072137	LCR00001-058221

Region	Regional Area	Regional Area	Regional Area	Regional Area	Regional Area	Regional Area
Drainage Area	0.6-2.5 km ²	0.6-2.5 km ²	0.6-2.5 km ²	0.6-2.5 km ²	0.6-2.5 km ²	0.6-2.5 km ²
Stream Gradient Groups	<1.5%	<1.5%	1.5-3%	1.5-3%	1.5-3%	3-7.5%
Predominant watershed land cover	agricultural	agricultural	forested	forested	agricultural	forested
Number of Primary Populations in the sub-basin	0-2	3+	0-2	3+	3+	0-2
1	LCR00001-104769	LCR00001-029553	LCR00001-006903	LCR00001-018893	LCR00001-001391	LCR00001-039667
2	LCR00001-052142	LCR00001-031921	LCR00001-021045	LCR00001-084591	LCR00001-124933	LCR00001-078110
3	LCR00001-139246	LCR00001-028530	LCR00001-103458	LCR00001-027954	LCR00001-025197	LCR00001-141138
4	LCR00001-129120	LCR00001-138205	LCR00001-008759	LCR00001-091170	LCR00001-087996	LCR00001-098029
5	LCR00001-089462	LCR00001-129892	LCR00001-035251	LCR00001-063831	LCR00001-118844	LCR00001-043827
6	LCR00001-080612	LCR00001-024902	LCR00001-110685	LCR00001-036635	LCR00001-005295	LCR00001-111872
7	LCR00001-044292	LCR00001-105543	LCR00001-085680	LCR00001-073024	LCR00001-123307	LCR00001-035379
8	LCR00001-112100	LCR00001-067283	LCR00001-055521	LCR00001-014515	LCR00001-012718	LCR00001-075792
9	LCR00001-089972	LCR00001-003247	LCR00001-129812	LCR00001-059565	LCR00001-063079	LCR00001-109281
10	LCR00001-045231	LCR00001-045418	LCR00001-024754	LCR00001-026530	LCR00001-126174	LCR00001-015434
11	LCR00001-091676	LCR00001-101138	LCR00001-080014	LCR00001-050286	LCR00001-042603	LCR00001-000331
12	LCR00001-020742	LCR00001-117634	LCR00001-010420	LCR00001-126284	LCR00001-094569	LCR00001-082721
13	LCR00001-110074	LCR00001-128148	LCR00001-070049	LCR00001-003796	LCR00001-140700	LCR00001-137068
14	LCR00001-064000	LCR00001-010415	LCR00001-020338	LCR00001-002692	LCR00001-072434	LCR00001-021104
15	LCR00001-135527	LCR00001-080012	LCR00001-085726	LCR00001-088422	LCR00001-081289	LCR00001-053868
16	LCR00001-122248	LCR00001-071154	LCR00001-024434	LCR00001-044395	LCR00001-081979	LCR00001-037959
17	LCR00001-066177	LCR00001-041131	LCR00001-140676	LCR00001-091731	LCR00001-097470	LCR00001-128646
18	LCR00001-130998	LCR00001-057512	LCR00001-078732	LCR00001-011631	LCR00001-131504	LCR00001-088518
19	LCR00001-010568	LCR00001-085544	LCR00001-094405	LCR00001-107225	LCR00001-090831	LCR00001-038983
20	LCR00001-080094	LCR00001-137363	LCR00001-008388	LCR00001-066277	LCR00001-083362	LCR00001-131380
21	LCR00001-026950	LCR00001-037044	LCR00001-130274	LCR00001-078454	LCR00001-045290	LCR00001-123333
22	LCR00001-088944	LCR00001-024758	LCR00001-123869	LCR00001-041579	LCR00001-080863	LCR00001-105299
23	LCR00001-117718	LCR00001-105467	LCR00001-041540	LCR00001-054338	LCR00001-080419	LCR00001-140981
24	LCR00001-043332	LCR00001-139350	LCR00001-071479	LCR00001-070023	LCR00001-124946	LCR00001-017890
25	LCR00001-014087	LCR00001-036331	LCR00001-132053	LCR00001-127697	LCR00001-126609	LCR00001-122092
26	LCR00001-030469	LCR00001-030444	LCR00001-011016	LCR00001-134347	LCR00001-108072	LCR00001-001508
27	LCR00001-013063	LCR00001-059249	LCR00001-051582	LCR00001-024941	LCR00001-138849	LCR00001-039088
28	LCR00001-106339	LCR00001-042731	LCR00001-035200	LCR00001-114414		LCR00001-096463
29	LCR00001-055042	LCR00001-079842	LCR00001-080336	LCR00001-040043		LCR00001-105288
30	LCR00001-135109	LCR00001-013175	LCR00001-133452	LCR00001-113724		LCR00001-110386
31	LCR00001-061760	LCR00001-042868	LCR00001-098852	LCR00001-073056		LCR00001-033863
32	LCR00001-098592	LCR00001-022390	LCR00001-130028	LCR00001-116514		LCR00001-133276
33	LCR00001-124045	LCR00001-041979	LCR00001-119964	LCR00001-013934		LCR00001-050245
34	LCR00001-028997	LCR00001-085308	LCR00001-008776	LCR00001-100172		LCR00001-014193
35	LCR00001-045379	LCR00001-062128	LCR00001-049822	LCR00001-097400		LCR00001-019906
36	LCR00001-125462	LCR00001-134515	LCR00001-006532	LCR00001-122582		LCR00001-035187
37	LCR00001-134315	LCR00001-041560	LCR00001-047487	LCR00001-064103		LCR00001-026633
38	LCR00001-001352	LCR00001-089715	LCR00001-036835	LCR00001-063612		LCR00001-079922
39	LCR00001-092817	LCR00001-100781	LCR00001-117752	LCR00001-068629		LCR00001-003524
40	LCR00001-075110	LCR00001-014779	LCR00001-046977	LCR00001-038315		LCR00001-139222
41	LCR00001-045123	LCR00001-097856	LCR00001-033134	LCR00001-118742		LCR00001-059243
42	LCR00001-069991	LCR00001-117491	LCR00001-082337	LCR00001-071399		LCR00001-138885
43	LCR00001-017766	LCR00001-063390	LCR00001-121059	LCR00001-058984		LCR00001-098097
44	LCR00001-047987	LCR00001-003558	LCR00001-008167	LCR00001-128390		LCR00001-074485
45	LCR00001-138910	LCR00001-095116	LCR00001-033348	LCR00001-093333		LCR00001-136286

Region	Regional Area	Regional Area	Regional Area	Regional Area	Regional Area	Regional Area
Drainage Area	0.6-2.5 km ²	0.6-2.5 km ²	0.6-2.5 km ²	0.6-2.5 km ²	2.5-50 km ²	2.5-50 km ²
Stream Gradient Groups	3-7.5%	3-7.5%	>7.5%	>7.5%	<1.5%	<1.5%
Predominant watershed land cover	forested	agricultural	forested	forested	forested	forested
Number of Primary Populations in the sub-basin	3+	3+	0-2	3+	0-2	3+
1	LCR00001-020698	LCR00001-118204	LCR00001-092459	LCR00001-072832	LCR00001-099137	LCR00001-033947
2	LCR00001-121807	LCR00001-125340	LCR00001-042739	LCR00001-074321	LCR00001-077558	LCR00001-058824
3	LCR00001-015713	LCR00001-140914	LCR00001-088622	LCR00001-067853	LCR00001-024309	LCR00001-101578
4	LCR00001-111541	LCR00001-079413	LCR00001-026357	LCR00001-001487	LCR00001-138259	LCR00001-030156
5	LCR00001-108060	LCR00001-009311	LCR00001-079774	LCR00001-004303	LCR00001-003895	LCR00001-117238
6	LCR00001-016061	LCR00001-094903	LCR00001-088034	LCR00001-077398	LCR00001-105257	LCR00001-097314
7	LCR00001-012926	LCR00001-070557	LCR00001-130088	LCR00001-121666	LCR00001-103044	LCR00001-079058
8	LCR00001-016428	LCR00001-012638	LCR00001-036595	LCR00001-131210	LCR00001-057137	LCR00001-070205
9	LCR00001-012080	LCR00001-102245	LCR00001-091389	LCR00001-109906	LCR00001-059140	LCR00001-088298
10	LCR00001-140771	LCR00001-104906	LCR00001-126806	LCR00001-106863	LCR00001-141578	LCR00001-137445
11	LCR00001-065667	LCR00001-056937	LCR00001-095815	LCR00001-078086	LCR00001-071657	LCR00001-029852
12	LCR00001-023203	LCR00001-077482	LCR00001-044467	LCR00001-092026	LCR00001-078100	LCR00001-126092
13	LCR00001-026428	LCR00001-034283	LCR00001-140886	LCR00001-101051	LCR00001-122389	LCR00001-131537
14	LCR00001-039704	LCR00001-019309	LCR00001-086964	LCR00001-033995	LCR00001-123863	LCR00001-062919
15	LCR00001-095361	LCR00001-118601	LCR00001-028085	LCR00001-002767	LCR00001-098989	LCR00001-051401
16	LCR00001-038144	LCR00001-013550	LCR00001-115146	LCR00001-129212	LCR00001-032944	LCR00001-097670
17	LCR00001-019987	LCR00001-044971	LCR00001-059056	LCR00001-088462	LCR00001-109892	LCR00001-134527
18	LCR00001-004258	LCR00001-042219	LCR00001-097439	LCR00001-043723	LCR00001-083328	LCR00001-034507
19	LCR00001-028307	LCR00001-049066	LCR00001-016138	LCR00001-053705	LCR00001-111578	LCR00001-093584
20	LCR00001-006710	LCR00001-088342	LCR00001-102421	LCR00001-120358	LCR00001-092183	LCR00001-023245
21	LCR00001-003702	LCR00001-103283	LCR00001-090801	LCR00001-052313	LCR00001-049326	LCR00001-019149
22	LCR00001-046871	LCR00001-127456	LCR00001-032520	LCR00001-037323	LCR00001-015370	LCR00001-046794
23	LCR00001-141195	LCR00001-049385	LCR00001-040755	LCR00001-090814	LCR00001-071187	LCR00001-054985
24	LCR00001-076237	LCR00001-031468	LCR00001-019189	LCR00001-121111	LCR00001-089418	LCR00001-112946
25	LCR00001-101304	LCR00001-101068	LCR00001-059784	LCR00001-124015	LCR00001-141254	LCR00001-099670
26	LCR00001-037776	LCR00001-107709	LCR00001-052617	LCR00001-115711	LCR00001-044208	LCR00001-141464
27	LCR00001-097269	LCR00001-133440	LCR00001-139866	LCR00001-107693	LCR00001-008372	LCR00001-009935
28	LCR00001-081536	LCR00001-058847	LCR00001-050865	LCR00001-027341	LCR00001-098268	LCR00001-075046
29	LCR00001-077585	LCR00001-030179	LCR00001-027445	LCR00001-026317	LCR00001-053422	LCR00001-095241
30	LCR00001-018322	LCR00001-072981	LCR00001-022197	LCR00001-138483	LCR00001-105591	LCR00001-100638
31	LCR00001-054772	LCR00001-070442	LCR00001-080914	LCR00001-074771	LCR00001-074522	LCR00001-022221
32	LCR00001-005870	LCR00001-135434	LCR00001-095852	LCR00001-137321	LCR00001-012467	LCR00001-064967
33	LCR00001-134562	LCR00001-093546	LCR00001-104081	LCR00001-079752	LCR00001-024994	LCR00001-140822
34	LCR00001-134479	LCR00001-022920	LCR00001-100695	LCR00001-028365	LCR00001-105601	LCR00001-095377
35	LCR00001-028764	LCR00001-075145	LCR00001-076082	LCR00001-015822	LCR00001-015590	LCR00001-000719
36	LCR00001-071442	LCR00001-021896	LCR00001-065071	LCR00001-042699	LCR00001-033028	LCR00001-065915
37	LCR00001-012143	LCR00001-021612	LCR00001-134030	LCR00001-061128	LCR00001-137999	LCR00001-028876
38	LCR00001-017452	LCR00001-050280	LCR00001-084646	LCR00001-036043	LCR00001-008628	LCR00001-120972
39	LCR00001-002274	LCR00001-119259	LCR00001-043403	LCR00001-098516	LCR00001-114452	LCR00001-141292
40	LCR00001-066657		LCR00001-083677	LCR00001-109491	LCR00001-025010	LCR00001-011899
41	LCR00001-095136		LCR00001-011063	LCR00001-102847	LCR00001-032625	LCR00001-120786
42	LCR00001-027508		LCR00001-044851	LCR00001-136971	LCR00001-092229	LCR00001-066559
43	LCR00001-119179		LCR00001-000823	LCR00001-076430	LCR00001-083374	LCR00001-001911
44	LCR00001-108924		LCR00001-065973	LCR00001-003791	LCR00001-083159	LCR00001-051057
45	LCR00001-019405		LCR00001-068645	LCR00001-139952	LCR00001-005300	LCR00001-076521

Region	Regional Area	Regional Area	Regional Area	Regional Area	Regional Area	Regional Area
Drainage Area	2.5-50 km ²	2.5-50 km ²	2.5-50 km ²	2.5-50 km ²	2.5-50 km ²	2.5-50 km ²
Stream Gradient Groups	<1.5%	<1.5%	1.5-3%	1.5-3%	3-7.5%	3-7.5%
Predominant watershed land cover	agricultural	agricultural	forested	forested	forested	forested
Number of Primary Populations in the sub-basin	0-2	3+	0-2	3+	0-2	3+
1	LCR00001-019718	LCR00001-116356	LCR00001-005863	LCR00001-141112	LCR00001-129016	LCR00001-045514
2	LCR00001-111594	LCR00001-044912	LCR00001-014090	LCR00001-081271	LCR00001-104669	LCR00001-090126
3	LCR00001-069543	LCR00001-016243	LCR00001-030472	LCR00001-034251	LCR00001-014006	LCR00001-017869
4	LCR00001-136957	LCR00001-035179	LCR00001-130690	LCR00001-119452	LCR00001-073096	LCR00001-141362
5	LCR00001-093889	LCR00001-134785	LCR00001-045538	LCR00001-005583	LCR00001-047858	LCR00001-110596
6	LCR00001-023814	LCR00001-057768	LCR00001-096436	LCR00001-141166	LCR00001-031476	LCR00001-021965
7	LCR00001-007432	LCR00001-102143	LCR00001-090180	LCR00001-108739	LCR00001-117398	LCR00001-054729
8	LCR00001-011528	LCR00001-002223	LCR00001-000436	LCR00001-067237	LCR00001-015094	LCR00001-099884
9	LCR00001-071755	LCR00001-046250	LCR00001-127044	LCR00001-003167	LCR00001-075898	LCR00001-137779
10	LCR00001-056578	LCR00001-018605	LCR00001-066671	LCR00001-019549	LCR00001-124591	LCR00001-128166
11	LCR00001-027974	LCR00001-039083	LCR00001-134283	LCR00001-125398	LCR00001-106919	LCR00001-119314
12	LCR00001-003400	LCR00001-005551	LCR00001-136525	LCR00001-107371	LCR00001-021301	LCR00001-117930
13	LCR00001-100012	LCR00001-072642	LCR00001-061507	LCR00001-018293	LCR00001-042759	LCR00001-031436
14	LCR00001-106649	LCR00001-114318	LCR00001-005195	LCR00001-090904	LCR00001-088634	LCR00001-135634
15	LCR00001-110766	LCR00001-008376	LCR00001-086540	LCR00001-063343	LCR00001-012982	LCR00001-021369
16	LCR00001-103881	LCR00001-088694	LCR00001-065763	LCR00001-046962	LCR00001-034531	LCR00001-126782
17	LCR00001-107445	LCR00001-041306	LCR00001-071425	LCR00001-102099	LCR00001-080510	LCR00001-103635
18	LCR00001-012040	LCR00001-090615	LCR00001-063087	LCR00001-002511	LCR00001-063235	LCR00001-064199
19	LCR00001-086418	LCR00001-062806	LCR00001-124518	LCR00001-120004	LCR00001-100428	LCR00001-036555
20	LCR00001-134179	LCR00001-112494	LCR00001-074618	LCR00001-052169	LCR00001-120156	LCR00001-004987
21	LCR00001-003960	LCR00001-045957	LCR00001-033200	LCR00001-094179	LCR00001-131222	LCR00001-032204
22	LCR00001-135725	LCR00001-081510	LCR00001-108477	LCR00001-140642	LCR00001-111552	LCR00001-069651
23	LCR00001-082605	LCR00001-105578	LCR00001-093199	LCR00001-053017	LCR00001-080320	LCR00001-080814
24	LCR00001-126874	LCR00001-008586	LCR00001-124187	LCR00001-076474	LCR00001-006923	LCR00001-034675
25	LCR00001-098100	LCR00001-118168	LCR00001-086366	LCR00001-078028	LCR00001-093616	LCR00001-075414
26	LCR00001-024438	LCR00001-072932	LCR00001-086006	LCR00001-006751	LCR00001-119992	LCR00001-106398
27	LCR00001-015223	LCR00001-031879	LCR00001-045043	LCR00001-086880	LCR00001-000267	LCR00001-010103
28	LCR00001-040820	LCR00001-030087	LCR00001-028661	LCR00001-137675	LCR00001-051269	LCR00001-062487
29	LCR00001-092014	LCR00001-071688	LCR00001-116428	LCR00001-069176	LCR00001-125985	LCR00001-115252
30	LCR00001-053106	LCR00001-120241	LCR00001-106813	LCR00001-010591	LCR00001-097660	LCR00001-006007
31	LCR00001-085374	LCR00001-005322	LCR00001-125964	LCR00001-039515	LCR00001-029768	LCR00001-062551
32	LCR00001-076522	LCR00001-033990	LCR00001-125392	LCR00001-065577	LCR00001-053420	LCR00001-035611
33	LCR00001-118572	LCR00001-039978	LCR00001-137695	LCR00001-078546	LCR00001-117026	LCR00001-049329
34	LCR00001-049011	LCR00001-047001	LCR00001-081127	LCR00001-029212	LCR00001-098178	LCR00001-104689
35	LCR00001-089798	LCR00001-080415	LCR00001-127606	LCR00001-131358	LCR00001-118216	LCR00001-025781
36	LCR00001-105291	LCR00001-011166	LCR00001-066205	LCR00001-091968	LCR00001-015990	LCR00001-140178
37	LCR00001-125213	LCR00001-004206	LCR00001-012518	LCR00001-012830	LCR00001-092901	LCR00001-097592
38	LCR00001-008056	LCR00001-092144	LCR00001-124010	LCR00001-131666	LCR00001-050654	LCR00001-020253
39	LCR00001-044916	LCR00001-076655	LCR00001-077910	LCR00001-098016	LCR00001-041779	LCR00001-091076
40	LCR00001-134068	LCR00001-116493	LCR00001-111990	LCR00001-104797	LCR00001-098294	LCR00001-111376
41	LCR00001-061297	LCR00001-054376	LCR00001-061866	LCR00001-050382	LCR00001-136791	LCR00001-074354
42	LCR00001-109721		LCR00001-025136	LCR00001-016925	LCR00001-002123	LCR00001-047282
43			LCR00001-128714	LCR00001-119316	LCR00001-021769	LCR00001-023501
44			LCR00001-112311	LCR00001-119644	LCR00001-014566	LCR00001-068279
45			LCR00001-083536	LCR00001-042931	LCR00001-123410	LCR00001-091506

Region	Regional Area	Regional Area	Regional Area	Regional Area	Regional Area	Regional Area
Drainage Area	2.5-50 km ²	2.5-50 km ²	50-200 km ²	50-200 km ²	50-200 km ²	50-200 km ²
Stream Gradient Groups	>7.5%	>7.5%	<1.5%	<1.5%	1.5-3%	1.5-3%
Predominant watershed land cover	forested	forested	forested	forested	forested	forested
Number of Primary Populations in the sub-basin	0-2	3+	0-2	3+	0-2	3+
1	LCR00001-134549	LCR00001-104370	LCR00001-114076	LCR00001-091458	LCR00001-115732	LCR00001-108107
2	LCR00001-005879	LCR00001-014030	LCR00001-040691	LCR00001-018381	LCR00001-037683	LCR00001-066605
3	LCR00001-093051	LCR00001-059080	LCR00001-106885	LCR00001-034763	LCR00001-014134	LCR00001-051145
4	LCR00001-021173	LCR00001-132870	LCR00001-010999	LCR00001-031836	LCR00001-118995	LCR00001-006095
5	LCR00001-049841	LCR00001-028281	LCR00001-124003	LCR00001-115298	LCR00001-026244	LCR00001-019037
6	LCR00001-076970	LCR00001-099207	LCR00001-140800	LCR00001-041931	LCR00001-108577	LCR00001-089888
7	LCR00001-053937	LCR00001-062319	LCR00001-086376	LCR00001-003959	LCR00001-058372	LCR00001-061463
8	LCR00001-076451	LCR00001-122770	LCR00001-038579	LCR00001-078306	LCR00001-132829	LCR00001-099618
9	LCR00001-039923	LCR00001-056949	LCR00001-111828	LCR00001-111378	LCR00001-070858	LCR00001-060301
10	LCR00001-069395	LCR00001-080720	LCR00001-036531	LCR00001-066822	LCR00001-079711	LCR00001-133424
11	LCR00001-073682	LCR00001-087848	LCR00001-067561	LCR00001-035699	LCR00001-123634	LCR00001-138173
12	LCR00001-064303	LCR00001-044491	LCR00001-131197	LCR00001-054217	LCR00001-015217	LCR00001-046111
13	LCR00001-015158	LCR00001-058392	LCR00001-010935	LCR00001-075506	LCR00001-059007	LCR00001-013267
14	LCR00001-122968	LCR00001-071863	LCR00001-089420	LCR00001-097252	LCR00001-013957	LCR00001-002772
15	LCR00001-028469	LCR00001-104231	LCR00001-003255	LCR00001-112530	LCR00001-069324	LCR00001-053262
16	LCR00001-077039	LCR00001-128534	LCR00001-044211	LCR00001-037835	LCR00001-056689	LCR00001-099432
17	LCR00001-036615	LCR00001-110320	LCR00001-030981	LCR00001-084820	LCR00001-023925	LCR00001-088360
18	LCR00001-072059	LCR00001-091230	LCR00001-069499	LCR00001-088404	LCR00001-105925	LCR00001-042256
19	LCR00001-012087	LCR00001-104183	LCR00001-059649	LCR00001-004127	LCR00001-078458	LCR00001-024338
20	LCR00001-061232	LCR00001-024013	LCR00001-132718	LCR00001-042331	LCR00001-113116	LCR00001-040720
21	LCR00001-116808	LCR00001-039371	LCR00001-015623	LCR00001-023413	LCR00001-054912	LCR00001-045440
22	LCR00001-045746	LCR00001-022389	LCR00001-133730	LCR00001-106489	LCR00001-002418	LCR00001-066045
23	LCR00001-125177	LCR00001-040395	LCR00001-139938	LCR00001-129636	LCR00001-131205	LCR00001-125497
24	LCR00001-138659	LCR00001-063943	LCR00001-032005	LCR00001-050777	LCR00001-094268	LCR00001-000959
25	LCR00001-062127	LCR00001-014198	LCR00001-004276	LCR00001-005727	LCR00001-020453	LCR00001-138703
26	LCR00001-099104	LCR00001-053961	LCR00001-078432	LCR00001-127516	LCR00001-053184	LCR00001-074898
27	LCR00001-000119	LCR00001-055753	LCR00001-016562	LCR00001-084116	LCR00001-018800	LCR00001-081232
28	LCR00001-141638	LCR00001-104509	LCR00001-037040	LCR00001-030748	LCR00001-009926	LCR00001-084582
29	LCR00001-066480	LCR00001-071311	LCR00001-103249	LCR00001-042587	LCR00001-085415	LCR00001-035969
30	LCR00001-032564	LCR00001-077627	LCR00001-109381	LCR00001-085464	LCR00001-070892	LCR00001-136946
31	LCR00001-016182	LCR00001-132957	LCR00001-020658	LCR00001-079690	LCR00001-036802	LCR00001-108171
32	LCR00001-110031	LCR00001-010703	LCR00001-067839	LCR00001-069969	LCR00001-038594	LCR00001-076224
33	LCR00001-102697	LCR00001-055153	LCR00001-120958	LCR00001-130596	LCR00001-022896	LCR00001-029761
34	LCR00001-044103	LCR00001-038771	LCR00001-023878	LCR00001-003023	LCR00001-104456	LCR00001-088950
35	LCR00001-112314	LCR00001-019229	LCR00001-104991	LCR00001-063431	LCR00001-025829	LCR00001-088390
36	LCR00001-068047	LCR00001-086480	LCR00001-087758	LCR00001-002655	LCR00001-094912	LCR00001-110945
37	LCR00001-092391	LCR00001-030580	LCR00001-057517	LCR00001-052078	LCR00001-054380	LCR00001-034897
38	LCR00001-046854	LCR00001-117708	LCR00001-139682	LCR00001-079378	LCR00001-009330	LCR00001-119799
39	LCR00001-048198	LCR00001-047407	LCR00001-028849	LCR00001-025629	LCR00001-070568	LCR00001-031506
40	LCR00001-112794	LCR00001-052526	LCR00001-116530	LCR00001-120230	LCR00001-129178	LCR00001-124606
41	LCR00001-064579	LCR00001-041843	LCR00001-132022	LCR00001-135171	LCR00001-011300	LCR00001-043793
42	LCR00001-091574	LCR00001-079290	LCR00001-107677	LCR00001-037915	LCR00001-134109	LCR00001-052303
43	LCR00001-036019	LCR00001-135413	LCR00001-018505	LCR00001-063340	LCR00001-024885	LCR00001-093792
44	LCR00001-106877	LCR00001-111331	LCR00001-036720	LCR00001-046959	LCR00001-109336	LCR00001-085907
45	LCR00001-090826	LCR00001-025461	LCR00001-076518	LCR00001-082051	LCR00001-033056	LCR00001-046928

Region	Regional Area	Regional Area	Regional Area	Regional Area	Regional Area	Regional Area
Drainage Area	50-200 km ²	50-200 km ²	50-200 km ²	50-200 km ²	200-1000 km ²	200-1000 km ²
Stream Gradient Groups	3-7.5%	3-7.5%	>7.5%	>7.5%	<1.5%	<1.5%
Predominant watershed land cover	forested	forested	forested	forested	forested	forested
Number of Primary Populations in the sub-basin	0-2	3+	0-2	3+	0-2	3+
1	LCR00001-020213	LCR00001-116960	LCR00001-060080	LCR00001-121388	LCR00001-139480	LCR00001-055401
2	LCR00001-043763	LCR00001-018781	LCR00001-015542	LCR00001-022109	LCR00001-096139	LCR00001-107077
3	LCR00001-013750	LCR00001-059416	LCR00001-022690	LCR00001-045679	LCR00001-061188	LCR00001-098223
4	LCR00001-108371	LCR00001-102573	LCR00001-113000	LCR00001-090774	LCR00001-045830	LCR00001-003279
5	LCR00001-132371	LCR00001-054297	LCR00001-039470	LCR00001-100258	LCR00001-141302	LCR00001-129826
6	LCR00001-025397	LCR00001-050142	LCR00001-069151	LCR00001-128236	LCR00001-090294	LCR00001-019661
7	LCR00001-097072	LCR00001-067031	LCR00001-026372	LCR00001-040016	LCR00001-098594	LCR00001-007375
8	LCR00001-109160	LCR00001-139562	LCR00001-134546	LCR00001-057017	LCR00001-012043	LCR00001-044123
9	LCR00001-078177	LCR00001-004148	LCR00001-125691	LCR00001-007301	LCR00001-013066	LCR00001-120420
10	LCR00001-018441	LCR00001-135037	LCR00001-070510	LCR00001-103465	LCR00001-123494	LCR00001-082731
11	LCR00001-034823	LCR00001-022482	LCR00001-081622	LCR00001-140777	LCR00001-091701	LCR00001-024925
12	LCR00001-075494	LCR00001-108109	LCR00001-039698	LCR00001-052907	LCR00001-064815	LCR00001-064711
13	LCR00001-054636	LCR00001-030417	LCR00001-057330	LCR00001-115695	LCR00001-135969	LCR00001-000463
14	LCR00001-031716	LCR00001-058317	LCR00001-026647	LCR00001-035637	LCR00001-058539	LCR00001-079000
15	LCR00001-048098	LCR00001-072526	LCR00001-028651	LCR00001-139593	LCR00001-136483	LCR00001-074632
16	LCR00001-109227	LCR00001-105333	LCR00001-079395	LCR00001-086921	LCR00001-017973	LCR00001-090064
17	LCR00001-088934	LCR00001-108005	LCR00001-078360	LCR00001-007397	LCR00001-120957	LCR00001-050265
18	LCR00001-123753	LCR00001-112282		LCR00001-057316	LCR00001-123519	LCR00001-045402
19	LCR00001-008134	LCR00001-081757		LCR00001-120845	LCR00001-086998	LCR00001-139094
20	LCR00001-118613	LCR00001-085490		LCR00001-137954	LCR00001-125208	LCR00001-099331
21	LCR00001-088300	LCR00001-078680		LCR00001-104982	LCR00001-039731	LCR00001-132912
22	LCR00001-139764	LCR00001-062780		LCR00001-085619	LCR00001-116355	LCR00001-128102
23	LCR00001-006308	LCR00001-057790		LCR00001-112731	LCR00001-107502	LCR00001-026397
24	LCR00001-055454	LCR00001-062524		LCR00001-076767	LCR00001-046898	LCR00001-068483
25	LCR00001-052160	LCR00001-061772		LCR00001-127673	LCR00001-036718	LCR00001-005215
26	LCR00001-129870	LCR00001-134323		LCR00001-050134	LCR00001-140979	LCR00001-038235
27	LCR00001-076009	LCR00001-007492		LCR00001-122557	LCR00001-120783	LCR00001-139446
28	LCR00001-003014	LCR00001-047439		LCR00001-058202	LCR00001-029492	LCR00001-013406
29	LCR00001-049728	LCR00001-021058		LCR00001-081488	LCR00001-110790	LCR00001-123679
30	LCR00001-123526	LCR00001-004676		LCR00001-099537	LCR00001-053100	LCR00001-058456
31	LCR00001-114673	LCR00001-082780		LCR00001-092507	LCR00001-094583	LCR00001-083570
32	LCR00001-054060	LCR00001-095086		LCR00001-063473	LCR00001-068023	LCR00001-033387
33	LCR00001-085888	LCR00001-132161		LCR00001-119591	LCR00001-003954	LCR00001-135999
34	LCR00001-013125	LCR00001-096747		LCR00001-029362	LCR00001-027910	LCR00001-101277
35	LCR00001-012849	LCR00001-001457		LCR00001-045744	LCR00001-090870	LCR00001-122728
36	LCR00001-029507	LCR00001-066310		LCR00001-037553	LCR00001-008712	LCR00001-113874
37	LCR00001-084643	LCR00001-069774		LCR00001-127199	LCR00001-033284	LCR00001-064871
38	LCR00001-094752	LCR00001-007857		LCR00001-108544	LCR00001-049666	LCR00001-043648
39	LCR00001-009030	LCR00001-094120		LCR00001-085835	LCR00001-042803	LCR00001-096169
40	LCR00001-131779	LCR00001-027311		LCR00001-134672	LCR00001-020998	LCR00001-080266
41	LCR00001-012018	LCR00001-124552		LCR00001-020188	LCR00001-026421	LCR00001-067533
42	LCR00001-014320	LCR00001-015024		LCR00001-035190	LCR00001-037380	LCR00001-037248
43	LCR00001-042989	LCR00001-073643		LCR00001-096909	LCR00001-118928	LCR00001-130049
44	LCR00001-072723	LCR00001-060494		LCR00001-069728	LCR00001-030516	LCR00001-028013
45	LCR00001-017412	LCR00001-053874		LCR00001-087935	LCR00001-020080	LCR00001-070291

Region	Regional Area	Regional Area	Regional Area	Regional Area	Regional Area	Regional Area
Drainage Area	200-1000 km ²	200-1000 km ²	200-1000 km ²	200-1000 km ²	200-1000 km ²	>1000 km ²
Stream Gradient Groups	1.5-3%	1.5-3%	3-7.5%	3-7.5%	>7.5%	<1.5%
Predominant watershed land cover	forested	forested	forested	forested	forested	forested
Number of Primary Populations in the sub-basin	0-2	3+	0-2	3+	3+	0-2
1	LCR00001-008370	LCR00001-114824	LCR00001-028425	LCR00001-033505	LCR00001-089804	LCR00001-126909
2	LCR00001-024752	LCR00001-134745	LCR00001-138323	LCR00001-130113	LCR00001-058026	LCR00001-123483
3	LCR00001-041523	LCR00001-015491	LCR00001-040711	LCR00001-018791	LCR00001-122841	LCR00001-013046
4	LCR00001-129810	LCR00001-108759	LCR00001-131796	LCR00001-082322	LCR00001-107918	LCR00001-045810
5	LCR00001-079114	LCR00001-111877	LCR00001-027721	LCR00001-135440	LCR00001-026456	LCR00001-112967
6	LCR00001-045229	LCR00001-078681	LCR00001-004663	LCR00001-068626	LCR00001-064205	LCR00001-038643
7	LCR00001-037038	LCR00001-006769	LCR00001-138597	LCR00001-097181	LCR00001-020812	LCR00001-022261
8	LCR00001-058160	LCR00001-084677	LCR00001-124775	LCR00001-091371	LCR00001-049480	LCR00001-068703
9	LCR00001-079808	LCR00001-071936	LCR00001-068333	LCR00001-138566	LCR00001-123680	LCR00001-121826
10	LCR00001-117432	LCR00001-079145	LCR00001-021577	LCR00001-060110	LCR00001-110639	LCR00001-069811
11	LCR00001-126733	LCR00001-011861	LCR00001-136775	LCR00001-110739	LCR00001-044829	LCR00001-105222
12	LCR00001-064106	LCR00001-025571	LCR00001-009291	LCR00001-124572	LCR00001-047900	LCR00001-052977
13	LCR00001-026597	LCR00001-130255	LCR00001-025673	LCR00001-029463	LCR00001-122598	LCR00001-094157
14	LCR00001-015334	LCR00001-120223	LCR00001-099726	LCR00001-075325	LCR00001-135043	LCR00001-003063
15	LCR00001-091595	LCR00001-031591	LCR00001-013386	LCR00001-021347	LCR00001-004150	LCR00001-141488
16	LCR00001-064874	LCR00001-050516	LCR00001-108175	LCR00001-116671	LCR00001-034722	LCR00001-078250
17	LCR00001-118293	LCR00001-034134	LCR00001-132520	LCR00001-108489		LCR00001-023541
18	LCR00001-049772	LCR00001-119391	LCR00001-110940	LCR00001-137788		LCR00001-007159
19	LCR00001-127835	LCR00001-000346	LCR00001-051505	LCR00001-113661		LCR00001-131368
20	LCR00001-128715	LCR00001-013672	LCR00001-010551	LCR00001-008590		LCR00001-056305
21	LCR00001-084445	LCR00001-137456	LCR00001-080086	LCR00001-013547		LCR00001-093743
22	LCR00001-054626	LCR00001-075681	LCR00001-124796	LCR00001-088427		LCR00001-052209
23	LCR00001-086961	LCR00001-100029	LCR00001-006342	LCR00001-034092		LCR00001-085338
24	LCR00001-039662	LCR00001-106034	LCR00001-051948	LCR00001-020255		LCR00001-086420
25	LCR00001-113519	LCR00001-021715	LCR00001-006898	LCR00001-095840		LCR00001-007991
26	LCR00001-109648	LCR00001-013524	LCR00001-100566	LCR00001-012226		LCR00001-077568
27	LCR00001-092492	LCR00001-108250	LCR00001-122008	LCR00001-137344		LCR00001-094193
28	LCR00001-140391	LCR00001-068410	LCR00001-025162			LCR00001-024373
29	LCR00001-004850	LCR00001-015060	LCR00001-033544			LCR00001-022281
30	LCR00001-056812	LCR00001-023143	LCR00001-141122			LCR00001-129378
31	LCR00001-096229	LCR00001-141387	LCR00001-091291			LCR00001-076257
32	LCR00001-131643	LCR00001-085009	LCR00001-023533			LCR00001-111666
33	LCR00001-081578	LCR00001-047312	LCR00001-047316			LCR00001-047498
34	LCR00001-127816	LCR00001-066546				LCR00001-031116
35	LCR00001-027146	LCR00001-044502				LCR00001-108903
36	LCR00001-117536	LCR00001-018267				LCR00001-117758
37	LCR00001-062448	LCR00001-101334				
38	LCR00001-131683	LCR00001-134604				
39	LCR00001-136211	LCR00001-001885				
40	LCR00001-018455	LCR00001-044021				
41	LCR00001-139684	LCR00001-138332				
42	LCR00001-010798	LCR00001-115875				
43	LCR00001-018988	LCR00001-106470				
44	LCR00001-115477	LCR00001-074495				
45		LCR00001-083350				

Region	Regional Area
Drainage Area	>1000 km ²
Stream Gradient Groups	<1.5%
Predominant watershed land cover	forested
Number of Primary Populations in the sub-basin	3+
1	LCR00001-119286
2	LCR00001-110432
3	LCR00001-001183
4	LCR00001-066165
5	LCR00001-058520
6	LCR00001-097152
7	LCR00001-081685
8	LCR00001-013470
9	LCR00001-072808
10	LCR00001-089484
11	LCR00001-044331
12	LCR00001-046282
13	LCR00001-062663
14	LCR00001-124896
15	LCR00001-060712
16	LCR00001-100552
17	LCR00001-064807
18	LCR00001-000559
19	LCR00001-065829
20	LCR00001-136397
21	LCR00001-085748
22	LCR00001-120144
23	LCR00001-111288
24	LCR00001-008751
25	LCR00001-130014
26	LCR00001-084178
27	LCR00001-127802
28	LCR00001-037419
29	LCR00001-049705
30	LCR00001-140472
31	LCR00001-021037
32	LCR00001-093027
33	LCR00001-050889
34	LCR00001-105469
35	LCR00001-024761
36	LCR00001-041143
37	LCR00001-074860
38	LCR00001-137751
39	LCR00001-015994
40	LCR00001-066009
41	LCR00001-017273
42	LCR00001-029304
43	LCR00001-067665
44	LCR00001-036723
45	LCR00001-064367

Appendix B-3

Detailed Field-collection Protocols

APPENDIX B-3

Table of Contents – Field Protocol

Indicators	Pages
1. Sample reach length	1–6
2. Channel type	7–23
3. Reach slope	24–28
4. Bank modifications	29–34
5. Density of habitat types	35–41
6. Bankfull width/depth and Floodplain width	42–44
7. Side channel habitat	45–49
8. Flow category	50–51
9. Benthic Macroinvertebrates	52–64
10. Residual Pool depth	65–68
11. Bank stability	69–70
12. Density/distribution instream wood	71–77
13. Substrate particle size	78–84
14. Shade	85–87
15. Riparian canopy and understory (% cover)	88–112
16. Temperature	113–116

Protocol are bookmarked using the indicator number and include the source from which the protocol is taken.

N/A = not applicable. No field measurements unique to these indicators are made.

FIELD PROTOCOLS FOR SAMPLE REACH LENGTH

Ecology. 2009. Status and Trends Monitoring for Watershed Health & Salmon Recovery: Field Data Collection Protocol Wadeable Streams. Washington Department of Ecology. <http://www.ecy.wa.gov/programs/eap/stsmf/docs/01sntwadeablemana-vv3bhfl.pdf>

Ecology. 2010. Status and Trends Monitoring for Watershed Health & Salmon Recovery: Field Data Collection Protocol Wide Streams and Rivers. Washington Department of Ecology.

Record Event Information

Next, on the *Site Verification Form* (Figure A-2), record the information below about the data collection event

Crew

Record the names of those who are in the crew. Also note the organization that each staff represents. The crew lead will be recorded in column 1. Staff sampling roles can be recorded later, after the day is done, by using the check boxes provided on the form.

Site

Bankfull Stage

Near the Index Station (X), visually estimate the bankfull stage. This is best done after considerable training. There are at least three good on-line sources of training materials for identifying bankfull stage:

1. <http://preview.tinyurl.com/8aabbm> (Buffington, 2007)
2. http://www.dnr.wa.gov/Publications/fp_bfw_video_pt1.wmv
http://www.dnr.wa.gov/Publications/fp_bfw_video_pt2.wmv (Grizzel, 2008)
3. http://www.stream.fs.fed.us/publications/bankfull_west.html (Leopold et al, 1995)

Bankfull stage height is *not* a value that gets recorded on the *Site Verification Form*. The crew merely uses their visual estimate to help understand where to measure bankfull width.

Bankfull Width

Using the estimated bankfull level, measure the channel width at each of 5 transects near the Index Station:

1. The Index Station (X)
2. 1 bankfull width upstream from X
3. 2 bankfull widths upstream from X
4. 1 bankfull width downstream from X
5. 2 bankfull widths downstream from X

Record the average (nearest meter) of these 5 bankfull width measurements on the *Site Verification Form* (Figure A-2). Width measurements can be made using either a 50-m tape, a measuring rod, or (if the channel is wide) with a laser rangefinder.

Site Length

Sites must be no shorter than 150 m and no longer than 2000 m. Multiply the average bankfull width times 20. This value (whole meters) is the site length for a path that follows the main flow of the river. However, for any site with bankfull width less than 8 meters, the site length will be

extended to 150 m; for any site with bankfull width over 100 m, reduce the length to 2000 m. Record the site length on the *Site Verification Form* (Figure A-2).

Sampling methods for waded streams are restricted to sites that are less than 25 meters wide (less than 500 m long). Larger sites can be waded if shallow, but will be sampled using raft protocols. This rule will allow sampling on large streams to be accomplished within a single work day.

Relative position of the Index Station (X) within the site

The index station (X) is normally located at the middle of the site (i.e. at major transect F). On the *Site Verification Form* (Figure A-2), record the distance (tenths of meters) from X to the bottom of the site (i.e., to major transect A) and the distance from X to the top of the site (i.e., to major transect K). This distance is measured along the thalweg channel. Unless there is a reason to adjust the position of X, the distance will be equal to half the site length, in each direction.

The relative position of X can be adjusted for reasons such as

- to keep the top or bottom of the site in lands where permission has not been denied, or
- to keep from changing Strahler stream order (at the 1:100,000 scale), or
- to account for barriers such as lakes.

The location of the Index Station's coordinates can never be changed. These are pre-defined by the survey design. Although the site position can change relative to X (called "sliding" the site), the site must always contain X.

Bed Form

Assess the site for its predominant reach type according to Montgomery and Buffington (1993, 1997). Review the source materials hot-linked in the references to help understand the differences between bed forms. These references discuss details and provide images of examples.

First decide whether the site is predominated by a reach that is colluvial, alluvial, or bedrock. Colluvial streams have a low chance of being sampled by this Status and Trends program, because we are limiting our sample to perennial streams. Bedrock streams are confined locations with little depositional material present. Most streams sampled will be alluvial.

Next, if the site is predominantly alluvial, decide which one of the following sub-classifications can be used to describe the site.

- cascade
- step-pool
- plane-bed
- pool-riffle
- regime
- braided

Place an X in the appropriate box of the *Site Verification Form* (Figure A-2) to describe the predominant bed form within the site. Refer to the references (Montgomery and Buffington, 1993, 1997, 1998) and the definitions table (Table A-1) for help. Figures A-4 and A-5 might help.




Figure A-4. Idealized positions (aerial view) of bed form types within a watershed. Modified from figure 22 of Montgomery and Buffington (1993).




Figure A-5. Idealized positions (plan view) of bed form types within a watershed (from figure 16 of Montgomery and Buffington (1993)).

References

- Armantrout, N.B., compiler: 1998. *Glossary of aquatic habitat inventory terminology*. American Fisheries Society, Bethesda, MD.
- Buffington, J.M. 2007. *Identifying Bankfull Elevation*. Pacific Northwest Aquatic Monitoring Partnership (PNAMP) Watershed Monitoring Workgroup meeting attachment for 1 February 2007.
<http://www.pnamp.org/web/Workgroups/documents.cfm?strWGShort=WM>
- Grizzel, J. 2008. Washington State Department of Natural Resources, Forest Practices Board. Olympia, WA. *Identifying Bankfull Channel Edge* (Parts 1 (1 min 52 sec) and 2 (9 min 6 sec)).
http://www.dnr.wa.gov/BusinessPermits/Topics/ForestPracticesRules/Pages/fp_board_manual.aspx.
- Leopold, L.B. W.W. Emmett, H.L. Silvey, and D. L. Rosgen. 1995. *A Guide for Field Identification of Bankfull Stage in the Western United States*. Online video (31 minutes, closed captioned). Stream Systems Technology Center USDA, Forest Service, Rocky Mountain Research Station, Fort Collins, CO.
<http://www.stream.fs.fed.us/publications/videos.html#eastandwest>
- Montgomery, D.R., and J.M. Buffington. 1993. *Channel Classification, Prediction of Channel Response and Assessment of Channel Condition, Washington State*. TFW-SH10-93-002.
http://www.krisweb.com/biblio/gen_wadnr_montgomeryetal_1993_tfwsh1093002.pdf
- Montgomery, D.R. and J.M. Buffington. 1997. *Channel-reach morphology in mountain drainage basins*. Geological Society of America Bulletin, 109(5):596-611.
<http://www.esm.ucsb.edu/academics/courses/235/Readings/Montgomery+Buffington%201997%20GSA.pdf>
- Montgomery, D.R., and J.M. Buffington, 1998, *Channel processes, classification, and response*, in River Ecology and Management, edited by R. Naiman and R. Bilby, Springer-Verlag, New York, NY, pp. 13-42.
http://www.fs.fed.us/rm/boise/publications/watershed/rmrs_1998_montomeryr001.pdf

FIELD PROTOCOLS FOR CHANNEL TYPE

Ecology. 2009. Status and Trends Monitoring for Watershed Health & Salmon Recovery: Field Data Collection Protocol Wadeable Streams. Washington Department of Ecology. <http://www.ecy.wa.gov/programs/eap/stsmf/docs/01sntwadeablemana-vv3bhfl.pdf>

Ecology. 2010. Status and Trends Monitoring for Watershed Health & Salmon Recovery: Field Data Collection Protocol Wide Streams and Rivers. Washington Department of Ecology.

Channel-reach morphology in mountain drainage basins

David R. Montgomery* }
John M. Buffington† } *Department of Geological Sciences, University of Washington, Seattle, Washington 98195*

ABSTRACT

A classification of channel-reach morphology in mountain drainage basins synthesizes stream morphologies into seven distinct reach types: colluvial, bedrock, and five alluvial channel types (cascade, step pool, plane bed, pool riffle, and dune ripple). Coupling reach-level channel processes with the spatial arrangement of reach morphologies, their links to hillslope processes, and external forcing by confinement, riparian vegetation, and woody debris defines a process-based framework within which to assess channel condition and response potential in mountain drainage basins. Field investigations demonstrate characteristic slope, grain size, shear stress, and roughness ranges for different reach types, observations consistent with our hypothesis that alluvial channel morphologies reflect specific roughness configurations adjusted to the relative magnitudes of sediment supply and transport capacity. Steep alluvial channels (cascade and step pool) have high ratios of transport capacity to sediment supply and are resilient to changes in discharge and sediment supply, whereas low-gradient alluvial channels (pool riffle and dune ripple) have lower transport capacity to supply ratios and thus exhibit significant and prolonged response to changes in sediment supply and discharge. General differences in the ratio of transport capacity to supply between channel types allow aggregation of reaches into source, transport, and response segments, the spatial distribution of which provides a watershed-level conceptual model linking reach morphology and channel processes. These two scales of channel network classification define a framework within which to investigate spatial and temporal patterns of channel response in mountain drainage basins.

INTRODUCTION

Geologists and engineers have long recognized fundamental differences between mountain channels and their lowland counterparts (e.g., Surell, 1841; Dana, 1850; Shaler, 1891). In contrast to self-formed flood-plain channels, the gradient and morphology of mountain channels are tremendously variable and prone to forcing by external influences. Although mountain channels provide important aquatic habitat (e.g., Nehlsen et al., 1991; Frissell, 1993), supply sediment to estuaries and the oceans (e.g., Milliman and Syvitski, 1992), and transmit land use disturbances from headwater areas down through drainage networks (e.g., Reid, 1993), they have received relatively little study compared to lowland rivers.

Improved ability to relate morphology and processes in mountain channels would facilitate understanding and predicting their response to both human and natural disturbance. Classification schemes can organize such understanding into conceptual models that provide further insight into channel

processes (e.g., Schumm, 1977). With few exceptions (e.g., Paustian et al., 1992; Whiting and Bradley, 1993), classifications of mountain channels are not process based, which compromises their use for assessing channel condition, response potential, and relations to ecological processes.

In order to provide a useful general classification of mountain channels, a typology should be applicable on more than a regional basis, yet adaptable to regional variability; otherwise proliferation of regional channel classifications could impede rather than enhance communication and understanding. Moreover, a classification should rely on aspects of channel form that reflect channel processes. Furthermore, it should encompass the whole channel network, rather than consider only channels inhabited by desirable organisms or indicator species. A process-based understanding of spatial linkages within a watershed is essential for assessment of channel condition, prediction of channel response to disturbance, and interpretation of the causes of historical channel changes.

Herein we systematize a channel classification that expands on Schumm's (1977) general delineation of erosion, transport, and deposition reaches and provides a framework for examining channel processes in mountain drainage basins. We also report a field test of the classification using data from drainage basins in Oregon and Washington and propose a genetic explanation for the distinct channel morphologies that we recognize. The tie to channel processes and morphogenesis provides a defensible theoretical and conceptual framework within which to classify channel morphology, assess channel condition, and interpret response potential. In particular, coupling of process-based channel classification with landscape-specific spatial linkages can provide insight into how disturbances propagate through drainage basins. Our classification arose from field work in mountain drainage basins where we repeatedly observed the same general sequence of channel morphologies down through the channel network. Here we draw on previous work and our own field observations to discuss these morphologies and propose a theory for the origin of distinct alluvial channel types. Although developed based on literature review and field observations in the Pacific Northwest (Montgomery and Buffington, 1993), subsequent field work confirms the relevance of the classification in other mountainous regions.

Channel-reach Morphology

A voluminous literature on channel classification attests to the wide variety of morphologies exhibited by stream channels. No single classification can satisfy all possible purposes, or encompass all possible channel types; each of the channel classifications in common use have advantages and disadvantages for use in geological, engineering, and ecological applications (see discussion in Kondolf, 1995). Although stream channels possess a continuum of characteristics identifiable at spatial scales that range from individual channel units to entire drainage basins (Frissell et al., 1986), channel reaches of at least 10 to 20 channel widths in length define a useful scale over which to relate stream morphology to channel processes, response potential, and habitat characteristics.

*E-mail: dave@bigdirt.geology.washington.edu

†E-mail: jbuff@u.washington.edu

CHANNEL-REACH MORPHOLOGY IN MOUNTAIN BASINS

TABLE 1. DIAGNOSTIC FEATURES OF EACH CHANNEL TYPE

	Dune ripple	Pool riffle	Plane bed	Step pool	Cascade	Bedrock	Colluvial
Typical bed material	Sand	Gravel	Gravel-cobble	Cobble-boulder	Boulder	Rock	Variable
Bedform pattern	Multilayered	Laterally oscillatory	Featureless	Vertically oscillatory	Random	Irregular	Variable
Dominant roughness elements	Sinuosity, bedforms (dunes, ripples, bars) grains, banks	Bedforms (bars, pools), grains, sinuosity, banks	Grains, banks	Bedforms (steps, pools), grains, banks	Grains, banks	Boundaries (bed and banks)	Grains
Dominant sediment sources	Fluvial, bank failure	Fluvial, bank failure	Fluvial, bank failure, debris flows	Fluvial, hillslope, debris flows	Fluvial, hillslope, debris flows	Fluvial, hillslope, debris flows	Hillslope, debris flows
Sediment storage elements	Overbank, bedforms	Overbank, bedforms	Overbank	Bedforms	Lee and stoss sides of flow obstructions	Pockets	Bed
Typical confinement	Unconfined	Unconfined	Variable	Confined	Confined	Confined	Confined
Typical pool spacing (channel widths)	5 to 7	5 to 7	None	1 to 4	<1	Variable	Unknown

We recognize three primary channel-reach substrates: bedrock, alluvium, and colluvium. Bedrock reaches lack a contiguous alluvial bed and reflect high transport capacities relative to sediment supply; they are typically confined by valley walls and have steep slopes. In contrast, alluvial channels exhibit a wide variety of morphologies and roughness configurations that vary with slope and position within the channel network, and may be either confined, with little to no associated flood plain, or unconfined, with a well-established flood plain. We recognize five distinct alluvial reach morphologies: cascade, step pool, plane bed, pool riffle, and dune ripple. Colluvial channels form an additional reach type that we recognize separately from alluvial channels, despite the common presence of a thin alluvial substrate. Colluvial channels typically are small headwater streams that flow over a colluvial valley fill and exhibit weak or ephemeral fluvial transport. Each of these channel types is distinguished by a distinctive channel-bed morphology, allowing rapid visual classification. Diagnostic features of each channel type are summarized in Table 1 and discussed below.

Cascade Channels

The term "cascade" connotes tumbling flow, although its specific morphologic definition varies and often is applied to both channel units and reaches (e.g., Bisson et al., 1982; Grant et al., 1990). Our delineation of cascade channels focuses on streams in which energy dissipation is dominated by continuous tumbling and jet-and-wake flow over and around individual large clasts (e.g., Peterson and Mohanty, 1960) (Fig. 1A). Cascade channels generally occur on steep slopes, are narrowly confined by valley walls, and are characterized by longitudinally and laterally disorganized bed material typically consisting of cobbles and boulders (Fig. 2A). Small, partially channel-spanning pools spaced less than a channel width apart are common in cascade channels. Tumbling flow over individual grain steps and turbulence associated with jet-and-wake flow around grains dissipates much of the mechanical energy of the flow (Fig. 3A).

Large particle size relative to flow depth makes the largest bed-forming material of cascade reaches effectively immobile during typical flows. Studies of steep-gradient channels report that large bed-forming grains typically become mobile only during infrequent (i.e., 50–100 yr) hydrologic events (Grant et al., 1990; Kondolf et al., 1991; Whittaker, 1987b). Mobilization of these larger clasts is accompanied by high sediment transport rates due to the release of finer sediment trapped under and around large grains (Sawada et al., 1983; Warburton, 1992). During lesser floods, gravel stored in low energy sites is mobilized and travels as bedload over larger bed-forming clasts (Griffiths, 1980; Schmidt and Ergenzinger, 1992). Gravel and finer material

are locally stored on stoss and lee sides of flow obstructions (i.e., large grains and large woody debris) due to physical impoundment and generation of velocity shadows. One tracer study (Kondolf et al., 1991) showed that material in such depositional sites was completely mobilized during a seven-year recurrence-interval event, whereas no tracer movement was observed during flows of less than the annual recurrence interval.

These observations suggest that there are two thresholds for sediment transport in cascade channels. During moderate recurrence-interval flows, bedload material is rapidly and efficiently transported over the more stable bed-forming clasts, which have a higher mobility threshold corresponding to more infrequent events. The lack of significant in-channel storage (Kondolf et al., 1991) and the rapid scour of depositional sites during moderately frequent high flows suggest that sediment transport is effectively supply limited in cascade channels. Bedload transport studies demonstrate that steep channels in mountain drainage basins are typically supply limited, receiving seasonal or stochastic sediment inputs (Nanson, 1974; Griffiths, 1980; Ashida et al., 1981; Whittaker, 1987). Because of this high transport capacity relative to sediment supply, cascade channels function primarily as sediment transport zones that rapidly deliver sediment to lower-gradient channels.

Step-Pool Channels

Step-pool channels are characterized by longitudinal steps formed by large clasts organized into discrete channel-spanning accumulations that separate pools containing finer material (Figs. 1B and 2B) (Ashida et al., 1976, 1981; Griffiths, 1980; Whittaker and Jaeggi, 1982; Whittaker and Davies, 1982; Whittaker, 1987a, 1987b; Chin, 1989; Grant et al., 1990). Primary flow and channel bed oscillations in step-pool reaches are vertical, rather than lateral, as in pool-riffle channels (Fig. 3B). The stepped morphology of the bed results in alternating critical to supercritical flow over steps and subcritical flow in pools (Bowman, 1977; Chin, 1989). Step-pool channels exhibit a pool spacing of roughly one to four channel widths (Bowman, 1977; Whittaker, 1987b; Chin, 1989; Grant et al., 1990), significantly less than the five to seven channel widths that typify self-formed pool-riffle channels (Leopold et al., 1964; Keller and Melhorn, 1978). Steps provide much of the elevation drop and roughness in step-pool channels (Ashida et al., 1976; Whittaker and Jaeggi, 1982; Whittaker, 1987a, 1987b; Chin, 1989). Step-pool morphology generally is associated with steep gradients, small width to depth ratios, and pronounced confinement by valley walls. Although step-forming clast sizes typically are comparable to annual high flow depths, a stepped longitudinal profile also may develop in steep sand-bedded channels (G. E. Grant, 1996, personal commun.).




Figure 1. Alluvial channel-reach morphologies: (A) cascade; (B) step pool; (C) plane bed; (D) pool riffle; (E) dune ripple; (F) colluvial (channel in photo is 0.5 m wide); and (G) forced pool riffle.

Step-forming material may be viewed as either a kinematic wave (Langbein and Leopold, 1968), a congested zone of large grains that causes increased local flow resistance and further accumulation of large particles

(Church and Jones, 1982), or as macroscale antidunes (McDonald and Banerjee, 1971; Shaw and Kellerhals, 1977; Grant and Mizuyama, 1991). Step-pool sequences form through armoring processes under high dis-




Figure 1. (Continued—caption on facing page).

charges and low sediment supply (Ashida et al., 1981; Whittaker and Jaeggi, 1982). Grant et al. (1990) suggested that low sediment supply and infrequent discharges capable of moving the coarsest sediment are required for development of stepped-bed morphology, and Grant and Mizuyama (1991) suggested that step-pool formation requires a heterogeneous bed mixture and near-critical flow. Furthermore, step spacing corresponds to maximum flow resistance, providing stability for a bed that would otherwise be mobile (Whittaker and Jaeggi, 1982; Abrahams et al., 1995).

Step-pool channels have several sediment transport thresholds. Large bed-

forming material generally is mobile only during relatively infrequent hydrologic events (Whittaker, 1987a, 1987b; Grant et al., 1990), although Warburton (1992) showed that step-forming clasts in steep proglacial channels may be mobile annually. Significant movement of all grain sizes occurs during extreme floods, and step-pool morphology is reestablished during the falling limb of the hydrograph (Sawada et al., 1983; Whittaker, 1987b; Warburton, 1992). During more frequent discharges, finer material stored in pools travels as bedload over stable bed-forming clasts (Ashida et al., 1981; Whittaker, 1987a, 1987b; Ergenzinger and Schmidt, 1990; Grant et al., 1990; Schmidt and Ergenzinger, 1992). In a series of tracer tests in a step-pool channel, Schmidt and Ergenzinger (1992) found that all of the tagged particles placed in pools mobilized during frequent, moderate discharges and were preferentially redeposited into pools. Transport of all the pool-filling material indicates that sediment transport of non-step-forming grains is supply limited. Bedload studies in step-pool channels demonstrate complex relations between discharge and sediment transport; transport rates are dependent on seasonal and stochastic sediment inputs, flow magnitude and duration, and antecedent events (Nanson, 1974; Griffiths, 1980; Ashida et al., 1981; Sawada et al., 1983; Whittaker, 1987a, 1987b; Warburton, 1992). Ashida et al. (1981), for example, observed a 10 hr lag between the hydrograph peak and onset of bedload transport for step-pool channels scoured of all pool-filling sediment during previous storms. Hydrograph peaks and bedload transport were, however, directly correlated during a subsequent storm due to the availability of sediment deposited in pools. Warburton (1992) suggested three phases of sediment transport in step-pool channels: a low-flow flushing of fines; frequent high-flow mobilization of pool-filling gravel (also noted by Sawada et al., 1983); and less-frequent higher-discharge mobilization of step-forming grains.

Although step-pool and cascade channel morphologies both reflect supply-limited transport, they are distinguished by differences in the spatial




Figure 2. Schematic planform illustration of alluvial channel morphologies at low flow: (A) cascade channel showing nearly continuous, highly turbulent flow around large grains; (B) step-pool channel showing sequential highly turbulent flow over steps and more tranquil flow through intervening pools; (C) plane-bed channel showing single boulder protruding through otherwise uniform flow; (D) pool-riffle channel showing exposed bars, highly turbulent flow through riffles, and more tranquil flow through pools; and (E) dune-ripple channel showing dune and ripple forms as viewed through the flow.

density and organization of large clasts. Step-pool channels are defined by discrete channel-spanning steps less than a channel width in length that separate pools spaced every one to four channel widths. Cascade channels are defined by ubiquitous tumbling and jet-and-wake flow over a series of individual large clasts that together exceed a channel width in length, with small, irregularly placed pools spaced less than a channel width apart. The regular sequence of pools and steps in step-pool channels probably represents the emergence of a fluvially organized morphology in alluvial channels. In contrast, the disorganized large clasts of cascade channels may include lag deposits forced by nonfluvial processes (e.g., debris flows, glaciers, and rock falls).

Plane-Bed Channels

The term "plane bed" has been applied to both planar bed phases observed to form in sand-bed channels (Simons et al., 1965) and planar gravel and cobble-bed channels (Florsheim, 1985) like the coarse-grained, threshold canals described by Lane and Carlson (1953). Our use of the term refers to the latter and encompasses glide (run), riffle, and rapid morphologies described in the fisheries literature (e.g., Bisson et al., 1982). Plane-bed channels lack discrete bars, a condition that is associated with low width to depth ratios (Sukegawa, 1973; Ikeda, 1975, 1977) and large values of relative

roughness (ratio of 90th percentile grain size to bankfull flow depth). Church and Jones (1982) considered bar formation unlikely at relative roughnesses of 0.3 to 1.0. Plane-bed reaches occur at moderate to high slopes in relatively straight channels that may be either unconfined or confined by valley walls. They typically are composed of sand to small boulder grain sizes, but are dominantly gravel to cobble bedded.

Plane-bed channels differ morphologically from both step-pool and pool-riffle channels in that they lack rhythmic bedforms and are characterized by long stretches of relatively featureless bed (Figs. 1C and 2C). The absence of tumbling flow and smaller relative roughness distinguish plane-bed reaches from cascade and step-pool channels (Fig. 3C). Plane-bed channels lack sufficient lateral flow convergence to develop pool-riffle morphology due to lower width to depth ratios and greater relative roughness, which may decompose lateral flow into smaller circulation cells. However, introduction of flow obstructions may force local pool and bar formation.

Plane-bed channels typically exhibit armored bed surfaces calculated to have a near-bankfull threshold for mobility, although elevated sediment loading can cause textural fining and a lower calculated mobility threshold (Buffington, 1995). Plane-bed channels with armored bed surfaces indicate a transport capacity greater than sediment supply (i.e., supply-limited conditions), whereas unarmored surfaces indicate a balance between transport capacity and sediment supply (Dietrich et al., 1989). Nevertheless, beyond




Figure 3. Schematic longitudinal profiles of alluvial channel morphologies at low flow: (A) cascade; (B) step pool; (C) plane bed; (D) pool riffle; and (E) dune ripple.

the threshold for significant bed-surface mobility, many armored gravel-bedded channels exhibit a general correspondence between bedload transport rate and discharge (e.g., Milhous, 1973; Jackson and Beschta, 1982; Sidle, 1988), implying transport-limited conditions. The above observations suggest that plane-bed channels are transitional between supply- and transport-limited morphologies.

Pool-Riffle Channels

Pool-riffle channels have an undulating bed that defines a sequence of bars, pools, and riffles (Leopold et al., 1964) (Fig. 1D). This lateral bedform oscillation distinguishes pool-riffle channels from the other channel types discussed above (Fig. 2D). Pools are topographic depressions within the channel and bars are corresponding high points (Fig. 3D); these bedforms

are thus defined relative to each other (O'Neill and Abrahams, 1984). Pools are rhythmically spaced about every five to seven channel widths in self-formed, pool-riffle channels (Leopold et al., 1964; Keller and Mellhorn, 1978), but channels with a high loading of large woody debris exhibit smaller pool spacing (Montgomery et al., 1995). Pool-riffle channels occur at moderate to low gradients and are generally unconfined, and have well-established flood plains. Substrate size in pool-riffle streams varies from sand to cobble, but typically is gravel sized.

Bar and pool topography generated by local flow convergence and divergence may be either freely formed by cross-stream flow and sediment transport, or forced by channel bends and obstructions (e.g., Lisle, 1986). Free-formed pool-riffle sequences initially result from internal flow perturbation that causes flow convergence and scour on alternating banks of the channel; concordant downstream flow divergence results in local sediment accumulation in discrete bars. Topographically driven convective accelerations reinforce convergent and divergent flow patterns, and thus pool-riffle morphogenesis (Dietrich and Smith, 1983; Dietrich and Whiting, 1989; Nelson and Smith, 1989). Alluvial bar development requires a sufficiently large width to depth ratio and small grain sizes that are easily mobilized and stacked by the flow (Church and Jones, 1982). Bar formation in natural channels appears to be limited to gradients ≤ 0.02 (Ikeda, 1977; Florsheim, 1985), although flume studies indicate that alternate bars may form at steeper gradients (Bathurst et al., 1983; Lisle et al., 1991). Bedform and grain roughness provide the primary flow resistance in free-formed pool-riffle channels.

Pool-riffle channels have heterogeneous beds that exhibit a variety of sorting and packing, commonly with a coarse surface layer and a finer subsurface (Leopold et al., 1964; Milhous, 1973). Armored gravel-bed channels typically exhibit a near-bankfull threshold for general and significant bed-surface mobility (e.g., Parker et al., 1982; Jackson and Beschta, 1982; Andrews, 1984; Carling, 1988; Buffington, 1995). Movement of surface grains releases fine sediment trapped by larger grains and exposes finer subsurface sediment to the flow, contributing to a steep rise in bedload transport with increasing shear stress (Milhous, 1973; Jackson and Beschta, 1982; Emmett, 1984). Bed movement is sporadic and discontinuous, depending on grain protrusion (Fenton and Abbott, 1977; Kirchner et al., 1990), friction angle (Kirchner et al., 1990; Buffington et al., 1992), imbrication (Komar and Li, 1986), degree of burial (Hammond et al., 1984; Buffington et al., 1992), and turbulent high-velocity sweeps of the channel bed. Very rarely is the whole bed in motion, and material eroded from one riffle commonly is deposited on a proximal downstream riffle.

Pool-riffle channels, like plane-bed channels, exhibit a mixture of supply- and transport-limited characteristics depending on the degree of bed-surface armoring and consequent mobility thresholds. Unarmored pool-riffle channels indicate a balance between transport capacity and sediment supply, while armored surfaces represent supply-limited conditions (e.g., Dietrich et al., 1989). Nevertheless, during armor-breaching events, bedload transport rates are generally correlated with discharge, demonstrating that sediment transport is not limited by supply once the bed is mobilized. Considerable fluctuations in observed transport rates, however, reflect a stochastic component of grain mobility caused by grain interactions, turbulent sweeps, and transient grain entrapment by bedforms (Jackson and Beschta, 1982; Sidle, 1988). Magnitudes of bedload transport also may vary for similar discharge events, depending on the chronology of antecedent transport events (Milhous, 1973; Reid et al., 1985; Sidle, 1988). Although both pool-riffle and plane-bed channels display a mix of supply- and transport-limited characteristics, the presence of depositional barforms in pool-riffle channels suggests that they are generally more transport limited than plane-bed channels. The transport-limited character of both of these morphologies, however, contrasts with the more supply-limited character of step-pool and cascade channels.

Dune-Ripple Channels

Dune-ripple morphology is most commonly associated with low-gradient, sand-bed channels (Figs. 1E, 2E, and 3E). A flow regime-dependent succession of mobile bedforms provides the primary hydraulic resistance in dune-ripple channels (e.g., Kennedy, 1975). However, even gravel-bed channels can exhibit a succession of multiple-scale bedforms during extreme discharges (e.g., Griffiths, 1989; Dinehart, 1992; Pitlick, 1992). The bedform configuration of dune-ripple channels depends on flow depth, velocity, bed-surface grain size, and sediment transport rate (e.g., Gilbert, 1914; Middleton and Southard, 1984), but generally follows a well-known morphologic sequence with increasing flow depth and velocity: lower-regime plane bed, ripples, sand waves, dunes, upper-regime plane bed, and antidunes (Gilbert, 1914; Simons et al., 1965; Harms et al., 1975). In channels transporting moderately to poorly sorted sediment, migrating bedload sheets composed of thin accumulations of sediment also may develop (Whiting et al., 1988). Several scales of bedforms may coexist in a dune-ripple channel; ripples, bedload sheets, and small dunes may climb over larger mobile dunes. A complete theoretical explanation for the development of such multiple-scale bedforms does not yet exist, but they are typically associated with low relative roughness. Dune-ripple channels also exhibit point bars or other bedforms forced by channel geometry. In contrast to the threshold sediment transport of plane-bed and pool-riffle streams, dune-ripple channels exhibit "live bed" transport (e.g., Henderson, 1963), in which significant sediment transport occurs at most stages. Hence, dune-ripple channels are effectively transport limited. The frequency of bed mobility and the presence of ripples and/or dunes distinguish dune-ripple channels from pool-riffle channels.

Colluvial Channels

Colluvial channels are small headwater streams at the tips of a channel network that flow over a colluvial valley fill and exhibit weak or ephemeral fluvial transport (Fig. 1F). Little research has focused on colluvial channels, even though first-order channels compose approximately half of the total length of a channel network (Montgomery, 1991). Dietrich et al. (1982) recognized that shallow flows in headwater channels have little opportunity for scour, and therefore sediment delivered from neighboring hillslopes generally accumulates to form colluvial valley fills. Benda and Dunne (1987) examined sediment in steep headwater valleys in the Oregon Coast Range and concluded that beneath a water-worked coarse surface layer, the valley fill consists of relatively unsorted colluvium delivered from surrounding hillslopes. Shallow and ephemeral flow in colluvial channels appears insufficient to mobilize all of the colluvial sediment introduced to the channel, resulting in significant storage of this material (Dietrich and Dunne, 1978; Dietrich et al., 1982; Benda, 1990). Large clasts, woody debris, bedrock steps, and in-channel vegetation further reduce the energy available for sediment transport in colluvial channels. Intermittent flow may rework some portion of the surface of the accumulated material, but it does not govern deposition, sorting, or transport of the valley fill.

Episodic transport by debris flows may account for most of the sediment transport in steep headwater channels. A sediment budget for a small basin in northern California indicated that debris flows account for more than half of the long-term sediment yield (Lehre, 1982). Swanson et al. (1982) estimated that only 20% of the total sediment yield from a first-order channel in the Cascade Range is accommodated by fluvial transport. Hence, the long-term sediment flux from low-order channels in steep terrain appears to be dominated by debris-flow processes. Differences in channel profiles support the hypothesis that different processes dominate the erosion of steep headwater channels and lower-gradient alluvial channels in the Oregon Coast Range (Seidl and Dietrich, 1992).

Dietrich and Dunne (1978) recognized that the residence time of sediment in headwater debris-flow-prone channels was on the order of hundreds of years. Kelsey (1980) also estimated that the sediment stored in first- and second-order channels is scoured by debris flows every 300 to 500 yr. Benda (1990) proposed a conceptual model for the evolution of channel morphology in steep headwater channels that involves cyclical alteration of bed morphology from gravel to boulder to bedrock in response to episodic sediment inputs. The accumulation of colluvial valley fills during periods between catastrophic scouring events indicates that transport capacity, rather than sediment supply, limits fluvial transport in colluvial channels.

Bedrock Channels

Bedrock channels lack a continuous alluvial bed. Although some alluvial material may be temporarily stored in scour holes, or behind flow obstructions, there is little, if any, valley fill. Hence, bedrock channels generally are confined by valley walls. Evidence from both anthropogenic badlands and mountain drainage basins indicates that bedrock channels are steeper than alluvial channels having similar drainage areas (Howard and Kerby, 1983; Montgomery et al., 1996). It is reasonable to adopt Gilbert's (1914) hypothesis that bedrock channels lack an alluvial bed due to high transport capacity associated with steep channel gradients and/or deep flow. Although bedrock channels in low-gradient portions of a watershed reflect a high transport capacity relative to sediment supply, those in steep portions of a watershed may also reflect recent catastrophic scouring.

Forced Morphologies

Flow obstructions can force a reach morphology that differs from the free-formed morphology for a similar sediment supply and transport capacity. In forested mountain drainage basins, for example, large woody debris may force local scour, flow divergence, and sediment impoundment that respectively form pools, bars, and steps (Fig. 1G). In an extreme example, Montgomery et al. (1996) found that log jams forced alluvial streambeds in otherwise bedrock reaches of a mountain channel network in western Washington.

Forced pool-riffle and step-pool channels are the most common obstruction-controlled morphologies in forested mountain drainage basins. A forced pool-riffle morphology is one in which most pools and bars are forced by obstructions such as large woody debris, and a forced step-pool channel is one in which large woody debris forms most of the channel-spanning steps that define the bed morphology. Forced morphologies can extend beyond the range of conditions characteristic of analogous free-formed morphologies (i.e., to steeper gradients and/or lower sediment supply). We recognize forced morphologies as distinct channel types because interpretation of whether such obstructions govern bed morphology is important for understanding channel response.

Intermediate and Other Morphologies

The channel types described above represent identifiable members along a continuum that includes several intermediate morphologies: riffle bar (pool riffle-plane bed); riffle step (plane bed-step pool); and cascade pool (step pool-cascade). Mixed alluvial and bedrock reaches exhibit subreach scale variations in alluvial cover. In our experience, however, it is simple to replicate identification of the seven basic reach types, even though they lie within a continuum of channel morphologies. Whether intermediate channel types are useful for classification purposes depends on the context of the application. Although our proposed classification does not cover all reach types in all environments (e.g., estuarine, cohesive-bed, or vegetated reaches), we have found it to be applicable in a variety of mountain environments.

TABLE 2. STUDY AREA CHARACTERISTICS

Study area	Geology	Drainage area (km ²)	Relief (m)	Land use
Finney Creek, Washington	Phyllite, greenschist, glacial sediments	128	1476	U.S. Forest Service, state forestry
Boulder River, Washington	Phyllite, glacial sediments	63	1985	U.S. Forest Service wilderness area
South Fork Hoh River, Washington	Sandstone, glacial sediments	129	>882	State forestry, national park
Deton Creek, Oregon	Sandstone	8	327	Private forestry

FIELD TEST

Process differences associated with reach morphology should result in distinct physical characteristics for each reach type. Data compiled from field studies in the Pacific Northwest reveal systematic association of channel types with slope, drainage area, relative roughness, and bed-surface grain size. Furthermore, these data suggest an explanation for the origin of distinct channel types.

Study Areas and Methods

Field surveys were conducted in four drainage basins in western Washington and coastal Oregon: Finney Creek, Boulder River, South Fork Hoh River, and Deton Creek (Table 2). In each study area, channel reaches 10–20 channel widths in length were surveyed throughout the drainage basin. Each reach was classified into one of the above-defined channel types. Reach slopes were surveyed using either an engineering level or a hand level and stadia rod. Topographic surveys and channel-spanning pebble counts of 100 grains (Wolman, 1954) were conducted at representative cross sections. Reach locations were mapped onto U.S. Geological Survey 1:24,000 scale topographic maps from which drainage areas were measured using a digital planimeter. Reach slopes were determined from topographic maps for some additional reaches where morphologies were mapped, but slope and grain-size measurements were not collected. We also included in our analysis data collected using similar field methods in related studies in

western Washington and southeast Alaska (Montgomery et al., 1995; Buffington, 1995).

Results

In each study area, there is a general downstream progression of reach types that proceeds as colluvial, cascade, step pool, plane bed or forced pool riffle, and pool riffle (Fig. 4); we encountered no dune-ripple reaches in the study basins, although we observed them in neighboring areas. Bedrock reaches occur at locally steep locations throughout the channel networks, and not all of these channel types are present in each watershed. Furthermore, the specific downstream sequence of reach types observed in each drainage basin reflects local factors controlling channel slope, discharge, sediment supply, bedrock lithology, and disturbance history.

Data from alluvial, colluvial, and bedrock reaches within each study basin define distinct fields on a plot of drainage area versus reach slope (Fig. 5). These data provide further evidence that, for a given drainage area, bedrock reaches have greater slopes, and hence greater basal shear stress and stream power, than either alluvial or colluvial reaches (Howard and Kerby, 1983; Montgomery et al., 1996). Alluvial reaches occur on slopes less than about 0.2 to 0.3, and different alluvial channel types generally segregate within an inversely slope-dependent band within which pool-riffle and plane-bed channels occur at the lowest slopes, and step-pool and cascade channels occur on steeper slopes. Colluvial reaches occur at lower drainage areas and extend to steeper slopes. Data from colluvial reaches define a relation between drainage area and slope that contrasts with that of lower-gradient alluvial reaches. This general pattern holds for each of the study basins, implying consistent differences among colluvial, alluvial, and bedrock reaches in mountain drainage basins.

The different drainage area–slope relation for colluvial and alluvial channel reaches implies fundamental differences in sediment transport processes. For equilibrium channel profiles, channel slope (S) and drainage area (A) are related by

$$S = KA^{-m/n} \quad (1)$$

where K , m , and n are empirical variables that incorporate basin geology, climate, and erosional processes (e.g., Howard et al., 1994). A log-linear regression of reach slope and drainage area data from alluvial and colluvial channels in Finney Creek yields m/n values of 0.72 ± 0.08 ($R^2 = 0.72$) and 0.26 ± 0.05 ($R^2 = 0.58$), respectively, which implies long-term differences in sediment transport processes between these channel types. This correspondence between the inflection in the drainage area–slope relation and the transition from colluvial to alluvial channels is consistent with the interpretation that scour by debris flows is the dominant incisional process in colluvial channels (Benda, 1990; Seidl and Dietrich, 1992; Montgomery and Foufoula-Georgiou, 1993).

Although slope ranges of free-form alluvial channel types overlap, they have distinct medians and quartile ranges (Fig. 6). Examination of the composite slope distributions indicates that reaches with slopes of less than 0.015 are likely to have a pool-riffle morphology; reaches with slopes of





Figure 4. Idealized long profile from hillslopes and unchanneled hollows downslope through the channel network showing the general distribution of alluvial channel types and controls on channel processes in mountain drainage basins.

Figure 5. Drainage area versus reach slope for channels in the Finney Creek watershed, Washington.



0.015 to 0.03 typically have a plane-bed morphology; reaches with slopes of 0.03 to 0.065 are likely to have a step-pool morphology; and alluvial reaches with slopes greater than 0.065 typically have a cascade morphology. These core slope ranges define zones over which each channel type is the

most likely to occur; however, the distributions overlap and channel type is not uniquely related to reach slope. Furthermore, forced pool-riffle reaches span the slope ranges for pool-riffle and plane-bed reaches, indicating that introduction of large woody debris can extend a forced morphology to slopes where such a morphology would not be expected under low woody debris loading (Montgomery et al., 1995). Nonetheless, the general segregation of reach type by slope allows prediction of likely channel morphology from topographic maps or digital elevation models.

Relative roughness (the ratio of the ninetieth percentile grain size to the bankfull flow depth [d_{90}/D]) and reach slope together differentiate alluvial reach types (Fig. 7): pool-riffle channels have relative roughness less than about 0.3 and occur on slopes <0.03; plane-bed channels exhibit relative roughness of roughly 0.2 to 0.8 on slopes of 0.01 to 0.04; step-pool reaches occur on steeper slopes and have relative roughness of 0.3 to 0.8; and the size of the largest clasts on the bed of steeper cascade reaches can approach those of bankfull flow depth. Relative roughness and reach slope together provide a reasonable stratification of channel morphology. In pool-riffle and plane-bed channels relative roughness increases rapidly with increasing slope, whereas there is little relation between relative roughness and slope for steeper step-pool and cascade reaches.

Composite bed-surface grain-size distributions for pebble counts from different channel types exhibit systematic coarsening from pool-riffle through cascade channels. For reaches in the Finney Creek watershed (Fig. 8), the median grain size increases from 17 mm for pool-riffle channels to 80 mm for cascade morphologies, and d_{84} increases from 57 mm to 250 mm. These systematic changes in bed-surface grain-size distributions indicate that progressive fining of the bed material accompanies the formation of different channel types downstream through a channel network.

The data reported above demonstrate that qualitatively defined channel types exhibit quantitatively distinguishable characteristics. Our data further indicate that channel morphology is related to reach-average bankfull shear stress (Fig. 9). Bedrock channels occur in reaches with the greatest shear stress; cascade and step-pool reaches plot at lower values, which in turn are greater than those for plane-bed and pool-riffle channels. Hence, it appears that, in part, local flow hydraulics influence the general distribution of channel types in a watershed.




Figure 6. Composite slope distributions for channel reaches surveyed in this and related studies (Buffington, 1995; Montgomery et al., 1995); boxes represent inner and outer quartiles; vertical lines represent inner and outer tenths.




Figure 7. Composite plot of relative roughness (d_{90}/D) versus field surveyed reach slope for data from alluvial reaches in our study areas.

ORIGIN OF REACH-LEVEL MORPHOLOGIES

The typical downstream sequence of channel morphologies (Fig. 4) is accompanied by a progressive decrease in valley-wall confinement, which in stream-formed valleys may reflect opposing downstream trends of sediment supply (Q_s) and transport capacity (Q_c). Transport capacity is defined here as a function of the total boundary shear stress and is distinguished from the effective transport capacity (Q_c'), which is a function of the effective shear stress available for sediment transport after correction for shear stress dissipation caused by hydraulic roughness elements. Transport capacity generally decreases downstream due to the slope decreasing faster than the depth increases, whereas total sediment supply generally increases with drainage area, even though sediment yield per unit area often decreases (Fig. 10). This combination may result in long-term patterns of downstream




Figure 8. Aggregated cumulative grain-size distributions for alluvial channels of reaches with different bed morphologies in the Finney Creek watershed.

deposition and development of wide flood plains and unconfined valleys. Insignificant sediment storage in a valley segment indicates that virtually all of the material delivered to the channel is transported downstream. In contrast, thick alluvial valley-fill deposits imply either a long-term excess of sediment supply over transport capacity, or an inherited valley fill.

These general patterns and our field observations discussed above lead us to propose that distinctive channel morphologies reflect the relative magnitude of transport capacity to sediment supply, which may be expressed as the ratio $q_r = Q_c/Q_s$. Colluvial channels are transport limited ($q_r < 1$), as in-




Figure 9. Plot of drainage area versus reach. Average shear stress for bedrock (triangles), cascade and step-pool (circles), and plane-bed and pool-riffle (squares) channel morphologies are from the South Fork Hoh River study area.




Figure 10. Schematic illustration of generalized relative trends in sediment supply (Q_s) and transport capacity (Q_c) in mountain drainage basins.

indicated by the accumulation of colluvium within valley bottoms. In contrast, the lack of an alluvial bed indicates that bedrock channels are supply limited ($q_r \gg 1$). For a given drainage area (and thus Q_s), bedrock reaches have greater slopes and shear stresses (Figs. 5 and 9), implying that they have higher transport capacities and thus greater q_r values than other channel types. Alluvial channels, however, probably represent a broad range of q_r : steep alluvial channels (cascade and step-pool) have higher shear stresses (Fig. 9) and thus higher Q_c and q_r values for a given drainage area and sediment supply; the lower-gradient plane-bed and pool-riffle channels are transitional between $q_r > 1$ and $q_r \approx 1$, depending on the degree of armoring (e.g., Dietrich et al., 1989) and the frequency of bed-surface mobility; and the live-bed mobility of dune-ripple channels indicates that $q_r \leq 1$. The variety of alluvial channel morphologies probably reflects a broad spectrum of q_r expressed through fining and organization of the bedload (Fig. 11), which leads to formation of distinct alluvial bed morphologies that represent the stable bed form for the imposed q_r . This hypothesized relation between q_r and stable channel morphologies in mountain drainage basins provides a genetic framework for explaining reach-level morphologies that elaborates on Lindley's (1919) regime concept. An alluvial channel with $q_r > 1$ will become stable when the bed morphology and consequent hydraulic roughness

produce an effective transport capacity that matches the sediment supply ($Q_c' \approx Q_s$).

Different channel types are stabilized by different roughness configurations that provide resistance to flow. In steep channels energy is dissipated primarily by hydraulic jumps and jet-and-wake turbulence. This style of energy dissipation is pervasive in cascade channels and periodic in step-pool channels. Skin friction and local turbulence associated with moderate particle sizes are sufficient to stabilize the bed for lower shear stresses characteristic of plane-bed channels. In pool-riffle channels, skin friction and bedform drag dominate energy dissipation. Particle roughness in dune-ripple channels is small due to the low relative roughness, and bedforms govern hydraulic resistance. The importance of bank roughness varies with channel type, depending on the width to depth ratio and vegetative influences, but in steep channels bank resistance is less important compared to energy dissipation caused by tumbling flow. These different roughness configurations represent a range in q_r values that varies from high in cascade reaches to low in dune-ripple channels.

Our hypothesis that different channel types represent stable roughness configurations for different q_r values implies that there should be an association of channel type and roughness. Even though the general correlation of morphology and slope (Fig. 6) implies discrete roughness characteristics among channel types, different channel morphologies occurring on the same slope should exhibit distinct roughness. Photographs and descriptions of channel morphology from previous studies in which roughness was determined from measured velocities (Barnes, 1967; Marcus et al., 1992) allow direct assessment of the roughness associated with different channel types. For similar slopes, plane-bed channels exhibit greater roughness than pool-riffle channels, and step-pool channels, in turn, appear to have greater roughness than plane-bed channels with comparable gradients (Fig. 12). Moreover, intermediate morphology reaches plot between their defining channel types. These systematic trends in roughness for a given slope strongly support the hypothesis that reach-level channel morphology reflects a dynamic adjustment of the bed surface to the imposed shear stress and sediment supply (i.e., the specific q_r value).

CHANNEL DISTURBANCE AND RESPONSE POTENTIAL

Natural and anthropogenic disturbances that change hydrology, sediment supply, riparian vegetation, or large woody debris loading can alter channel processes and morphology. The effect that watershed disturbance has on a particular channel reach depends on hillslope and channel coupling, the sequence of upstream channel types, and site-specific channel morphology. In particular, the variety and magnitude of possible morphologic responses to




Figure 11. Schematic illustration of the transport capacities relative to sediment supply for reach-level channel types.




Figure 12. Plot of reach roughness coefficient (Manning's n) versus reach slope for channels classified according to our system using data and photographs in Barnes (1967) and Marcus et al. (1992). Note that channel types interpreted to reflect greater relative transport capacity have higher roughness over similar slopes.

a given disturbance depend on channel type, external influences (e.g., confinement, riparian vegetation, large woody debris), and disturbance history. Together these considerations provide an integrative approach for examining spatial and temporal patterns of channel disturbance and response in mountain watersheds.

Spatial Distribution of Channel Types

The spatial distribution of channel types and their coupling to both hillslopes and one another can strongly influence the potential for a channel to be affected by a disturbance. In general, the degree of hillslope-channel coupling changes downstream through mountain channel networks, resulting in changes in both the characteristics and delivery mechanisms of sediment supplied to a channel (e.g., Rice, 1994). Furthermore, the general downstream progression of channel morphologies in mountain drainage basins (Fig. 4) causes an association of hillslope coupling and channel type. Headwater colluvial channels are strongly coupled to adjacent hillslopes, and net sediment transport from these weakly fluvial reaches is affected by the frequency of upslope debris flows and mass movements. Valley-wall confinement allows direct sediment input by hillslope processes to cascade and step-pool channels, which makes them prone to periodic disturbance from hillslope failures. Debris flows can dominate the disturbance frequency in headwater portions of the basin, scouring high-gradient channels and aggrading the first downstream reach with a gradient low enough to cause deposition of the entrained material (e.g., Benda and Dunne, 1987). Consequently, the effects of debris-flow processes on channel morphology can be divided into those related to scour, transport, and deposition. Farther downstream, the coupling between hillslopes and lower-gradient channels (i.e., plane-bed, pool-riffle, and dune-ripple) is buffered by wider valleys and depositional flood plains, making these reaches less susceptible to direct disturbance from hillslope processes. Sediment characteristics, delivery, and trans-

port are generally dominated by fluvial processes in these lower-gradient channels, although forcing by large woody debris and impingement of channels on valley walls can have a significant influence on the local transport capacity and sediment supply (e.g., Rice, 1994).

The downstream sequence in which channel types are arranged also affects the potential for a disturbance to impact a particular reach. Position within the network and differences between q_r values allow general aggregation of channel reaches into source, transport, and response segments. In steep landscapes, source segments are transport-limited, sediment-storage sites subject to intermittent debris-flow scour (i.e., colluvial channels). Transport segments are morphologically resilient channels with a high q_r (i.e., bedrock, cascade, and step-pool channels) that rapidly convey increased sediment loads. Response segments are channels with a low q_r (i.e., plane-bed, pool-riffle, and dune-ripple) in which significant morphologic adjustment occurs in response to increased sediment supply. These distinctions build upon Schumm's (1977) concept of erosion, transport, and deposition zones within a watershed to provide a conceptual model that allows identification of reach-specific response potential throughout a channel network.

The spatial distribution of source, transport, and response segments governs the distribution of potential impacts and recovery times within a watershed. Downstream transitions from transport to response reaches define locations where impacts from increased sediment supply may be both pronounced and persistent. Transport segments rapidly deliver increased sediment loads to the first downstream reach with insufficient transport capacity to accommodate the additional load. Consequently, the "cumulative" effects of upstream increases in sediment supply may be concentrated in response segments where longer time and/or significant morphological change is required to transport the additional sediment. In this regard, reach-level classification identifies areas most sensitive to increases in upstream sediment inputs. Hence, downstream transitions from transport to response segments can provide ideal locations to monitor network response and should serve as critical components of watershed monitoring studies. Most important, the relation between channel type and response potential provides a direct link between upstream sediment inputs and downstream response. Identification of source, transport, and response segments thereby provides a context for examining connections between watershed modifications, impacts on channel morphology, and biological response.

Influence of Channel Type

Differences in confinement, transport capacity relative to sediment supply, and channel morphology influence channel response to perturbations in sediment supply and discharge. Thus, it is important to assess channel response potential in the context of reach type and location within a watershed. An understanding of reach morphologies, processes, and environments allows reach-specific prediction of the likely degree and style of response to a particular perturbation. Small to moderate changes in discharge or sediment supply can alter channel attributes (e.g., grain size, slope, and channel geometry); large changes can transform reach-level channel types. On the basis of typical reach characteristics and locations within mountainous watersheds, we assessed the relative likelihood of specific morphologic responses to moderate perturbations in discharge and sediment supply for each channel type (Table 3).

Channels with different bed morphology and confinement may have different potential responses to similar changes in discharge or sediment supply. Changes in sediment storage dominate the response of colluvial channels to altered sediment supply because of transport-limited conditions and low fluvial transport capacities (Table 3); depending on the degree of valley fill, increased discharge can significantly change channel geometry. In contrast, bedrock, cascade, and step-pool channels are resilient to most discharge or

TABLE 3. INTERPRETED REACH-LEVEL CHANNEL RESPONSE POTENTIAL TO MODERATE CHANGES IN SEDIMENT SUPPLY AND DISCHARGE

	Width	Depth	Roughness	Scour depth	Grain size	Slope	Sediment storage
Dune ripple	+	+	+	+	o	+	+
Pool riffle	+	+	+	+	+	+	+
Plane bed	p	+	p	+	+	+	p
Step pool	o	p	p	p	p	p	p
Cascade	o	o	p	o	p	o	o
Bedrock	o	o	o	o	o	o	o
Colluvial	p	p	o	p	p	o	+

Notes: +—likely, o—unlikely, p—possible.

sediment-supply perturbations because of high transport capacities and generally supply-limited conditions. Many bedrock channels are insensitive to all but catastrophic changes in discharge and sediment load. Lateral confinement and large, relatively immobile, bed-forming clasts make channel incision or bank cutting unlikely responses to changes in sediment supply or discharge in most cascade and step-pool channels. Other potential responses in step-pool channels include changes in bedform frequency and geometry, grain size, and pool scour depths, whereas only limited textural response is likely in cascade channels. Lower gradient plane-bed, pool-riffle, and dune-ripple channels become progressively more responsive to altered discharge and sediment supply with decreasing q_r , smaller grain sizes, and less channel confinement. Because plane-bed channels occur in both confined and unconfined valleys, they may or may not be susceptible to channel widening or changes in valley-bottom sediment storage. Smaller, more mobile grain sizes in plane-bed and pool-riffle channels allow potentially greater response of bed-surface textures, scour depth, and slope compared to cascade and step-pool morphologies. Unconfined pool-riffle and dune-ripple channels generally have significant potential for channel geometry responses to perturbations in sediment supply and discharge. Changes in both channel and valley storage are also likely responses, as well as changes in channel roughness due to alteration of channel sinuosity and bedforms. There is less potential for textural response in dune-ripple than in pool-riffle and plane-bed channels simply because of smaller and more uniform grain sizes. At very high sediment supply, any of the above channel types may acquire a braided morphology (e.g., Mollard, 1973; Church, 1992). The general progression of alluvial channel types downstream through a channel network (Fig. 4) suggests that there is a systematic downstream increase in response potential to altered sediment supply or discharge.

The above predictions of response potential are largely conceptual, based on typical reach processes, characteristics, and locations within a drainage basin. Nevertheless, our approach provides a rational, process-based alternative to channel assessments based solely on descriptive typologic classification. For example, a channel-reach classification developed by Rosgen (1994) recognizes 7 major and 42 minor channel types primarily on the basis of bed material and slope; there is also the option of more detailed classification using entrenchment, sinuosity, width to depth ratio, and geomorphic environments. However, the classification lacks a basis in channel processes. The lack of an explanation of the rationale underlying Rosgen's (1994) assessment of response potential for each minor channel type emphasizes this shortcoming. Furthermore, Rosgen's (1994) classification combines reach morphologies that may have very different response potentials: Rosgen's (1994) C channels may include reaches with dune-ripple, pool-riffle, plane-bed, or forced pool-riffle morphologies; his B channels may include plane-bed, forced-pool riffle, and step-pool morphologies; and his A channels may include colluvial, cascade, and step-pool reaches. Although bed material and slope provide a convenient classification for many channels, the lack of a process-based methodology compromises such an approach to structuring channel assessments, predicting channel response, and investigating relations to ecological processes.

External Influences

Channel response potential also reflects external influences on channel morphology, the most prominent of which are confinement, riparian vegetation, and large woody debris loading. Valley-wall confinement limits changes in both channel width and flood-plain storage and maximizes channel response to increased discharge by limiting overbank flow. Although there is a general downstream correspondence between channel type and valley-wall confinement in many mountain watersheds, structural controls and geomorphic history can force confinement in any portion of the channel network.

Riparian vegetation influences channel morphology and response potential by providing root strength that contributes to bank stability (e.g., Shaler, 1891; Gilbert, 1914), especially in relatively noncohesive alluvial deposits. The effect of root strength on channel bank stability is greatest in low-gradient, unconfined reaches, where loss of bank reinforcement may result in dramatic channel widening (Smith, 1976). Riparian vegetation is also an important roughness source (e.g., Arcement and Schneider, 1989) that can mitigate the erosive action of high discharges.

Large woody debris provides significant control on the formation and physical characteristics of pools, bars, and steps (Heede, 1985; Lisle, 1986; Montgomery et al., 1995; Wood-Smith and Buffington, 1996), thereby influencing channel type and the potential for change in sediment storage and bedform roughness in response to altered sediment supply, discharge, or large woody debris loading. Woody debris may decrease the potential for channel widening by armoring stream banks; alternatively, it may aid bank erosion by directing flow and scour toward channel margins. Furthermore, bed-surface textures and their response potential are strongly controlled by hydraulic roughness resulting from in-channel wood and debris-forced bedforms (Buffington, 1995). Although large woody debris can force morphologic changes ranging from the scale of channel units to reaches, its impact depends on the amount, size, orientation, and position of debris, as well as channel size (Bilby and Ward, 1989; Montgomery et al., 1995) and rates of debris recruitment, transport, and decay (Bryant, 1980; Murphy and Koski, 1989). In general, individual pieces of wood can dominate the morphology of small channels, whereas debris jams are required to significantly influence channel morphology in larger rivers where individual pieces are mobile (Abbe and Montgomery, 1996). Thus, the relative importance of large woody debris in controlling channel morphology and response potential varies through a channel network.

Temporal Changes in Channel Morphology

The spatial pattern of channel types within a watershed provides a snapshot in time of a channel network, but history also influences the response potential of mountain channels, because past disturbance can condition channel response. Temporal variations in macroscopic channel morphology reflect (1) changes in large woody debris loading (e.g., Beschta, 1979;

Heede, 1985); (2) changes in discharge and sediment input (e.g., Hammer, 1972; Graf, 1975; Megahan et al., 1980; Coats et al., 1985); and (3) routing of sediment waves through the channel network (e.g., Gilbert, 1917; Kelsey, 1980; Church and Jones, 1982; Madej, 1982; Reid, 1982; Beschta, 1983).

Channels in which large woody debris forces pool formation and sediment storage are particularly sensitive to altered wood loading. For example, removal of large woody debris from forced pool-riffle channels may lead to either a pool-riffle or plane-bed morphology (Montgomery et al., 1995). Similarly, loss of large woody debris may transform a forced step-pool channel into a step-pool, cascade, or bedrock channel, depending on channel slope, discharge, and availability of coarse sediment.

Changes in reach-level channel type resulting from increased sediment supply typically represent a transient response to a pulsed input, although a longer-term response may result from sustained inputs. A landslide-related pulse of sediment may result in a transient change to a morphology with a lower q_r that subsequently relaxes toward the original morphology as the perturbation subsides. Pool-riffle reaches, for example, can develop a braided morphology while transmitting a pulse of sediment and subsequently revert to a single-thread pool-riffle morphology. Channel reaches with high q_r should recover quickly from increased sediment loading, because they are able to rapidly transport the load downslope. Reaches with a low q_r should exhibit more persistent morphologic response to a comparable increase in sediment supply. Transient morphologic change can also result from debris-flow scour of steep-gradient channels. For example, colluvial and cascade channels that are scoured to bedrock by a debris flow may slowly revert to their predisturbance morphologies.

The spatial pattern of channel types provides a template against which to assess channel response potential, but the disturbance history of a channel network also is important for understanding both current conditions and response potential. Reach-level channel morphology provides a general indication of differences in response potential, but specific responses depend on the nature, magnitude, and persistence of disturbance, as well as on local conditions, including riparian vegetation, in-channel large woody debris, bank materials, and the history of catastrophic events. Furthermore, concurrent multiple perturbations can cause opposing or constructive response, depending on both channel type and the direction and magnitude of change. Hence, assessment of either present channel conditions or the potential for future impacts in mountain drainage basins should consider both disturbance history and the influences of channel morphology, position in the network, and local external constraints.

CONCLUSIONS

Systematic variations in bed morphology in mountain drainage basins provide the basis for a classification of channel-reach morphology that reflects channel-forming processes, serves to illustrate process linkages within the channel network, and allows prediction of general channel response potential. The underlying hypothesis that alluvial bed morphology reflects a stable roughness configuration for the imposed sediment supply and transport capacity implies a fundamental link between channel processes and form. The association of reach types and ratios of transport capacity to sediment supply combined with identification of external influences and the spatial coupling of reaches with hillslopes and other channel types provides a conceptual framework within which to investigate channel processes, assess channel conditions, and examine spatially distributed responses to watershed disturbance. Integration of this approach into region-specific landform and valley segment classifications would provide a common language to studies of fluvial processes and response to disturbance. This classification, however, is not ideal for all purposes; characterization of river planforms, for example, is useful for classifying flood-plain rivers. The development of specific

restoration designs requires further information on reach-specific characteristics. Our classification simply characterizes aspects of reach-level channel morphology useful for assessing channel condition and potential response to natural and anthropogenic disturbance in mountain drainage basins.

ACKNOWLEDGMENTS

This research was supported by the Sediment, Hydrology, and Mass Wasting Committee of the Washington State Timber-Fish-Wildlife agreement through grant FY95-156 and by the U.S. Forest Service through cooperative research agreements PNW 93-0441 and 94-0617. Tamara Mas-song, Carolyn Trayler, and Matt Coglon provided assistance in the field. We thank Jim Knox, Gordon Grant, and Andrew Marcus for insightful reviews of the manuscript, and Mike Church for thorough critiques that sharpened the discussion.

REFERENCES CITED

- Abbe, T. B., and Montgomery, D. R., 1996, Large woody debris jams, channel hydraulics and habitat formation in large rivers: Regulated rivers: Research and Management, v. 12, p. 201-221.
- Abrahams, A. D., Li, G., and Atkinson, J. F., 1995, Step-pool streams: Adjustment to maximum flow resistance: Water Resources Research, v. 31, p. 2593-2602.
- Andrews, E. D., 1984, Bed material entrainment and hydraulic geometry of gravel-bed rivers in Colorado: Geological Society of America Bulletin, v. 95, p. 371-378.
- Arceement, G. J., and Schneider, V. R., 1989, Guide for selecting Manning's roughness coefficients for natural channels and flood plains: U.S. Geological Survey Water-Supply Paper 2339, 38 p.
- Ashida, K., Takahashi, T., and Sawada, T., 1976, Sediment yield and transport on a mountainous small watershed: Bulletin of the Disaster Prevention Research Institute, v. 26, p. 119-144.
- Ashida, K., Takahashi, T., and Sawada, T., 1981, Processes of sediment transport in mountain stream channels. in Erosion and sediment transport in Pacific rim steepplains: International Association of Hydrological Sciences Publication 132, p. 166-178.
- Barnes, H. H., 1967, Roughness characteristics of natural channels: U.S. Geological Survey Water-Supply Paper 1849, 213 p.
- Bathurst, J. C., Graf, W. H., and Cao, H. H., 1983, Bedforms and flow resistance in steep gravel-bed channels, in Mutlu Sumer, M., and Muller, A., eds., Mechanics of sediment transport: Rotterdam, Netherlands, A. A. Balkema, p. 215-221.
- Benda, L., 1990, The influence of debris flows on channels and valley floors in the Oregon coast range, USA: Earth Surface Processes and Landforms, v. 15, p. 457-466.
- Benda, L., and Dunne, T., 1987, Sediment routing by debris flows, in Beschta, R. L., Blinn, R., Grant, G. E., Lee, G., and Swanson, F. J., eds., Erosion and sedimentation in the Pacific rim: International Association of Hydrological Sciences Publication 165, p. 213-223.
- Beschta, R. L., 1979, Debris removal and its effects on sedimentation in an Oregon Coast Range stream: Northwest Science, v. 53, p. 71-77.
- Beschta, R. L., 1983, Channel changes following storm-induced hillslope erosion in the upper Kowai basin, Torlesse Range, New Zealand: New Zealand Journal of Hydrology, v. 22, p. 93-111.
- Bilby, R. E., and Ward, J. W., 1989, Changes in characteristics and function of woody debris with increasing size of streams in western Washington: Transactions of the American Fisheries Society, v. 118, p. 368-378.
- Bisson, P. A., Nielsen, J. L., Palmason, R. A., and Grove, L. E., 1982, A system of naming habitat types in small streams, with examples of habitat utilization by salmonids during low streamflow, in Armantrout, N. B., ed., Proceedings of a Symposium on Acquisition and Utilization of Aquatic Habitat Inventory Information: Portland, Oregon, Western Division of the American Fisheries Society, p. 62-73.
- Bowman, D., 1977, Stepped-bed morphology in arid gravelly channels: Geological Society of America Bulletin, v. 88, p. 291-298.
- Bryant, M. D., 1980, Evolution of large, organic debris after timber harvest: Maybeso Creek, 1949 to 1978: Portland, Oregon, Pacific Northwest Forest and Range Experiment Station, U.S. Department of Agriculture, Forest Service General Technical Report PNW-101, 30 p.
- Buffington, J. M., 1995, Effects of hydraulic roughness and sediment supply on surface textures of gravel-bedded rivers [master's thesis]: Seattle, University of Washington, 184 p.
- Buffington, J. M., Dietrich, W. E., and Kirchner, J. W., 1992, Friction angle measurements on a naturally formed gravel streambed: Implications for critical boundary shear stress: Water Resources Research, v. 28, p. 411-425.
- Carling, P., 1988, The concept of dominant discharge applied to two gravel-bed streams in relation to channel stability thresholds: Earth Surface Processes and Landforms, v. 13, p. 355-367.
- Chin, A., 1989, Step pools in stream channels: Progress in Physical Geography, v. 13, p. 391-407.
- Church, M., 1992, Channel morphology and typology, in Carlow, P., and Petts, G. E., eds., The rivers handbook: Oxford, United Kingdom, Blackwell Scientific Publications, p. 126-143.
- Church, M., and Jones, D., 1982, Channel bars in gravel-bed rivers, in Hey, R. D., Bathurst, J. D., and Thorne, C. R., eds., Gravel-bed rivers: Fluvial processes, engineering and management: Chichester, United Kingdom, John Wiley and Sons, p. 291-338.

- Coats, R., Collins, L., Florsheim, J., and Kaufman, D., 1985, Channel change, sediment transport, and fish habitat in a coastal stream: Effects of an extreme event: *Environmental Management*, v. 9, p. 35-48.
- Dana, J. D., 1850, On denudation in the Pacific: *American Journal of Science*, ser. 2, v. 9, p. 48-62.
- Dietrich, W. E., and Dunne, T., 1978, Sediment budget for a small catchment in mountainous terrain: *Zeitschrift für Geomorphologie*, Supplementband 29, p. 191-206.
- Dietrich, W. E., and Smith, J. D., 1983, Influence of the point bar on flow through curved channels: *Water Resources Research*, v. 19, p. 1173-1192.
- Dietrich, W. E., and Whiting, P., 1989, Boundary shear stress and sediment transport in river meanders of sand and gravel, in Ikeda, S., and Parker, G., eds., *River meandering: American Geophysical Union Water Resources Monograph 12*, p. 1-50.
- Dietrich, W. E., Dunne, T., Humphrey, N., and Reid, L., 1982, Construction of sediment budgets for drainage basins, in Swanson, F. J., Janda, R. J., Dunne, T., and Swanson, D. N., eds., *Sediment budgets and routing in forested drainage basins: Portland, Oregon, Pacific Northwest Forest and Range Experiment Station, U.S. Department of Agriculture, Forest Service, General Technical Report PNW-141*, p. 2-23.
- Dietrich, W. E., Kirchner, J. W., Ikeda, H., and Iseya, F., 1989, Sediment supply and the development of the coarse surface layer in gravel-bedded rivers: *Nature*, v. 340, p. 215-217.
- Dinehart, R. L., 1992, Evolution of coarse-gravel bedforms: Field measurements at flood stage: *Water Resources Research*, v. 28, p. 2667-2689.
- Emmett, W. W., 1984, Measurement of bedload in rivers, in Hadley, R. F., and Walling, D. E., eds., *Erosion and sediment yield: Some methods of measurement and modeling: Norwich, United Kingdom, GeoBooks*, p. 91-109.
- Ergenzinger, P., and Schmidt, K.-H., 1990, Stochastic elements of bed load transport in a step-pool mountain river, in Sinniger, R. O., and Monbaron, M., eds., *Hydrology in mountainous regions. II—Artificial reservoirs, water and slopes: International Association of Hydrological Sciences Publication 194*, p. 39-46.
- Fenton, J. D., and Abbott, J. E., 1977, Initial movement of grains in a stream bed: The effects of relative protrusion: *Proceedings of the Royal Society of London*, v. 352A, p. 532-537.
- Florsheim, J. L., 1985, Fluvial requirements for gravel bar formation in northwestern California [master's thesis]: Arcata, California, Humboldt State University, 105 p.
- Frissell, C. A., 1993, Topology of extinction and endangerment of native fishes in the Pacific Northwest and California (U.S.A.): *Conservation Biology*, v. 7, p. 342-354.
- Frissell, C. A., Liss, W. J., Warren, C. E., and Hurley, M. D., 1986, A hierarchical framework for stream habitat classification: Viewing streams in a watershed context: *Environmental Management*, v. 10, p. 199-214.
- Gilbert, G. K., 1914, The transportation of débris by running water: U.S. Geological Survey Professional Paper 86, 263 p.
- Gilbert, G. K., 1917, Hydraulic-mining débris in the Sierra Nevada: U.S. Geological Survey Professional Paper 105, 154 p.
- Graf, W. L., 1975, The impact of suburbanization on fluvial geomorphology: *Water Resources Research*, v. 11, p. 690-692.
- Grant, G. E., and Mizuyama, T., 1991, Origin of step-pool sequences in high gradient streams: A flume experiment, in *Proceedings of the Japan-U.S. workshop on snow avalanche: Landslide, debris flow prediction and control: Tsukuba, Japan, Organizing Committee of the Japan-U.S. Workshop on Snow Avalanche, Landslide, Debris Flow Prediction and Control*, p. 523-532.
- Grant, G. E., Swanson, F. J., and Wolman, M. G., 1990, Pattern and origin of stepped-bed morphology in high-gradient streams, Western Cascades, Oregon: *Geological Society of America Bulletin*, v. 102, p. 340-352.
- Griffiths, G. A., 1980, Stochastic estimation of bed load yield in pool-and-riffle mountain streams: *Water Resources Research*, v. 16, p. 931-937.
- Griffiths, G. A., 1989, Form resistance in gravel channels with mobile beds: *Journal of Hydraulic Engineering*, v. 115, p. 340-355.
- Hammer, T. R., 1972, Stream channel enlargement due to urbanization: *Water Resources Research*, v. 8, p. 1530-1540.
- Hammond, F. D. C., Heathcote, A. D., and Langhorne, D. N., 1984, A comparison between Shields' threshold criterion and the movement of loosely packed gravel in a tidal channel: *Sedimentology*, v. 31, p. 51-62.
- Harms, J. C., Southard, J. B., Spearing, D. R., and Walker, R. G., 1975, Depositional environments as interpreted from primary sedimentary structures and stratification sequences: *Society for Economic Paleontologists and Mineralogists Short Course 2*, 161 p.
- Heede, B. H., 1985, Channel adjustments to the removal of log steps: An experiment in a mountain stream: *Environmental Management*, v. 9, p. 427-432.
- Henderson, F. M., 1963, Stability of alluvial channels: *Transactions of the American Society of Civil Engineers*, v. 128, p. 657-686.
- Howard, A. D., and Kerby, G., 1983, Channel changes in badlands: *Geological Society of America Bulletin*, v. 94, p. 739-752.
- Howard, A. D., Dietrich, W. E., and Seidl, M. A., 1994, Modeling fluvial erosion on regional to continental scales: *Journal of Geophysical Research*, v. 99, p. 13971-13986.
- Ikeda, H., 1975, On the bed configuration in alluvial channels: Their types and condition of formation with reference to bars: *Geographical Review of Japan*, v. 48, p. 712-730.
- Ikeda, H., 1977, On the origin of bars in the meandering channels: *Bulletin of the Environmental Research Center, University of Tsukuba*, v. 1, p. 17-31.
- Jackson, W. L., and Beschta, R. L., 1982, A model of two-phase bedload transport in an Oregon coast range stream: *Earth Surface Processes and Landforms*, v. 7, p. 517-527.
- Keller, E. A., and Melhorn, W. N., 1978, Rhythmic spacing and origin of pools and riffles: *Geological Society of America Bulletin*, v. 89, p. 723-730.
- Kelsey, H. M., 1980, A sediment budget and an analysis of geomorphic process in the Van Duzen River basin, north coastal California, 1941-1975: *Geological Society of America Bulletin*, v. 91, p. 1119-1216.
- Kennedy, J. F., 1975, Hydraulic relations for alluvial streams, in Vanoni, V., ed., *Sedimentation engineering: American Society of Civil Engineers Manual 54*, p. 114-154.
- Kirchner, J., Dietrich, W. E., Iseya, F., and Ikeda, H., 1990, The variability of critical boundary shear stress, friction angle, and grain protrusion in water-worked sediments: *Sedimentology*, v. 37, p. 647-672.
- Komar, P. D., and Li, Z., 1986, Pivoting analyses of the selective entrainment of sediments by size and shape with application to gravel threshold: *Sedimentology*, v. 33, p. 425-436.
- Kondolf, G. M., 1995, Geomorphological stream channel classification in aquatic habitat restoration: Uses and limitations: *Aquatic conservation: Marine and Freshwater Ecosystems*, v. 5, p. 127-141.
- Kondolf, G. M., Cada, G. F., Sale, M. J., and Felando, T., 1991, Distribution and stability of potential salmonid spawning gravels in steep boulder-bed streams of the eastern Sierra Nevada: *Transactions of the American Fisheries Society*, v. 120, p. 177-186.
- Lane, E. W., and Carlson, E. J., 1953, Some factors affecting the stability of canals constructed in coarse granular materials: *Proceedings of the Minnesota International Hydraulics Convention, International Association for Hydraulic Research and American Society of Civil Engineers*, p. 37-48.
- Langbein, W. B., and Leopold, L. B., 1968, River channel bars and dunes—Theory of kinematic waves: U.S. Geological Survey Professional Paper 422-L, 20 p.
- Lehre, A. K., 1982, Sediment budget of a small Coast Range drainage basin in north-central California, in Swanson, F. J., Janda, R. J., Dunne, T., and Swanson, D. N., eds., *Sediment budgets and routing in forested drainage basins: Portland, Oregon, Pacific Northwest Forest and Range Experiment Station, U.S. Department of Agriculture, Forest Service General Technical Report PNW-141*, p. 67-77.
- Leopold, L. B., Wolman, M. G., and Miller, J. P., 1964, *Fluvial processes in geomorphology*: San Francisco, California, W. H. Freeman, 522 p.
- Lindley, E. S., 1919, Régime channels: *Proceedings of the Punjab Engineering Congress*, v. 7, p. 63-74.
- Lisle, T. E., 1986, Stabilization of a gravel channel by large streamside obstructions and bedrock bends, Jacoby Creek, northwestern California: *Geological Society of America Bulletin*, v. 97, p. 999-1011.
- Lisle, T. E., Ikeda, H., and Iseya, F., 1991, Formation of stationary alternate bars in a steep channel with mixed-size sediment: A flume experiment: *Earth Surface Processes and Landforms*, v. 16, p. 463-469.
- Madej, M. A., 1982, Sediment transport and channel changes in an aggrading stream in the Puget Lowland, Washington, in Swanson, F. J., Janda, R. J., Dunne, T., and Swanson, D. N., eds., *Sediment budgets and routing in forested drainage basins: Portland, Oregon, Pacific Northwest Forest and Range Experiment Station, U.S. Department of Agriculture, Forest Service General Technical Report PNW-141*, p. 97-108.
- Marcus, W. A., Roberts, K., Harvey, L., and Tackman, G., 1992, An evaluation of methods for estimating Manning's *n* in small mountain streams: *Mountain Research and Development*, v. 12, p. 227-239.
- McDonald, B. C., and Banerjee, I., 1971, Sediments and bed forms on a braided outwash plain: *Canadian Journal of Earth Sciences*, v. 8, p. 1282-1301.
- Megahan, W., Platts, W. S., and Kulesza, B., 1980, Riverbed improves through time: South Fork Salmon River, in *Symposium on watershed management*: New York, American Society of Civil Engineers, p. 380-395.
- Middleton, G. V., and Southard, J. B., 1984, *Mechanics of sediment movement: Society of Economic Paleontologists and Mineralogists Short Course 3*, 401 p.
- Milhous, R. T., 1973, Sediment transport in a gravel-bottom stream [Ph.D. dissert.]: Corvallis, Oregon State University, 232 p.
- Milliman, J. D., and Syvitski, J. P. M., 1992, Geomorphic/tectonic control of sediment discharge to the ocean: The importance of small mountainous rivers: *Journal of Geology*, v. 100, p. 525-544.
- Mollard, J. D., 1973, Air photo interpretation of fluvial features: Edmonton, Canada, *Proceedings of the 9th Canadian Hydrology Symposium*, p. 341-380.
- Montgomery, D. R., 1991, Channel initiation and landscape evolution [Ph.D. dissert.]: Berkeley, University of California, 421 p.
- Montgomery, D. R., and Buffington, J. M., 1993, Channel classification, prediction of channel response, and assessment of channel condition: Olympia, Washington State Department of Natural Resources Report TFW-SH10-93-002, 84 p.
- Montgomery, D. R., and Foufoula-Georgiou, E., 1993, Channel network source representation using digital elevation models: *Water Resources Research*, v. 29, p. 3925-3934.
- Montgomery, D. R., Buffington, J. M., Smith, R. D., Schmidt, K. M., and Pess, G., 1995, Pool spacing in forest channels: *Water Resources Research*, v. 31, p. 1097-1105.
- Montgomery, D. R., Abbe, T. B., Buffington, J. M., Peterson, N. P., Schmidt, K. M., and Stock, J. D., 1996, Distribution of bedrock and alluvial channels in forested mountain drainage basins: *Nature*, v. 381, p. 587-589.
- Murphy, M. L., and Koski, K. V., 1989, Input and depletion of woody debris in Alaska streams and implications for streamside management: *North American Journal of Fisheries Management*, v. 9, p. 427-436.
- Nanson, G. C., 1974, Bedload and suspended-load transport in a small, steep, mountain stream: *American Journal of Science*, v. 274, p. 471-486.
- Nehlsen, W., Williams, J. E., and Lichatowich, J. A., 1991, Pacific salmon at the crossroads: Stocks at risk from California, Oregon, Idaho, and Washington: *Fisheries*, v. 16, p. 4-21.
- Nelson, J. M., and Smith, J. D., 1989, Evolution and stability of erodible channel beds, in Ikeda, S., and Parker, G., eds., *River meandering: American Geophysical Union Water Resources Monograph 12*, p. 321-377.
- O'Neill, M. P., and Abrahams, A. D., 1984, Objective identification of pools and riffles: *Water Resources Research*, v. 20, p. 921-926.
- Parker, G., Klingeman, P. C., and McLean, D. G., 1982, Bedload size and distribution in paved gravel-bed streams: *Journal of the Hydraulics Division, American Society of Civil Engineers*, v. 108, p. 544-571.

- Paustian, S. J., and 13 others. 1992. A channel type users guide for the Tongass National Forest, Southeast Alaska: U.S. Department of Agriculture Forest Service, Alaska Region R10 Technical Paper 26, 179 p.
- Peterson, D. F., and Mohanty, P. K., 1960, Flume studies of flow in steep, rough channels: *Journal of the Hydraulics Division, American Society of Civil Engineers*, v. 86, p. 55-76.
- Pitlick, J., 1992, Flow resistance under conditions of intense gravel transport: *Water Resources Research*, v. 28, p. 891-903.
- Reid, I., Frostick, L. E., and Layman, J. T., 1985, The incidence and nature of bedload transport during flood flows in coarse-grained alluvial channels: *Earth Surface Processes and Landforms*, v. 10, p. 33-44.
- Reid, L., 1982, Evaluating and mapping sources and temporary storage areas of sediment, in *Sediment budgets and routing in forested drainage basins*: Portland, Oregon, Pacific Northwest Forest and Range Experiment Station, U.S. Department of Agriculture, Forest Service General Technical Report PNW-141, p. 138-142.
- Reid, L. M., 1993, Research and cumulative watershed effects, Berkeley, California, Pacific Southwest Research Station: U.S. Department of Agriculture, Forest Service General Technical Report PSW-GTR-141, 118 p.
- Rice, S., 1994, Towards a model of changes in bed material texture at the drainage basin scale, in Kirkby, M. J., ed., *Process models and theoretical geomorphology*: Chichester, United Kingdom, Wiley and Sons, p. 158-172.
- Rosgen, D. L., 1994, A classification of natural rivers: *Catena*, v. 22, p. 169-199.
- Sawada, T., Ashida, K., and Takahashi, T., 1983, Relationship between channel pattern and sediment transport in a steep gravel bed river: *Zeitschrift für Geomorphologie, Supplementband 46*, p. 55-66.
- Schmidt, K.-H., and Ergenzinger, P., 1992, Bedload entrainment, travel lengths, step lengths, rest periods—Studied with passive (iron, magnetic) and active (radio) tracer techniques: *Earth Surface Processes and Landforms*, v. 17, p. 147-165.
- Schumm, S. A., 1977, *The fluvial system*: New York, John Wiley and Sons, 338 p.
- Seidl, M., and Dietrich, W. E., 1992, The problem of channel incision into bedrock, in Schmidt, K.-H., and de Ploey, J., eds., *Functional geomorphology*, Catena Supplement 23: Cremlingen, Germany, Catena Verlag, p. 101-124.
- Shaler, N. S., 1891, The origin and nature of soils: U.S. Geological Survey 12th Annual Report, p. 213-345.
- Shaw, J., and Kellerhals, R., 1977, Paleohydraulic interpretations of antidune bedforms with applications to antidunes in gravel: *Journal of Sedimentary Petrology*, v. 47, p. 257-266.
- Sidle, R. C., 1988, Bed load transport regime of a small forest stream: *Water Resources Research*, v. 24, p. 207-218.
- Simons, D. B., Richardson, E. V., and Nordin, C. F., 1965, Sedimentary structures generated by flow in alluvial channels, in Middleton, G. V., ed., *Primary sedimentary structures and their hydrodynamic interpretation*: Tulsa, Oklahoma, Society of Economic Paleontologists and Mineralogists, p. 34-52.
- Smith, D. G., 1976, Effect of vegetation on lateral migration of anastomosed channels of a glacier meltwater river: *Geological Society of America Bulletin*, v. 87, p. 857-860.
- Sukegawa, N., 1973, Condition for the formation of alternate bars in straight alluvial channels, in *Proceedings of the international symposium on river mechanics*: Bangkok, Thailand, International Association for Hydraulic Research, A58-1-A58-11.
- Surell, A., 1841, *Étude sur les torrents des Hautes-Alpes*: Paris, France.
- Swanson, F. J., Fredriksen, R. L., and McCorison, F. M., 1982, Material transfer in a western Oregon forested watershed, in Edmonds, R. L., ed., *Analysis of coniferous forest ecosystems in the western United States*: Stroudsburg, Pennsylvania, Hutchinson Ross Publishing, p. 233-266.
- Warburton, J., 1992, Observations of bed load transport and channel bed changes in a proglacial mountain stream: *Arctic and Alpine Research*, v. 24, p. 195-203.
- Whiting, P. J., and Bradley, J. B., 1993, A process-based classification for headwater streams: *Earth Surface Processes and Landforms*, v. 18, p. 603-612.
- Whiting, P. J., Dietrich, W. E., Leopold, L. B., Drake, T. G., and Shreve, R. L., 1988, Bedload sheets in heterogeneous sediment: *Geology*, v. 16, p. 105-108.
- Whittaker, J. G., 1987a, Modeling bed-load transport in steep mountain streams, in Beschta, R. L., Blinn, T., Grant, G. E., Ice, G. G., and Swanson, F. J., eds., *Erosion and sedimentation in the Pacific rim*: International Association of Hydrological Sciences Publication 165, p. 319-332.
- Whittaker, J. G., 1987b, Sediment transport in step-pool streams, in Thorne, C. R., Bathurst, J. C., and Hey, R. D., eds., *Sediment transport in gravel-bed rivers*: Chichester, United Kingdom, John Wiley and Sons, p. 545-579.
- Whittaker, J. G., and Davies, T. R. H., 1982, Erosion and sediment transport processes in step-pool torrents in Walling, D. E., ed., *Recent developments in the explanation and prediction of erosion and sediment yield*: International Association of Hydrological Sciences Publication 137, p. 99-104.
- Whittaker, J. G., and Jaeggi, M. N. R., 1982, Origin of step-pool systems in mountain streams: *Journal of the Hydraulics Division: Proceedings of the American Society of Civil Engineers*, v. 108, p. 99-104.
- Wolman, M. G., 1954, A method of sampling coarse bed material: *Transactions, American Geophysical Union*, v. 35, p. 951-956.
- Wood-Smith, R. D., and Buffington, J. M., 1996, Multivariate geomorphic analysis of forest streams: Implications for assessment of land use impact on channel condition: *Earth Surface Processes and Landforms*, v. 21, p. 377-393.

MANUSCRIPT RECEIVED BY THE SOCIETY JULY 20, 1995

REVISED MANUSCRIPT RECEIVED AUGUST 12, 1996

MANUSCRIPT ACCEPTED OCTOBER 3, 1996

FIELD PROTOCOLS FOR REACH SLOPE

Lazorchak, J.M., Hill, B.H., Averill, D.K., D.V. Peck, and D.J. Klemm (editors). 2000. Environmental Monitoring and Assessment Program -Surface Waters: Field Operations and Methods for Measuring the Ecological Condition of Non-Wadeable Rivers and Streams U.S. Environmental Protection Agency, Cincinnati OH.

Lazorchak, J.M., Klemm, D.J., and D.V. Peck (editors). 1998. Environmental Monitoring and Assessment Program -Surface Waters: Field Operations and Methods for Measuring the Ecological Condition of Wadeable Streams. EPA/620/R-94/004F. U.S. Environmental Protection Agency, Washington, D.C.




Figure 7-3. Large woody debris influence zones (modified from Robison and Beschta, 1990)

four diameter class combinations. Each LWD piece is tallied in only one box. There are 12 size classes for wood at least partially in Zones 1 and 2, and 12 for wood partially within Zone 3. Wood that is not at least partially within those zones is not tallied.

7.5 CHANNEL AND RIPARIAN MEASUREMENTS AT CROSS-SECTION TRANSECTS

7.5.1 Slope and Bearing


The slope, or gradient, of the stream reach is useful in three different ways. First, the overall stream gradient is one of the major stream classification variables, giving an indication of potential water velocities and stream power, which are in turn important con-

trols on aquatic habitat and sediment transport within the reach. Second, the spatial variability of stream gradient is a measure of habitat complexity, as reflected in the diversity of water velocities and sediment sizes within the stream reach. Lastly, using methods described by Stack (1989) and Robison and Kaufmann (1994), the water surface slope will allow us to compute residual pool depths and volumes from the multiple depth and width measurements taken in the thalweg profile (Section 7.4.1). Compass bearings between cross section stations, along with the distance between stations, will allow us to estimate the sinuosity of the channel (ratio of the length of the reach divided by the straight line distance between the two reach ends).

Measure slope and bearing by "backsiting" downstream between transects (e.g., transect "B" to "A", "C" to "B", etc.) as shown in Figure 7-4. To measure the slope and bearing between adjacent stations, use a clinometer, bearing compass, tripod, tripod extension, and flagging, following the procedure presented in Table 7-5. Record slope and bearing data on the Slope and Bearing Form as shown in Figure 7-5.

Slope can also be measured by two people, each having a pole that is marked at the same height. Alternatively, the second person can be "flagged" at the eye level of the person doing the backsiting. Be sure that you mark your eye level on the other person or on a separate pole beforehand while standing on level ground. Site to **your eye level** when backsiting on your co-worker. If two marked poles are used, site from the mark on one pole to the mark on the other. Also, be sure that the second person is standing (or holding the marked pole) at the water's edge or in the same depth of water as you are. The intent is to get a measure of the **water surface slope**, which may not necessarily be the same as the bottom slope. The clinometer reads both percent slope and degrees of the slope angle; be careful to read and record percent slope. Percent slope is the scale on the right-hand side as you look through most clinometers. If using an Abney Level, insure that you are reading the scale marked "PERCENT." With the clinometer or the Abney level, verify this by comparing the two scales. Percent slope is always a higher number than degrees of slope angle (e.g., 100% slope=45° angle). For slopes > 2%, read the clinometer to the nearest 0.5%. For slopes < 2%, read to the nearest 0.25%. If the clinometer reading is 0%, but water is moving, record the slope as 0.1%. If the clinometer reading is 0% and water is not moving, record the slope as 0%.

Slope (gradient) Measurement



Bearing Measurement Between Transects




Figure 7-4. Channel slope and bearing measurements.

TABLE 7-5. PROCEDURE FOR OBTAINING SLOPE AND BEARING DATA

1. Stand in the center of the channel at the downstream cross-section transect. Determine if you can see the center of the channel at the next cross-section transect upstream. If not, you will have to take supplementary slope and bearing measurements.
2. Set up the tripod in shallow water or at the water's edge at the downstream cross-section transect (or at a supplemental point). Standing tall in a position with your feet as near as possible to the water surface elevation, set the tripod extension and mark it with a piece of flagging at your eye level. Remember the depth of water in which you are standing when you adjust the flagging to eye level.
 - On gradually sloped streams, it is advisable to use two people, each holding a pole marked with flagging at the same height on both poles.
3. Walk upstream to the next cross-section transect. Find a place to stand at the upstream transect (or at a supplemental point) that is at the same depth as where you stood at the downstream transect when you set up the eye-level flagging.
 - If you have determined in Step 1 that supplemental measurements are required for this segment, walk upstream to the furthest point where you can still see the center of the channel at the downstream cross-section transect from the center of the channel. Mark this location with a different color flagging than that used to mark the cross-section transects.
4. With the clinometer, site back downstream on your flagging at the downstream transect (or at the supplementary point). Read and record the **percent** slope in the "MAIN" section on the Slope and Bearing Form. Record the "PROPORTION" as 100%.
 - If two people are involved, place the base of each pole at the water level (or at the same depth at each transect). Then site with the clinometer (or Abney level) from the flagged height on upstream pole to the flagged height on the downstream pole.
 - If you are backsiting from a supplemental point, record the slope (%) and proportion (%) of the stream segment that is included in the measurement in the appropriate "SUPPLEMENTAL" section of the Slope and Bearing Form.
5. Stand in the middle of the channel at upstream transect (or at a supplemental point), and site back with your compass to the middle of the channel at the downstream transect (or at a supplemental point). Record the bearing (degrees) in the "MAIN" section of the Slope and Bearing Form.
 - If you are backsiting from a supplemental point, record the bearing in the appropriate "SUPPLEMENTAL" section of the Slope and Bearing Form.
6. Retrieve the tripod from the downstream cross section station (or from the supplemental point) and set it up at the next upstream transect (or at a supplemental point) as described in Step 2.
7. When you get to each new cross-section transect (or to a supplementary point), backsit on the previous transect (or the supplementary point), repeat Steps 2 through 6 above.

FIELD PROTOCOLS FOR BANK MODIFICATIONS

Lazorchak, J.M., Hill, B.H., Averill, D.K., D.V. Peck, and D.J. Klemm (editors). 2000. Environmental Monitoring and Assessment Program -Surface Waters: Field Operations and Methods for Measuring the Ecological Condition of Non-Wadeable Rivers and Streams U.S. Environmental Protection Agency, Cincinnati OH.

Lazorchak, J.M., Klemm, D.J., and D.V. Peck (editors). 1998. Environmental Monitoring and Assessment Program -Surface Waters: Field Operations and Methods for Measuring the Ecological Condition of Wadeable Streams. EPA/620/R-94/004F. U.S. Environmental Protection Agency, Washington, D.C.

The procedure to estimate the types and amounts of fish cover is outlined in Table 6-10. Data are recorded in the "Fish Cover/Other" section of the Channel/Riparian Transect Form as shown in Figure 6-5. Crews will estimate the areal cover of all of the fish cover and other listed features that are in the water and on the banks within the 10m x 20m plot (refer to Figure 6-2).

Observations to assess fish cover and several other in-channel features apply to a 10 m x 20 m inundated area adjacent to the selected bank extending 10 m out from the channel margin, and then upstream 10 m and downstream 10 m from each of the 11 transect cross-sections (Figure 6-2). These plot dimensions are estimated by eye. The ranges of percentage areal cover corresponding to each of these codes are the same as for riparian vegetation cover (Section 6.6.6) and are also shown on the Field Form.

Table 6-10. Procedure For Estimating Fish Cover.

1. Stop at the designated shoreline at a cross-section transect and estimate a 10m distance upstream and downstream (20m total length), and a 10m distance out from the banks to define a 20m x 10m littoral plot.
2. Examine the water and the banks within the 20m x 10m littoral plot for the following features and types of fish cover: filamentous algae, aquatic macrophytes, large woody debris, brush and small woody debris, overhanging vegetation, undercut banks, boulders, and artificial structures.
3. For each cover type, estimate its areal cover by eye and/or by sounding with a pole. Record the appropriate cover class in the "Fish Cover/Other" section of the Channel/Riparian Transect Form ("0"=absent: zero cover, "1"=sparse: <10%, "2"=moderate: 10-40%, "3"=heavy: 40-75%, or "4"=very heavy: >75%).
4. Repeat Steps 1 through 3 at each cross-section transect, recording data from each transect on a separate field data form.

Filamentous algae pertains to long streaming algae that often occur in slow moving waters. Aquatic macrophytes are water loving plants in the river, including mosses, that could provide cover for fish or macroinvertebrates. If the river channel contains live wetland grasses, include these as macrophytes. Woody debris includes the larger pieces of wood that can provide cover and influence river morphology (i.e., those pieces that would be included in the large woody debris tally [Section 6.6.3]). Brush/woody debris pertains to the smaller wood that primarily affects cover but not morphology. The entry for trees or brush within one meter above the water surface is the amount of brush, twigs, small debris etc. that is not in the water but is close to the river and provides cover. Boulders are typically basketball to car sized particles. Many streams contain artificial structures designed for fish habitat enhancement. Streams may also have in-channel structures discarded (e.g. cars or tires) or purposefully placed for diversion, impoundment, channel stabilization, or other purposes. Record the cover of these structures on the form.

6.6.8 Human Influences

Field characterization of the presence and proximity of various important types of human activities, disturbances, and land use in the river riparian area is adapted from methods developed by Kaufmann and Robison (1998) for wadeable streams. This information shall be used in combination with riparian and watershed landuse information from aerial photos and satellite imagery to assess the potential degree of disturbance of the sample river reaches.

For the left and right banks at each of the 11 detailed Channel/Riparian Cross-Sec-

tions, evaluate the presence/absence and the proximity of 11 categories of human influences outlined in Table 6-11. Confine your observations to the river and riparian area within 10m upstream and 10m downstream from the cross-section transect (Figure 6-2). Four proximity classes are used: On the riverbank within 10m upriver or downriver of the cross-section transect, present within the 10m x 20m riparian plot, present outside of the riparian plot, and not present. Record human influences on the Channel/Riparian Transect Form (Figure 6-5).

You may mark "P" more than once for the same human influence observed outside of more than one riparian observation plot (e.g. at both Transect D and E). The rule is that you count human disturbance items as often as you see them, BUT NOT IF you have to site through a previously counted transect or its 10x20m riparian plot.

6.7 Summary of Workflow

Table 6-12 lists the activities performed at and between each transect for the physical habitat characterization. The activities are performed along the chosen river bank and mid-channel (thalweg profile).

6.8 Equipment and Supplies

Figure 6-8 lists the equipment and supplies required to conduct all the activities described for characterizing physical habitat. This checklist is similar to the checklist presented in Appendix A, which is used at the base location (Section 3) to ensure that all of the required equipment is brought to the river. Use this checklist to ensure that equipment and supplies are organized and available at

Table 6-11. Procedure for Estimating Human Influence.

1. Stop at the designated shoreline at a cross-section transect, look toward the left bank (left when facing downstream), and estimate a 10m distance upstream and downstream (20m total length). Also, estimate a distance of 10m back into the riparian zone to define a riparian plot area.
2. Examine the channel, bank and riparian plot area adjacent to the defined river segment for the following human influences: (1) walls, dikes, revetments, riprap, and dams; (2) buildings; (3) pavement (e.g., parking lot, foundation); (4) roads or railroads, (5) inlet or outlet pipes; (6) landfills or trash (e.g., cans, bottles, trash heaps); (7) parks or maintained lawns; (8) row crops; (9) pastures, rangeland, or hay fields; (10) logging; and (11) mining (including gravel mining).
3. For each type of influence, determine if it is present and what its proximity is to the river and riparian plot area. Consider human disturbance items as present if you can see them from the cross-section transect. Do not include them if you have to site through another transect or its 10m x 20m riparian plot.
4. For each type of influence, record the appropriate proximity class in the "Human Influence" part of the "Visual Riparian Estimates" section of the Channel/Riparian Transect Form. Proximity classes are:
 - B ("Bank") Present within the defined 20m river segment and located in the stream or on the wetted or bankfull bank.
 - C ("Close") Present within the 10 x 20m riparian plot area, but above the bankfull level.
 - P ("Present") Present, but observed outside the riparian plot area.
 - O ("Absent") Not present within or adjacent to the 20m river segment or the riparian plot area at the transect
5. Repeat Steps 1 through 4 for the opposite bank.
6. Repeat Steps 1 through 5 for each cross-section transect, recording data for each transect on a separate field form.

Table 6-12. Summary of Workflow - River Physical Habitat Characterization.

A. At the chosen bank on first transect (farthest upstream):

1. Move boat in a "loop" within 10 x 20 meter littoral plot, measuring five littoral depths and probing substrate.
2. Estimate dominant and subdominant littoral substrate, based on probing the five locations.
3. Estimate areal cover of fish concealment features in 10 x 20 meter littoral plot.
4. Tally LWD within or partially within the 10 x 20 meter littoral plot.
5. Measure water conductivity and temperature.
6. Do densiometer measurements at bank (facing upstream, downstream, left, right).
7. Choose bank angle class, estimate bankfull height, width and channel incision. (Note that width and incision estimates incorporate both left and right banks.).
8. Tally LWD entirely out of water but at least partially within the bankfull channel.
9. Estimate and record distance to riparian vegetation on the chosen bank.
10. Make visual riparian vegetation cover estimates for the 10 x 20 meter riparian plot on both sides of the channel. (Note that riparian plot starts at bankfull and continues back 10m away from the bankfull line).
11. Identify species, height, Dbh, and distance from riverbank of largest riparian tree within your vision.
12. Make visual human disturbance tally. It has the same plot dimensions as the riparian vegetation -- except if a disturbance item is observed in the river or within the bankfull channel, then the proximity code is "B", the closest rating. Disturbances within the plot get a rating of "C"; those visible beyond the plot are rated "P".
13. Siting clinometer level (0%) towards the near or far bank at the current transect, mark or remember an eye-level point to which you will be siting when backsiting from the next downstream transect.
14. Get out far enough from the bank so you can see downstream. Then use the laser rangefinder to site and record the distance to the intended position of the next downstream transect.

B. Thalweg Profile:

1. As soon as you get out from the bank after doing transect activities, take the first of 20 thalweg depth measurements and substrate/snag probes using sonar and pole -- also classify habitat type.
2. Estimate thalweg measurement distance increments by keeping track of boat lengths or channel-width distances traversed; each increment is 1/10th (or 1/20th) the distance between transects.
3. At the 20th thalweg measurement location, you are one increment upstream of the next transect. Backsite compass bearing mid-channel, then measure the distance and % slope back to your visual "mark" on the bank at the previous transect.

C. Repeat the Whole Process (for the remaining 10 transects and spaces in between).

the river site in order to conduct the activities efficiently.

6.9 Literature Cited

- | | |
|---|--|
| <p>Allen-Gil, S., M. Green, and D. H. Landers. Unpublished manuscript. Fish abundance, instream habitat and the effects of historical landuse practices in two large alluvial rivers on the Olympic Peninsula, Washington. U.S. EPA, WED.</p> | <p>Bain, M.B., J.T. Finn, and H.E. Booke. 1985. Quantifying stream substrate for habitat analysis studies. Nor. Amer. Jour. of Fish. Man. 5:499-500.</p> <p>Frissell, C.A., W.J. Liss, C.E. Warren, and M.D. Hurley. 1986. A hierarchical framework for stream habitat classification: viewing streams in a watershed context. Environ. Mgmt. 10(2):199-214.</p> |
|---|--|

7.5.7 Human Influence

The field evaluation of the presence and proximity of various important types of human land use activities in the stream riparian area is used in combination with mapped watershed land use information to assess the potential degree of disturbance of the sample stream reaches.

For the left and right banks at each of the 11 detailed Channel and Riparian Cross-Sections, evaluate the presence/absence and the proximity of 11 categories of human influences with the procedure outlined in Table 7-11. Relate your observations and proximity evaluations to the stream and riparian area within 5 m upstream and 5 m downstream from the station (Figure 7-10). Four proximity classes are used: In the stream or on the bank within 5 m upstream or downstream of the cross-section transect, present within the 10 m × 10 m riparian plot but not in the stream or on the bank, present outside of the riparian plot, and absent. Record data on the Channel/Riparian Cross-section and Thalweg Profile Form as shown in Figure 7-6. If a disturbance is within more than one proximity class, record the one that is closest to the stream (e.g., “C” takes precedence over “P”).

A particular influence may be observed outside of more than one riparian observation plot (e.g., at both transects “D” and “E”). Record it as present at every transect where you can see it without having to site through another transect or its 10 m × 10 m riparian plot.

7.6 EQUIPMENT AND SUPPLIES

Figure 7-11 lists the equipment and supplies required to conduct all the activities described for characterizing physical habitat. This checklist is similar to the checklist presented in Appendix A, which is used at the base location (Section 3) to ensure that all of the required equipment is brought to the stream. Use this checklist to ensure that equipment and supplies are organized and available at the stream site in order to conduct the activities efficiently.

TABLE 7-11. PROCEDURE FOR ESTIMATING HUMAN INFLUENCE

1. Standing mid-channel at a cross-section transect, look toward the left bank (left when facing downstream), and estimate a 5m distance upstream and downstream (10 m total length). Also, estimate a distance of 10 m back into the riparian zone to define a riparian plot area.
2. Examine the channel, bank and riparian plot area adjacent to the defined stream segment for the following human influences: (1) walls, dikes, revetments, riprap, and dams; (2) buildings; (3) pavement (e.g., parking lot, foundation); (4) roads or railroads, (5) inlet or outlet pipes; (6) landfills or trash (e.g., cans, bottles, trash heaps); (7) parks or maintained lawns; (8) row crops; (9) pastures, rangeland, or hay fields; (10) logging; and (11) mining (including gravel mining).
3. For each type of influence, determine if it is present and what its proximity is to the stream and riparian plot area. Consider human disturbance items as present if you can see them from the cross-section transect. Do not include them if you have to site through another transect or its 10 m × 10 m riparian plot.
4. For each type of influence, record the appropriate proximity class in the "HUMAN INFLUENCE" part of the "VISUAL RIPARIAN ESTIMATES" section of the Channel/Riparian Cross-section and Thalweg Profile Form. Proximity classes are:
 - B ("Bank") Present within the defined 10 m stream segment and located in the stream or on the stream bank.
 - C ("Close") Present within the 10 × 10 m riparian plot area, but away from the bank.
 - P ("Present") Present, but outside the riparian plot area.
 - O ("Absent") Not present within or adjacent to the 10 m stream segment or the riparian plot area at the transect
5. Repeat Steps 1 through 4 for the right bank.
6. Repeat Steps 1 through 5 for each cross-section transect, recording data for each transect on a separate field form.

FIELD PROTOCOLS FOR DENSITY OF HABITAT TYPES

Lazorchak, J.M., Hill, B.H., Averill, D.K., D.V. Peck, and D.J. Klemm (editors). 2000. Environmental Monitoring and Assessment Program -Surface Waters: Field Operations and Methods for Measuring the Ecological Condition of Non-Wadeable Rivers and Streams U.S. Environmental Protection Agency, Cincinnati OH.

Lazorchak, J.M., Klemm, D.J., and D.V. Peck (editors). 1998. Environmental Monitoring and Assessment Program -Surface Waters: Field Operations and Methods for Measuring the Ecological Condition of Wadeable Streams. EPA/620/R-94/004F. U.S. Environmental Protection Agency, Washington, D.C.

snags, and measure depth with the aid of sonar. The number of large snags hit by this rod shall be recorded as an index of fish cover complexity (modification of Bain's "snag drag"). While dragging the sounding rod along the bottom, the crew member shall record the dominant substrate type sensed by dragging the rod along the bottom (bedrock/hardpan, boulder, cobble, gravel, sand, silt & finer) (Figure 6-3). In shallow, "wild," fast-water situations, where pole-dragging might be hazardous, crews will estimate bottom conditions the best they can visually and by using paddles and oars. If unavoidable, suspend measurements until out of whitewater situations, but make notes and appropriately flag observations concerning your best judgements of depth and substrate.

6.5.3 Channel Habitat Classification

The crew will classify and record the channel habitat types shown in Figure 6-3 (fall, cascade, rapid, riffle, glide, pool, dry) and check presence of off-channel and backwater habitat at a spatial resolution of about 0.4 channel-widths on a 40 Channel-width reach. On a 100 Channel-width reach habitat classifications are made every 1.0 channel-widths and off-channel and backwater habitat presence is checked every 0.5 channel-width distance -- the same interval as thalweg depths. The resulting database of traditional visual habitat classifications will provide a bridge of common understanding with other studies. The procedures for classifying channel habitat are presented in Table 6-2. The designation of side channels, backwaters and other off-channel areas is independent of the main-channel habitat type. Main channel habitat units must meet a minimum size criteria in addition to the qualitative criteria listed

in Table 6-3. Before being considered large enough to be identified as a channel-unit scale habitat feature, the unit should be at least as long as the channel is wide. For instance, if there is a small, deep (pool-like) area at the thalweg within a large riffle area, don't record it as a pool unless it occupies an area about as wide or long as the channel is wide.

Mid-Channel Bars, Islands, and Side Channels pose some problems for the sampler conducting a thalweg profile and necessitate some guidance. Mid-channel bars are defined here as channel features below the bankfull flow level that are dry during baseflow conditions (see Section 6.6.4 for definition of bankfull channel). Islands are channel features that are dry even when the river is at bankfull flow. If a mid-channel feature is as high as the surrounding flood plain, it is considered an island. Both mid-channel bars and islands cause the river to split into side channels. When a bar or island is encountered along the thalweg profile, choose to navigate and survey the channel that carries the most flow.

When side channels are present, the comments column of the Thalweg Profile form should reflect their presence by checking the "Off-Channel" column. These checkmarks will begin at the point of divergence from the main channel, continuing downstream to the point of where the side channel converges with the main channel. In the case of a slough or alcove, the "off-channel" checkmarks should continue from the point of divergence.

6.6 Channel Margin ("Littoral") And Riparian Measurements

Components of this section include slope and bearing, channel margin depth and sub-

Table 6-2. Thalweg Profile Procedure.

1. Determine the interval between measurement stations based on the wetted width used to determine the length of the sampling reach.
2. Complete the header information on the Thalweg Profile Form, noting the transect pair (upstream to downstream).
3. Begin at the upstream transect (station "1" of "20" or station "1" of "10").

Thalweg Depth Profile

- a) While floating downstream along the thalweg, record depths at frequent, approximately even-spaced downstream intervals while observing a sonar display and holding a surveyor's rod off the side of the boat.
- b) A depth recording approximately every 0.4 (or 0.5) channel-width distance is required, yielding 10 (or 20) measurements between channel/riparian cross-section transects.
- c) If the depth is less than approximately 0.5 meters, or contains a lot of air bubbles, the sonar fathometer will not give reliable depth estimates. In this case, record depths using a calibrated measuring rod. In shallow, "wild," fast-water situations depths may have to be visually estimated to the nearest 0.5 meter.
- d) Measure depths to nearest 0.1 m and record in the "SONAR" or "POLE" column on the Thalweg Profile Form.

Pole Drag for Snags and Substrate Characteristics

- a) From the gunwale of the boat, hold a fiberglass surveying rod or calibrated PVC sounding tube down vertically into the water.
- b) Lightly drag the rod on the river bottom to "feel" the substrate and detect snags.
- c) Observations are taken at half the frequency as depth measurements (i.e., at every other depth measurement point on 100 Channel-Width reaches).
- d) Record the number of snags hit by the rod and the dominant substrate type sensed by dragging the rod along the bottom.
- e) On the Thalweg Profile Form, circle the appropriate "SUBSTRATE" type and tally the number of "SNAGS".

Channel Habitat Classification

- a) Classify and record the channel habitat type at increments of every 1.0 channel width.
 - b) Check for off-channel and backwater habitat at increments of every 0.4 (or 0.5) channel width.
 - c) If channel is split by a bar or island, navigate and survey the channel with the most discharge.
 - d) When a side channel is encountered, check the "OFF-CHANNEL" column beginning with the point of divergence from the main channel, continuing downriver until the side channel converges with the main channel.
 - e) On the Thalweg Profile Form, circle the appropriate "CHANNEL HABITAT" and check the off-channel column as described in (d) above.
4. Proceed downriver to the next station ("2"), and repeat the above procedures.
 5. Repeat the above procedures until you reach the next transect. Prepare a new Thalweg Profile Form, then repeat the above procedures for each of the reach segments, until you reach the downriver end of the sampling reach (Transect "K").

Table 6-3. Channel Unit Categories.

Channel Unit Habitat Classes ^a	
Class (Code)	Description
Pools (PO):	Still water, low velocity, smooth, glassy surface, usually deep compared to other parts of the channel:
Plunge Pool	Pool at base of plunging cascade or falls.
Trench Pool	Pool-like trench in the center of the stream
Lateral Scour Pool	Pool scoured along a bank.
Backwater Pool	Pool separated from main flow off the side of the channel.
Dam Pool	Pool formed by impoundment above dam or constriction.
Glide (GL)	Water moving slowly, with a smooth, unbroken surface. Low turbulence.
Riffle (RI)	Water moving, with small ripples, waves and eddies -- waves not breaking, surface tension not broken. Sound: "babbling", "gurgling".
Rapid (RA)	Water movement rapid and turbulent, surface with intermittent whitewater and breaking waves. Sound: continuous rushing, but not as loud as cascade.
Cascade (CA)	Water movement rapid and very turbulent over steep channel bottom. Most of the water surface is broken in short, irregular plunges, mostly whitewater. Sound: roaring.
Falls (FA)	Free falling water over a vertical or near vertical drop into plunge, water turbulent and white over high falls. Sound: from splash to roar.
Dry Channel (DR)	No water in the channel
Off-Channel Areas	Side-channels, sloughs, backwaters, and alcoves that are separated from the main channel.

^a Note that in order for a channel habitat unit to be distinguished, it must be at least as wide or long as the channel is wide.

strate, large woody debris, bank angle and channel cross-section morphology, canopy cover, riparian vegetation structure, fish cover, and human influences. All measurements are recorded on the two-sided Channel/Riparian Transect Form (Figures 6-4 and 6-5).

6.6.1 Slope and Bearing

The slope, or gradient, of the stream reach is useful in three different ways. First, the overall stream gradient is one of the ma-

TABLE 7-3. CHANNEL UNIT AND POOL FORMING ELEMENT CATEGORIES

Channel Unit Habitat Classes^a	
Class (Code)	Description
Pools:	Still water, low velocity, smooth, glassy surface, usually deep compared to other parts of the channel:
Plunge Pool (PP)	Pool at base of plunging cascade or falls.
Trench Pool (PT)	Pool-like trench in the center of the stream
Lateral Scour Pool (PL)	Pool scoured along a bank.
Backwater Pool (PB)	Pool separated from main flow off the side of the channel.
Impoundment Pool (PD)	Pool formed by impoundment above dam or constriction.
Pool (P)	Pool (unspecified type).
Glide (GL)	Water moving slowly, with <u>a smooth, unbroken surface</u> . Low turbulence.
Riffle (RI)	Water moving, with <u>small ripples, waves and eddies</u> -- waves not breaking, <u>surface tension not broken</u> . Sound: "babbling", "gurgling".
Rapid (RA)	Water movement rapid and turbulent, surface with <u>intermittent white-water</u> with breaking waves. Sound: continuous rushing, but not as loud as cascade.
Cascade (CA)	Water movement rapid and very turbulent over steep channel bottom. Most of the water surface is broken in <u>short, irregular plunges, mostly whitewater</u> . Sound: roaring.
Falls (FA)	<u>Free falling water</u> over a vertical or near vertical drop into plunge, water turbulent and white over high falls. Sound: from splash to roar.
Dry Channel (DR)	No water in the channel

(continued)

^a Note that in order for a channel habitat unit (other than a backwater pool) to be distinguished, it must be at least as wide or long as the channel is wide.

TABLE 7-3 (Continued)

Categories of Pool-forming Elements^b	
Code	Category
N	Not Applicable, Habitat Unit is not a pool
W	Large Woody Debris.
R	Rootwad
B	Boulder or Bedrock
F	Unknown cause (unseen fluvial processes)
WR, RW, RBW	Combinations
OT	Other (describe in the comments section of field form)

^b Remember that most pools are formed at high flows, so you may need to look at features, such as large woody debris, that are dry at baseflow, but still within the bankfull channel.

mid-channel features below the bankfull flow mark that are dry during baseflow conditions (see Section 7.5.3 for the definition of bankfull channel). Islands are mid-channel features that are dry even when the stream is experiencing a bankfull flow. Both bars and islands cause the stream to split into side channels. When a mid-channel bar is encountered along the thalweg profile, it is noted on the field form and the active channel is considered to include the bar. Therefore, the wetted width is measured as the distance between wetted left and right banks. It is measured across and over mid-channel bars and boulders. If mid-channel bars are present, record the bar width in the space provided.

If a mid-channel feature is as high as the surrounding flood plain, it is considered an island. Treat side channels resulting from islands different from mid-channel bars. Handle the ensuing side channel based on visual estimates of the percent of total flow within the side channel as follows:

Less than 15%	Indicate the presence of a side channel on the field data form.
16 to 49%	Indicate the presence of a side channel on the field data form. Establish a secondary transect across the side channel and designate it as "X" plus the primary transect letter; e.g., XA). Complete the detailed channel and riparian cross-section measurements for the side channel, using a separate copy of the field data form.


When a side channel occurs due to an island, reflect its presence with continuous entries in the "Side Channel" field on the thalweg profile form (Figure 7-2). In addition, note the points of divergence and confluence of the side channel in the comments section of the thalweg profile form. Begin entries at the point where the side channel converges with the main channel; note the side channel presence continuously until the upstream point where it diverges. When doing width measures with a side channel separated by an island, include only the width of the main channel in the measures at the time and then measure the side channel width separately.

For dry and intermittent streams, where no water is in the channel at a thalweg station, record zeros for depth and wetted width. Record the habitat type as dry channel (DR).

FIELD PROTOCOLS FOR BANKFULL WIDTH/DEPTH AND FLOODPLAIN WIDTH

Extracted from Aquatic Inventories Project, Methods for Stream Habitat and Snorkel Surveys (Oregon Department of Fish and Wildlife, Version 26.1, May 2016)


GUIDE TO MEASURING CHANNEL METRICS



Step 1: Clinometer (CLINO) identifies his eye height on the depth staff.




Step 2: CLINO and survey partner (TAPE) discuss and agree on the active channel scour or margin on either side of the stream. **NOTE:** Channel metrics are to be conducted at the pool tail crest or at the top or bottom of a fast water unit type.




Step 3: TAPE places depth staff at top of the active channel. CLINO stands at the water surface. TAPE slides her hand down the depth staff until CLINO sees the hand come into view while keeping the clinometer on 0% slope.

Step 4: Subtract the height where CLINO saw the hand on the depth staff (Step 3) from the eye height established in Step 1. This is the height above the water surface ("A" in Step 3).



Step 5: CLINO takes the end of the tape measure and starts across the channel while TAPE stays at the active channel margin. CLINO takes 3 depth measurements at $\frac{1}{4}$, $\frac{1}{2}$, and $\frac{3}{4}$ distance of the active channel width while crossing the channel (the measurements are usually the water depth but occasionally can be an exposed gravel bar above the water surface - thus a negative value).

Step 6: Take the average of the three measurements. The example in Step 5 has the measurements 0.15, 0.30, and -0.15 (average = 0.10). Add this value to the measurement "A" obtained in Step 3. This sum is the Active Channel Height (ACH). It is also equivalent to the bankfull depth.



Step 7: TAPE repositions her hand at CLINO's eye height on the depth staff. On the other side of the stream, CLINO backs up the bank until his eye is level with TAPE's hand on the depth staff (using the clinometer at 0% slope). CLINO has now established the active channel margin on the other bank. The distance between CLINO and TAPE is the Active Channel Width (ACW) as x depicts above. It is also equivalent to the bankfull width.

FIELD PROTOCOLS FOR SIDE CHANNEL HABITAT

CHaMP (Columbia Habitat Monitoring Program). 2015. Scientific protocol for salmonid habitat surveys within the Columbia Habitat Monitoring Program. Prepared by the Columbia Habitat Monitoring Program.

SECTION 6: CHANNEL SEGMENTS AND SIDE CHANNELS

Equipment: N/A

Objective: Identify and label the main channel and different side channel types.

6.1 Channel Segment Numbers and Side Channel Classification

Channel segment numbers are used to differentiate the main channel from side channels. Assign a unique channel segment number to the main channel and all qualifying side channels.

Step 1. Identify the main channel.

- i. Main (primary) channel: Contains the greatest amount of stream flow at a site.

Step 2. Identify side channels.

- i. Side channel: To be considered a side channel, the channel must be separated from another channel by an island that is $\geq$ the bankfull elevation for a length $\geq$ the average bankfull width. At small sites that are 120 m in length, an island must be $\geq$ 6 m to qualify.
 - a. If a channel is separated from another channel by an island that is shorter than the average bankfull width (or < 6 m at small sites), then consider the channel part of the adjacent channel.
 - b. If a channel is separated from another channel by a bar ($<$ bankfull elevation) or boulder, then consider the side channel part of the adjacent channel.

Step 3. Identify side channel type.

- i. Determine if side channel is qualifying or non-qualifying.
 - a. Qualifying side channel: Channel is located within the active bankfull channel and separated from another channel by an island $\geq$ the average bankfull width.
 - i. Qualifying side channels are further divided into large and small side channels (see Step 3, ii.).
 - ii. Refer to the decision tree in Figure 17 regarding segment number and channel unit designations for qualifying side channels.
 - b. Non-qualifying side channel: Channel is located outside the active bankfull channel or possesses one or more of the following characteristics:
 - i. The elevation of the channel's streambed is above bankfull at any point.
 - ii. Channel lacks a continuously defined streambed or developed streambanks.
 - iii. Channel contains terrestrial vegetation.
- ii. Determine whether qualifying side channel is large or small.

Visually estimate stream flow at both the upstream and downstream ends of the side channel as a percentage of the total flow at the site.

- a. Large side channel: Has between 16% and 49% flow at either end.
- b. Small side channel: Has $< 16\%$ flow at both ends.

Step 4. Assign segment numbers to channels.

- i. The main channel is assigned “Segment 1” throughout the site (Figure 16).
- ii. The first large or small side channel encountered when laying out the site (moving upstream) is designated as “Segment 2”. Designate additional qualifying side channels sequentially (2, 3, 4, etc.) until all large and small side channels have been uniquely numbered (Figure 16).
- iii. Do not assign segment numbers to non-qualifying side channels.

Note: If a qualifying side channel continues downstream beyond the bottom of site, begin surveying the side channel in line with the bottom of site. Likewise, end surveying a side channel in line with the top of site.

Note: If a large side channel splits and each channel contains $> 16\%$ of the total stream flow, assign the original segment number to the largest channel and assign a new segment number to the second channel. If a large side channel splits, and flow in either channel is $< 16\%$ of the total flow, assign the original channel segment number to the largest channel, and assign a new segment number to the smaller channel (now considered a small side channel).

Step 5. Record measurements. What to measure in each channel type:

- i. Main channel:
 - a. Classify channel units, collect all channel unit attributes, and conduct topographic survey.
- ii. Large side channels:
 - a. Classify channel units, collect all channel unit attributes, and conduct topo survey.
- iii. Small side channels:
 - a. Classify the entire side channel (both wet and dry portions) as a Small Side Channel unit (Figure 15C) and conduct topographic survey.
 - b. Quantify Large Woody Debris (Section 8.4). Do not collect any additional channel unit attributes.
 - c. Categorize the side channel as continuously wet, partially wet, or dry.
 - d. Estimate the total length of the side channel centerline.
 - e. Estimate the average bankfull width of the side channel.
 - f. Estimate the percent of the bankfull channel area that is wet at the time of sampling.
- iii. Non-qualifying side channels:
 - a. Capture the area where the side channel enters/exits the adjacent channel in the topographic survey but do not conduct the topo survey throughout the side channel.
 - b. Do not classify channel units, collect any channel unit attributes, or categorize it.
 - c. Do not estimate side channel length, width, or percent wetted.




Figure 16. How to number channel segments within a site. The main channel is assigned segment 1 throughout the site. Both large and small side channels are assigned sequential segment numbers working upstream. In the figure, channel segment numbers are preceded with a “S” (S1-S3) and channel unit numbers with a “U” (U1-13).

Qualifying Side Channel Decision Tree




Figure 17. Decision tree outlining segment number and channel unit designations, along with topographic codes for qualifying side channels and islands.

FIELD PROTOCOLS FOR FLOW CATEGORY

ODFW. 2014. Aquatic Inventories Project Methods for Stream Habitat Surveys. Oregon Department of Fish and Wildlife, Aquatic Inventories Project, Conservation and Recovery Program, Corvallis, Oregon.
<http://odfw.forestry.oregonstate.edu/freshwater/inventory/pdffiles/hmethd14.pdf>

Land Uses continued

BK	Bug Kill. Eastside forests with > 60% mortality from pests and diseases. Enter bug kill as a comment on the unit sheet when it is observed in small patches.
LG	Light Grazing Pressure. Grasses, forbs and shrubs present, banks not broken down, animal presence obvious only at limited points such as water crossings. Cow pies evident.
HG	Heavy Grazing Pressure. Broken banks, well established cow paths. Primarily bare earth or early successional stages of grasses and forbs present.
EX	EXclosure. Fenced area that excludes cattle from a portion of rangeland
GN	Green way. Designated Green Way areas, Parks (city, county, state).
UR	URban
RR	Rural Residential
IN	INDustrial
DW	Domestic Water supply watershed.
CR	Conservation area or wildlife Refuge .
GF	GolF course.
MI	MIning
WA	Designated Wilderness Area or Wilderness Study Area
WL	WetLand .
NU	No Use identified.
WS	Wild and Scenic Area

9. **Water Temperature.** Stream temperature recorded at each reach change or a minimum of once per page of data. Record the time as well. Note if the temperature is measured in °C or °F.

At named tributaries, record the stream temperature of the tributary **and** in the mainstem stream upstream from the tributary confluence. Identify and record each temperature in the appropriate line of the Note column.

10. **Stream Flow.** Description of observed discharge condition. Best observed in riffles. If a gauging station is present, be sure to record the stage height.

DR	DRy
PD	PuDdled. Series of isolated pools connected by surface trickle or subsurface flow.
LF	Low Flow. Surface water flowing across 50 to 75 percent of the active channel surface. Consider general indications of low flow conditions.
MF	Moderate Flow. Surface water flowing across 75 to 90 percent of the active channel surface.
HF	High Flow. Stream flowing completely across active channel surface but not at bankfull.
BF	Bankfull Flow. Stream flowing at the upper level of the active channel bank.
FF	Flood Flow. Stream flowing over banks onto low terraces or flood plain.

11. **Location.** Township, range, section and quarter at the start of the reach. Use the following example as the format: T10S-R05W-S22SE.

FIELD PROTOCOLS FOR BENTHIC MACROINVERTEBRATES

Pages extracted from Larson (2015):

Washington State Department of Ecology

Environmental Assessment Program

Standard Operating Procedures and Minimum Requirements for the Collection of
Freshwater Benthic Macroinvertebrates in Streams and Rivers

Version 2.0

Author – Chad Larson

Date – April 2015

Reviewers – Brandee Era-Miller, Jennifer Wolfe, Chris Hartman & Glenn Merritt,
George Onwumere

Date – April 2015

QA Approval - William R. Kammin, Ecology Quality Assurance Officer

Date – 3/28/2016

EAP073

Recertified: 03/28/2016

Please note that the Washington State Department of Ecology's Standard Operating Procedures (SOPs) are adapted from published methods, or developed by in-house technical and administrative experts. Their primary purpose is for internal Ecology use, although sampling and administrative SOPs may have a wider utility. Our SOPs do not supplant official published methods. Distribution of these SOPs does not constitute an endorsement of a particular procedure or method.

Any reference to specific equipment, manufacturer, or supplies is for descriptive purposes only and does not constitute an endorsement of a particular product or service by the author or by the Department of Ecology.

Although Ecology follows the SOP in most instances, there may be instances in which Ecology uses an alternative methodology, procedure, or process. X:\EA PROGRAM\ECYEAPSOP\Approved

SOP Revision History

Revision Date	Rev number	Summary of changes	Sections	Reviser(s)
April 2015	2.0	Version has changed because the scope of the SOP has been changed to incorporate more streams. Current version distinguishes between narrow and wide protocols.	throughout	Chad Larson

Environmental Assessment Program

Standard Operating Procedure and Minimum Requirements for the Collection of Freshwater Benthic Macroinvertebrates in Streams and Rivers

1.0 Purpose and Scope

- 1.1 This document is the Environmental Assessment Program (EAP) Standard Operating Procedure (SOP) for the collection of freshwater benthic macroinvertebrate (BMI) data. Collection of BMI in wadeable streams and rivers (< 25 m average bankfull width) and larger rivers ($\geq$ 25 m average bankfull width) using narrow and wide protocols, respectively is discussed. It provides minimum requirements for the standardized methods of collecting and preserving aquatic insects, as well as for the taxonomic identification and reporting of the contents of BMI samples.
- 1.2 The methods described here are compatible with those used by other federal and state agencies in the Pacific Northwest Region (Hayslip, 2007). Data collected using these methods allows us to share data with other agencies, thereby allowing for more efficient use of time in the field and potentially more extensive sampling of the streams and rivers in Washington.


2.0 Applicability

- 2.1 The procedures outlined here are used by EAP staff when collecting macroinvertebrates during a data collection event (DCE) from rivers and streams in Washington State. In addition, to allow for comparable results, any data submitted for analysis using Ecology's bioassessment models by outside entities should be conducted in this manner.
- 2.2 The methods outlined here are employed by several of EAP's programs conducting status and trends monitoring for the state, which is carried out by the Watershed Health Monitoring (WHM), Ambient Freshwater Biological Monitoring and Sentinel programs. However, these methods also pertain to biological assessment conducted for potential regulatory purposes, i.e. directed studies (e.g. TMDL studies) or outside entities assessing sites for potential listing on the state's 303(d) list for 'biological impairment' (see Ecology's Water Quality Program Policy 1-11: Bioassessment).

3.0 Definitions

- 3.1 **Narrow Protocol:** The set of SOPs that describes the sample and data collection at wadeable sites with an average bankfull width less than 25 m.
- 3.2 **Wide Protocol:** The set of SOPs for collecting data and samples at non-wadeable sites or sites wider than 25 m bankfull width. It is an abbreviated version of the Narrow Protocol.
- 3.3 **D-Frame Kicknet** – A light weight, packable net used for the collection of aquatic macroinvertebrates composed of a 3-4 foot pole with a D-shaped frame attached to the bottom such that the flat side can be placed against the substrate. The frame is 1 foot wide

and 1 foot tall. A 500 micron mesh net is attached to the frame. With the ability to be deployed across most diverse types of substrates, this is the required sampling device for status and trends monitoring.



- 3.4 Hess Sampler – A cylindrical shaped mesh frame that is open on either end to allow access to bottom substrates through the top of the cylinder. This cylinder has a 500 micron mesh net attached to part of the wall for sample collection. This sampler prevents escape of sample organisms, and prevent outside materials and organisms from drifting into the net.




Image taken from <http://www.ilmb.gov.bc.ca/risc/pubs/aquatic/freshwaterbio/assets/freshwaterbio.pdf> page 29 Figure 8

- 3.5 Surber Sampler – A net used for sampling aquatic insects that is composed of a 12 x 12 inch square frame with a 500 micron mesh net attached. It has another 12 x 12 inch square frame that sits on the substrate to border your sampling area.




Image taken from <http://www.ilmb.gov.bc.ca/risc/pubs/aquatic/freshwaterbio/assets/freshwaterbio.pdf> page 29 Figure 8

- 3.6 Reach-wide Composite Sample – A reach wide sample represents a standard stream site in which the BMI sample is composited from 8 predefined stations. Each station is located on a separate transect. Each station is selected without regard to whether it is in a pool, riffle, or other habitat type. Invertebrate distribution is usually patchy, so sampling from multiple, dispersed locations, helps to provide a more representative sample.
- 3.7 Reach-wide Station – This is one of 8 locations from which a reach wide sample is composited. Locations are predetermined by randomly choosing 8 of 11 transects from a Standard Stream Site.
- 3.7.1 **Narrow protocol stations** – Sampling BMI for the narrow protocol occurs in a zig-zag sequence (Table 1) when moving upstream.

Table 1. Pre-determined station locations on each transect of a Standard Stream Site.

Station	% Transect Distance Left to Right
1	25
2	50
3	75
4	50
5	25
6	50
7	75
8	50

- 3.7.2 **Wide protocol stations** – For the wide protocol, sampling at each of the 8 transects occurs on the side of the stream/river where habitat is also surveyed. At each of the selected transects, a sample is collected from a representative portion (as much as practical) of a littoral zone extending 10 meters into the stream/river from the wetted bank and 10 meters upstream and downstream, respectively from the transect. The sample should also be collected in an area shallow enough to deploy the kicknet and in an area away from backwaters, eddies, or other edge habitat.
- 3.8 Targeted Riffle Sampling – A targeted sample represents sampling a single habitat type from a stream reach that extends at least twice its bankfull width. A targeted sample is composed of 8 feet of surface area sampled across multiple riffles or pools. Targeted sampling from a single habitat type can help to reduce the variation in the data and to provide a clear response signal. Individual directed studies may decide on the utility of using targeted riffle sampling; however, projects involved in status and trends monitoring employ only reach-wide composite sampling.
- 3.9 MSDS – Material Safety Data Sheets provide both workers and emergency personnel with the proper procedures for handling or working with a particular substance. An MSDS includes information such as physical data (melting point, boiling point, flash point, etc.), toxicity, health effects, first aid, reactivity, storage, disposal, protective equipment and spill/leak procedures.

4.0 Personnel Qualifications/Responsibilities

- 4.1 For collection of the sample, personnel should at a minimum review the Quality Assurance Monitoring Plans for the status and trends monitoring programs (e.g. [Ambient Biological Monitoring, WHM](#)) and the training tutorial [Sampling Macroinvertebrates in Wadeable Streams in Washington State](#). Alternatively, they may receive formal training from staff who have themselves been formally trained. EAP has been holding formal training sessions for Watershed Health monitoring during June of each year. These sessions are open to the public.
- 4.2 For taxonomic analysis of the sample, the personnel should be certified for identification of Western United States taxa to the Genus or Species level by the Society for Freshwater Science (<http://www.nabstep.com/>). Sample identification and enumeration should be to the lowest practical level as outlined in: [Quality Assurance Monitoring Plan: Ambient Biological Monitoring in Rivers and Streams: Benthic Macroinvertebrates and Periphyton](#)
- 4.3 All staff must comply with the requirements of the EA Safety Manual (EA Program, 2012). A full working knowledge of the procedures in Chapter 1 is expected.
- 4.4 All staff must be familiar and comply with the requirements of Ecology's Chemical Hygiene Plan and Hazardous Materials Management Plan (EA Program 2011). [h](#)
- 4.5 Field staff must be annually trained to minimize the spread of invasive species. See SOP EAP070: <http://www.ecy.wa.gov/programs/eap/quality.html>
- 4.6 Read this standard operating procedure and discuss any questions with your supervisor or task team leader.
- 4.7 Read the Material Safety Data Sheets (MSDS) for ethanol before beginning the sorting/taxonomic procedures. The MSDS are available in the Ecology Headquarters benthic laboratory. Use proper protective clothing and equipment as indicated.
- 4.8 Immediately report to your supervisor any symptoms or reactions that might be related to Ethanol exposure.

5.0 Minimum Equipment, Reagents, and Supplies for Sample Collection

- 5.1 Wide-mouth polyethylene jar (128 oz or 3.8 L is a recommended size)
- 5.2 D-Frame kick net (pre-cleaned of organisms) with these characteristics:
 - 5.2.1 Frame mouth that is 1 ft (30.5 cm) wide by 1 ft tall
 - 5.2.2 500-µm mesh net
- 5.3 95% Ethanol (add 3 parts by volume for each part sample)
- 5.4 Label (waterproof) for jar exterior
- 5.5 Label (waterproof) for jar interior
- 5.6 Soft-lead pencil

- 5.7 Clear tape
- 5.8 Electrical tape
- 5.9 Pocket knife
- 5.10 Wading gear (pre-cleaned of organisms)

6.0 Summary of Procedure

6.1 Details of the procedure are determined by the purpose for monitoring (Table 2).

Table 2. Details of benthic sampling based on monitoring purpose.

Monitoring Purpose	Status & Trends (narrow protocols)	Status & Trends (wide protocols)	Regulatory
Device	D-frame Kicknet	D-frame Kicknet	D-frame Kicknet, or Surber, or Hess
Mesh	500 µm	500 µm	500 µm
Site length	20 bankfull widths (150-500 m)	20 bankfull widths (150-2000 m)	2 bankfull widths (or more)
Sample area	8 ft ²	8 ft ²	8 ft ²
Station distribution	8 transects, 4 margins + 4 central	8 transects, littoral zone on side of stream where habitat is surveyed	Multiple riffles or 8 transects
Time to suspend	30 seconds	30 seconds	30-120 seconds
Sample	Reach-wide composite	Reach-wide composite	Reach-wide or Targeted-Riffle composite
Season	July 1-Oct 15	July 1-Oct 15	July 1-Oct 15
Subsample goal	500+ organisms	500+ organisms	500+ organisms
Taxonomic resolution	Lowest practical	Lowest practical	Lowest practical

6.2 Field Sampling

- 6.2.1 For status and trends monitoring purposes (e.g. WHM), the sampling season extends from July 1 to October 15. For regulatory monitoring purposes, sampling should be conducted during the same period.
- 6.2.2 Samples should be collected with a device that uses 500 micron mesh, including D-frame kick nets, Surber samplers, or Hess Samplers. Samples collected for status and trends monitoring, i.e. WHM, Ambient Stream Biological Monitoring and Sentinel programs should use a D-frame kick net.
- 6.2.3 Samples should be collected from 8 square feet of stream bottom surface area and composited in the same jar. These samples should come from multiple locations across the study site.
- 6.2.3.1 Samples taken for the purpose of monitoring status and trends of stream health (e.g. WHM) should be composited (regardless of habitat) from 8 randomly-selected transects dispersed across a site at least 150 m long. See the WHM SOP for Verification and Layout (in production) or Adams (2010) for a description of the site layout procedures.

- 6.2.3.2 Samples taken for the purpose of regulatory assessment should be composited from 8 feet of surface area taken from multiple fast water habitats in the study reach. Aliquots may be from either turbulent (e.g. riffles) or non-turbulent habitat (e.g. glides), as long as flow is sufficient to carry organisms into the net.
- 6.2.4 For aliquots from **fast-water**, place the sampling device firmly against the stream bottom to eliminate gaps under the frame with the opening of the collection net facing the flow of water. Identify the surface area to be sampled. Gently scrub large substrate particles (larger than 5 cm in diameter) in front of the sampling device to remove any organisms that cling to the substrates and allow the flow to carry them into the mesh. After each particle in the sample surface area is cleaned, inspect it for any remaining organisms, and then set it outside of the sample area.
- 6.2.5 Suspend the substrate into the water column from the specified surface area and allow the flow of the water to carry the BMI into the mesh. This may be accomplished by kicking or using a trowel, for a minimum of 30 seconds, to stir up and suspend the substrate in front of the net.
- 6.2.6 If the aliquot is being taken in a **slack water** habitat, where flow is unable to carry the BMI's into the mesh, a different approach should be taken. First, visually inspect the stream bottom for any heavy or large organisms such as mussels and snails and place them in the sample jar. Pick up any loose rocks or large substrate particles and scrub them over the net, allowing the organisms to fall into the mesh and then set aside. After scrubbing, vigorously kick the remaining finer substrate within your sampled surface area and drag the net repeatedly (for 30-120 seconds) through the disturbed area just above the bottom. Keep moving the net all the time so the organisms remain trapped in the net and do not escape, and continue kicking. On completion of sampling, remove the net from the water with a quick upward/upstream motion to wash the organisms to the bottom of the net.
- 6.2.7 Wash the contents of the net down to the bottom for ease of placing the sample aliquot into a jar. Remove relatively large debris, i.e. pieces of wood or rocks from the net following inspection for attached invertebrates. Once the bulk of the aliquot is in the jar, carefully inspect the mesh itself and remove any remaining insects that may be stuck to the net. Adding a small amount of ethanol to the jar prior to sample collection helps to reduce the number of insects sticking to the net and minimizes sample degradation during the sampling event.
- 6.2.8 Add 95% non-denatured ethanol to equal 2/3 of the volume of the total sample and add a label printed on waterproof paper to the contents of the jar (ratio is 3:1). Sufficient ethanol is necessary to preserve the contents of the jar until taxonomic enumeration.
- 6.2.9 Seal the jar securely, wrap the lid with electrical tape at the junction with the bottle, and affix a second label printed on waterproof paper to the outside of the jar. Contents are now ready to be delivered to the taxonomist for identification and enumeration.
- 6.2.10 To help minimize the risk of spreading invasive species before sampling in another stream/river, treat boots, boats, and nets according to EAP070 Environmental Assessment Procedure 01-15. <http://www.ecy.wa.gov/programs/eap/quality.html>

6.3 Data Reporting

- 6.3.1 At a minimum, a target of 500 organisms should be identified by the lab for each sample. There are occasional situations that lead to fewer than 500 organisms per sample and do not meet this target. In these cases, the lab should identify the entire sample. Acceptance of smaller count (<500 organisms identified) data into our database for assessment purposes will be allowed at Ecology's discretion.
- 6.3.2 Each organism should be identified to the "lowest practical level". "Lowest practical level" is generally to genus or species, unless the specimen is under-developed or has been damaged, preventing identification to this level. Adams (2010) outlined the standard taxonomic effort employed by EAP's status and trends monitoring projects (appendices G & H on <https://fortress.wa.gov/ecy/publications/summarypages/1003109.html>).
- 6.3.3 Lab data reported should include at a minimum:
 - 6.3.3.1 Lab Name/Taxonomist
 - 6.3.3.2 Integrated Taxonomic Information System (ITIS) Taxa Number
 - 6.3.3.3 Scientific name of taxa
 - 6.3.3.4 Collection date
 - 6.3.3.5 Sampling device
 - 6.3.3.6 Habitat sampling scheme (reach wide or targeted)
 - 6.3.3.7 Protocol used (narrow or wide)
 - 6.3.3.8 Number of organisms identified
 - 6.3.3.9 Density of taxa per meter square
 - 6.3.3.10 Number of each taxa by life stage
 - 6.3.3.11 Report number of damaged taxa and indicate if unable to identify to lowest level
 - 6.3.3.12 Report taxa uniqueness for non-specific identifications (to estimate diversity)

7.0 Records Management

- 7.1 List every sample on a Chain-of-Custody form submitted to the taxonomist. This form should include location, date, and sampling information.
- 7.2 The taxonomist will submit data to Ecology's EIM database at <http://www.ecy.wa.gov/eim/> or to [Puget Sound Stream Benthos](#). Arrangements should be made with King County DNR to give permissions for the taxonomist to submit data to the Puget Sound Stream Benthos website.

8.0 Quality Control and Quality Assurance Section

8.1 Field Quality Assurance

- 8.1.1 *Visit precision* measures variability in the sampling method and is related to the variability of collecting a composite sample in a reach. *Visit precision* is estimated by

collecting side-by-side duplicate composite samples of the invertebrate communities within the same reach during the same day at 10% of the reaches sampled annually. *Visit precision* is calculated using the relative standard deviation (RSD) from two replicate composite samples and should be <20% in reference streams when using the taxa richness metric.

- 8.1.2 For additional information see the Quality Assurance Monitoring Plan for Ambient Biological Monitoring in Rivers and Streams: Benthic Macroinvertebrates and Periphyton (Adams, 2010). Appendix C in <https://fortress.wa.gov/ecy/publications/summarypages/1003109.html>

8.2 Macroinvertebrate Sorting Efficiency

- 8.2.1 Quality control procedures for initial sample processing and subsampling involves checking *sorting efficiency*. These checks are conducted on 10% of the samples by independent observers who microscopically re-examine the sorted substrate from each sample. All organisms that were missed are counted. *Sorting efficiency* is evaluated by applying the following calculation:

$$SE = n_1/n_2 \times 100$$

where SE is the sorting efficiency, expressed as a percentage, n_1 is the total number of specimens in the first sort, and n_2 is the total number of specimens in the first and second sorts combined. *Sorting efficiency* is recorded on each benchsheet by the person/lab enumerating the sample. If 95% sorting efficiency is not achieved for a given sample, a failure is recorded on the benchsheet and in the database. The sorted portion of that sample is then completely resorted before the sorting efficiency test is repeated for that sample. *Sorting efficiency* statistics for each technician and for the entire laboratory are reviewed monthly. Sorting efficiency for each sample in a project is reported to the client in the technical summary document. Technicians who do not maintain the target sorting efficiency are given remedial training, and larger portions of the samples they process are examined for the sorting efficiency test until they are able to maintain the target sorting efficiency.

- 8.2.2 A second evaluation of the sub-sampling process is applied to a small proportion of samples processed in each month; typically one sample per week is subjected to the following test of *precision of the sub-sampling process*. The procedure is only applied to samples where the target number of organisms was achieved in less than half of the Caton grids. A sample is randomly selected, and a second sub-sample is re-sorted from the unprocessed sample remnant. A second technician performs this sort. The resulting sub-sample is identified, and Bray-Curtis similarity index is calculated for the results of both sub-samples. Results that are less than 90% similar would indicate the need for more thorough distribution of sample materials in the sub-sampling tray or more special attention given to easily missed taxa when sorting (i.e. increased magnification).

8.3 Taxonomic Accuracy and Precision

- 8.3.1 Taxonomic misidentification results in inadequate biological characterization of a stream. Errors in identification should be less than 5% of the total taxa in the sample. Re-

identification of samples is conducted for 10% of the total number of samples in each year. Secondary identification is conducted by experienced taxonomists in order to maintain confidence in the data set. Difficult taxa should be sent to museum curators whose specialty includes members of the order in question. Voucher collections are maintained by the Orma J. Smith Museum of Natural History in Caldwell, Idaho. A voucher collection should be prepared from the set of samples for the year and shipped to the address below:

The Orma J. Smith Museum of Natural History
College of Idaho
2112 Cleveland BLVD
Caldwell, ID 83605-4432

9.0 Safety

9.1 Field Safety

All field staff must comply with the requirements of the EA Safety Manual (EA Program, 2012).

9.1.1 Sampling will not take place if the stream is not safe to enter.

9.1.2 Field work should be conducted by a team of two people at a minimum to ensure the safety of the sampler.

9.1.3 If a given sampling location within a study site/reach appears unsafe (such as too deep, too steep, or covered with loose material as a log jam), it may be shifted to allow sampling in nearby portion of the same or similar habitat conditions to the one avoided.

9.1.4 Proper field gear should be worn, including shoes with adequate lugging, felting, or studs to allow for traction on slick surfaces.

9.2 Chemical Safety

9.2.1 All employees should read this standard operating procedure and discuss any questions with her/his supervisor or task team leader.

9.2.2 Ethanol should be kept in small quantities in a tightly sealed container out of direct sunlight.

9.2.3 Read all relevant Material Safety Data Sheets (MSDS) before beginning this procedure. The MSDS are available in the Ecology benthic laboratory located at the EAP Operations Center.

9.2.4 Report to supervisor immediately any symptoms or reactions that might be related to Ethanol exposure.

10.0 References

- 10.1 Adams, K., 2010. Ambient Biological Monitoring in Rivers and Streams: Benthic Macroinvertebrates and Periphyton – Quality Assurance Monitoring Plan. Publication No. 10-03-109. Washington State Department of Ecology, Olympia, WA.
<https://fortress.wa.gov/ecy/publications/summarypages/1003109.html>
- 10.2 Environmental Assessment Program, 2012. Environmental Assessment Program Safety Manual. Washington State Department of Ecology. Olympia, WA.
- 10.3 Environmental Assessment Program 2011. Environmental Assessment Program Chemical Hygiene Plan and Hazardous Materials Management Plan. Washington State Department of Ecology, Olympia, WA.
- 10.4 Hayslip, Gretchen, editor. 2007. Methods for the collection and analysis of benthic macroinvertebrate assemblages in wadeable streams of the Pacific Northwest. Pacific Northwest Aquatic Monitoring Partnership, Cook, Washington.
<http://www.pnamp.org/document/1359>

FIELD PROTOCOLS FOR RESIDUAL POOL DEPTH

ODFW. 2014. Aquatic Inventories Project Methods for Stream Habitat Surveys. Oregon Department of Fish and Wildlife, Aquatic Inventories Project, Conservation and Recovery Program, Corvallis, Oregon.
<http://odfw.forestry.oregonstate.edu/freshwater/inventory/pdffiles/hmethd14.pdf>

UNIT-2 FORM

Information recorded by the "Numerator" member of each field crew.

1. **Unit Number.** Corresponds to number on "Estimator" sheet.
2. **Unit Type:** Corresponds to same type on "Estimator" sheet.
3. **Depth.** Maximum depth in pools, modal or typical depth in glides and fast water units. Measure to the nearest 0.05 meter as accurately as possible in pools. Probe the bottom with the depth staff to find the deepest point. Small differences in pool depth are significant.
4. **Depth at Pool Tail Crest:** The pool tail crest (PTC) location is where the water surface slope breaks into the downstream habitat unit. Measure the maximum depth to the nearest 0.01 meter along the hydraulic control feature that forms the pool. For beaver ponds unit type (BP) that do not have water flowing over the top of the dam yet there is subsurface flow through the sticks and logs of the dam, record the PTC depth as 0.01 meter. For subunit pools (BW, AL, IP), a PTC is not measured or recorded.
5. **Verified Length and Width.** Verified measurements only apply to Basin surveys. Refer to Appendix 2 for description and survey detail.
6. **Substrate.** Percent distribution by streambed area of substrate material in six size classes: silt and fine organic matter, sand, gravel (pea to baseball; 2-64mm), cobble (baseball to bowling ball; 64-256mm), boulders, and bedrock. Estimate distribution relative to the total area of the habitat unit (wetted area only). Round off each class to nearest 5 percent
 - *Do not worry about totaling your estimates exactly to 100 percent; your values will be weighted accordingly during analysis.*
 - *Estimate the distribution of the surrounding and/or supporting substrate to the best of your ability at **SS** (step over structure), **SL** (step over log), and **CC** (culvert crossing) units. For open-bottom culverts, estimate the substrate as for a normal habitat unit.*
 - *Be sensitive to the difference between surface flocculants and other fine sediment. Fine sediment that covers and embeds gravel and cobble should be part of your estimate. A thin layer of low density fine material over bedrock or boulders should not.*
 - *Hardpan clay or conglomerate substrate has bedrock characteristics; therefore, it is classified as bedrock when estimating percent composition. Indicate this in the Note field.*
7. **Boulder Count.** Count of boulders greater than 0.5 m in average diameter. Within this size class, include only the boulders that have any portion protruding above the water surface and those at the margin of the wetted channel. In dry units and dry channels, estimate the boulder count within the active channel.

8. **Bank Erosion.** Actively eroding, recently eroding, or collapsing banks that have the following characteristics: (1) exposed mineral soils and inorganic material, evidence of tension cracks, or active sloughing, **and** (2) lack of woody vegetation, roots, rocks (gravel, cobble, boulder), or logs. Eroding banks may contribute material slowly to the stream or collapse in large chunks. Determine if bank erosion is present from the top of the active channel and above, yet not to exceed the height of the floodprone. Record presence / absence if cumulatively over 25 percent of all bank length exhibits signs of erosion. If so, select the appropriate box on the PDA or write 'Y' (yes) or 'N' (no) on the paper data form.
9. **Undercut Bank.** The undercut must be at least 1 meter in length and have an average of 15 horizontal centimeters of immediate overhanging ceiling. If present, select the appropriate box on the PDA or write 'Y' (yes) or 'N' (no) on the paper data form.

Look for areas that provide good hiding cover for fish. Include areas undercut beneath root wads.

10. **Comment Codes.** Comments identifying important features. Enter as many codes as appropriate. For codes which apply to a specific bank, use a slash (/) to indicate the stream, and (when looking upstream) record those features originating on the left side of the stream on the left side of the slash, and like-wise for those features on the right.

- AM Amphibian.** Record species (if known) in Note field.
- BC Bridge Crossing.** Record road name or number in Note field.
- BD Beaver Dam.** Include height of step/dam created by beavers.
- BK Bug Kill.** Patches of insect or disease tree mortality.
- BV BeaVer Activity** (beaver den, cut trees, chewings, pond, etc.)
Indicate age of activity – very old, old, new, recent, fresh.
- CC Culvert Crossing.** Stream passes through a culvert. Record road name or number, as well as culvert material and dimensions.
There must be a matching CC unit type.
- CE Culvert Entry.** Applies to those tributaries a distance from the stream, usually for road drainage.
- CS Channelized Streambanks.** Rip-rap or other artificial bank stabilization and stream control.
- DJ Debris Jam.** Accumulation of large woody debris that fills the majority of the stream channel and traps additional sediment and debris. These have potential to alter channel morphology.
- FC Fence Crossing.**
- GS Gauging Station.**
- HS Artificial Habitat Structure.** Describe type: gabion, log weir, cabled wood, interlocking log jams, etc. If the habitat structure spans several habitat units, record it in the unit most affected by the structure. Identify the habitat units it spans in the NOTE field.
- MI Mining.** Dredging, sluicing, tailings (old or new), equipment, etc.
- PA Potential Artificial Barrier.** Potential artificial or human-created barrier to upstream or downstream migration of fish.
- PN Potential Natural Barrier.** Potential natural barrier to upstream or downstream fish migration.

Natural and Artificial Barriers are relative to the stream size, fish species, and fish age class encountering them. Consider these variables when using this Comment Code.

Document the height, take photographs, and record in Notes.

Comment Codes continued

- RF** **Road Ford.** Road that crosses within the active channel of the stream (no bridge).
- SD** **Screened Diversion.** Pump or canal diverting water. Give some indication of size or capacity.
- SS** **Spring or Seep.** Usually small amounts of flow (<5% of total flow) directly entering from hillslope. For large springs, estimate the contribution to flow. Springs do not have defined channels.
- TJ** **Tributary Junction** (both named and unnamed). Use the TJ class only for tributaries with clearly developed channels. Survey even if the trib is dry. Place this code on the primary (01) channel unit, and indicate the side of the stream where the trib is located. Place the tributary name on the tributary (11) channel unit. Record a temperature and the ACW in the Note column. Record the unit number of primary channel unit on the topo map.
- UD** **Unscreened Diversion.** Unscreened pump or canal diverting water. Give some indication of size or capacity.
- WL** **WildLife** use of stream or riparian zone. Identify species if possible. This code refers to everything except fish, amphibian, and shellfish species. Use the AM code for amphibian observations and record fish or shellfish observations only in the Note column.

*If a code does not exist for an observation, do not invent a code.
Add detail/describe in the Note column.*

Mass Movement. A two-part Comment Code to identify the type and condition of mass movements. The first letter of the code identifies the type of mass movement failure. The second letter evaluates the apparent activity of the failure. (Example: AI = inactive debris avalanche.) Do not confuse mass movements with bank erosion. Mass movements are not immediate stream bank-associated scouring or degradation. If a mass movement spans across several habitat units record it once. Put the Comment Code in the unit most affected and record the other impacted units in the Notes column.

Type:

- E** **Earthflow:** general movement and encroachment of hillslope upon the channel. These can be identified by groups of unusually leaning trees on a hillslope
- L** **Landslide:** failure of locally adjacent hill slope. Usually steep, broad, often shaped like a half oval, with exposed soils.
- A** **Avalanche:** failure of small, high-gradient trib. Often appear "spoon shaped" looking upslope. Water may flow in these intermittent or ephemeral channels that contribute alluvial soils debris.

Condition:

- A** **Active:** contributing material now.
- I** **Inactive:** evidence of contribution of material during previous winter or high flows.
- S** **Stabilized:** vegetated scars, no evidence of recent activity.

11. **Note.** Additional information to describe or identify the habitat unit, Comment Code, riparian vegetation, fish species, measurements of steps, culverts, barriers, etc.

FIELD PROTOCOLS FOR BANK STABILITY

Lazorchak, J.M., Hill, B.H., Averill, D.K., D.V. Peck, and D.J. Klemm (editors). 2000. Environmental Monitoring and Assessment Program -Surface Waters: Field Operations and Methods for Measuring the Ecological Condition of Non-Wadeable Rivers and Streams U.S. Environmental Protection Agency, Cincinnati OH.

Lazorchak, J.M., Klemm, D.J., and D.V. Peck (editors). 1998. Environmental Monitoring and Assessment Program -Surface Waters: Field Operations and Methods for Measuring the Ecological Condition of Wadeable Streams. EPA/620/R-94/004F. U.S. Environmental Protection Agency, Washington, D.C.

RAPID HABITAT ASSESSMENT FORM: RIFFLE/RUN - STREAMS (continued)

SITE NAME: _____

DATE: / / VISIT: G1 G2 ____

SITE ID: _____ - _____

TEAM ID (X): G1 G2 G3 G4 G5 G6 G7 G8

HABITAT PARAMETER	CATEGORY			
	OPTIMAL	SUB-OPTIMAL	MARGINAL	POOR
7. FREQUENCY OF RIFFLES SCORE:	Occurrence of riffles is relatively frequent; the distance between riffles divided by the width of the stream equals 5 to 7; variety of habitat.	Occurrence of riffles is infrequent; distance between riffles divided by the width of the stream equals 7 to 15.	Occasional riffle or bend; bottom contours provide some habitat; distance between riffles divided by the width of the stream is between 15 to 25.	Generally all flat water or shallow riffles; poor habitat; distance between riffles divided by the width of the stream is greater than 25.
	20 19 18 17 16	15 14 13 12 11	10 9 8 7 6	5 4 3 2 1 0
8. CHANNEL FLOW STATUS SCORE:	Water reaches the base of both banks and a minimal area of channel substrate is exposed.	Water fills more than 75% of the available channel; or less than 25% of the channel substrate is exposed.	Water fill 25 to 75% of the available channel; and/or riffle substrates are mostly exposed.	Very little water in channel, and mostly present as standing pools.
	20 19 18 17 16	15 14 13 12 11	10 9 8 7 6	5 4 3 2 1 0
9. CONDITION OF BANKS SCORE:	Banks stable; no evidence of erosion or bank failure.	Banks moderately stable; infrequent, small areas of erosion mostly healed over.	Moderately unstable; up to 60% of banks in reach have areas of erosion.	Unstable; many eroded areas; "raw" areas frequent along straight sections and bends; on side slopes, 60 to 100% of bank has erosional scars.
	20 19 18 17 16	15 14 13 12 11	10 9 8 7 6	5 4 3 2 1 0
10. BANK VEGETATIVE PROTECTION SCORE:	More than 90% of the stream bank surfaces are covered by vegetation.	70 to 90% of the stream bank surfaces are covered by vegetation.	50 to 70% of the stream bank surfaces are covered by vegetation.	Less than 50% of the stream bank surfaces are covered by vegetation.
	20 19 18 17 16	15 14 13 12 11	10 9 8 7 6	5 4 3 2 1 0
11. GRAZING OR OTHER DISRUPTIVE PRESSURE SCORE:	Vegetative disruption, through grazing or mowing is minimal or not evident; almost all plants are allowed to grow naturally.	Disruption is evident but is not affecting full plant growth potential to any great extent; more than one-half of the potential plant stubble height remaining.	Disruption is obvious; patches of bare soil or closely cropped vegetation are common; less than one-half of the potential plant stubble height remaining.	Disruption of stream bank vegetation is very high; vegetation has been removed to 2 inches or less in average stubble height.
	20 19 18 17 16	15 14 13 12 11	10 9 8 7 6	5 4 3 2 1 0
12. RIPARIAN VEGETATION ZONE WIDTH (LEAST BUFFERED SIDE) SCORE:	Width of riparian zone is greater than 18 m; human activities (i.e.; parking lots, roadbeds, clearcuts, lawns, or crops) have not impacted this zone.	Zone width is between 12 and 18 m; human activities have only minimally impacted this zone.	Zone width is between 6 and 12 m; human activities have impacted the zone a great deal.	Width of zone is less than 6 m; little or no riparian vegetation due to man-induced activities.
	20 19 18 17 16	15 14 13 12 11	10 9 8 7 6	5 4 3 2 1 0

FIELD PROTOCOLS FOR DENSITY/DISTRIBUTION INSTREAM WOOD

AREMP. 2010. Field Protocol Manual. Aquatic and Riparian Effectiveness Monitoring Program. Regional Interagency Monitoring for the Northwest Forest Plan.

<http://www.reo.gov/monitoring/reports/watershed/2010.FieldProtocol.Final.pdf>

Large Wood

Objective:

- Quantify the number and size of large wood pieces that are present within the bankfull channel, including qualifying side-channels.

Sampling method:

1. In order to be counted, each piece must meet **ALL** of the following criteria.
 - a. Each piece must be greater than 3 meter in length and at least 30 cm in diameter one-third of the way up from the base, or largest end.
 - b. Only include standing trees that lean within the bankfull channel if they are dead. Dead trees are defined as being devoid of needles or leaves, or where **ALL** of the needles and leaves have turned brown. Consider it living if the leaves or needles are green (Figure 15).

Note: Use caution when assessing the condition of a tree or fallen log. Nurse logs can appear to have living branches when seedlings or saplings are growing on them.
 - c. Wood that is embedded within the stream bank is counted if the exposed portion meets the length and width requirements.
 - d. Do not count a piece if only the roots (but not the stem/bole) extend within the bankfull channel (Figure 16).
 - e. Some pieces crack or break when they fall. Include the entire length when the two pieces are still touching at any point along the break (Only count as one piece if they are from the same original piece of wood). Treat them separately if they are no longer touching along the break. Count only the portion within the bankfull channel when they are no longer touching (Figures 17 &18).
2. Record the piece number, estimated length (nearest 10 cm), and estimated width (nearest cm) of all pieces in the site. The same person will make all estimates for a given site.
3. Also measure the length (nearest 10 cm) and diameter (nearest cm) of the first 10 pieces you encounter. The person estimating should not be made aware of the measured value.
4. A subset of pieces will be measured at sites with more than 10 qualifying pieces of wood.
 - a. For sites estimated to have between 11 and 100 pieces, measure the first 10 pieces of wood encountered. Starting at piece number 11, measure every 5th piece of wood up to and including the 35th piece of wood. All subsequent pieces of wood will be measured every 10th piece (starting with number 45).
 - b. For sites estimated to have over 100 pieces, measure the first ten pieces, then starting at the 11th piece only measure every 10th piece.

- c. If the piece of wood designated for measurement can not be measured safely; then measure the next piece of qualifying wood. Then continue measuring as specified above in a and b.
- 5. Measure the length of the main stem and not branches or roots. Begin measurements where the roots attach to the base of the stem when the roots are still connected.
- 6. Do not measure (just estimate) standing dead trees, pieces buried in log jams, or pieces that are unsafe to measure.
- 7. Begin counting from the bottom up when pieces are stacked on each other.
- 8. For wood in qualifying side channels, count only the pieces that are within bankfull.
- 9. Percent of the wood submerged at bankfull is an estimate of how much of the piece of wood will be underwater when the stream reaches its **bankfull** height.
- 10. Number of pieces touching, wood location and wood type will be collected and recorded. Evaluate wood location relative to the bankfull channel (See Table 5 and Figure 19).




Figure 15. Illustration of large woody debris. Pieces numbered 1 and 2 would be included in the survey, while pieces numbered 3 would not be counted.




Figure 16. Examples of qualifying large woody debris (1). The pieces on the right side (3) are not counted because only the roots extend over the bankfull channel (upper) and the exposed section is < 3 m in length (lower).




Figure 17. Examples of how to measure the length of broken pieces. Measure the length of the entire piece on the left (pieces still connected). Only measure the piece within the bankfull channel on the right.




Figure 18. Variations of touching vs. not touching along the break.




Figure 19. Example of wood locations in relation to the stream channel.

Table 5. Codes to be used with the wood data form.

Code Type	Definition
# Pieces Touching	
S →	Single piece
**A (1, 2, 3...)	Accumulation (2-4 pieces)
**J (1, 2, 3...)	Jam (≥5 pieces)
Wood Type	
N →	Natural (broken ends or entire trees)
C →	Cut end
A →	Artificial (part of a man-made structure)
RN →	Root wad attached to trunk with Natural end (broken or entire tree)
RC →	Root wad with opposite end Cut
Wood Location	
S →	Side of the channel - Piece of wood covers or extends over a small portion (0-25%) of the stream channel (near bankfull edge).
M →	Mid channel - Wood is in the main flow of the channel at bankfull (can be any orientation, not exclusive to center of the channel).
G →	Gravel Bar- (Build up of sediment below bankfull elevation with water flowing on both sides.) - 50% or more of the <u>piece of wood</u> is located on the gravel bar
F →	Full channel - Wood extends across 75% or more of the stream channel. Portions may extend beyond bankfull elevation.
O →	Over the channel - Suspended over the active channel, above the bankfull elevation. Includes pieces with a suspended bole but the branches extend below bankfull elevation.
Percent Submerged	
A	Categories: 0-25%
B	25-50%
C	50-75%
D	≥75%

****Jams and accumulations will be numbered sequentially, in the order that they are encountered.**

If you do not encounter any wood on a longitude, fill-in the datasheet with the longitude and add to comments that there is no wood on that particular longitude.

FIELD PROTOCOLS FOR SUBSTRATE PARTICLE SIZE

CHaMP (Columbia Habitat Monitoring Program). 2015. Scientific protocol for salmonid habitat surveys within the Columbia Habitat Monitoring Program. Prepared by the Columbia Habitat Monitoring Program.

8.6 Particle Size Distribution and Cobble Embeddedness

Equipment: Gravelometer, depth rod.

Objective: Quantify the size distribution of substrate in fast water habitats and to estimate cobble embeddedness.

8.6.1 Particle Size Distribution

Step 1. Determine where to place cross-sections.

- i. Count the number of Tier II riffle channel units that occur within the main channel and large side channels.
 - a. If there are ≥ 10 riffles, place one cross-section in each of the first 10 riffles (working upstream).
 - b. If there are less than 10 riffles, evenly distribute additional cross-sections into riffles according to the proportion of stream length that each unit comprises relative to the other riffles. If there is not enough space to conduct all measurements in riffles (see Step 1, ii, c), then evenly distribute remaining cross-sections into non-turbulent units (working upstream). If there is not enough space to conduct all measurements in riffles and non-turbulent units, then distribute remaining cross-sections into rapids.
- ii. Cross-section location and spacing.
 - a. When there is only one cross-section in a unit, place the cross-section at the midpoint of the unit.
 - b. When there are multiple cross-sections in a unit, equally space the cross-sections throughout the unit (Figure 29). Cross-sections should be oriented perpendicular to the bankfull channel.
 - c. Cross-sections should not be closer than $1/100^{\text{th}}$ of the site length apart. Move additional cross-sections to the next largest unit if too crowded. For example, the minimum spacing between cross-sections at a 120 m long site would be 1.2 m.
 - d. Cross-sections should not cross two or more laterally adjacent channel units.




Figure 29. Example of how to distribute pebble count cross-sections at a site.

Step 2. Select 11 sampling points at each cross-section.

- At each cross-section, visually divide the cross-section into 11 equally spaced sampling points running perpendicular to the stream channel, and spanning the width of the bankfull channel. (Figure 30).




Figure 30. Example of a cross-section layout. In this example, distance between samples is 1 m, because the bankfull width is 12 m. Particle sample location is shown with a circle and crosshairs.

Step 3. Select and measure particles.

- i. Select particles at sample points by turning your eye away and extending your finger down and picking up the first particle that you feel at the tip of your boot.
 - a. Use a gravelometer (Figure 31) to classify the b-axis of each particle. Record the size category (Table 8) for the largest square opening that the particle does not fit through. For example, if the particle fits through the 180 mm square but does not fit through the 128 mm square it is classified as the 128-180 mm size class.
 - b. Record silt and clay particles that are < 0.06 mm in the 0.0002-0.06 mm size class. Silt and clay particles are smooth when rubbed between the thumb and fingers whereas sand rolls between the fingers (is gritty).
 - c. Use the thin edge of the gravelometer to determine sand particles between 0.06 and 2 mm. (Note the thin edge of the gravelometer is 2 mm wide).
 - d. For particles > 128 mm and < 512 mm, measure the b-axis using the notches at the top of the gravelometer.
 - e. For particles > 512 mm, measure and record the length of the b-axis using the top edge of the gravelometer or a depth rod.
 - f. Record “bedrock” when encountered at sample points.
 - g. If your finger touches a thin layer of fine sediment covering a larger particle, then measure the fine sediment, not the larger particle. Conversely, if your finger touches a rock covered by individual fine sediment particles; measure the rock.
 - h. **Do not measure stream bank particles.**
 - i. For embedded particles that cannot be removed from the stream bed, use the notched edge of the gravelometer or the depth rod to measure the b-axis, and record the appropriate size class.



Figure 31. Gravelometer used to classify the b-axis of particles.

Table 8. Size categories for sediment in the range of silt/clay to bedrock. Record the size range that the particle falls within (e.g., 45-64).

Description of particle size		Size Range (mm)	
		Lower	Upper
Bedrock		n/a	n/a
Boulder	mega	> 4000	n/a
	very large	2896	4000
		2048	2896
	large	1448	2048
		1024	1448
	medium	724	1024
		512	724
	small	362	512
256		362	
Cobble	large	180	256
		128	180
	small	90	128
		64	90
Gravel	very coarse	45	64
		32	45
	coarse	22.6	32
		16	22.6
	medium	11.3	16
		8	11.3
	fine	5.7	8
		4	5.7
very fine	2	4	
Sand		0.06	2
Silt/Clay		0.0002	0.06

8.6.2 Cobble Embeddedness

Cobble embeddedness is a measure of the degree to which a cobble is buried by fine sediment.

Embeddedness is the percentage of a cobble's surface that is surrounded by fine sediment (< 2 mm). High cobble embeddedness results in a reduction of interstitial spaces between particles and makes the substrate more difficult to move (think of a fish's tail).

- i. Estimate embeddedness for all cobble-sized particles (64 mm – 256 mm) that are selected during particle size distribution sampling. Record estimates to the nearest 5%.
- ii. Embeddedness is estimated as the product of two values:
 - a. The percentage of the cobble's surface that is buried below the surface of the streambed (Figure 32A), and
 - b. The percentage of fine sediment < 2 mm in the substrate immediately surrounding the cobble (Figure 32B).

Appendix J

Shade Measurements at Major Transects in Waded Streams

Purpose and Scope

This method explains how to measure shade for the Status and Trends Program at each of 11 equidistant transects at each site. Measurements in this procedure will be restricted to one main channel. This method must be preceded by the Major Transects Method.

Instruments included on the procedure include a distance measuring device (e.g., measuring rod), and a convex densiometer (modified according to Mulvey *et al.* (1992)).

Definitions

Definitions of acronyms and other terms are found in Table J-1.

Table J-1. Definitions.

Term or Accronym	Definition
bankfull channel width	Horizontal distance between the bankfull stage on the left bank and the bankfull stage on the right bank.
bankfull stage	This stage is delineated by the elevation point of incipient flooding, indicated by deposits of sand or silt at the active scour mark, break in stream bank slope, perennial vegetation limit, rock discoloration, and root hair exposure (Endreny 2009).
left bank	A person facing downstream will have the left bank on their left side.
main channel	Channels in a stream are divided by islands (dry ground that rises above bankfull stage). Main channels contain the greatest proportion of flow. For this method it is called channel number 0.
major transect	One of 11 equidistant transects across the length of a site. These are labeled as follows: A0 (lowest), B0,C0,...K0 (highest) A major transect will cross the main channel and side channels.
right bank	A person facing downstream will have the right bank on their right

	side.
station	Any location within the site where an observation is made or part of a sample is collected.
side channels	Channels that contain less flow than the main channels. These are identified and enumerated (1,2,3 etc.) as encountered (see the method for thalweg measurements) during the data collection event.
site	A site is defined by the coordinates provided to a sampling crew and the boundaries established by the site layout method. Typically, the site extends 10 bankfull widths downstream from the coordinates and 10 bankfull widths upstream. The site also includes all riparian plots examined during the <i>Data Collection Event</i> . The site consists of many stations at which measurements or samples are collected.
transect	A line of study that crosses the direction of flow, divided into intervals where observations are collected.

Personnel Responsibilities

This method is performed by 1 person. This method is applied at every DCE, at each major transect. Staff performing this method must have been trained.

Equipment, Reagents, Supplies

- No. 2 pencil
- *Major Transect Form*
- measuring rod or 50-m tape
- Modified convex densiometer

Summary of Procedure

Refer to the *Major Transect Form* (Figure J-1). At each of the major Transects (A0-K0), assess the main channel (channel number 0). Use a convex densiometer (Lemmon, 1957) that has been modified according to Mulvey *et al* (1992; figure J-2); it has 17 intersections.

FIELD PROTOCOLS FOR SHADE

Ecology. 2009. Status and Trends Monitoring for Watershed Health & Salmon Recovery: Field Data Collection Protocol Wadeable Streams. Washington Department of Ecology. <http://www.ecy.wa.gov/programs/eap/stsmf/docs/01sntwadeablemana-vv3bhfl.pdf>

Ecology. 2010. Status and Trends Monitoring for Watershed Health & Salmon Recovery: Field Data Collection Protocol Wide Streams and Rivers. Washington Department of Ecology.

DENSIOMETER MEASUREMENTS					
(0-17Max)					
Flag			Flag		
CenUp	5		CenR	9	
CenL	0		Left	0	
CenDwn	4		Right	17	

Figure J-1. Densimeter portion of The *Major Transects Form*, with example data.




Figure J-2. An example reading from a modified convex densimeter. It shows 10 of 17 intersections with shade (a score of “10”). Note the proper positions of the bubble and head reflection (From Mulvey *et al.* 1992).

Record how many of the 17 cross-hairs have shade over them. Do this for each of six directions on the major transect (Figure J-3):

- Facing the left bankfull stage

- Facing the right bankfull stage
- Bankfull channel center, facing upstream
- Bankfull channel center, facing right
- Bankfull channel center, facing downstream
- Bankfull channel center, facing left

At each wetted station, hold the densiometer 30 cm above the water. At each dry station, hold the densiometer 30 cm above the ground. Bank readings should be able to detect shade from riparian understory vegetation such as ferns.




Figure J-3. Stations for densiometer measurement on each major transect. The densiometer is held level, and 30 cm above water for wet stations and 30 cm above ground for dry stations.

References

Endreny, T.A. 2009. *Fluvial Geomorphology Modules*, State University of New York College of Environmental Science and Forestry, National Oceanic and Atmospheric Administration, and the University Corporation for Atmospheric Research. www.fgmorph.com

Lemmon, P.E. 1957. A New Instrument for Measuring Forest Overstory Density. *Journal of Forestry*. 55(9):667-668.

Mulvey, M, L. Caton, and R. Hafele. 1992. Oregon Nonpoint Source Monitoring Protocols and Stream Bioassessment Field Manual for Macroinvertebrates and Habitat Assessment, Draft. Oregon Department of Environmental Quality, Portland, Oregon.

FIELD PROTOCOLS FOR RIPARIAN CANOPY AND UNDERSTORY (% COVER)

Ecology. 2009. Status and Trends Monitoring for Watershed Health & Salmon Recovery: Field Data Collection Protocol Wadeable Streams. Washington Department of Ecology. <http://www.ecy.wa.gov/programs/eap/stsmf/docs/01sntwadeablemana-vv3bhfl.pdf>

Ecology. 2010. Status and Trends Monitoring for Watershed Health & Salmon Recovery: Field Data Collection Protocol Wide Streams and Rivers. Washington Department of Ecology.

Appendix L

Riparian Vegetation Structure at Transects in Wide Streams & Rivers

Purpose and Scope

This method explains how to collect measurements for WHSR at each of 11 transects at each site. Observations in this procedure will be restricted to one main channel. This method must follow pre-season site layout.

Definitions

Definitions of acronyms and other terms are found in Table L-1.

Table L-1. Definitions.

Term or Acronym	Definition
Bankfull stage	This stage is delineated by the elevation point of incipient flooding, indicated by deposits of sand or silt at the active scour mark, break in stream bank slope, perennial vegetation limit, rock discoloration, and root hair exposure (Endreny 2009).
Broadleaf evergreen	Non-coniferous trees that maintain foliage through the seasons. A native example for Washington is the madrona (<i>Arbutus menziesii</i>)
Canopy	The functional definition for this method: Vegetation above 5 m high within a 10 m x 10 m riparian plot.
Coniferous	Any of various mostly needle-leaved or scale-leaved, chiefly evergreen, cone-bearing gymnospermous trees or shrubs such as pines, spruces, and firs. This includes larch.
Cover	This can be thought of as the amount of shadow cast by a particular layer alone when the sun is directly overhead. Conceptually remove vegetation from higher layers before estimating.
DCE	Data Collection Event. Data are indexed using this code which includes the SITE_ID, the date, and the time that the event began. It uses this format: WAM06600-NNNNNN-dce-20YY-MMDD-HHMM NNNNNN = the number portion of the SITE_ID. YY = the last two numeric digits of the year that the event occurred. MM = the two numeric digits for the month that the event occurred.

	DD = the two numeric digits for the day within the month that the event occurred. HHMM = the military time when the event began.
Deciduous	Non-coniferous trees that shed their leaves annually. Examples include alder, oak, maple, and cottonwood.
Duff	Organic matter in various stages of decomposition on the floor of the forest.
Forbs	A broad-leaved herb other than a grass, such as those that grow in a field, prairie, or meadow.
Ground cover	The functional definition for this method: Vegetation or bare ground below 0.5 m high within a 10 m x 10 m riparian plot.
Herbs	Plants whose stems do not produce woody, persistent tissue. They generally die back at the end of each growing season.
Left bank	A person facing downstream will have the left bank on their left side.
Main channel	Channels in a stream are divided by islands (dry ground that rises above bankfull stage). Main channels contain the greatest proportion of flow. For this method it is called channel number 0.
major transect	One of 11 equidistant transects across the length of a site. These are labeled as follows: A0 (lowest), B0,C0,...K0 (highest)
Mixed	Vegetation type if more than 10% of the cover is made up of an alternate type.
Right bank	A person facing downstream will have the right bank on their right side.
Side channels	Channels that contain less flow than the main channels. These are identified and enumerated (1,2,3 etc.) as encountered (see the method for thalweg measurements) during the DCE.
Understory	The functional definition for this method: Vegetation below 5 m high but above 0.5 m high within a 10 m x 10 m riparian plot.

Personnel Responsibilities

This method is performed by 1 person. This method is applied at every DCE, at each major transect. Observations are made at both banks of the main channel. Staff performing this method must have been trained.

Equipment, Reagents, Supplies

- No. 2 pencil
- *Major Transect Data Form*

Summary of Procedure

This procedure is derived from Peck et al. (2006) and Moberg (2007).

Refer to the *Major Transect Data Form* (Figure L-1). At each of the major Transects (A0-K0), in the main channel, evaluate a 10 m x 20 m riparian plot (Figure L-2) on the bank that was designated during pre-season site layout.. The riparian plot dimensions can be estimated rather than measured. On steeply sloping channel margins, plot boundaries are defined as if they were projected down from an aerial view.

Conceptually divide the riparian vegetation into three layers:

- Canopy (> 5 m high),
- Understory (0.5 to 5 m high),
- Ground Cover layer (< 0.5 m high).

Within each layer, consider the type of vegetation present and the amount of cover provided. Do this independently of what is contained in higher layers.

Cover quantity is coded on the field form (Figure L-1) as follows:

- 0 - absent
- 1- sparse (< 10% cover)
- 2 - moderate (10-40% cover)
- 3 - heavy (40-75% cover)
- 4 – very heavy (> 75% cover)

The maximum cover in each layer is 100%, so the sum of the cover for the combined three layers could add up to 300%. Ground cover scores must add to 100%.

RIPARIAN		0 = Absent (0%) 1 = Sparse (<10%) 2 = Moderate (10-40%) 3 = Heavy (40-75%) 4 = Very Heavy (>75%)					D = Deciduous C = Coniferous E = Broadleaf Evergreen M = Mixed N = None				
RIPARIAN VEGETATION COVER	Left Bank					Right Bank					Flag
Canopy (>5 m high)											
Woody Vegetation Type	D	C	E	M	N	D	C	E	M	N	
BIG Trees (Trunk >0.3 m DBH)	0	1	2	3	4	0	1	2	3	4	
SMALL Trees (Trunk <0.3 m DBH)	0	1	2	3	4	0	1	2	3	4	
Understory (0.5 to 5 m high)											
Woody Vegetation Type	D	C	E	M	N	D	C	E	M	N	
Woody Shrubs & Saplings	0	1	2	3	4	0	1	2	3	4	
Non-Woody Herbs, Grasses, & Forbs	0	1	2	3	4	0	1	2	3	4	
Ground Cover (<0.5 m high)											
Woody Shrubs & Saplings	0	1	2	3	4	0	1	2	3	4	
Non-Woody Herbs, Grasses and Forbs	0	1	2	3	4	0	1	2	3	4	
Barren, Bare Dirt or Duff	0	1	2	3	4	0	1	2	3	4	

Figure L-1. A portion of the *Major Transect Data Form*, with example data.




Figure L-2. One of two riparian plots at a transect.

Canopy

On the *Major Transect Form* (Figure L-1), circle the appropriate vegetation **type code** (D, C, E, M, or N). Type codes are defined on the form. The M (mixed) code means that there is any percentage of a second vegetation type.

Then circle the appropriate cover **quantity code** (0, 1, 2, 3, or 4) for each of 2 classes:

- Big trees – trees having trunks larger than 0.3 m diameter (at breast height)
- Small trees – trees having trunks smaller than 0.3 m diameter (at breast height)

Understory

On the *Major Transect Form* (Figure I-1), circle the appropriate vegetation **type code** (D, C, E, M, or N) for any *woody* vegetation that might be present. Then circle the appropriate cover **quantity code** (0, 1, 2, 3, or 4) for each of 2 classes:

- Woody vegetation - such as shrubs, saplings, or tree trunks
- Non-woody vegetation - such as herbs, grasses, or forbs

Ground Cover

Circle the appropriate cover **quantity code** (0, 1, 2, 3, or 4) for each of 3 classes:

- Woody (living)
- Non-woody (living)
- Bare dirt (or decomposing debris)

The sum of cover quantity ranges for these 3 types of ground cover should include 100%.

References

Endreny, T.A. 2009. *Fluvial Geomorphology Modules*, State University of New York College of Environmental Science and Forestry, National Oceanic and Atmospheric Administration, and the University Corporation for Atmospheric Research. www.fgmorph.com

Peck, D.V., Herlihy, A.T., Hill, B.H., Hughes, R.M., Kaufmann, P.R., Klemm, D.J., Lazorchak, J.M., McCormick, F.H., Peterson, S.A., Ringold, P.L., Magee, T., and Cappaert, M.R. Environmental Monitoring and Assessment Program-Surface Waters, Western Pilot Study, Field Operations Manual for Wadeable Streams. EPA/620/R-06/003. U.S. Environmental Protection Agency, Washington, D.C.
<http://www.epa.gov/wed/pages/publications/authored/EPA620R-06003EMAPSWFieldOperationsManualPeck.pdf>

Moberg, J. 2007. A field manual for the habitat protocols of the Upper Columbia Monitoring Strategy. Prepared for and funded by Bonneville Power Administration's Integrated Status and Effectiveness Monitoring Program. Terraqua, Inc. Wauconda, WA
<http://www.nwfsc.noaa.gov/research/divisions/cbd/mathbio/isemp/docs/isemphabitatprotocolsfieldmanualdraft070615.pdf>

Appendix M

Riparian Vegetation Structure at Major Transects in Waded Streams

Purpose and Scope

This method explains how to collect measurements for the Status and Trends Program at each of 11 equidistant transects at each site. Observations in this procedure will be restricted to one main channel. This method must follow the method for establishing major transects.

Definitions

Definitions of acronyms and other terms are found in Table M-1.

Table M-1. Definitions.

Term or Acronym	Definition
Bankfull stage	This stage is delineated by the elevation point of incipient flooding, indicated by deposits of sand or silt at the active scour mark, break in stream bank slope, perennial vegetation limit, rock discoloration, and root hair exposure (Endreny 2009).
Broadleaf evergreen	Non-coniferous trees that maintain foliage through the seasons. A native example for Washington is the madrona (<i>Arbutus menziesii</i>)
Canopy	The functional definition for this method: Vegetation above 5 m high within a 10 m x 10 m riparian plot.
Coniferous	Any of various mostly needle-leaved or scale-leaved, chiefly evergreen, cone-bearing gymnospermous trees or shrubs such as pines, spruces, and firs. This includes larch.
Cover	This can be thought of as the amount of shadow cast by a particular layer alone when the sun is directly overhead. Conceptually remove vegetation from higher layers before estimating.
DCE	Data Collection Event. Data are indexed using this code which includes the SITE_ID, the date, and the time that the event began. It uses this format: WAM06600-NNNNNN-dce-20YY-MMDD-HHMM NNNNNN = the number portion of the SITE_ID. YY = the last two numeric digits of the year that the event occurred. MM = the two numeric digits for the month that the event occurred.

	DD = the two numeric digits for the day within the month that the event occurred. HHMM = the military time when the event began.
Deciduous	Non-coniferous trees that shed their leaves annually. Examples include alder, oak, maple, and cottonwood.
Duff	Organic matter in various stages of decomposition on the floor of the forest.
Forbs	A broad-leaved herb other than a grass, such as those that grow in a field, prairie, or meadow.
Ground cover	The functional definition for this method: Vegetation or bare ground below 0.5 m high within a 10 m x 10 m riparian plot.
Herbs	Plants whose stems do not produce woody, persistent tissue. They generally die back at the end of each growing season.
Left bank	A person facing downstream will have the left bank on their left side.
Main channel	Channels in a stream are divided by islands (dry ground that rises above bankfull stage). Main channels contain the greatest proportion of flow. For this method it is called channel number 0.
major transect	One of 11 equidistant transects across the length of a site. These are labeled as follows: A0 (lowest), B0,C0,...K0 (highest)
Mixed	Vegetation type if more than 10% of the cover is made up of an alternate type.
Right bank	A person facing downstream will have the right bank on their right side.
Side channels	Channels that contain less flow than the main channels. These are identified and enumerated (1,2,3 etc.) as encountered (see the method for thalweg measurements) during the DCE.
Understory	The functional definition for this method: Vegetation below 5 m high but above 0.5 m high within a 10 m x 10 m riparian plot.

Personnel Responsibilities

This method is performed by 1 person. This method is applied at every DCE, at each major transect. Observations are made at each bank of the main channel. Staff performing this method must have been trained.

Equipment, Reagents, Supplies

- No. 2 pencil
- *Major Transect Data Form*

Summary of Procedure

This procedure is derived from Peck et al. (2006) and Moberg (2007).

Refer to the *Major Transect Data Form* (Figure M-1).

RIPARIAN VEGETATION COVER		0 = Absent (0%) 1 = Sparse (<10%) 2 = Moderate (10-40%) 3 = Heavy (40-75%) 4 = Very Heavy (>75%) D = Deciduous C = Coniferous E = Broadleaf Evergreen M = Mixed N = None										
		Left Bank					Right Bank					Flag
Canopy (>5 m high)												
Woody Vegetation Type		D	C	E	M	N	D	C	E	M	N	
BIG Trees (Trunk >0.3 m DBH)		0	1	2	3	4	0	1	2	3	4	
SMALL Trees (Trunk <0.3 m DBH)		0	1	2	3	4	0	1	2	3	4	
Understory (0.5 to 5 m high)												
Woody Vegetation Type		D	C	E	M	N	D	C	E	M	N	
Woody Shrubs & Saplings		0	1	2	3	4	0	1	2	3	4	
Non-Woody Herbs, Grasses, & Forbs		0	1	2	3	4	0	1	2	3	4	
Ground Cover (<0.5 m high)												
Woody Shrubs & Saplings		0	1	2	3	4	0	1	2	3	4	
Non-Woody Herbs, Grasses and Forbs		0	1	2	3	4	0	1	2	3	4	
Barren, Bare Dirt or Duff		0	1	2	3	4	0	1	2	3	4	

Figure M-1. A portion of the *Major Transect Data Form*, with example data.

On each major transect of the main channel, assess a plot on each bank. Each plot extends 5 meters downstream, 5 meters upstream, and 10 meters back from the bankfull margin. The riparian plot dimensions can be estimated rather than measured. On steeply sloping channel margins, plot boundaries are defined as if they were projected down from an aerial view.




Figure M-2. Riparian plots

Conceptually divide the riparian vegetation into three layers:

- Canopy (> 5 m high),
- Understory (0.5 to 5 m high),
- Ground Cover layer (< 0.5 m high).

Within each layer, consider the type of vegetation present and the amount of cover provided. Do this independently of what is contained in higher layers.

Cover quantity is coded on the field form (Figure I-1) as follows:

- 0 - absent
- 1- sparse (< 10% cover)
- 2 - moderate (10-40% cover)
- 3 - heavy (40-75% cover)
- 4 – very heavy (> 75% cover)

The maximum cover in each layer is 100%, so the sum of the cover for the combined three layers could add up to 300%.

Canopy

On the *Major Transect Form* (Figure I-1), circle the appropriate vegetation **type code** (D, C, E, M, or N). Type codes are defined on the form.

Then circle the appropriate cover **quantity code** (0, 1, 2, 3, or 4) for each of 2 classes:

- Big trees – trees having trunks larger than 0.3 m diameter (at breast height)
- Small trees– trees having trunks smaller than 0.3 m diameter (at breast height)

Understory

On the *Major Transect Form* (Figure I-1), circle the appropriate vegetation **type code** (D, C, E, M, or N) for any *woody* vegetation that might be present. Then circle the appropriate cover **quantity code** (0, 1, 2, 3, or 4) for each of 2 classes:

- Woody vegetation - such as shrubs or saplings
- Non-woody vegetation - such as herbs, grasses, or forbs

Ground Cover

Circle the appropriate cover **quantity code** (0, 1, 2, 3, or 4) for each of 3 classes:

- Woody (living)
- Non-woody (living)
- Bare dirt (or decomposing debris)

The sum of cover quantity ranges for these 3 types of ground cover should include 100%.

References

Endreny, T.A. 2009. *Fluvial Geomorphology Modules*, State University of New York College of Environmental Science and Forestry, National Oceanic and Atmospheric Administration, and the University Corporation for Atmospheric Research. www.fgmorph.com

Moberg, J. 2007. A field manual for the habitat protocols of the Upper Columbia Monitoring Strategy. Prepared for and funded by Bonneville Power Administration's Integrated Status and Effectiveness Monitoring Program. Terraqua, Inc. Wauconda, WA
<http://www.nwfsc.noaa.gov/research/divisions/cbd/mathbio/isemp/docs/isemphabitatprotocolsfieldmanualdraft070615.pdf>

Peck, D.V., Herlihy, A.T., Hill, B.H., Hughes, R.M., Kaufmann, P.R., Klemm, D.J., Lazorchak, J.M., McCormick, F.H., Peterson, S.A., Ringold, P.L., Magee, T., and Cappaert, M.R. Environmental Monitoring and Assessment Program-Surface Waters, Western Pilot Study, Field Operations Manual for Wadeable Streams. EPA/620/R-06/003. U.S. Environmental Protection Agency, Washington, D.C.
<http://www.epa.gov/wed/pages/publications/authored/EPA620R-06003EMAPSWFieldOperationsManualPeck.pdf>

Appendix L

Riparian Vegetation Structure at Transects in Wide Streams & Rivers

Purpose and Scope

This method explains how to collect measurements for WHSR at each of 11 transects at each site. Observations in this procedure will be restricted to one main channel. This method must follow pre-season site layout.

Definitions

Definitions of acronyms and other terms are found in Table L-1.

Table L-1. Definitions.

Term or Acronym	Definition
Bankfull stage	This stage is delineated by the elevation point of incipient flooding, indicated by deposits of sand or silt at the active scour mark, break in stream bank slope, perennial vegetation limit, rock discoloration, and root hair exposure (Endreny 2009).
Broadleaf evergreen	Non-coniferous trees that maintain foliage through the seasons. A native example for Washington is the madrona (<i>Arbutus menziesii</i>)
Canopy	The functional definition for this method: Vegetation above 5 m high within a 10 m x 10 m riparian plot.
Coniferous	Any of various mostly needle-leaved or scale-leaved, chiefly evergreen, cone-bearing gymnospermous trees or shrubs such as pines, spruces, and firs. This includes larch.
Cover	This can be thought of as the amount of shadow cast by a particular layer alone when the sun is directly overhead. Conceptually remove vegetation from higher layers before estimating.
DCE	Data Collection Event. Data are indexed using this code which includes the SITE_ID, the date, and the time that the event began. It uses this format: WAM06600-NNNNNN-dce-20YY-MMDD-HHMM NNNNNN = the number portion of the SITE_ID. YY = the last two numeric digits of the year that the event occurred. MM = the two numeric digits for the month that the event occurred.

	DD = the two numeric digits for the day within the month that the event occurred. HHMM = the military time when the event began.
Deciduous	Non-coniferous trees that shed their leaves annually. Examples include alder, oak, maple, and cottonwood.
Duff	Organic matter in various stages of decomposition on the floor of the forest.
Forbs	A broad-leaved herb other than a grass, such as those that grow in a field, prairie, or meadow.
Ground cover	The functional definition for this method: Vegetation or bare ground below 0.5 m high within a 10 m x 10 m riparian plot.
Herbs	Plants whose stems do not produce woody, persistent tissue. They generally die back at the end of each growing season.
Left bank	A person facing downstream will have the left bank on their left side.
Main channel	Channels in a stream are divided by islands (dry ground that rises above bankfull stage). Main channels contain the greatest proportion of flow. For this method it is called channel number 0.
major transect	One of 11 equidistant transects across the length of a site. These are labeled as follows: A0 (lowest), B0,C0,...K0 (highest)
Mixed	Vegetation type if more than 10% of the cover is made up of an alternate type.
Right bank	A person facing downstream will have the right bank on their right side.
Side channels	Channels that contain less flow than the main channels. These are identified and enumerated (1,2,3 etc.) as encountered (see the method for thalweg measurements) during the DCE.
Understory	The functional definition for this method: Vegetation below 5 m high but above 0.5 m high within a 10 m x 10 m riparian plot.

Personnel Responsibilities

This method is performed by 1 person. This method is applied at every DCE, at each major transect. Observations are made at both banks of the main channel. Staff performing this method must have been trained.

Equipment, Reagents, Supplies

- No. 2 pencil
- *Major Transect Data Form*

Summary of Procedure

This procedure is derived from Peck et al. (2006) and Moberg (2007).

Refer to the *Major Transect Data Form* (Figure L-1). At each of the major Transects (A0-K0), in the main channel, evaluate a 10 m x 20 m riparian plot (Figure L-2) on the bank that was designated during pre-season site layout.. The riparian plot dimensions can be estimated rather than measured. On steeply sloping channel margins, plot boundaries are defined as if they were projected down from an aerial view.

Conceptually divide the riparian vegetation into three layers:

- Canopy (> 5 m high),
- Understory (0.5 to 5 m high),
- Ground Cover layer (< 0.5 m high).

Within each layer, consider the type of vegetation present and the amount of cover provided. Do this independently of what is contained in higher layers.

Cover quantity is coded on the field form (Figure L-1) as follows:

- 0 - absent
- 1- sparse (< 10% cover)
- 2 - moderate (10-40% cover)
- 3 - heavy (40-75% cover)
- 4 – very heavy (> 75% cover)

The maximum cover in each layer is 100%, so the sum of the cover for the combined three layers could add up to 300%. Ground cover scores must add to 100%.

RIPARIAN		0 = Absent (0%) 1 = Sparse (<10%) 2 = Moderate (10-40%) 3 = Heavy (40-75%) 4 = Very Heavy (>75%)					D = Deciduous C = Coniferous E = Broadleaf Evergreen M = Mixed N = None				
RIPARIAN VEGETATION COVER	Left Bank					Right Bank					Flag
Canopy (>5 m high)											
Woody Vegetation Type	D	C	E	M	N	D	C	E	M	N	
BIG Trees (Trunk >0.3 m DBH)	0	1	2	3	4	0	1	2	3	4	
SMALL Trees (Trunk <0.3 m DBH)	0	1	2	3	4	0	1	2	3	4	
Understory (0.5 to 5 m high)											
Woody Vegetation Type	D	C	E	M	N	D	C	E	M	N	
Woody Shrubs & Saplings	0	1	2	3	4	0	1	2	3	4	
Non-Woody Herbs, Grasses, & Forbs	0	1	2	3	4	0	1	2	3	4	
Ground Cover (<0.5 m high)											
Woody Shrubs & Saplings	0	1	2	3	4	0	1	2	3	4	
Non-Woody Herbs, Grasses and Forbs	0	1	2	3	4	0	1	2	3	4	
Barren, Bare Dirt or Duff	0	1	2	3	4	0	1	2	3	4	

Figure L-1. A portion of the *Major Transect Data Form*, with example data.




Figure L-2. One of two riparian plots at a transect.

Canopy

On the *Major Transect Form* (Figure L-1), circle the appropriate vegetation **type code** (D, C, E, M, or N). Type codes are defined on the form. The M (mixed) code means that there is any percentage of a second vegetation type.

Then circle the appropriate cover **quantity code** (0, 1, 2, 3, or 4) for each of 2 classes:

- Big trees – trees having trunks larger than 0.3 m diameter (at breast height)
- Small trees– trees having trunks smaller than 0.3 m diameter (at breast height)

Understory

On the *Major Transect Form* (Figure I-1), circle the appropriate vegetation **type code** (D, C, E, M, or N) for any *woody* vegetation that might be present. Then circle the appropriate cover **quantity code** (0, 1, 2, 3, or 4) for each of 2 classes:

- Woody vegetation - such as shrubs, saplings, or tree trunks
- Non-woody vegetation - such as herbs, grasses, or forbs

Ground Cover

Circle the appropriate cover **quantity code** (0, 1, 2, 3, or 4) for each of 3 classes:

- Woody (living)
- Non-woody (living)
- Bare dirt (or decomposing debris)

The sum of cover quantity ranges for these 3 types of ground cover should include 100%.

References

Endreny, T.A. 2009. *Fluvial Geomorphology Modules*, State University of New York College of Environmental Science and Forestry, National Oceanic and Atmospheric Administration, and the University Corporation for Atmospheric Research. www.fgmorph.com

Peck, D.V., Herlihy, A.T., Hill, B.H., Hughes, R.M., Kaufmann, P.R., Klemm, D.J., Lazorchak, J.M., McCormick, F.H., Peterson, S.A., Ringold, P.L., Magee, T., and Cappaert, M.R. Environmental Monitoring and Assessment Program-Surface Waters, Western Pilot Study, Field Operations Manual for Wadeable Streams. EPA/620/R-06/003. U.S. Environmental Protection Agency, Washington, D.C.
<http://www.epa.gov/wed/pages/publications/authored/EPA620R-06003EMAPSWFieldOperationsManualPeck.pdf>

Moberg, J. 2007. A field manual for the habitat protocols of the Upper Columbia Monitoring Strategy. Prepared for and funded by Bonneville Power Administration's Integrated Status and Effectiveness Monitoring Program. Terraqua, Inc. Wauconda, WA
<http://www.nwfsc.noaa.gov/research/divisions/cbd/mathbio/isemp/docs/isemphabitatprotocolsfieldmanualdraft070615.pdf>

Appendix M

Riparian Vegetation Structure at Major Transects in Waded Streams

Purpose and Scope

This method explains how to collect measurements for the Status and Trends Program at each of 11 equidistant transects at each site. Observations in this procedure will be restricted to one main channel. This method must follow the method for establishing major transects.

Definitions

Definitions of acronyms and other terms are found in Table M-1.

Table M-1. Definitions.

Term or Acronym	Definition
Bankfull stage	This stage is delineated by the elevation point of incipient flooding, indicated by deposits of sand or silt at the active scour mark, break in stream bank slope, perennial vegetation limit, rock discoloration, and root hair exposure (Endreny 2009).
Broadleaf evergreen	Non-coniferous trees that maintain foliage through the seasons. A native example for Washington is the madrona (<i>Arbutus menziesii</i>)
Canopy	The functional definition for this method: Vegetation above 5 m high within a 10 m x 10 m riparian plot.
Coniferous	Any of various mostly needle-leaved or scale-leaved, chiefly evergreen, cone-bearing gymnospermous trees or shrubs such as pines, spruces, and firs. This includes larch.
Cover	This can be thought of as the amount of shadow cast by a particular layer alone when the sun is directly overhead. Conceptually remove vegetation from higher layers before estimating.
DCE	Data Collection Event. Data are indexed using this code which includes the SITE_ID, the date, and the time that the event began. It uses this format: WAM06600-NNNNNN-dce-20YY-MMDD-HHMM NNNNNN = the number portion of the SITE_ID. YY = the last two numeric digits of the year that the event occurred. MM = the two numeric digits for the month that the event occurred.

	DD = the two numeric digits for the day within the month that the event occurred. HHMM = the military time when the event began.
Deciduous	Non-coniferous trees that shed their leaves annually. Examples include alder, oak, maple, and cottonwood.
Duff	Organic matter in various stages of decomposition on the floor of the forest.
Forbs	A broad-leaved herb other than a grass, such as those that grow in a field, prairie, or meadow.
Ground cover	The functional definition for this method: Vegetation or bare ground below 0.5 m high within a 10 m x 10 m riparian plot.
Herbs	Plants whose stems do not produce woody, persistent tissue. They generally die back at the end of each growing season.
Left bank	A person facing downstream will have the left bank on their left side.
Main channel	Channels in a stream are divided by islands (dry ground that rises above bankfull stage). Main channels contain the greatest proportion of flow. For this method it is called channel number 0.
major transect	One of 11 equidistant transects across the length of a site. These are labeled as follows: A0 (lowest), B0,C0,...K0 (highest)
Mixed	Vegetation type if more than 10% of the cover is made up of an alternate type.
Right bank	A person facing downstream will have the right bank on their right side.
Side channels	Channels that contain less flow than the main channels. These are identified and enumerated (1,2,3 etc.) as encountered (see the method for thalweg measurements) during the DCE.
Understory	The functional definition for this method: Vegetation below 5 m high but above 0.5 m high within a 10 m x 10 m riparian plot.

Personnel Responsibilities

This method is performed by 1 person. This method is applied at every DCE, at each major transect. Observations are made at each bank of the main channel. Staff performing this method must have been trained.

Equipment, Reagents, Supplies

- No. 2 pencil
- *Major Transect Data Form*

Summary of Procedure

This procedure is derived from Peck et al. (2006) and Moberg (2007).

Refer to the *Major Transect Data Form* (Figure M-1).

RIPARIAN VEGETATION COVER		0 = Absent (0%) 1 = Sparse (<10%) 2 = Moderate (10-40%) 3 = Heavy (40-75%) 4 = Very Heavy (>75%)										D = Deciduous C = Coniferous E = Broadleaf Evergreen M = Mixed N = None			
		Left Bank					Right Bank					Flag			
Canopy (>5 m high)															
Woody Vegetation Type		D	C	E	M	N	D	C	E	M	N				
BIG Trees (Trunk >0.3 m DBH)		0	1	2	3	4	0	1	2	3	4				
SMALL Trees (Trunk <0.3 m DBH)		0	1	2	3	4	0	1	2	3	4				
Understory (0.5 to 5 m high)															
Woody Vegetation Type		D	C	E	M	N	D	C	E	M	N				
Woody Shrubs & Saplings		0	1	2	3	4	0	1	2	3	4				
Non-Woody Herbs, Grasses, & Forbs		0	1	2	3	4	0	1	2	3	4				
Ground Cover (<0.5 m high)															
Woody Shrubs & Saplings		0	1	2	3	4	0	1	2	3	4				
Non-Woody Herbs, Grasses and Forbs		0	1	2	3	4	0	1	2	3	4				
Barren, Bare Dirt or Duff		0	1	2	3	4	0	1	2	3	4				

Figure M-1. A portion of the *Major Transect Data Form*, with example data.

On each major transect of the main channel, assess a plot on each bank. Each plot extends 5 meters downstream, 5 meters upstream, and 10 meters back from the bankfull margin. The riparian plot dimensions can be estimated rather than measured. On steeply sloping channel margins, plot boundaries are defined as if they were projected down from an aerial view.




Figure M-2. Riparian plots

Conceptually divide the riparian vegetation into three layers:

- Canopy (> 5 m high),
- Understory (0.5 to 5 m high),
- Ground Cover layer (< 0.5 m high).

Within each layer, consider the type of vegetation present and the amount of cover provided. Do this independently of what is contained in higher layers.

Cover quantity is coded on the field form (Figure I-1) as follows:

- 0 - absent
- 1- sparse (< 10% cover)
- 2 - moderate (10-40% cover)
- 3 - heavy (40-75% cover)
- 4 – very heavy (> 75% cover)

The maximum cover in each layer is 100%, so the sum of the cover for the combined three layers could add up to 300%.

Canopy

On the *Major Transect Form* (Figure I-1), circle the appropriate vegetation **type code** (D, C, E, M, or N). Type codes are defined on the form.

Then circle the appropriate cover **quantity code** (0, 1, 2, 3, or 4) for each of 2 classes:

- Big trees – trees having trunks larger than 0.3 m diameter (at breast height)
- Small trees– trees having trunks smaller than 0.3 m diameter (at breast height)

Understory

On the *Major Transect Form* (Figure I-1), circle the appropriate vegetation **type code** (D, C, E, M, or N) for any *woody* vegetation that might be present. Then circle the appropriate cover **quantity code** (0, 1, 2, 3, or 4) for each of 2 classes:

- Woody vegetation - such as shrubs or saplings
- Non-woody vegetation - such as herbs, grasses, or forbs

Ground Cover

Circle the appropriate cover **quantity code** (0, 1, 2, 3, or 4) for each of 3 classes:

- Woody (living)
- Non-woody (living)
- Bare dirt (or decomposing debris)

The sum of cover quantity ranges for these 3 types of ground cover should include 100%.

References

Endreny, T.A. 2009. *Fluvial Geomorphology Modules*, State University of New York College of Environmental Science and Forestry, National Oceanic and Atmospheric Administration, and the University Corporation for Atmospheric Research. www.fgmorph.com

Moberg, J. 2007. A field manual for the habitat protocols of the Upper Columbia Monitoring Strategy. Prepared for and funded by Bonneville Power Administration's Integrated Status and Effectiveness Monitoring Program. Terraqua, Inc. Wauconda, WA
<http://www.nwfsc.noaa.gov/research/divisions/cbd/mathbio/isemp/docs/isemphabitatprotocolsfieldmanualdraft070615.pdf>

Peck, D.V., Herlihy, A.T., Hill, B.H., Hughes, R.M., Kaufmann, P.R., Klemm, D.J., Lazorchak, J.M., McCormick, F.H., Peterson, S.A., Ringold, P.L., Magee, T., and Cappaert, M.R. Environmental Monitoring and Assessment Program-Surface Waters, Western Pilot Study, Field Operations Manual for Wadeable Streams. EPA/620/R-06/003. U.S. Environmental Protection Agency, Washington, D.C.
<http://www.epa.gov/wed/pages/publications/authored/EPA620R-06003EMAPSWFieldOperationsManualPeck.pdf>

FIELD PROTOCOLS FOR TEMPERATURE

CHaMP (Columbia Habitat Monitoring Program). 2015. Scientific protocol for salmonid habitat surveys within the Columbia Habitat Monitoring Program. Prepared by the Columbia Habitat Monitoring Program.

9.5 Water Temperature

Reference: Isaak et al. (2010).

Equipment: Onset TidbiT, PVC housing material/cables, epoxy, rubber gloves, underwater viewer.

Objective: Install year round water temperature sensors at sites using one of two installation methods.

Water temperature sensors will be placed at all annual and rotating panel sites within each CHaMP subbasin. At new sites where sensors have not been established, it is important that watershed leads make a concerted effort to install all sensors before high summer temperatures (approx. July 15). When early flow conditions do not permit installation with the epoxy method, use the wire method initially and have the crew members apply the epoxy method (where applicable) after flows have subsided. Temperature data should be downloaded in the fall and before high spring flows.

9.5.1 Establishing New Sensors

Step 1. Identify sensor placement location.

- i. Epoxy Method: Search for a large rock or boulder (charismatic megaboulders are best) that will be immobile during large floods and is easy for others to identify on subsequent site visits. Finding a good rock is the most important step to a successful sensor installation. If a suitable rock is not available, consider placement using the wire method.
 - a. Optimal placement locations for rock and boulder secured sensors include:
 - i. Rocks, boulders, or structures that will not move or be disturbed at high flows.
 - ii. Boulders large enough that they protrude above the low flow water surface and wide enough that they can effectively shield the sensor from moving rocks or debris during high flows.
 - iii. Areas downstream of large rocks in pockets of relatively calm water with smaller substrate sizes.
 - iv. A relatively flat downstream attachment surface that is deep enough to remain submerged in flowing water for the entire year.
- ii. Cable Method: If there is not a suitable rock or boulder within or in close proximity (100 m) to the site, identify a secure location such as the base of a tree or root wad to attach the sensor using a metal cable.
 - a. Optimal placement locations for cable secured sensors include:
 - i. Areas with sufficient stream flow that will maintain year-round flow, but outside of strong currents. Also consider whether the sensor attached to the wire will move at high flows and place sensor so that it will not get hung up in vegetation or left on the bank.
 - ii. Locations away from seeps or steep banks on the side of stream in order to avoid groundwater influences.

- iii. Camouflaged or inconspicuous locations at sites with high public use. In these instances, vegetation, grasses, or cobbles may be used to cover wire or hold wire in place.
- b. Suitable locations for attaching sensors may be relatively rare within low-gradient, meadow reaches. In these instances, examine potential placement locations no more than 100 m upstream or downstream of the site and away from tributary influences.

Step 2. Install and record sensor location details.

- i. After identifying a suitable sensor placement location:
 - a. Record sensor serial number.
 - b. Install sensor.
 - c. Take a GPS reading. Record UTM coordinates, accuracy, and the date and time installed.
 - d. Record the stream bank that the sensor is nearest to and the distance from that stream bank. If cable is attached to a tree on the bank, record the distance from bank as 0.
 - e. Record the attachment method as cable or epoxy.
 - f. Take a photo of the sensor location. Include enough of the surrounding environment in the photo to relocate the sensor.
 - g. Write a detailed description of the sensor location in the placement location field. Description should include distance from site bottom and any other pertinent information for relocating sensor at subsequent visits. The more detail the better. For example: Sensor attached to grey, rectangular boulder 1 m in diameter near river left (~1.5 m from bank), 5 m upstream from transect 12 OR Sensor is attached to the base of a small willow, ~ 6 m downstream from top of site on river right.
 - h. Note sensor location on site map.
 - i. After sensor has been in the water for approximately 1 hour, measure and record the instantaneous water temperature near the sensor using a handheld thermometer. Record the date and time instantaneous temperature is measured. It is preferable to measure the instantaneous water temperature at the top of the hour when the installed sensor will be recording information.

9.5.2 Previously Installed Sensors

Step 1. Locate previously installed sensor.

- i. Use existing photographs, GPS coordinates, and site maps to locate the previously installed water temperature sensor.
 - a. If sensor location is found but sensor is missing, search downstream to see if sensor can be found. Note if sensor cannot be located. Establish a new sensor using the criteria outlined above.

Step 2. Download sensor data and record information

- i. Remove the sensor from the housing unit and confirm that the correct sensor serial number was recorded when originally installed. Avoid removing sensor from the water when it will be recording one of its hourly temperature measurements (on the hour).
 - a. Download sensor using the sensor shuttle (Appendix G).
 - b. Note whether the red light on the sensor is blinking. If there is no blinking light, replace the sensor and notify the watershed lead.
 - c. Record in the sensor condition field the current condition of the sensor as being submerged in flowing water, submerged in non-flowing water, dry, or missing.
 - d. Record if the sensor has been left in place, removed, or moved to a more suitable location. Move the sensor if it is in non-flowing water or buried in sediment. Replace sensor with a new one if it is missing. Record action in the action field.
 - e. Take a new GPS reading. Record UTM coordinates, accuracy, and the date and time sensor was downloaded or checked.
 - f. Verify and update sensor location information as needed such as stream bank, distance from bank, attachment method, and location description.
 - g. Take a new photo of the sensor.
 - h. Measure and record the instantaneous water temperature near the sensor using a handheld thermometer. Record the date and time instantaneous temperature is measured. It is preferable to measurement the instantaneous water temperature at the top of the hour when the installed sensor will be recording information.
 - i. Note the sensor location in the site map.

Appendix C-3

Example Data Sheets

Wolmann Pebble Count

Date _____ Stream _____
 Reach _____ Crew _____
 Unit # _____ BFW (m) _____
 Transect # _____

	size (mm)	Count	Total #
Clay/Silt	<0.062		
Sand	0.062-4.0		
G R A V E L S	4 - 5.6		
	5.6 - 8		
	8-11		
	11-16		
	16 - 22		
	22 – 32		
	32 - 45		
	45 - 64		
C O B B	64 - 90		
	90 - 128		
	128 - 180		
	180 - 256		
B L D R S	256 - 362		
	362 - 512		
	512 - 1024		
	1024 - 2048		
	2048 - 4096		
Bdrck	Bedrock		

Total =

Comments:

Date _____ Stream _____
 Reach _____ Crew _____
 Unit # _____ BFW (m) _____
 Transect # _____

	size (mm)	Count	Total #
Clay/silt	<0.062		
Sand	0.062-4.0		
G R A V E L S	4 - 5.6		
	5.6 - 8		
	8-11		
	11-16		
	16 - 22		
	22 – 32		
	32 - 45		
	45 - 64		
C O B B	64 - 90		
	90 - 128		
	128 - 180		
	180 - 256		
B L D R S	256 - 362		
	362 - 512		
	512 - 1024		
	1024 - 2048		
	2048 - 4096		
Bdrck	Bedrock		

Total =

Comments:

Transect Characteristics Datasheet

Date _____ Crew _____ Page _____ of _____

Stream Name _____ Reach # _____ Habitat Unit _____ Transect # _____

GPS Location (*US and DS end*) US _____ DS _____

Waypoint: _____ -or- UTM (Zone 11T): Easting: _____ Northing: _____

Channel form and constraining features

Channel Type (circle): *Colluvial* *Alluvial* *Bedrock*

Alluvial type (circle): *Cascade* *Step pool* *Forced step pool* *Plane bed*

Pool/riffle *Forced pool/riffle* *Dune-ripple*

Bank stability (circle) *Optimal* *Sub-optimal* *Marginal* *Poor*

Bank modification (% of each code)¹

LB _____

RB _____

Bankfull Depth (BFD):

Rod Height at Thalweg: _____ Rod Height at Bankfull Elev. _____ Difference = BFD _____

Bankfull Width: _____ Flood Prone Width: _____

Riparian vegetation

Cover = (0 - absent, 1-sparse [<10%], 2-moderate [10-40%], 3-heavy [40-75%], or 4-very heavy [>75%])

Type = (D)eciduous, (C)oniferous, (B)road-leaved evergree, (M)ixed, (N)one

Left Bank

Canopy vegetation: Cover code A) _____ B) _____ Type code _____ A=big trees, B=small trees

Understory vegetation: Cover code A) _____ B) _____ Type code _____ A=woody, B=non-woody

Ground vegetation: Cover code A) _____ B) _____ C) _____ Type code _____ A=woody, B=non-woody, C=bare dirt

Right Bank

Canopy vegetation: Cover code A) _____ B) _____ Type code _____ A=big trees, B=small trees

Understory vegetation: Cover code A) _____ B) _____ Type code _____ A=woody, B=non-woody

Ground vegetation: Cover code A) _____ B) _____ C) _____ Type code _____ A=woody, B=non-woody, C=bare dirt

Stream canopy closure (*from channel*) *Indicate the number of covered grid intersections (0-17)*

UP _____ Down _____ Right _____

Left _____

Transect Notes

Transect Photos (*photograph channel looking upstream and downstream and both banks/riparian*)

Photo #	Description

¹a) walls, dikes, revetments, riprap, and dams, b) buildings, c) pavement (e.g., parking lot, foundation), d) roads or railroads, e) inlet or outlet pipes, f) landfills or trash (e.g., cans, bottles, trash heaps, g) parks or maintained lawns, h) row crops, i) pastures, rangeland, or hay fields, j) logging, k) mining (including gravel mining)